



DB9



Workshop Manual
Issue 7



ASTON MARTIN

Aston Martin Lagonda Limited
Banbury Road, Gaydon, WARWICK, Warwickshire,
England, MK16 9AN
Telephone: (01926) 644700 Fax: (01926) 644733

Aston Martin are constantly seeking to improve the specification, design and production of their vehicles and alterations take place accordingly. While every effort has been made to ensure the accuracy of this Manual, it should not be regarded as an infallible guide to current specifications of any particular vehicle.

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system or transmitted, in any form, electronic, mechanical, photocopying, recording or other means without prior written permission from Aston Martin Lagonda Limited.

The manufacturer reserves the right to vary specifications without notice in accordance with its policy of continual product improvement.

Produced by the Technical Publications Department
Aston Martin Lagonda Limited

DB9 Workshop Manual

Contents

Introduction

Welcome	i-i-iv
Safety Precautions	i-i-v
Lifting and Jacking	i-i-vii
Vehicle Recovery	i-i-viii
Vehicle Identification Number	i-i-ix

Body System (01.00)

Body Structure (01.01)	1-1-3
Front End System (01.02)	1-2-1
Body Closures (01.03)	1-3-1
Interior Trim (01.05)	1-5-1
Exterior Trim (01.08)	1-8-1
Mirrors (01.09)	1-9-1
Seating (01.10)	1-10-1
Glass, Frame and Mechanism (01.11)	1-11-1
Instrument Panel (IP) (01.12)	1-12-1
Handles and Lock Mechanisms (01.14)	1-14-1
Wipers and Washer System (01.16)	1-16-1
Bumpers (01.19)	1-19-1
Restraining Devices (01.20)	1-20-1

Frame and Mounting (02.00)

Subframes (02.03)	2-1-2
-------------------------	-------

Engine System (03.00)

Engine Assembly (03.00)	3-0-3
Engine Structure (03.01)	3-1-1
Lubrication System (03.02)	3-2-1
Cooling System (03.03)	3-3-1
Fuel Charging System (03.04)	3-4-1
Accessory Drive System (03.05)	3-5-1
Engine Cranking System (03.06)	3-6-1
Ignition System (03.07)	3-7-1
Emission Control (03.08)	3-8-1
Valve Train (03.09)	3-9-1
Engine Sealing (03.10)	3-10-1
Power Conversion (03.11)	3-11-1
Air Charging (03.12)	3-12-1
Evaporative Emissions (03.13)	3-13-1
Engine Management System (03.14)	3-14-1
Throttle Control (03.16)	3-16-1

Suspension (04.00)

Road Wheel Alignment (04.00)	4-0-2
Front Suspension (04.01)	4-1-1
Rear Suspension (04.02)	4-2-1
Road Wheels and Tyres (04.04)	4-4-1

Driveline (05.00)

Driveshaft (05.01)	5-1-2
Rear Drive System (05.02)	5-2-1
Halfshafts (05.05)	5-5-1

Brake System (06.00)

Description	6-1-2
Front Disc Brake (06.03)	6-3-1
Rear Disc Brakes (06.04)	6-4-1
Hand Brake (06.05)	6-5-1
Brake Actuation System (06.06)	6-6-1
Power Brake System (06.09)	6-9-1

Transmission (07.00)

Automatic Transmission (07.01)	7-1-2
Transmission Cooling (07.02)	7-2-1
Manual Transmission (07.03)	7-3-1
Automatic Control System (07.05)	7-5-1

Clutch (08.00)

Clutch Controls (08.02)	8-2-1
-------------------------------	-------

Exhaust (09.00)

Exhaust Overview	9-1-2
Silencer Assembly (09.01)	9-1-3
Pipes and Supports (09.03)	9-3-1

Fuel (10.00)

Fuel Tank and Lines (10.01)	10-1-2
-----------------------------------	--------

Steering (11.00)

Steering Gear (11.01)	11-1-2
Power Steering (11.02)	11-2-1
Steering Column (11.04)	11-4-1
Steering Column Switches (11.05)	11-5-1
Steering Wheel (11.06)	11-6-1

Climate Control (12.00)

Body Ventilation system (12.01)	12-1-3
Heater System (12.02)	12-2-1
Air Conditioning (A/C) System (12.03)	12-3-1
A/C Control System (12.04)	12-4-1

Information, Gauge and Warning (13.00)

Instrument Cluster (13.01)	13-1-2
----------------------------------	--------

Power Supply (14.00)

Battery System (14.01)	14-1-2
Alternator and Regulator System (14.02)	14-2-1



Vehicle Entertainment (15.00)

Audio System 15-1-1

Vacuum Distribution (16.00)

Body Vacuum System (16.01)..... 16-1-1

Lighting (17.00)

Front Lights (17.01) 17-1-2

Interior Lighting (17.02)..... 17-2-1

Rear Lights (17.03) 17-3-1

Lighting Mechanisms (17.04)..... 17-4-1

Electric Distribution/Electronic Control (18.00)

Wiring and Circuit Protection (18.01) 18-1-2

Vehicle Control System (18.08) 18-8-1

Electronic Features (19.00)

Active Anti-Theft System (19.01)..... 19-1-2

Navigation (19.07)..... 19-7-1

Appendix & Glossary

Diagnostic Ports..... 20-1-2

Fluids/Capacities..... 20-1-3

Abbreviations 20-1-3

Terms..... 20-1-3

Special Tools - Pictorial Index..... 20-1-4

Specialist Tool Operation 20-1-8

Maintenance Schedules..... 20-1-11

Torque Figures 20-1-14

Torque Conversion Tables..... 20-1-31

Introduction

Contents

Welcome	I-I-VI
Chapters	I-VI
Chapter Navigation	I-VI
Numbering	I-VI
Special Tools	I-VI
Location References	I-VI
Warnings, Cautions and Notes	I-VI
Repairs and Replacements	I-VI
Safety Precautions	I-I-VII
Battery Disconnection	I-VII
Air Conditioning (A/C) System	I-VII
Chemical Handling and Storage	I-VII
Electrical Equipment	I-VII
Exhaust Fumes	I-VIII
Fire Precautions	I-VIII
Tools and Equipment	I-VIII
Used Engine Oil	I-IX
Health Protection Precautions	I-IX
Environmental Protection	I-IX
Lifting and Jacking	I-I-IX
Safety	I-IX
Jacking Points	I-IX
<i>Stands</i>	I-X
Workshop Hoist	I-X
Vehicle Recovery	I-I-X
General	I-X
Transporting	I-X
Suspended Towing.....	I-X
<i>Front Suspended Tow</i>	I-X
<i>Rear Suspended Tow</i>	I-XI
Towing an Automatic Vehicle.....	I-XI
Towing Regulations	I-XI
Towing by Another Vehicle	I-XI
Push-start	I-XI
Identification Numbers	I-I-XII
Vehicle Identification Number (VIN)	I-XII
VIN Number Location.....	I-XII
Engine Number	I-XIII
Gearbox Number	I-XIII
Automatic Gearbox.....	I-XIII
Manual Gearbox.....	I-XIII

Introduction

Welcome

This Workshop Manual is part of a suite of technical manuals provided for DB9. Other technical manuals include:

- Parts manual
- OBDII Diagnostic manual
- Man hour schedules

Chapters

The DB9 suite of manuals incorporate a new chapter structure.

Each chapter in this workshop manual is associated with a 4 digit number, i.e. Transmission (07.00). Each chapter is then further broken into sections, i.e. Automatic Transmission (07.01).

Chapter Navigation

Example 1:


Previous workshop manuals would have Steering and Suspension together in one chapter. The new structure now places Steering and Suspension into their own chapters. Road wheels are also now included in Suspension.

Example 2:

Fuel, emissions and exhaust is now in three different chapters. Fuel has its own chapter and includes all fuel aspects up to the fuel rails (Fuel rails and fuel injection now come under Engine System). Exhaust, not including manifolds, has its own chapter and Emissions now come under the Engine system.

When required references are made out to other chapters.

Numbering



Chapters and sections within chapters are numbered using the system detailed above. All technical manuals for this vehicle use the same numbering system. When carrying out a procedure, the relevant parts illustration and spare parts list can be found using the same numbering system.


To avoid excessive repetition, each procedure is fully detailed once in its appropriate chapter. In any other location where this procedure is required, it is referenced by its title and chapter / page number.

Special Tools

Where special service tools are required to perform an operation, the tool number is recorded at the point of use within the procedure. Where the operation of a special service tool is complicated or not obvious, refer to the Appendix and Glossary for detailed operation procedures. A pictorial list of special service tools available for this vehicle can also be found in the Appendix and Glossary.

Location References

References to left, right, front or rear of the vehicle or of a component are referenced from sitting in the drivers seat facing forward. Any such references to assemblies removed from the vehicle are to the normal orientation of the assembly when installed in the vehicle.



Warnings, Cautions and Notes

The following Warnings, Cautions and Notes are used within this workshop manual to call your attention to specific types of information.

Warnings

WARNING
INJURY OR DEATH TO PERSONNEL IS POSSIBLE IF YOU DO NOT OBEY THE INSTRUCTIONS.

Cautions

CAUTION
DAMAGE TO THE VEHICLE, EQUIPMENT OR TOOLS IS POSSIBLE IF YOU DO NOT OBEY THE INSTRUCTIONS.

Notes

Note: To give information that will help you do the procedure.

Repairs and Replacements

Where replacement parts are required, it is essential that only genuine Aston Martin parts are used. Your attention is drawn to the following points concerning repairs and the fitting of genuine Aston Martin parts and accessories:

- Safety features embodied in the vehicle may be impaired if other than genuine Aston Martin parts are installed. In certain territories, legislation prohibits the installation of parts which are not produced to the manufacturers specification
- Adhere to torque wrench settings given in this manual
- Locking devices, where specified, must be installed. If the efficiency of a locking device is impaired during removal, it must be renewed
- The vehicle warranty may be invalidated by the installation of other than genuine Aston Martin parts

Safety Precautions

All service workshops are a source of potential danger and repair work should only be performed by technically trained staff following procedures detailed in this manual. A safety conscious approach to the performance of all service procedures must be observed at all times. Statutory requirements governing all aspects of health and safety at work including directives for the proper use of materials and equipment must be implemented.

The following headings highlight particular safety precautions which should be observed (The list is not intended to be exhaustive).

Battery Disconnection

Where a procedure requires the vehicle battery to be physically disconnected (disconnect the vehicle battery earth (Negative) lead), the following items will have to be reset or re-learnt on connection:

- Seats memory
- Radio pre-sets
- DTCs will be lost

Air Conditioning (A/C) System

Do not break into the A/C refrigeration system until the refrigerant has been evacuated using the procedure detailed in this manual. Do not disconnect any A/C refrigerant system pipes unless trained and instructed to do so. The refrigerant used can cause blindness if allowed to contact your eyes.



Chemical Handling and Storage

WARNING
OBEY ALL HANDLING AND SAFETY INFORMATION THAT IS ON CONTAINERS AND LABELS.

WARNING
DO NOT STORE CHEMICALS IN CONTAINERS THAT ARE NOT LABELLED OR NOT CORRECTLY LABELLED.

WARNING
DO NOT LEAVE CONTAINERS OPEN THAT ARE USED FOR STORING CHEMICALS. THE CHEMICALS CAN BE SPILLED OR FUMES CAN EVAPORATE THAT CAN BE INFLAMMABLE OR TOXIC.

WARNING
DO NOT MIX CHEMICALS UNLESS INSTRUCTED TO DO SO, FOLLOWING MANUFACTURERS GUIDELINES.

WARNING
DO NOT BREATHE IN CHEMICAL MATERIALS TO IDENTIFY THEM. THEY CAN BE TOXIC.

WARNING
DO NOT USE PETROL, KEROSENE, DIESEL FUEL, GAS OIL, THINNERS OR SOLVENTS TO CLEAN THE SKIN.

WARNING
DO NOT SPRAY CHEMICALS THAT ARE MADE FROM SOLVENTS (FOR EXAMPLE: PAINT) IN A CONFINED AREA. THE WORK AREAS THAT ARE USED FOR THESE OPERATIONS MUST BE WELL VENTILATED AND FUME EXTRACTION EQUIPMENT MUST BE USED.

WARNING
CONTAINERS THAT HAVE A CAPACITY MORE THAN 25 LITRES (5 GALLONS) NEED A BUND WALL TO CONTAIN SPILLAGES.

WARNING
AVOID SPLASHING THE SKIN, EYES AND CLOTHING.

WARNING
MAKE SURE THAT THERE IS SUFFICIENT VENTILATION WHEN YOU USE VOLATILE DEGREASING MATERIALS.

WARNING
CLEAN ALL CHEMICALS FROM THE SKIN AND CLOTHING AS SOON AS POSSIBLE AFTER CONTAMINATION.

WARNING
PUT ON PROTECTIVE CLOTHING SUCH AS GOGGLES, NON-POROUS GLOVES AND AN APRON WHEN YOU WORK WITH BATTERY ACID AND OTHER CORROSIVE AND TOXIC MATERIALS.

WARNING
DO NOT SMOKE NEAR VOLATILE DEGREASING AGENTS.

WARNING
FUME EXTRACTION EQUIPMENT MUST BE IN OPERATION WHEN YOU USE SOLVENTS. FOR EXAMPLE: TRICHLOROETHANE, WHITE SPIRIT, SBP3, METHYLENE CHLORIDE, PERCHLOROETHYLENE.

acids, adhesives, antifreeze, brake fluids, coolants, grease, oil, paint, resin and solvents. Exposure to some chemicals through direct contact or inhalation can cause injury or death.

Potential hazards can also be present from the incorrect use, storage and handling of chemicals. causing a fire risk.

Electrical Equipment

WARNING
MAKE SURE THAT ALL ELECTRICAL EQUIPMENT THAT YOU USE IS IN SAFE WORKING CONDITION BEFORE.

WARNING
INSPECT THE POWER LEADS OF ALL MAINS ELECTRICAL EQUIPMENT FOR DAMAGE AND CORRECT INSTALLATION. CHECK THAT THE EQUIPMENT IS PROPERLY EARTHED WHERE NECESSARY.

WARNING
MAKE SURE THAT ELECTRICAL EQUIPMENT IS PROTECTED BY A FUSE OF THE CORRECT CURRENT RATING.

WARNING
DISCONNECT THE BATTERY BEFORE YOU DO REPAIR OPERATIONS TO THE ELECTRICAL SYSTEM, FUEL SYSTEM AND THE ENGINE OR WHEN YOU WORK BELOW THE VEHICLE.

Exhaust Fumes

WARNING
DO NOT BREATHE EXHAUST FUMES. EXHAUST FUMES CONTAIN CARBON MONOXIDE. CARBON MONOXIDE IS A DANGEROUS GAS, WHICH IS COLOURLESS AND ODOURLESS AND CAN CAUSE UNCONSCIOUSNESS AND CAN BE FATAL. NEVER START OR LEAVE THE ENGINE RUNNING IN AN ENCLOSED AREA THAT IS NOT VENTILATED.

WARNING
DO NOT TOUCH EXHAUST SYSTEM AND ENGINE COMPONENTS, ENGINE FLUIDS AND ESCAPING STEAM WITH YOUR SKIN. THEY CAN BE HOT AND CAUSE BURNS.

Engines must only be operated where there is fume extraction equipment in operation or where there is adequate ventilation.

Chemicals used in the servicing of motor vehicles include:

Fire Precautions

WARNING
MAKE SURE THAT AN APPLICABLE TYPE OF FIRE EXTINGUISHER IS LOCATED NEAR THE WORK AREA.

WARNING
KEEP OILS, SOLVENTS AND COMBUSTIBLE MATERIALS AWAY FROM NAKED FLAMES AND OTHER SOURCES OF IGNITION.

WARNING
PUT NO SMOKING SIGNS ARE NEAR AREAS WHERE THERE CAN BE COMBUSTIBLE MATERIALS AND VAPOUR. MAKE SURE THAT THE WARNINGS ARE STRICTLY OBEYED.

WARNING
MAKE SURE THAT DRY SAND IS AVAILABLE TO ABSORB SPILLED FUEL OR OTHER FLAMMABLE MATERIALS.

WARNING
FUME EXTRACTION EQUIPMENT MUST BE IN OPERATION TO REMOVE COMBUSTIBLE AND TOXIC FUMES.

WARNING
ALL PERSONNEL MUST KNOW THE FIRE DRILL PROCEDURES AND SAFETY PRECAUTIONS.

Tools and Equipment

WARNING
DO NOT LEAVE TOOLS, EQUIPMENT OR SPILLED MATERIALS NEAR OR IN THE WORK AREA.

WARNING
MAKE SURE THAT ALL TOOLS AND EQUIPMENT THAT YOU USE ARE IN GOOD CONDITION. DO NOT USE DAMAGED OR DEFECTIVE TOOLS OR EQUIPMENT.

CAUTION
DO NOT APPLY HEAT TO FREE STIFF NUTS OR FITTINGS. THIS CAN CAUSE DAMAGE TO PROTECTIVE COATINGS, ELECTRONIC EQUIPMENT, HARNESSES AND BRAKE LINES.

Use the recommended service tool where instructed to do so.

Used Engine Oil

WARNING
LONG AND FREQUENT CONTACT WITH USED ENGINE OILS CAN CAUSE SERIOUS SKIN PROBLEMS THAT INCLUDE DERMATITIS AND CANCER. PREVENT TOO MUCH SKIN CONTACT AND WASH FULLY AFTER CONTACT.

WARNING
OBEY ALL LOCAL LAWS WHEN YOU DISCARD WASTE OIL AND TOXIC FLUIDS. IF YOU DO NOT, YOU COULD BE PROSECUTED AND DAMAGE TO THE ENVIRONMENT CAN OCCUR.

The workplace should have sufficient washing facilities and materials to protect the the skin available.

Health Protection Precautions

WARNING
LONG AND FREQUENT CONTACT WITH USED ENGINE OILS CAN CAUSE SERIOUS SKIN PROBLEMS THAT INCLUDE DERMATITIS AND CANCER. PREVENT TOO MUCH SKIN CONTACT AND WASH FULLY AFTER CONTACT.

- Put on protective clothing, including impervious gloves where possible.
- Do not put oily rags in your pockets.
- Do not get oil on your clothes.
- Clean your work clothes regularly. Discard clothes that cannot be washed and footwear that is soaked with oil.
- Get First aid treatment immediately for open cuts or wounds.
- Use barrier creams and apply them before each work period to help the removal of oil from the skin.
- Wash the skin with soap and water or an approved cleaner to make sure that all oil is removed. Materials that contain lanolin will replace the natural skin oils that have been removed.
- Do not use petrol, kerosene, diesel fuel, gas oil, thinners or solvents to clean the skin.
- If you get skin problems, get medical help.
- Where possible, degrease all components before you touch them.
- When there is a risk of eye contact, put on approved eye protection. There must be an eye-wash station in the work place.

Environmental Protection

It is illegal to pour used oil on the ground, down sewers or drains, or into water courses. The burning of used engine oil in small space heaters or boilers is not recommended unless emission control equipment is installed. Refer to the local laws and the environmental department of your Local Authority for advice about how to correctly discard waste fluids and materials.

Lifting and Jacking Safety

WARNING
OBEY THE LOCAL WORKSHOP REGULATIONS WHEN YOU TOW OR LIFT A VEHICLE.

WARNING
DO NOT USE A JACK TO HOLD A VEHICLE WHEN YOU DO WORK UNDER IT. ALWAYS USE A VEHICLE LIFT, RAMP OR PIT WHEN YOU WORK UNDER THE VEHICLE. IF YOU DO NOT, THE JACK CAN COLLAPSE AND PERSONAL INJURY OR DEATH CAN OCCUR.

WARNING
WHEN YOU WORK UNDER A VEHICLE, CHOCK THE WHEELS AND APPLY THE HANDBRAKE.


WARNING
MAKE SURE THAT THE VEHICLE IS ON FIRM, LEVEL GROUND WHEN YOU JACK OR LIFT IT.

WARNING
DO A CHECK THAT THE LIFTING EQUIPMENT HAS SUFFICIENT CAPACITY FOR THE LOAD BEING LIFTED. MAKE SURE THAT THE EQUIPMENT IS IN GOOD WORKING ORDER.


Jacking Points

CAUTION
JACK THE VEHICLE ON THE LOWER SUSPENSION ARMS (FRONT OR REAR).

This vehicle jacking points are at positions shown.



The vehicle may also be jacked with the jack placed on the front subframe, front crossmember.



Always use a jack with a rubber contact pad. Avoid the use of jacks with sharp contact pads which could damage the vehicle floor pan. Always chock the opposite road wheels as well as applying the handbrake when using a hydraulic jack.

To prevent body distortion, avoid single point or one side jacking with the tunnel shear panel removed.

To avoid any danger of bodywork damage when using a hydraulic jack, the vehicle must only be lifted at the jacking points.

Stands

When carrying out work (other than a wheel change) which requires a wheel to be raised, a stand must be used, located at the jacking point, to provide a secure support for the vehicle.

Workshop Hoist

Use of a workshop hoist is recommended for all operations where vehicles must be raised. Follow manufacturers instructions. If using an adjustable arm type, ensure lifting pads are correctly positioned at the four jacking points before lifting.

Vehicle Recovery

General

The preferred method of vehicle recovery is by a flat bed, covered, transporter.

The towing eye is primarily for emergency use when towing for short distances, e.g. removing vehicle if it is causing an obstruction or winching vehicle onto a flatbed transporter.

If moving this vehicle in such a situation, install the towing eye to the bracket, which is located behind the registration number plate.

CAUTION

TAKE CARE TO PROTECT THE PAINT WORK WHEN INSTALLING THE TOWING EYE. ENSURE THE TOWING EYE IS TIGHT.

Transporting

If vehicle is to be transported on a trailer or flat bed transporter the handbrake must be applied and the road wheels must be chocked.

Suspended Towing

CAUTION

DO NOT TOW WITH 'SLING' TYPE EQUIPMENT, DAMAGE TO BODYWORK WILL RESULT.

Take care when using 'spectacle frame' type towing equipment that the towing device is well clear of front or rear apron. Body damage may occur if vehicle passes over uneven road surfaces.

Ensure the recovery team follow the following towing instructions:


Front Suspended Tow

Automatic Transmission Only

1. Switch the ignition 'On'.
2. Pull back twice on both paddles, simultaneously, to force the gearbox into 'Neutral'.
Switch the ignition 'Off' within three seconds.


Manual and Automatic Transmissions

3. Remove the ignition key from the ignition.
4. Raise the vehicle using a 'spectacle frame' type lifting device with a cradle positioned under each front wheel as indicated below.



Rear Suspended Tow

1. Set the steering in the 'straight ahead' position.
2. Remove the ignition key from the ignition. Ensure the steering is locked in the straight ahead position.
3. Raise the vehicle using a 'spectacle frame' style lifting device where a cradle is positioned under each rear wheel as indicated below.



Towing an Automatic Vehicle

CAUTION

A VEHICLE WITH AN AUTOMATIC TRANSMISSION INSTALLED CAN BE TOWED ON ITS DRIVEN WHEELS AT NOT MORE THAN 70 KM/H ROAD SPEED AND FOR A MAXIMUM DISTANCE OF 500 KM. THE TRANSMISSION MUST BE SET TO NEUTRAL (N). IF THE ABOVE SPEED AND DISTANCE LIMITS ARE EXCEEDED, THE AUTOMATIC TRANSMISSION WILL BE DAMAGED.

Towing Regulations

In some countries, the registration number plate of the towing vehicle and an "ON TOW" sign or warning triangle must be shown that can be easily seen at the rear of vehicle being towed.

Towing by Another Vehicle

WARNING

THE BRAKE BOOSTER AND THE POWER STEERING WILL NOT OPERATE WHEN THE ENGINE IS NOT OPERATING. THE STEERING AND THE BRAKES WILL NEED MUCH MORE EFFORT TO OPERATE.

The vehicle may be towed for short distances by another vehicle at speeds of not more than 48 km/h (30 mph). Make sure that the towed vehicle transmission is in neutral (manual) or position "N" (automatic), the ignition key turned to position "II" to release steering lock and to let the horn, indicators and brake lights operate.

Push-start

Vehicles with automatic transmissions cannot be started by push-starting.

Identification Numbers

Vehicle Identification Number (VIN)


The Vehicle Identification Number (VIN) is a 17 character number which uniquely identifies the vehicle and gives important data about the build site, date and initial configuration of the vehicle.

VIN Location

The VIN number is stamped / plated in the locations that follow:

Under the bottom edge of the windscreen.

At the front of the engine bay.




Stamped on the floorpan in the RH front footwell.



Engine Number

The engine number is stamped on the LH side of the engine block.



Gearbox Number

Automatic Gearbox

The automatic gearbox number plate is located on the LH side of the gearbox.



Manual Gearbox

To follow.



ASTON MARTIN

Body System (01.00)

Contents

Body Structure (01.01)	1-1-3	Maintenance	9-1
Overview	1-3	Door Mirrors.....	9-1
Front End (01.02)	1-2-1	<i>Removal</i>	9-1
Front Wings	2-1	<i>Installation</i>	9-1
Specifications.....	2-1	Seating (01.10)	1-10-1
Maintenance.....	2-1	Description	10-1
<i>Front Wing</i>	2-1	Heated Seats	10-1
Body Closures (01.03)	1-3-1	Seat Module	10-1
Specifications	3-1	Specifications	10-1
Doors	3-1	Maintenance	10-1
Boot Lid.....	3-1	Front Seat - Remove and Install.....	10-1
Bonnet.....	3-1	<i>Remove</i>	10-1
Maintenance	3-2	<i>Install</i>	10-2
Doors	3-2	Seat Base Control Motors.....	10-2
<i>Removal</i>	3-2	Front Seat Squab Cover Assembly (Each, from 08MY)	
<i>Installation</i>	3-2	- Remove and Install	10-2
New Door Assembly	3-3	<i>Remove</i>	10-2
<i>Preliminary Hinge Setup</i>	3-3	<i>Install</i>	10-2
Boot Lid.....	3-4	Seat Module	10-2
<i>Removal</i>	3-4	<i>Remove</i>	10-2
<i>Installation</i>	3-4	<i>Install</i>	10-2
Bonnet.....	3-5	Seat Module Calibration	10-3
<i>Removal</i>	3-5	Rear Seats.....	10-3
<i>Installation / Realignment</i>	3-5	<i>Removal (Coupe)</i>	10-3
Interior Trim (01.05)	1-5-1	<i>Installation (Coupe)</i>	10-3
Specifications	5-1	<i>Removal (Volante)</i>	10-4
Maintenance	5-1	<i>Installation (Volante)</i>	10-4
IP Trim.....	5-1	Lumbar Pump for the Front Seat (From 08MY)	
<i>Remove</i>	5-1	- Remove and Install	10-4
<i>Installation Notes</i>	5-1	<i>Remove</i>	10-4
Roof Trim	5-2	<i>Install</i>	10-4
<i>Removal</i>	5-2	Lumbar Valve for the Front Seat (From 08MY)	
<i>Installation</i>	5-2	- Remove and Install	10-4
Door Trim.....	5-3	<i>Remove</i>	10-4
<i>Removal</i>	5-3	<i>Install</i>	10-4
<i>Installation</i>	5-4	Lumbar Bladder for the Front Seat (From 08MY)	
Rear Trim.....	5-5	- Remove and Install	10-5
<i>Removal (Coupe)</i>	5-5	<i>Remove</i>	10-5
<i>Install (Coupe)</i>	5-6	<i>Install</i>	10-5
<i>Removal (Volante)</i>	5-6	Glass, Frame and Mechanism (01.11)	1-11-1
<i>Install (Volante)</i>	5-6	Description	11-1
Boot Trim	5-7	Frameless doors	11-1
<i>Removal</i>	5-7	Specifications.....	11-1
<i>Installation</i>	5-7	Maintenance	11-1
Exterior Trim (01.08)	1-8-1	Glass Regulator	11-1
Maintenance	8-1	<i>Removal</i>	11-1
Side Trim	8-1	<i>Installation</i>	11-2
<i>Removal</i>	8-1	Door Glass.....	11-3
<i>Installation</i>	8-1	<i>Removal</i>	11-3
Sill Trim	8-2	<i>Installation</i>	11-4
<i>Remove</i>	8-2	Door Glass Setup.....	11-6
<i>Installation</i>	8-2	Rear Quarter Glass (Coupe)	11-7
Mirrors (01.09)	1-9-1	<i>Remove</i>	11-7
Specifications	9-1	<i>Installation</i>	11-7

Rear Quarter Glass (Volante)	11-7	Maintenance	17-2
Remove	11-7	Roof	17-2
Installation	11-9	Removal	17-2
Instrument Panel (IP) (01.12).....	1-12-1	Installation	17-2
Specifications	12-1	Roof Material	17-3
Maintenance	12-1	Removal	17-3
IP	12-1	Installation	17-4
Removal	12-1	Weather Seals	17-8
Installation	12-3	Removal	17-8
Veneer Bezel for the Instrument Panel (IP)		Installation	17-8
- Remove and Install	12-5	Roof Pump.....	17-8
Remove	12-5	Removal	17-8
Install	12-10	Installation	17-10
Centre Console Panel - Remove and Install.....	12-15	Roof Module	17-11
Handles and Lock Mechanisms (01.14)	1-14-1	Removal	17-11
Description	14-1	Installation	17-11
Vehicle Key/Remote Transmitter	14-1	Roof Lid Hydraulic Rams.....	17-11
Central Locking System	14-1	Removal	17-11
Remote Transmitter.....	14-1	Installation	17-11
Fuel Filler Assembly.....	14-1	Bumpers (01.19)	1-19-1
Manual Boot Release.....	14-1	Front Bumper.....	19-1
Boot Emergency Release	14-1	Specifications	19-1
Specifications	14-2	Maintenance	19-1
Maintenance	14-2	Removal	19-1
Door Handle / Latch Unit.....	14-2	Installation	19-2
Removal	14-2	Rear Bumper	19-3
Installation	14-3	Specifications	19-3
Wipers and Washer System (01.16).....	1-16-1	Maintenance	19-3
Headlamp Washing	16-2	Removal	19-3
Specifications	16-2	Installation	19-5
Maintenance	16-2	Restraining Devices (01.20)	1-20-1
Driver's Side Wiper Blade - Remove and Install		Seat Belts	20-1
(12MY onward)	16-2	Pre-tensioner and Load Limiting Systems	20-1
Removal	16-2	Emergency Locking Retractor (ELR)	20-2
Install	16-3	Automatic Locking Retractor (ALR)	20-2
Passenger's Side Wiper Blade - Remove		Specifications	20-2
and Install	16-3	Airbag System	20-3
Removal	16-3	Airbag Deployment	20-3
Install	16-4	Dual Inflation Technology	20-3
Windscreen Reservoir and Motor Assembly		Driver airbag Module.....	20-3
- Remove and Install (12MY onward).....	16-4	Passenger Airbag Module	20-3
Removal	16-4	Side Airbag Module	20-3
Install	16-4	Clockspring	20-3
Low Level Water Sensor - Remove and Install.....	16-5	Restrains Control Module (RCM)	20-4
Removal	16-5	Impact Sensors	20-4
Install	16-5	Specifications	20-4
Headlamp Wash Motor and Pump Assembly		Maintenance	20-4
- Remove and Install.....	16-5	Driver Airbag.....	20-4
Removal	16-5	Passenger Airbag.....	20-4
Install	16-6	Side Impact Airbag	20-5
Windscreen Wiper Motor.....	16-6	Deployable Rollbars	20-6
Removal	16-6	Specifications	20-6
Installation	16-7	Maintenance	20-6
Wiper Arms.....	16-8	Rollbar Unit.....	20-6
Removal	16-8	Rollbar Sensor	20-8
Installation	16-9		
Convertible Roof (01.17).....	1-17-1		
Description	17-1		
Specifications	17-1		

Body System (01.00)

Body Structure (01.01)


Overview

The all aluminium body underframe is bonded using an immensely strong hot-cured XD4600 red adhesive.

The rear quarter panels, roof and side mouldings are bonded to the structure using cold-cured 2810 MV adhesive. The curing cycle is improved by using a hot air impingement system. In addition, the roof panel is connected to the rear quarter panels through ultrasonic welds.

The composite front wings are bolted to the structure.

At no time should the body structure be subjected to temperatures in excess of 120°C (248°F).



01-01-020



ASTON MARTIN

Body System (01.00)

Body Structure (01.01)


Overview

The all aluminium body underframe is bonded using an immensely strong hot-cured XD4600 red adhesive.

The rear quarter panels, roof and side mouldings are bonded to the structure using cold-cured 2810 MV adhesive. The curing cycle is improved by using a hot air impingement system. In addition, the roof panel is connected to the rear quarter panels through ultrasonic welds.

The composite front wings are bolted to the structure.

At no time should the body structure be subjected to temperatures in excess of 120°C (248°F).



01-01-020




ASTON MARTIN

Body System (01.00)

Front End (01.02)

Front Wings Specifications



Wing Standard (mm)				
Item	1	2	3	4
Nominal gap	3.5	2.0	3.75	3.0
Tolerance	±0.75	+0.5 / -0.0	± 0.75	±0.5
Flush	-0.0	0.0	0.0	-0.5
Tolerance	±1.5	+0.0 / -0.5	±1.5	±0.5
Taper	N/A			
Symmetry	N/A			

Torque Figures

Description	Nm.	lbs / ft.
Wing Top	8	6
Wing Top Single nut	Tight with 'Threadlock'	
Lower Rear	8	6
Slam panel	8	6
PCM Bracket	10	7
Bonnet Damper	25	18



Maintenance

Front Wing

Repair Operation Time (ROT)	
Item	Code
Front Wing Renew	(LH) 01.02.KB
	(RH) 01.02.LB

Removal



1. Disconnect the vehicle battery.
2. Remove the wing top nut.



If using a two post vehicle lift, remove the screws that secure the rear section of the road wheel arch liner. Hold back the rear section of the road wheel arch liner to allow the foot of the vehicle lift to be positioned correctly. (Refer to 'Jacking Points', page I-I-IX)

3. Remove the front road wheel and road wheel arch liner.

4. Disconnect the side repeater lamp wiring harness plug. 7. Remove bolts (x3).



5. Disconnect the wing from the bumper (Refer to 'Front Bumper', page 1-19-1).


Release Clip

Remove Bolts x4

Front Bumper

01-02-044

6. Remove the slam panel (bolts x12). Remove the front grill bolt (x2).




8. Loosen bolts (x2).




9. Lift from the rear lower edge to disengage the wing from the two loosened bolts. Pull the wing from the body.

Installation


1. Place the wing to the body.
2. Locate:
 - The wing top stud




- The rear lower wing to the loosened bolts
3. Install the wing lower edge clips and bolt.
 4. Connect the wing to the bumper.
 5. Install bolts to the wing top edge. Do not tighten.





The two lower rear wing bolts have the same bolt / washer arrangement.



6. Install the slam panel.



7. Check wing alignment. Refer to specifications. Adjust if required.
8. Torque all wing fixings.




9. Connect the side repeater lamp wiring harness plug.
10. Install the road wheel and road wheel arch liner (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
11. Connect the vehicle battery.

Body System (01.00)

Body Closures (01.03)

Specifications

Doors




Door Standard (mm)				
Item	1	*2	3	4
Nominal gap	3.5	3.00	3.00	3.75
Tolerance	±0.75	±1.0	±1.0	±0.75
Flush	0.0	-1.0	-1.0	0.0
Tolerance	±1.5 / 0.0	+0.0 / -1.0	±1.0	±1.5
Taper	N/A			
Symmetry	N/A			

* Flushness blends to 0.0 at the rear quarter

* Gap blends to 3.5 at rear quarter

Torque Figures		
Description	Nm.	lb. / ft.
Hinge to Door	47.5	33.5
Hinge to Body	36	26.5
Door Striker plate		


Boot Lid



Boot Standard (mm)		
Item	1	2
Nominal gap	3.5	3.5
Tolerance	±0.75	±1.0
Flush	-0.5	N/A
Tolerance	+0.5 / -1.0	N/A
Taper	1 mm Max. across the length	
Symmetry	1 mm Max. difference LH to RH	

Torque Figures		
Description	Nm	lb. / ft.
Hinge to Body	25	18

Bonnet



Bonnet Standard (mm)	
Item	1
Nominal gap	3.5
Tolerance	±0.75
Flush	-0.0
Tolerance	±1.5
Taper	N/A
Symmetry	N/A

Torque Figures		
Description	Nm	lb. / ft.
Hinge to Body	25	18

Maintenance

Doors

Repair Operation Time (ROT)		
Item		Code
Remove and reinstall	LH	01.03.EA
	RH	01.03.FA

Removal


Warning

The doors are heavy. Removal is a two person operation.


Caution

Before removing the door ensure that the vehicle body work is sufficiently protected from possible damage.


1. Disconnect the vehicle battery.
2. Open the vehicle door.
3. Slightly loosen the door hinge lock screws (x2).



4. Remove part of the roadwheel arch liner to gain access to the door check rod. Disconnect the door check rod.



5. Lift the door off the support studs and withdraw the door enough to gain access to the door wiring harness plug. Disconnect the wiring harness plug.



6. Withdraw the door from the vehicle and install on service tool (Refer to '501-F111 (Door Service Trolley)', page 20-1-8).

Installation

Warning

The doors are heavy. Replacement is a two person operation.

Caution

Before installing the door ensure that the vehicle body work is sufficiently protected from possible damage.

1. Place the door to the vehicle. Connect the door wiring harness plug.
2. Align the door to the upper and lower hinges. Install the door onto the hinges.





3. Connect the door check rod. Install the roadwheel arch liner.
4. Align the door. Manoeuvre the door to achieve correct gaps and flush (add / remove shims as required). Tighten the bolts. Do not torque.

5. Connect the vehicle battery.

⚠ Warning ⚠

Never touch the door lock linkage with electrical power available to the door. The window mechanism can move and trap hands, arms, etc. in door frame.

6. Check door alignment and closure of the door catch. Adjust striker plate if required.
7. When satisfied with the door install - torque the hinge bolts.
 - Hinge to Body - **36 Nm.**
 - Hinge to Door - **47.5 Nm.**



8. Check for:
 - Correct operation of all door lock functions.
 - Correct operation and sealing of the door window.

New Door Assembly

Repair Operation Time (ROT)		
Item	Code	
Remove and install	LH	01.03.CB
	RH	01.03.DB



Preliminary Hinge Setup

1. Install the door onto the hinges.
2. Place a weight of 16 kg (to compensate for weight of door windows, locks etc.) hanging from inner door skin as shown.



Weight and position are critical to accurately simulate weight and distribution of door furniture. Adjustment is difficult on a fully installed door.

3. If removed, install the front wing (Refer to 'Front Wing', page 1-2-1).
4. Gently close the door. Check for an acceptable initial install.
5. Align the door. Manoeuvre the door to achieve correct gaps and flush (add / remove shims as required). Tighten the bolts. Do not torque.
6. Open the door and torque all hinge bolts. Remove the door weight.
 - Hinge to Body - **36 Nm.**
 - Hinge to Door - **47.5 Nm.**



7. Release the hinge locking screws and remove the door for installation of window, locks etc.

Boot Lid


Repair Operation Time (ROT)	
Item	Code
Remove and reinstall	01.03.BB

Removal

⚠ Warning ⚠

The boot lid is heavy. Removal / replacement is a two person operation.

1. Open the boot lid.
2. Remove the boot lid trim panel (Fir trees).
3. Disconnect the boot lid harness.




4. Slightly loosen the bolts (x4) that secure the boot lid to the boot lid hinges.
5. Support the boot lid. Remove the hinge bolts.
6. Withdraw the boot lid from the vehicle.

Installation


1. Align the boot lid to its hinges. Install bolts (x4) sufficiently to manoeuvre the boot lid on its hinges. Gently lower the boot lid rear edge, ensure the front corners do not touch the rear wings.
2. Align the boot lid front edge centrally in the boot aperture. Manoeuvre as required to achieve correct gaps.
3. Partially raise the boot lid and 'nip' up the hinge bolts.



4. Lower the boot lid. Check for correct alignment and readjust if required.
5. Fully raise the boot lid. Torque the hinge bolts to 25 Nm.



6. Gently close the boot lid. Check for correct engagement of the boot latch. Adjust the boot latch if required. Torque the boot latch bolts, to 9 Nm.



7. Connect the boot lid wiring harness plugs.
8. Fully close the boot lid. Check for correct operation of the boot release switch and remote transmitter boot lid enable.
9. Install the boot lid trim.

Bonnet

Repair Operation Time (ROT)	
Item	Code
Remove and reinstall	01.03.AB

Removal

⚠ **Warning** ⚠
The bonnet is heavy. Removal is a two person operation.

1. Open the bonnet.
2. Disconnect the windscreen wash pipe.
3. Slightly loosen the bolts (x4) that secure the bonnet to the hinge.
4. With the bonnet supported, disconnect the gas struts and remove the hinge bolts (x4).




5. Withdraw the bonnet from the vehicle.

Installation / Realignment


⚠ **Warning** ⚠
The bonnet is heavy. Replacement is a two person operation.

1. Align the bonnet to its hinges. Install bolts (x4) sufficiently to manoeuvre the bonnet on its hinges. Gently lower the bonnet. Adjust so that the corners do not touch the wings at the front and rear. Align the bonnet front edge centrally in the aperture.



01-02-009

2. Partially raise the bonnet. 'Nip' up one hinge bolt either side.
3. Lower the bonnet. Check for correct alignment. Readjust if required.



01-01-047

4. Fully raise the bonnet. Torque all hinge bolts to **25 Nm**.
5. Install the bonnet gas struts.
6. Gently close the bonnet. Check for correct engagement of the bonnet latch. Adjust if required to achieve the flush specification.
 - Turn the nut anti-clockwise to raise or clockwise to lower the bonnet catch until the bonnet is flush with the wings when closed.



01-01-046

7. Fully close the bonnet. Check for correct operation of the bonnet release lever.



ASTON MARTIN

Body System (01.00)

Interior Trim (01.05)

This section covers removal and installation of the interior mouldings and trim panels. In many instances, one component overlaps another component. If this condition is found, it will be necessary to loosen or remove the overlapping component before removal, to prevent damage to either component.

Specifications

Torque Figures		
Description	Nm	lb. / ft.
Door Handle	9	6.5
Seat Belt Mounts	35	26


Maintenance

IP Trim

If required, removal of the IP trim can be achieved while the IP is in the vehicle.

Remove

1. Panel (1)- Pull off.
2. Hood (2) - Pull off.
3. Panel (3) - Pull off.
4. Panel (4) - Pull off. Disconnect the air temperature pipe.
5. Panel (5) - Front, screws (x3)
6. Glove box.
 - 6.1 Pull of the outer trim panel. Disconnect the glovebox release switch wiring harness plug.
 - 6.2 Release the damper cord.
 - 6.3 Remove screws (x3) from the glovebox door hinge. Remove door.
 - 6.4 Remove screws (x4) from the sight shield. Remove the sight shield and glovebox.
7. Panel, Airbag (7).



Caution

Withdraw the airbag panel carefully. The airbag panel can crease if forced out.

- 7.1 Remove screws (x3).
- 7.2 Lift from the front edge. Withdraw out of clips (x3).
8. Remove the airbag.

Warning ⚠

When removed, place the airbag in a secure container to prevent personal injuries if the airbag activates.

- 8.1 Disconnect the wiring harness plugs (x2).
- 8.2 Remove bolts (x4). Withdraw the airbag.
9. Panel (9) - Screws (x2), then pull off.
10. Panel (10) - Screws (x4).

11. If required, remove the center stack.
 - 11.1 Pull off the veneer panel (Service tool No. TBA). Disconnect the wiring harness plugs.
 - 11.2 Remove the speaker grill - Screws (x2).
 - 11.3 Remove the center panel (Radio etc.) - Screws (x4)
 - 11.4 Remove the center stack - Screws (x6).
 - 11.5 Remove the media player - Screws (x2). Disconnect the wiring harness plugs.

Installation Notes

The panels, etc., are best replaced in the order they were removed. Note the following:

1. When installing the glovebox shield ensure that the tab in the top centre locates into the slot in the substrate.

Roof Trim

Removal

1. Remove (pull away) the cant rail.

The cant rail is held in by 'FirTrees'.


The front of the cant rail is held in place by the 'IP'. Pull the cant rail away from the back first then pull the front out from the 'IP'.

2. Remove the interior mirror (screw x1).
3. Remove the reading lamp pod (clips x2, screw x1, wiring harness plugs x2)
4. Remove the sun visors (screws x2 (x2)).

The front headlining will fall away.

5. Remove the headlining.

Held in place with 'FirTrees' and two velcro panels at the rear.



01-01-023

Installation

1. Install the roof lining.
2. Install the front headlining.
While holding the front headlining in place install the sun visors.
3. Install the interior mirror.
4. Install the cant rails.
Place the front of the cant rail into location at the IP, and work towards the rear, locating the 'FirTrees'.



Door Trim

Removal


1. Lower the door glass fully.
2. Disconnect vehicle battery.
3. Release the door handle (Bolts x2).




4. Remove the door handle trim plate and disconnect the release cable.




5. Remove the door mirror cheater panel.




6. Remove outer chrome waist rail trim.



7. From the outside remove screws (x2).



8. Remove the door trim panel screws (x6). Withdraw the door trim panel to gain access to the window and mirror switches. Disconnect the switches.




Installation

1. Place the door trim panel to the door and connect the wiring harness plugs.
2. Install the door trim panel screws (x6).
3. Install screws (x2).














4. Install the outer weather seal strip.



5. Install the door mirror cheater panel.
6. Install the door pull
 - 6.1 Connect the door inner release cable.
 - 6.2 Install the door pull trim plate.
 - 6.3 Install the door handle. Torque to **9 Nm**.
7. Connect the vehicle battery.

Rear Trim Removal (Coupe)





Install (Coupe)

Install the trim in reverse order to remove.

Torque seat belt mounts to **35 Nm**.

Removal (Volante)

1. Remove the seat bases.
2. Remove the seat backs.
 - 2.1 Pull off and up to remove the head support.
 - 2.2 Remove screws (x2 (Bottom) and x2 (top)).
3. Remove the door 'kick' plates.
 - 3.1 Remove screws x2.
 - 3.2 Remove screws x4. Withdraw the 'kick' plate.
 - 3.3 Repeat for the second 'kick' plate.
4. Remove the rear seat belt top mounts.
5. Remove the rear quarter panels.

Screws (x2 (lower)), screw (x1 (upper)) and pull the front away (firtrees). Repeat for the second quarter panel.
6. Remove the 1st trim panel of the rear console.

Pull up at the front and lift off.
7. Remove the 2nd trim (speaker) panel of the rear console.

Remove the screws (x2).
8. Remove the 3rd trim panel of the rear console.

Remove the screws (x2) from the bottom and screws (x2) from the rear of the ROPS closure panel.
9. Remove the rear center console.


Install (Volante)

1. Install the rear center console.
2. Install the center console trim panels.
3. Install the rear quarter panels.
4. Install the door 'kick' plates.
5. Install the seat belt top mounts. Torque to **35 Nm**.
6. Install the seat backs and bases.


Boot Trim

Removal

1. Remove the boot weather seal.



2. Remove the boot trim in the following order detailed above.



01-01-012

Item	Fixings	Item	Fixings
1.	Fir trees	6.	Fir trees
2.	Fir trees	7.	Fir trees
3.	Fir trees	8.	Fir trees
4.	Fir trees	9.	Fir trees
5.	Fir trees	10.	Fir trees
		11.	Fir trees

Installation

The rear trim is best installed in reverse order of the removal procedure.



ASTON MARTIN

Body System (01.00)

Exterior Trim (01.08)


Maintenance

Side Trim

Removal

1. Remove the trim panel.
 - 1.1 Remove the top / bottom screws (x2). Remove the outer panel.


Pull the top of the outer panel away from the vehicle and slide it forward.



2. Pull the inner trim panel away from the vehicle.

Pull the inner trim panel downwards.

3. Remove the door sealing rubber.
4. Remove the rear 1/4 glass and seal.



5. Remove the chrome trim screws (x18). Remove the chrome trim.

Support the trim as it is removed.



Installation

1. Install the chrome trim.
2. Rear 1/4 glass seal and glass.
3. Install the mirror trim panels. Insert the section of door sealing rubber as the inner and outer trim panels are installed.


The lower screw, screws into fibre glass. Ensure that the lower screw is screwed into the original threads.

4. Install the door sealing rubber.



Sill Trim

Remove

1. Remove the front and rear road wheel arch liners sufficiently to gain access.
2. Remove (x3) screws and (x2) scrivenuts.




3. Remove (x3) nut and bolt (front x2, rear x1).
4. Remove the door aperture screws (x3).




5. Unclip the sill trim from the vehicle body. Withdraw the sill trim.

Installation

1. Offer the sill trim to the vehicle.
2. Install the sill trim using 3 clips (front x1, rear x2).
3. Install the door aperture screws (x3).
4. Install (x3) nut and bolt (front x2, rear x1). Torque to 6 Nm.



5. Install (x3) screws and (x2) scrivenuts.



6. Install the front and rear road wheel arch liners.



ASTON MARTIN

Body System (01.00)

Mirrors (01.09)

Specifications

Torque Figures

Description	Nm	lb. / ft.
Mirror Mounting	20-25	15-18.5

Maintenance


Repair Operation Time (ROT)

Item	Code	
Remove and install	LH	01.09.AB
	RH	01.09.BB

Door Mirrors

Removal

1. Remove the door trim panel (Refer to 'Door Trim', page 1-5-3).
2. Remove the door mirror 'cheater' panel (pull off).



3. Disconnect the wiring harness plug.
4. Remove bolts (x2) and withdraw mirror.


Installation

1. Place the mirror into position. Install bolts (x2).

The spring washer goes between the mirror bracket and the door. On the front bolt of each mirror, ensure that the plain washer goes between the bolt head and the mirror bracket.

Torque to **20-25 Nm**. As the front bolt is tightened ensure a flush install with the door.

The front bolt hole on each mirror has an enlarged hole, to allow a small amount of adjustment.



2. Connect the wiring harness plug.
3. Install the door mirror 'cheater' panel.
4. Install the door trim panel (Refer to 'Door Trim', page 1-5-3).



ASTON MARTIN

Body System (01.00)

Seating (01.10)

Description

The front seats are installed with the following features:

- Integral side airbags
- Head restraints
- Safety belt buckle / pretensioner
- Electrically adjustable seat positioning and lumbar support
- Heated seat (optional)

Heated Seats

The heated seat system comprises:

- Heated seat switches
- Backrest heater element
- Cushion heater element and thermostat

The heated seat function permits the electrical heating of the seat back and cushion on the driver and front passenger seats. The heating system of each seat is selected by separate switches located on the inside of each seat base.

Once the heated seat function has been activated, it will operate until one of the following conditions have been satisfied:

- A fixed period of time has expired (10 minutes)
- If the engine is not running and the ignition key is removed
- A malfunction is detected by the heated seat module

Confirmation that the heated seat function is active is indicated by the illumination of an amber light in the instrument cluster.

Seat Module

The seat module is located under the front edge of the seat.

Specifications

Torque Figures		
Description	Nm.	lb. / ft.
Seat mountings	20-25	15-18.5
Seat Belt Mounts	35	26

Maintenance

Front Seat - Remove and Install

Repair Operation Time (ROT)		
Item	Code	
Front Seat - Remove and Install	LH	01.10.AA
	RH	01.10.BA


Remove

The front and rear seat rail mountings are positioned on four washers. Ensure the washers are collected during seat removal.


1. Motor the seat forward.

To power the drivers seat the ignition switch must be in the 'II' position


2. Remove bolts (x2) that secure the rear of the seat rails.



3. Motor the seat to the rear. Remove bolts (x2) that secure the front of the seat rails.




4. Tip the seat rearwards and disconnect the wiring harness plugs (x4).




5. Remove the seat assembly.

Install

1. Place the seat in the vehicle.
2. Connect the wiring harness plugs (x4).
3. Place the two spacers in position. Locate the seat over the seat mountings.



4. Install the front bolts, power the seat forwards and install the rear bolts. Torque bolts (x4) to **20-25 Nm**.



Seat Base Control Motors

The seat base control motors are an integral part of the seat base.

Front Seat Squab Cover Assembly (Each, from 08MY) - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Front Seat Squab Cover Assembly (from 08MY) - Remove and Install	01.10.AC

Remove

Procedure to follow.


Install

Procedure to follow.

Seat Module

Remove

1. Remove seat from vehicle.
2. Remove the seat module. The seat module is held in by fir trees (x4).



Install

1. Remove seat from vehicle.
2. Remove the seat module. The seat module is held in by fir trees (x4).

Seat Module Calibration

This mode allows the seat module to learn its position. The seat needs to know exactly where it is to electronically prevent seat movement into certain areas within the mechanical seat movement envelope.

Once the seat has been put in to calibration mode it will remain in this mode until it has been re-taught its position. There is no physical indication that the seat is in calibration mode, the seat could be left in this mode for some time before a user notices.

There is nothing wrong with the seat being in calibration mode for extended periods of time, it will only be apparent to the user when a rearward / downward seat movement is required.

The seat must be calibrated before rearward / downward movement is allowed.

Calibration mode is activated by a diagnostic command or by switching on the BDS while holding up the seat height switches.

1. With the Interior light relay 'On', i.e. door open, move the seat forwards or backwards, then disconnect the vehicle battery (either physically or via the BDS) before the interior light relay switches 'Off' (five minutes unlocked, 30 second locked).

The seat module is now in calibration mode.

The seat will not go into calibration mode if the interior light relay has been allowed to switch off since the last seat movement.

2. Drive the seat fully forward, allow the motors to stall against the seats mechanical end stops.
3. Drive the seat fully upwards, allow the motors to stall against the seats mechanical end stops.



The seat up switch needs to be operated front up then back up.

When each end stop is reached the motor will know where it is on that particular axis, the seat will only allow forward or upward movement until each axis position has been learnt

4. The seat module is now out of calibration mode.

Rear Seats

Removal (Coupe)




Installation (Coupe)

Install the rear seat in reverse order.


Torque seat belt mounts to **35 Nm**.

Removal (Volante)

1. Remove the seat bases. Pull off.



2. Remove the headrest panel. Pull off at the top and pull up to remove.
3. Remove screws (x4) that secure the seat back. Withdraw the seat back.



Installation (Volante)

Install the rear seat in reverse order.
Torque seat belt mounts to **35 Nm**.

Lumbar Pump for the Front Seat (From 08MY) - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Lumbar Pump for the Front Seat (From 08MY) - Remove and Install	01.10.EF

Remove

1. Remove the applicable front seat (Refer to 'Front Seat - Remove and Install', page 1-10-1).
2. Remove the cover for the squab from the seat (Refer to 'Front Seat Squab Cover Assembly (Each, from 08MY) - Remove and Install', page 1-10-2).
3. Move the lumbar inlay to give access.
4. Remove the tape that attaches the air hoses for the bladder into the lumbar inlay.
5. Move the air pump out of the lumbar inlay.
6. Disconnect the air hoses from the pump.

7. Disconnect the electrical connector for the pump.
8. Remove the pump assembly.

Install

1. Connect the the air hose to the pump.
2. Put the air valve in position into the inlay.
3. Connect the electrical connector for the pump.
4. Put the pump into the correct position in the lumbar inlay.
5. Use applicable tape to hold the hoses into the lumbar inlay.
6. Put the lumbar inlay into the correct position.
7. Install the cover for the seat squab (Refer to 'Front Seat Squab Cover Assembly (Each, from 08MY) - Remove and Install', page 1-10-2).
8. Install the seat (Refer to 'Front Seat - Remove and Install', page 1-10-1).

Lumbar Valve for the Front Seat (From 08MY) - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Lumbar Valve for the Front Seat (From 08MY) - Remove and Install	01.10.EH

Remove

1. Remove the applicable seat (Refer to 'Front Seat - Remove and Install', page 1-10-1).
2. Remove the cover for the squab from the seat (Refer to 'Front Seat Squab Cover Assembly (Each, from 08MY) - Remove and Install', page 1-10-2).
3. Remove the tape that attaches the air hoses for the bladder into the lumbar inlay.
4. Record the air-hose connections to the air valve.
5. Move the air valve out of the lumbar inlay.
6. Disconnect the air hoses from the valve.
7. Disconnect the electrical connector for the valve.
8. Remove the valve assembly.

Install

1. Connect the the air hoses to the valve at the positions recorded during removal.
2. Connect the electrical connector to the valve assembly.
3. Put the valve into the correct position in the lumbar inlay.
4. Use applicable tape to hold the pipes into the lumbar inlay.
5. Put the lumbar inlay into the correct position.
6. Install the cover for the seat squab (Refer to 'Front Seat Squab Cover Assembly (Each, from 08MY) - Remove and Install', page 1-10-2).
7. Install the seat (Refer to 'Front Seat - Remove and Install', page 1-10-1).

Lumbar Bladder for the Front Seat (From 08MY) - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Lumbar Bladder for the Front Seat (From 08MY) - Remove and Install	01.10.EK

Remove

1. Remove the applicable front seat (Refer to 'Front Seat - Remove and Install', page 1-10-1).
2. Remove the cover for the squab from the seat (Refer to 'Front Seat Squab Cover Assembly (Each, from 08MY) - Remove and Install', page 1-10-2).
3. Release the clips that attach the lumbar bladder.
4. move the bladder to give access.
5. Release and remove the clips that attach the lumbar inlay.
6. Remove the tape that attaches the air hoses for the bladder into the lumbar inlay.
7. Record the air-hose connections to the air valve.
8. Move the air valve out of the lumbar inlay.
9. Disconnect the air hoses from the valve.
10. Remove the bladder assembly.

Install

1. Put the bladder in position on the seat.
2. Connect the the air hoses to the valve at the positions recorded during removal.
3. Put the air valve in position into the inlay.
4. Use applicable tape to hold the hoses into the lumbar inlay.
5. Put the lumbar inlay into the correct position.
6. Put the bladder into the correct position.
7. Install the bladder attachment clips.
8. Install the cover for the seat squab (Refer to 'Front Seat Squab Cover Assembly (Each, from 08MY) - Remove and Install', page 1-10-2).
9. Install the seat (Refer to 'Front Seat - Remove and Install', page 1-10-1).



ASTON MARTIN

Body System (01.00)

Glass, Frame and Mechanism (01.11)

Description

Power to the door window regulator motor is available when the ignition switch is at position '0' and is supplied, through a thermal cut-out, to the left and right window switches. The switches are double pole earth so that the current through a window regulator motor may be switched in either direction to raise or lower the glass.

Frameless doors

To avoid damaging the body seals during door opening, the door glass must be lowered before the door can be opened. This function is controlled by the door modules.

The door module senses the rotation of the latch claw as the door opens, the door module then drives the door window regulator motor briefly to lower the door glass until it clears the glass seals. After closing a door, the window regulator motor operates to raise the door glass to seat against the body seals.

Specifications

Torque Figures			
Description		Nm	lb. / ft.
Door regulator	M6	9	7
	M10	10-15	7.5-11.5
Glass grip screws		5-6	4-4.5
Door Handle		9	7
Rear quarter regulator	M6	9	7
	M10	10-15	7.5-11.5
Seat belt and speaker plate		8-10	6-7.5

⚠ **WARNING** ⚠

PUT ON PROTECTIVE GLOVES AND EYE PROTECTION WHEN YOU HOLD THE GLASS COMPONENTS.

THE GLASS CAN BREAK EASILY AND CAUSE INJURY.

Maintenance

Glass Regulator

Repair Operation Time (ROT)		
Item		Code
Door Glass Motor	LH	01.11.LH
	RH	01.11.RH
Door Glass Regulator	LH	01.11.FB
	RH	01.11.GB

Removal

1. Remove the door trim panel (Refer to 'Door Trim', page 1-5-3).
2. Power the door glass to a 'half open' position.

To enable access to the screws which secure the door glass.




3. Disconnect the vehicle battery.

⚠ **WARNING** ⚠



PUT ON PROTECTIVE GLOVES AND EYE PROTECTION WHEN YOU HOLD THE GLASS COMPONENTS.

THE GLASS CAN BREAK EASILY AND CAUSE INJURY.

4. Remove the door glass grip screws. Withdraw the door glass from the door.
5. Release the window regulator motor from the door.



6. Release nuts (x4). Withdraw the window regulator from the door.
2. Install nuts. Torque nuts (x3) M6 to **9 Nm.** and (x1) M10 to **10-15 Nm.**




Installation

1. Install the window regulator assembly.




3. Install the window regulator motor (screws x3). Torque to **5-6 Nm.**



Ensure the window regulator motor wiring harness clips to the window regulator motor.

4. Install the weather strips (x2). If removed.

Ensure the window regulator cable remains in place during installation.



Ensure that the wiring harness running by the adjuster bolt locates above the adjuster bolt.

Ensure the wiring harness does not get 'trapped'.

Window regulators are 'Handed' (L/H and R/H). The adjuster is always located at the bottom rear of the door.

Place the window regulator unit into position and locate the four mountings through the door inner skin.

⚠ **WARNING** ⚠
PUT ON PROTECTIVE GLOVES AND EYE PROTECTION WHEN YOU HOLD THE GLASS COMPONENTS.
THE GLASS CAN BREAK EASILY AND CAUSE INJURY.

5. Lower the door glass into the door.

Insert the front end of the door glass first then lower the door glass and insert the rear end.

- 5.1 Locate the rear end of the door glass into it's grip.
5.2 Locate the front end of the door glass into it's grip.

The front grip has to be located by feel alone.

- 5.3 Line up the holes in door glass with the openings in the grips (x2).

6. Install the grip screws (x2). Do not tighten.


The grip screws are, apart from length, the same as the latch unit screws (x3). Do not install the, shorter, latch unit screws to the grips.

7. Align the door glass. Ensure the following when installing a new door glass.

- The glass is flush with the mirror trim edge



- The two dots on the door glass are equal distance from the door edge.



8. Install the door module (if removed).

⚠ WARNING ⚠

DANGER OF HANDS BEING TRAPPED IN THE WINDOW REGULATOR MECHANISM. DO NOT PUT YOUR HANDS THROUGH THE DOOR GLASS APERTURE WITH THE DOOR HARNESS CONNECTED.


9. Connect the vehicle battery.
10. Check alignment of the door glass to the door seals.
If required, disconnect the power to the door and realign the door glass.
Once satisfactory alignment is achieved, torque both grip screws to **5-6 Nm**.
11. Install the door mirror. If removed.
12. Install the outer weather strip. If removed.
13. Install the door trim.

Door Glass


Repair Operation Time (ROT)		
Item	Code	
Door Glass Renew	LH	01.11.BB
	RH	01.11.HB
Door Glass Adjust	LH	01.11.CD
	RH	01.11.JD

Removal



1. Remove the door outer weather strip.



2. Release the door handle (Bolts x2).



3. Remove the door handle trim plate and disconnect the release cable.



4. While looking through the access holes provided by removing the door handle, power the door glass to show the glass grip screws.



5. Disconnect the vehicle battery.

⚠ WARNING ⚠
PUT ON PROTECTIVE GLOVES AND EYE PROTECTION WHEN YOU HOLD THE GLASS COMPONENTS.
THE GLASS CAN BREAK EASILY AND CAUSE INJURY.

6. Remove the door glass grip screws. Withdraw the door glass from the door.

Installation

⚠ WARNING ⚠
PUT ON PROTECTIVE GLOVES AND EYE PROTECTION WHEN YOU HOLD THE GLASS COMPONENTS.
THE GLASS CAN BREAK EASILY AND CAUSE INJURY.

1. Lower the door glass into the door.

Insert the front end of the door glass first then lower the door glass and insert the rear end.

- 1.1 Locate the rear end of the door glass into it's grip.
1.2 Locate the front end of the door glass into it's grip.

The front grip has to be located by feel alone.

- 1.3 Line up the holes in door glass with the openings in the grips (x2).

2. Install the grip screws (x2). Do not tighten.



The grip screws are, apart from length, the same as the latch unit screws (x3). Do not install the, shorter, latch unit screws to the grips.

3. Align the door glass. Ensure the following when installing a new door glass.



- The glass is flush with the mirror trim edge



- The two dots on the door glass are equal distance from the door edge.




4. Connect the inner release cable and install the door handle trim plate.



5. Install the door handle Torque bolts (x2) to 9 Nm.

6. Install the door outer weather strip.



7. Connect the vehicle battery.
8. Check that the door glass operates correctly. Perform the 'Door glass Setup' procedure.

Door Glass Setup

1. Sit in the driver's seat.
2. Ensure both doors are closed and switch the ignition to '0'.
3. Press firmly and hold the window switch until the window is at the maximum down position. Continue to hold the button for 5 seconds then release.
4. Pull back and hold the window switch until the window is in the maximum up position. Continue to hold the switch for a further 5 seconds, then release.
5. The window is now reset. Repeat for the second window.

Rear Quarter Glass (Coupe)

4. Disconnect the vehicle battery.

Repair Operation Time (ROT)	
Item	Code
Rear Quarter Glass Renew	LH 01.11.LB
	RH 01.11.MB

Remove

1. Pull the door sealing rubber away from the rear quarter glass.
2. Remove screws (x2).

⚠ WARNING ⚠

PUT ON PROTECTIVE GLOVES AND EYE PROTECTION WHEN YOU HOLD THE GLASS COMPONENTS.

THE GLASS CAN BREAK EASILY AND CAUSE INJURY.

3. Pull the rear quarter glass away from the body.


Installation

⚠ WARNING ⚠

PUT ON PROTECTIVE GLOVES AND EYE PROTECTION WHEN YOU HOLD THE GLASS COMPONENTS.

THE GLASS CAN BREAK EASILY AND CAUSE INJURY.

1. Install the rear quarter glass.
2. Install screws (x2).



3. Install the door sealing rubber.


Rear Quarter Glass (Volante)

Repair Operation Time (ROT)	
Item	Code
Rear Quarter Glass Renew	LH
	RH

Remove


1. Power the front seat forward.
2. Lower the convertible roof.
3. Remove the rear seat back and seat base.

5. Remove the seat belt top mount.




6. Remove the rear 1/4 panel.


- 6.1 bolts x2
- 6.2 fir trees x3




7. Remove bolts (x10) that secure the seat belt and speaker plate. Withdraw the plate.




8. Disconnect the wiring harness plugs (x2).



9. Disconnect the glass regulator wiring harness plug.




10. Power up the glass regulator to line up the two glass securing screws through the two holes in the top bracket.





⚠ WARNING ⚠
PUT ON PROTECTIVE GLOVES AND EYE PROTECTION WHEN YOU HOLD THE GLASS COMPONENTS.
THE GLASS CAN BREAK EASILY AND CAUSE INJURY.

11. Remove the two glass securing screws and withdraw the glass.

Remove Glass Securing Screws




12. Power the glass regulator down.
13. Remove the nuts (x2) that secure the bottom of the glass regulator. Pull the bottom of the glass regulator to reveal bolts (x2). Remove the bolts (x2).



14. Remove the nut from the top of the glass regulator and withdraw the glass regulator.

Installation


1. Install the glass regulator. Install the nut to the top of the glass regulator. Do not torque.






2. Install the lower bolts (x2). Push the bottom of the glass regulator into place and install nuts (x2).
3. Power up the glass regulator to line up the two glass securing screw holes through the two holes in the top bracket.

⚠ WARNING ⚠
PUT ON PROTECTIVE GLOVES AND EYE PROTECTION WHEN YOU HOLD THE GLASS COMPONENTS.
THE GLASS CAN BREAK EASILY AND CAUSE INJURY.

4. Install the glass. Secure with screws (x2). Do not torque
5. Remove the outer chrome trim.
6. Torque the upper nut (1) of the glass regulator to **9 Nm**.



7. Adjust the lower mountings (2) to achieve the 5 mm gap between the glass and the edge of the vehicle body.



- When adjusted, torque the outer nuts to **10-15 Nm**.
8. Secure the quarter glass. Torque the screws to **5-6 Nm**.
 9. Connect the glass regulator wiring harness plug.
 10. Check glass alignment.
 - 10.1 Raise the convertible roof.

Check the alignment of the glass to the door glass.
Check the alignment of the glass with the convertible roof seals.
 11. Install the seat belt and speaker plate. Torque bolts to **8-10 Nm**.
 12. Connect the wiring harness plugs (x2).
 13. Install the rear 1/4 panel.
 14. Install the seat belt top mount. Torque bolt to **35 Nm**.
 15. Install the rear seat back and seat base.
 16. Power the front seat forward.

Body System (01.00)

Instrument Panel (IP) (01.12)



Specifications

Torque Figures		
Description	Nm	lb. / ft.
IP Mountings	22.5	17
Glue pot bolts	8	6
Blower motor to bulkhead	10-14	7.5-10.5

Maintenance

IP

Repair Operation Time (ROT)	
Item	Code
IP Renew	01.12.AA

Removal


1. Evacuate the A/C system (Refer to 'Air Conditioning (A/C) System (12.03)', page 12-3-1).
2. Remove both doors (Refer to 'Body Closures (01.03)', page 1-3-1).
3. Remove both seats (Refer to 'Seating (01.10)', page 1-10-1).
4. Disconnect the vehicle battery.
5. Remove the passenger side road wheel and arch liner.
6. Remove the cant rails (pull off) (Refer to 'Roof Trim', page 1-5-2).
7. Remove the steering column (Refer to 'Steering Wheel - Remove and Install', page 11-6-1).
8. Remove the rear trim panels (Refer to 'Rear Trim', page 1-5-5). Including the centre arm rest and surround.
9. Remove / Pull back the front carpet (allowing access to the IP mounts and wiring harness plugs).
10. Remove the engine bay fusebox and fusebox mounting bracket.




11. Remove the A/C evaporator pipes.
Cap the open ends of all pipes.



12. Disconnect the wiring harness plugs.

Remove the bonnet pull lever to gain access to L/H harness plugs.






13. Manual Gearbox Only.

Remove the gear-lever.


13.1 Disengage the manual shift control cables (x2).

13.2 Remove screws (x6) that secure the gear lever pivot block. Withdraw the gear lever.




14. Remove, L/H and R/H, bolts securing the IP to vehicle.

14.1 Bolts (x6 L/H and R/H).




14.2 Bolts (x2).




14.3 Glue pot bolts (x2).



14.4 Bolt (x1) from heater blower.



15. Remove the window defrost air duct screws (x3 each side).




To prevent the screws falling down the air ducts - place a rag / cloth into the air ducts.

15.1 Disengage clips (x3) from each window defrost air duct) to release the window defrost air ducts from the IP.

15.2 Remove screws (x3 for each duct).


16. Manoeuvre the service tool (Refer to '501-F116 (IP Removal)', page 20-1-8) into position, through the passenger side opening, and attach to the IP.



17. Move the IP rearwards sufficient to gain access to the heater pipes. Disconnect the heater pipes.

One person to open the spring clip from inside the vehicle and one person to pull the pipes off from inside the engine bay.

CAUTION
TAKE CARE NOT TO LET COOLANT DRIP ONTO THE VEHICLE CARPET.



18. Withdraw the IP from the vehicle.

As the IP is withdrawn from the vehicle the evaporator drain pipe will come with it.


Take care not to break the blower motor bracket when manoeuvring over the vehicle tunnel.

Installation

1. Manoeuvre the IP, attached to service tool, through the passenger side opening.
2. Place the A/C Evaporator drain pipe through the opening provided.

Ensure A/C breather pipe is secure and correctly located. It is not accessible once the IP is installed.


3. Install the heater pipes.
4. Raise the IP and locate into position.
5. Install the following bolts
 - 5.1 Bolts (x6 (L and R/H)). Do not torque.




5.2 Install bolts (x2 L and R/H). Do not tighten.




6.3 Bolts (x2 L and R/H). Torque bolts to **22.5 Nm**.



5.3 Install the glue pot bolts (x2). Do not tighten.



7. Install the heater blower to the bulkhead bolt. Torque to **10-14 Nm**.




6. Torque the bolts in the following order.

6.1 Bolts (x6 (L and R/H)).

Torque bolts (1) to **22.5 Nm**

Torque bolts (2) to **22.5 Nm**.



8. Connect the wiring harness plugs.

If removed, install the bonnet pull lever.

9. Install screws (x3 each) that secure the window defrost air ducts.

10. Engage clips (x3) for each window defrost air duct vent panel.

11. Install the steering column (Refer to 'Steering Column - Remove and Install', page 11-4-3).

Note the steering rack to steering column position from removal.

12. Install the cant rail (Refer to 'Roof Trim', page 1-5-2).

13. Connect the A/C pipes.

14. Install the fusebox mounting bracket, fusebox and fusebox wiring harness blocks.

15. Install the rear trim (Refer to 'Rear Trim', page 1-5-5), front carpets and centre arm rest.

16. **Manual Gearbox Only.**

Install the gear-lever.

17. Install the road wheel arch liner.

18. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-8).

19. Install the seats (Refer to 'Seating (01.10)', page 1-10-1).

20. Install the doors (Refer to 'Body Closures (01.03)', page 1-3-1).

21. Connect the vehicle battery.

22. Charge the A/C system (Refer to 'Air Conditioning (A/C) System (12.03)', page 12-3-1).

6.2 The glue pot bolts (x2). Torque bolts to **8 Nm**.




Veneer Bezel for the Instrument Panel (IP) - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Veneer Bezel for the Instrument Panel (IP)	01.12.AV


Remove

1. Do the battery disconnection procedure (Refer to Workshop Manual procedure 14.01.CA - Battery Disconnection and Connection Procedure).
2. Use the special tool to release the veneer bezel from the Instrument Panel (IP).




CAUTION
BE CAREFUL WHEN YOU RELEASE THE IP VENEER BEZEL. THE BEZEL CAN BE EASILY DAMAGED.


3. Release the veneer bezel from the four clips that attach it to the IP.




4. Disconnect the electrical connectors from each of the four transmission control switches.




5. Disconnect the electrical connector from the ignition switch module.




6. Disconnect the electrical connector from the ignition switch module.




7. Disconnect the two electrical connectors from the navigation display screen.




10. Remove the right heater vent.



8. Remove the veneer bezel.




11. Remove the three Torx screws that attach the left heater vent to the veneer bezel.




Note: If removal of the veneer bezel is to give access only, do not do the steps that follow.


9. Remove the three Torx screws that attach the right heater vent to the veneer bezel.



12. Remove the left heater vent.




13. Remove the four Torx screws that attach the ignition switch module to the veneer bezel.




F-01-12-AV-10

16. Remove the four transmission switches from the veneer bezel.




F-01-12-AV-13

14. Remove the ignition switch module.




F-01-12-AV-11

17. Remove the 12 Torx screws that attach the transmission switch retainer to the veneer bezel.




F-01-12-AV-14

15. Release the four transmission switches from the veneer bezel.




F-01-12-AV-12

18. Remove the transmission switch retainer from the veneer bezel.




F-01-12-AV-15


19. Release the electrical connector from the clip that attaches it to the mechanism for the navigation display screen.




22. Cut the cable tie that attaches the wiring harness to the navigation display screen.



20. Release the wiring harness for the navigation display screen from the clip that attaches it to the mechanism for the navigation display screen.




23. Disconnect the electrical connector from the navigation display screen.




21. Manually move the navigation display screen into the open position.



24. Remove the two screws that attach the holder for the navigation display screen to the mechanism for the navigation display screen.




25. Release the holder for the navigation display screen from the mechanism for the navigation display screen.




G-19-07-CB-07

28. Remove the navigation display screen.




G-19-07-CB-10

26. Release the holder for the navigation display screen from the two clips that attach it to the mechanism for the navigation display screen.




G-19-07-CB-08

29. Remove the four screws that attach the veneer bezel door for the navigation display screen to the mechanism for the navigation display screen.




G-01-12-AV-04

27. Remove the holder for the navigation display screen.




G-19-07-CB-09

30. Remove the veneer bezel door.




G-01-12-AV-05


31. Remove the four screws that attach the mechanism for the navigation display screen to the veneer bezel.




2. Install but do not fully tighten, the four screws that attach the mechanism for the navigation display screen to the veneer bezel.



32. Remove the mechanism for the navigation display screen.




3. Install the veneer bezel door.




Install


1. Install the mechanism for the navigation display screen.




4. Install and tighten the four screws that attach the veneer bezel door for the navigation display screen to the mechanism for the navigation display screen.




5. Install the navigation display screen.




6. Put the holder for the navigation display screen into position.




7. Install the holder for the navigation display screen to the two clips that attach it to the mechanism for the navigation display screen.




8. Install the holder for the navigation display screen to the mechanism for the navigation display screen.




9. Install and tighten the two screws that attach the holder for the navigation display screen to the mechanism for the navigation display screen.




10. Connect the electrical connector to the navigation display screen.



11. Install a new cable tie to attach the wiring harness to the navigation display screen.




14. Install the electrical connector to the clip that attaches it to the mechanism for the navigation display screen.




12. Manually move the navigation display screen into the Closed position.




15. Use the adjusters to make sure that the veneer bezel door is correctly aligned with the veneer bezel.




13. Install the wiring harness for the navigation display screen to the clip that attaches it to the mechanism for the navigation display screen.



16. Tighten the four screws that attach the mechanism for the navigation display screen to the veneer bezel.




17. Install the transmission switch retainer to the veneer bezel.




F-01-12-AV-15

18. Install and tighten the 12 Torx screws that attach the transmission switch retainer to the veneer bezel.




F-01-12-AV-14

19. Install the four transmission switches to the veneer bezel.




F-01-12-AV-13

20. Put the four transmission switches into the correct positions.




F-01-12-AV-12

21. Install the ignition switch module.




F-01-12-AV-11

22. Install and tighten the four Torx screws that attach the ignition switch module to the veneer bezel.




F-01-12-AV-10


23. Install the left side heater vent.



26. Install and tighten the three Torx screws that attach the right side heater vent to the veneer bezel.




24. Install and tighten the three Torx screws that attach the left side heater vent to the veneer bezel.




27. Put the veneer bezel into position.




25. Install the right side heater vent.



28. Connect the two electrical connectors to the navigation display screen.




29. Connect the electrical connector to the ignition switch module.




F-01-12-AV-16

30. Connect the electrical connector to the ignition switch module.



F-01-12-AV-03


31. Connect the electrical connectors to each of the four transmission control switches.



F-01-12-AV-04

Note: Make sure that the air vents align with the air ducts.

32. Attach the veneer bezel with the four clips.



F-01-12-AV-02


33. Do the battery connection procedure (Refer to Workshop Manual procedure 14.01.CA - Battery Disconnection and Connection Procedure).

Centre Console Panel - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Centre Console Panel - Remove and Install	01.12.DG

Remove

1. Do the battery disconnection procedure (14.01.CA - Battery Disconnection and Connection Procedure).
2. Remove the trim piece to get access to the screws.



E-01-12-DA-01

Figure E-01-12-DA-01

3. Remove the two screws that attach the armrest to the centre console.




Figure E-01-12-DA-02

6. Remove the two Torx bolts that attach the front of the armrest to the bracket.




Figure E-01-12-DA-07

4. Remove the foam spacer-pad from the armrest.




Figure E-01-12-DA-05

7. Disconnect the three electrical connectors.




Figure E-01-12-DA-03

5. Remove the cup holder rubber-pad from the armrest.




Figure E-01-12-DA-06

8. Remove the armrest.




Figure E-01-12-DA-04

Note: The bracket and washers will fall off the armrest in the step that follows

9. Remove the two screws that attach the centre console panel to the body.




Figure C-01-12-DA-13

10. Compress and turn the gear knob counterclockwise.




Figure C-01-12-DA-14

11. Remove the gear knob.




Figure C-01-12-DA-16

12. Release the centre console panel from the body.




Figure C-01-12-DA-17

13. Disconnect the electrical connector from each of the four switches.




Figure C-01-12-DA-18

14. Remove the centre console panel.




Figure C-01-12-DA-19

Install

1. Put the centre console panel into position (refer to Figure C-01-12-DA-19).

2. Connect the electrical connector to each of the four switches.




Figure C-01-12-DA-18

6. Install the two screws that attach the centre console panel to the body.




Figure C-01-12-DA-13

3. Install the gear knob.




Figure C-01-12-DA-16

7. Install, but do not tighten, the two Torx screws, washers and bracket onto the armrest.





Figure E-01-12-DA-08

4. Install the switches and attach them with the two screws
5. Compress and turn the gear knob clockwise.



Figure C-01-12-DA-15


8. Release the rear console lower-panel from the two fir tree clips.



E-01-04-BB-02

9. Remove the rear console lower-panel.

10. Remove the four screws that attach the rear console to the body.



E-01-04-BB-04

11. Move the rear console to let the armrest move below.




Figure E-01-12-DA-09

12. Connect the three electrical connectors.




Figure E-01-12-DA-03

13. Install the armrest to the centre console.

14. Tighten the two Torx screws at the front of the armrest.




Figure E-01-12-DA-07

15. Install and tighten the two screws that attach the armrest to the centre console.

16. Install the rubber-pad onto the armrest.




Figure E-01-12-DA-06

17. Install the foam spacer-pad onto the armrest.




Figure E-01-12-DA-05

18. Install the trim piece onto the armrest.




Figure E-01-12-DA-01

21. Install the rear console lower-panel.




Figure E-01-04-BB-03

19. Move the rear console to the initial position.




Figure E-01-12-DA-09

22. Install the rear console lower-panel into the two fir tree clips.




Figure E-01-04-BB-02

20. Install and tighten the four screws that attach the rear console to the body.




Figure E-01-04-BB-04

23. Operate the seats to their initial positions.

Body System (01.00)

Handles and Lock Mechanisms (01.14)

Description

Vehicle Key/Remote Transmitter

The vehicle key operates the ignition and the door lock, the remote transmitter operates the central locking and alarm systems.

Do not leave them in the vehicle.

Central Locking System

The Central Locking system consists of lock actuators in both doors, the boot and the fuel flap. Central locking control is through the door modules.

Each lock actuator incorporates a microswitch which signals a change of state when any motor runs to drive the actuator. The microswitches are of the change over type and provide an earth for lock/unlock signals to the door module.

The boot will remain locked or will be unlocked simultaneously with the doors dependant on the boot lock position. The boot lock can be enabled at any time using the remote transmitter irrespective of the Central Locking status.

Remote Transmitter

The remote control system consists of a transmitter and an antenna (radio frequency system). The remote control transmitter for the radio frequency system will operate without the transmitter being directed at the vehicle. The normal range between the transmitter and the antenna is up to 5 meters. Before the remote control system can be used, each transmitter must be initialized to the vehicle. A maximum number of four transmitters can be initialized to any vehicle. All remote transmitters must be initialized at the same time. The keyless entry /remote operated locks will not operate when the ignition key is in the ignition switch.

(A) Lock - One step vehicle locking and alarm enable.

The vehicle will deadlock after 25 seconds.

(B) Un-lock - One step vehicle unlocking or two step vehicle unlocking and alarm disable.


(C) Boot Open - Press to enable the boot catch.

(D) Panic Alarm - Activates / deactivates the panic alarm.

(E) Approach Light - Activates the front and rear side lights.



Fuel Filler Assembly




Manual Boot Release

In the event of a total loss of vehicle power the boot can be opened by pulling the manual boot release handle.

Remove the LH rear seat base and undo the two knurled bolts that secure the cover. Remove the cover and pull the boot release.

Boot Emergency Release

The boot can be opened from inside the boot by pulling the luminous emergency release handle.



Specifications

Torque Figures

Description	Nm	lb. / ft.
Door handle	5	4
Latch	9	7

Maintenance


Door Handle / Latch Unit

Repair Operation Time (ROT)



Item		Code
Door Catch and Outer Lock	LH	01.14.MB
	RH	01.14.NB

Removal


1. Disconnect the vehicle battery.
2. Remove the door handle (Bolts x2).



3. Remove the door handle trim plate and disconnect the inner release cable.





4. Remove the door trim (Refer to 'Door Trim', page 1-5-3).
5. Remove the door glass and regulator (Refer to 'Glass Regulator', page 1-11-1).
6. Disconnect the wiring harness plug.



7. Disconnect the outer release cable from the outer handle and feed the inner release cable back through the door.


Take care not to break the cable mounts.






Ensure that the fir tree on the release cable is removed.

- 8. Remove the lock and latch assembly.
 - 8.1 Remove the latch screws (x3).



- 8.2 Remove the lock lower bolt and loosen the top nut.
 - 8.3 Rotate and withdraw the lock along with latch assembly.
- 9. Remove the nuts (x3) from the outer handle. Withdraw the outer handle from the door.




Installation

- 1. Install the outer door handle.


The outer door handle is reversible (installs to L/H and R/H).

Caution
 Ensure the Inertia block is in the 'Floating' position.




Secure with nuts (x3). Torque to **5 Nm**.

Do not over tighten. If over tightened the studs may pull from their mounts.




2. Connect the outer, inner and lock cables to the latch. Insert the lock and latch assembly into position. Feed the inner cable through the hole provided in the door.

Do not push the inner cable when it is hanging from the door. This may disconnect the link at the latch end.



4. Install the latch (screws x3). Torque to **9 Nm**.




5. Install the outer release cable to the outer release handle.

Ensure that both the release and lock cables locate behind the lock and barrel unit top nut (rear of door).

Ensure that the fir tree on the release cable is installed.

3. Install the lock.

- 3.1 Locate the barrel through the door and rotate the lock into position.
- 3.2 Install nut on lower mount.
- 3.3 Tighten both nuts.




6. Connect the wiring harness plug.
7. Install the door glass and regulator (Refer to 'Glass Regulator', page 1-11-1).
8. Install the door trim and the inner release handle (Refer to 'Door Trim', page 1-5-3).
9. Connect the vehicle battery. Check operation of the door latches.

Body System (01.00)

Wipers and Washer System (01.16)

The wipers and washer system consists of the following components:

- Wipers and washers
- Mounting arm and pivot shaft
- Wiper motor
- Reservoir and washer pump
- Headlamp washing system




The wipers have a two speed control (low and high) and an intermittent wipe mode. The wipers will park automatically irrespective of their position when the 'Off' position of the ignition or control switch is selected or the bonnet is opened.

Within the wiper and washer system the following features can be attained:

- Adjustable interval intermittent wiping
The intermittent wiping has six speed settings, 3, 6, 9, 12, 15, 18 seconds.
- Programmable wash and wipe sequences
The programmable wash and wipe sequence is driver controlled. With a depression of the wash / wipe switch between 40 milliseconds and 1.2 seconds the wash pump will be activated for a duration of 1.2 seconds. When the wash/wipe switch is depressed for longer than 1.2 seconds the wash pump will be activated for the duration of switch depression, a 10 second duration is the maximum available.


The wiping system is automatically activated with a depression of the wash switch of **more** than 0.5 seconds. If the wash switch is only pressed for 0.5 seconds **or less** then only the water pump will operate.



Headlamp Washing

The headlamp washers operate once per ignition cycle and are activated the first time the window washers are operated.

Headlamp washing is only available when the headlamps are switched on.



Specifications

Torque Figures

Description		Nm	lb. / ft.
Wiper link to wiper motor		35-42	26-31
Wiper motor mounting bolts		7-10	5.5-7.5
Wiper assembly plate	M6 Torx	6	4.5
	M6 bolt	8	6
Brake servo nuts		21-24	15.5-18
Brake master cylinder nuts		25	18.5
Wiper arm (Driver)		17	13
Wiper arm (Passenger)	M10	24	18
	M6	6	4.5

Maintenance


Driver's Side Wiper Blade - Remove and Install (12MY onward)

Repair Operation Time (ROT)


Item	Code
Driver's Side Wiper Blade - Remove and Install (12MY onward)	01.16.AF

Remove

1. Move the wiper arm away from the windshield.



2. Release the wiper blade from the wiper arm.



3. Remove the wiper blade.




Install


1. Put the wiper blade into position.

CAUTION: MAKE SURE THAT THE WIPER BLADE CLIP IS IN THE CORRECT POSITION.

2. Install the wiper blade onto the wiper arm.



3. Move the wiper arm into the correct position.




Passenger's Side Wiper Blade - Remove and Install (12MY onward)


Repair Operation Time (ROT)	
Item	Code
Passenger's Side Wiper Blade - Remove and Install (12MY onward)	01.16.AG

Remove

1. Move the wiper arm away from the windshield.



2. Release the wiper blade from the wiper arm.



3. Remove the wiper blade.



Install

1. Put the wiper blade into position.




2. Install the wiper blade onto the wiper arm.



CAUTION: MAKE SURE THAT THE WIPER BLADE CLIP IS IN THE CORRECT POSITION.

3. Move the wiper arm into the correct position.



Windscreen Reservoir and Motor Assembly - Remove and Install

Repair Operation Time (ROT)

Item	Code
Windscreen Reservoir and Motor Assembly - Remove and Install	01.16.DA

Remove

1. Raise the vehicle and make it safe.
2. On Volante vehicles, remove the centre undertray.
3. Remove the front right roadwheel.
4. Remove the M6 Torx-head screws that attach the rear of the wheelarch liner.
5. Remove the self-tapping screw that attaches the rear of the wheelarch liner into the wheelarch.
6. Turn the steering fully to the right.
7. Move the rear of the wheelarch liner away to get access to the windscreen reservoir.
8. Disconnect the windscreen washer pipe and drain the reservoir into an applicable container.
9. Disconnect the two clips that attach the battery harness to the bottom of the reservoir.
10. Move the harness away.
11. Disconnect the clip that attaches the harness for the level sensor to the reservoir.
12. Remove the rear bottom M6 reservoir attachment screw.
13. Lower the vehicle on the lift.
14. Disconnect the electrical connector for the windscreen washer motor.
15. Release the headlamp washer pipe from the clip and turn the motor to disconnect the pipe (quickfit) and the electrical connector.
16. Release the windscreen washer pipe from the reservoir.
17. Remove the two M6 reservoir attachment screws.
18. Let the reservoir fall, then release the filler tube from the clip.
19. Move the reservoir down and forward to get access.
20. Disconnect the electrical connector from the level sensor.

Install

1. Connect the electrical connector to the level sensor.
2. Move the reservoir into position.
3. Install the filler pipe into the clip.
4. Install the three M6 attachment screws.
5. Install the windscreen washer pipe into clips on the reservoir and connect it to the motor.
6. Install the headlamp washer pipe. Connect the pipe to the pump.
7. Connect the electrical connector to the pump.

8. Connect the electrical connector for the windscreen washer motor.
9. Raise the vehicle on the lift.
10. Connect the clip that attaches the level sensor harness to the reservoir.
11. Connect the two clips that attach the battery harness to bottom of the reservoir.
12. Put the wheelarch liner back into position.
13. Turn the steering to the centre position.
14. Install the self-tapping screw that attaches the rear of the wheelarch liner into the wheelarch.
15. Install the M6 Torx-head screws that attach the rear of the wheelarch liner.
16. Install the front right roadwheel.
17. On Volante vehicles, install the centre undertray.
18. Lower the vehicle.
19. Fill the washer reservoir.

Low Level Water Sensor - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Low Level Water Sensor - Remove and Install	01.16.DC

Removal

1. Raise the vehicle and make it safe.
2. On Volante vehicles, remove the centre undertray.
3. Remove the front right roadwheel.
4. Remove the M6 Torx-head screws that attach the rear of the wheelarch liner.
5. Remove the self-tapping screw that attaches the rear of the wheelarch liner into the wheelarch.
6. Turn the steering fully to the right.
7. Move the rear of the wheelarch liner away to get access to the windscreen reservoir.
8. Disconnect the windscreen washer pipe and drain the reservoir into an applicable container.
9. Disconnect the two clips that attach the battery harness to the bottom of the reservoir.
10. Move the harness away.
11. Disconnect the clip that attaches the level sensor harness to the reservoir.
12. Remove the rear-lower reservoir fixing.
13. Lower the vehicle on the lift.
14. Disconnect the electrical connector from the windscreen washer motor.
15. Unclip headlamp washer pipe and turn motor to disconnect pipe (quickfit) and multiplug.
16. Unclip the windscreen washer pipe from the reservoir.
17. Remove the two reservoir attachment screws.
18. Let the reservoir fall, then release the filler tube from the clip.
19. Move the reservoir down and forward to give access.
20. Disconnect the electrical connector for the level sensor.
21. Remove level sensor and seal from reservoir.

Install

1. Install the level sensor and seal in the reservoir.
2. Connect the electrical connector for the level sensor
3. Move the reservoir into position.
4. Install the filler pipe in the clip.
5. Install the three attachment screws.
6. Clip the windscreen washer pipe into reservoir and install it onto the motor.
7. Clip the headlamp washer pipe, connect the pipe (quickfit) and the electrical connector.
8. Connect windscreen washer motor multiplug.
9. Raise ramp.
10. Connect the clip that attaches the level sensor harness to the reservoir.
11. Connect the two clips that attach the battery harness to the bottom of the reservoir.
12. Put the wheelarch liner back into position.
13. Turn the steering to the centre position.
14. Install the self-tapping screw that attaches the rear of the wheelarch liner into the wheelarch.
15. Install the M6 Torx-head screws that attach the rear of the wheelarch liner.
16. Install the front right roadwheel.
17. On Roadster vehicles, install the centre undertray.
18. Lower the vehicle.
19. Fill the washer reservoir.

Headlamp Wash Motor and Pump Assembly - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Headlamp Wash Motor and Pump Assembly - Remove and Install	01.16.EB

Remove

1. Raise the vehicle and make it safe.
2. On Volante vehicles, remove the centre undertray.
3. Remove the front right roadwheel.
4. Remove the M6 Torx-head screws that attach the rear of the wheelarch liner.
5. Remove the self-tapping screw that attaches the rear of the wheelarch liner into the wheelarch.
6. Turn the steering fully to the right.
7. Move the rear of the wheelarch liner away to get access to the windscreen reservoir.
8. Disconnect the windscreen washer pipe and drain the reservoir into an applicable container.
9. Disconnect the two clips that attach the battery harness to the bottom of the reservoir. Move the harness away.
10. Disconnect the clip that attaches the harness for the level sensor to the reservoir.

11. Remove the rear-lower reservoir fixing.
12. Lower the vehicle on the lift.
13. Disconnect the electrical connector for the windscreen washer motor.
14. Release the headlamp washer pipe and turn the motor to disconnect the pipe (quickfit) and the electrical connector.
15. Release the windscreen washer pipe from the reservoir.
16. Remove the two reservoir attachment screws.
17. Let the reservoir fall, then release the filler tube from the clip.
18. Move the reservoir down and forward to give access.
19. Disconnect the electrical connector for the level sensor.
20. Remove the headlamp washer motor, seal and support clip from reservoir.


3. Remove the wiper arms. Note the position of the wiper arms on the glass for installation.

Note: Do not remove the nut that secures the idle arm to the wiper spindle. Remove the four bolts that attach the idle arm mounting plate.

4. Remove the wiper box to scuttle panel bolts (x6).




5. Remove the brake master cylinder. Lay the master cylinder to one side.



01-6-014

6. From inside remove the brake booster fixings. Allow the brake booster to drop slightly.



01-01-065

7. Disconnect the engine breather hose from the rear of the camshaft cover.

Install


1. Install the headlamp washer motor, seal and support clip into the reservoir.
2. Connect the electrical connector for the level sensor.
3. Move the reservoir into position.
4. Connect the filler pipe and install the clip.
5. Install the three attachment screws.
6. Clip the windscreen washer pipe into reservoir and connect it to the motor.
7. Install the headlamp washer pipe in position. Connect the pipe (quickfit) and the electrical connector.
8. Connect the electrical connector for the windscreen washer motor.
9. Raise ramp.
10. Connect the clip that attaches the level sensor harness to the reservoir.
11. Connect the two clips that attach the battery harness to the bottom of the reservoir.
12. Put the wheelarch liner back into position.
13. Turn the steering to the centre position.
14. Install the self-tapping screw that attaches the rear of the wheelarch liner into the wheelarch.
15. Install the M6 Torx-head screws that attach the rear of the wheelarch liner.
16. Install the front right roadwheel.
17. On Volante vehicles, install the centre undertray.
18. Lower the vehicle.
19. Fill washer reservoir.

Windscreen Wiper Motor


Repair Operation Time (ROT)	
Item	Code
Wiper Motor Renew	01.16.HB

Removal


1. Disconnect the vehicle battery.
2. Remove the inlet manifolds (Refer to 'Inlet Manifold', page 3-1-7).




- Remove the wiper assembly mounting bolts and allow the wiper assembly drop sufficiently to access the wiper motor bolts.



1 bolt




3 bolts




4 bolts

- Remove the wiper motor bolts (x3).



3 Bolts

- Disconnect the wiper linkage from the wiper motor (bolt x1). Withdraw the wiper motor.



Bolt



Installation

- Connect the wiper linkage to the wiper motor (bolt x1) using service tool (Refer to '501-112 (Wiper Linkage to Wiper Motor)', page 20-1-8). Torque nut to **35-42 Nm**.



Torque 35-42 Nm

- Install the wiper motor bolts (x3). Torque bolts to **7-10 Nm**.
- Install the wiper assembly plate
 - Torque bolts to **8 Nm**.



3.2 Torque bolt to **6 Nm**.



4. Connect the engine breather hose to the rear of the camshaft cover.
5. From inside the vehicle install the brake servo fixings. Torque to **21-24 Nm**.
6. Install the brake master cylinder. Torque to **25 Nm**.
7. Install the wiper box. Torque bolts to **7-10 Nm**.
8. Install the wiper arms. Position the wiper arms as per their position on removal.



Passenger Arm

Torque M10 nut to **24 Nm**.

Torque M6 (x4) nuts to **6 Nm**.

Driver Arm

Torque M8 nut to **17 Nm**.



9. Install the inlet manifolds (Refer to 'Inlet Manifold', page 3-1-7).

10. Connect the vehicle battery.

Wiper Arms

Repair Operation Time (ROT)	
Item	Code
Wiper Arm Renew	LHF 01.16.KG
	RHF 01.16.LB

Removal

Note the position of the wiper arms on the glass for installation.

Do not remove the nut that secures the idle arm to the wiper spindle. Remove the 3 bolts securing the idle arm mounting plate.

1. Remove the following screws and nuts.



Installation

1. Install the wiper arms. Position the wiper arms as per their position on removal.


Passenger Arm

Torque M10 nut to **24 Nm**.

Torque M6 (x4) nuts to **6 Nm**.

Driver Arm

Torque M8 nut to **17 Nm**.





ASTON MARTIN


Body System (01.00)

Convertible Roof (01.17)

Description

The convertible roof system comprises an electrically driven hydraulic pump and six hydraulic rams, four for raising and lowering the roof and two for raising and lowering the tonneau cover. The pump is powered via either the 'Roof Up' or 'Roof Down' relay. Two further pairs of change-over relays power the rear quarter windows (one pair for each window). The roof hydraulic pump is protected by a 30A fuse.

The Roof control module is actuated by the roof switch on the centre console and controls the operation of both the roof and rear quarter window circuits. They can only be operated in a pre-programmed manner.



Specifications

Torque Figures		
Description	Nm.	lb. / ft.
Pump plate	7-10	5.5-7.5
Module plate	7-10	5.5-7.5
Roof Mountings		

Maintenance

Roof

Removal

⚠ WARNING ⚠

DO NOT PLACE ANY OBJECTS ON THE TOP OF THE DEPLOYABLE ROLLBAR COVERS BEHIND THE REAR SEAT BACKS.

⚠ WARNING ⚠

DO NOT ALLOW ANY PERSON TO SIT ON THE DEPLOYABLE ROLLBAR COVERS AT ANY TIME.

⚠ WARNING ⚠

IF THE ROOF IS NOT STOWED AND THE DEPLOYABLE ROLLBARS DEPLOY THEY WILL BREAK THROUGH THE REAR GLASS.

1. Raise the roof. Do not lock in position.
2. Remove the ignition key and wait for a minimum of five seconds. The roof can now be moved in any direction.

⚠ WARNING ⚠

KEEP FINGERS CLEAR OF THE ROOF LINKAGE WHEN MOVING THE ROOF MANUALLY.

During this time the roof hydraulics will relax allowing manual movement of the roof. Some hydraulic fluid resistance will still be present in the operating rams. It may take considerable effort to fully raise the roof manually.

3. Disconnect the vehicle battery at the negative terminal and ensure the ignition key is removed.

⚠ WARNING ⚠

ALLOW A TWO MINUTE POWER DOWN PERIOD BEFORE PROCEEDING. THIS WILL ENSURE THAT THERE IS NO POWER TO THE DEPLOYABLE ROLLBAR SYSTEM.

⚠ WARNING ⚠

DO NOT LEAN OVER THE ROLLBARS. IF THE ROLLBARS DEPLOY WHILE SOMEONE IS LEANING OVER THEM, THEY WILL CAUSE SEVERE INJURY.

4. Remove the rear seats and trim panels (Refer to 'Rear Trim', page 1-5-5).
5. Raise the tonneau cover and secure in the fully open position.

6. Manually raise the tension bow to 90°.

For access to the hydraulic pipes and wiring harness plugs.

With the roof in the raised position and the tension bow in the 90° position the hydraulic rams have the minimum amount of hydraulic oil in them.



7. Disconnect the hydraulic pipes (x2) for each hydraulic ram.

Hydraulic pipes are self sealing.

8. Disconnect the wiring harness plug from the LH hydraulic ram unit.
9. Disconnect the two wiring harness plugs from inside the boot RH area. Route the cables into the roof storage area.
10. Remove bolts (x6 (3 each side)). Withdraw the roof mechanism.

Installation

1. Place the roof mechanism into position. Locate on the dowels provided and secure using bolts x6 (3 each side). Torque the bolts to **TBA Nm**.

The locating dowels are adjustable. In normal circumstances the dowels will not require to be adjusted.

2. Connect the hydraulic pipes.
3. Connect the LH hydraulic ram unit wiring harness plug.
4. Route the RH cable into the boot area. Connect the wiring harness plugs (x3) in the boot RH area.
5. Install the rear trim panels (Refer to 'Rear Trim', page 1-5-5).
6. Install the rear seat belt top mount. Torque to **35 Nm**.
7. Install the rear seat bases and backs.
8. Connect the vehicle battery.
9. Reset both door windows (Refer to 'Door Glass Setup', page 1-11-6).
10. Operate the roof and check for correct installation.

Roof Material

⚠ WARNING ⚠
DO NOT PLACE ANY OBJECTS ON THE TOP OF THE DEPLOYABLE ROLLBAR COVERS BEHIND THE REAR SEAT BACKS.

⚠ WARNING ⚠
DO NOT ALLOW ANY PERSON TO SIT ON THE DEPLOYABLE ROLLBAR COVERS AT ANY TIME.

⚠ WARNING ⚠
IF THE ROOF IS NOT STOWED AND THE DEPLOYABLE ROLLBARS DEPLOY THEY WILL BREAK THROUGH THE REAR GLASS.


Removal

1. Disconnect the vehicle battery at the negative terminal and ensure the ignition key is removed.

⚠ WARNING ⚠
ALLOW A TWO MINUTE POWER DOWN PERIOD BEFORE PROCEEDING. THIS WILL ENSURE THAT THERE IS NO POWER TO THE DEPLOYABLE ROLLBAR SYSTEM.

⚠ WARNING ⚠
DO NOT LEAN OVER THE ROLLBARS. IF THE ROLLBARS DEPLOY WHILE SOMEONE IS LEANING OVER THEM, THEY WILL CAUSE SEVERE INJURY.

2. If the roof is raised and locked, unlock and open, slightly.



3. Remove the ignition key and wait for a minimum of five seconds. The roof can now be moved in any direction.

⚠ WARNING ⚠
KEEP FINGERS CLEAR OF THE ROOF LINKAGE WHEN MOVING THE ROOF MANUALLY.

During this time the roof hydraulics will relax allowing manual movement of the roof. Some hydraulic fluid resistance will still be present in the operating rams. It may take considerable effort to fully raise the roof manually.

4. Disconnect the vehicle battery.
5. Raise the roof lid and secure in the fully raised position.
6. Raise the tension bow to 90° to the vehicle.

7. Remove the rear roof seal.




8. Remove the screws retaining the trim strip.
9. Remove the roof material from the roof frame (rear).



10. Lift the roof material from the rear of the tension bow.



11. Disconnect the window tension cord.
 - 11.1 Remove the window tension cord springs.



11.2 Remove the three tension cord mounts.



12. Roll the roof material back to the 3rd cross bar.
Remove the screws that secure the roof lining to the cross bar.
Pull the roof material from the cross bar.
13. Roll the roof material back to the 2nd cross bar.
Remove the screws that secure the roof lining to the cross bar.
Pull the roof material from the cross bar.
14. Remove the front of the roof material from the header rail.



15. Remove the corners of the front of the roof material from the header plate.

The outer screws on both sides of the header plate are not currently used.



16. Pull the roof material from the roof header rail.

17. Remove the two side cable securing clips (two each side) and withdraw the side tension cables through the roof lining.




Ensure that the two cable securing clips (each side) are retained for installation.

18. Roll the roof material back to the 1st cross bar.
Remove the screws that secure the roof lining to the cross bar.
Pull the roof material from the cross bar.
19. Remove the strip in the roof material from the front of the header rail.



Installation

1. Manually raise the roof to the raised position.
2. Lay the roof material on the roof frame.
 - 2.1 Locate the strip in the roof material to the header rail. Secure with screws x4.



3. Roll the roof material to the 1st cross bar.
4. Remove the sticky strip protection and locate to the first cross bar.



Ensuring that the material is central, stick to the frame cross bar. Affix from centre out, ensuring the holes in the material locate over the holes in the cross bar.

The material with the sticky surface goes under and up around the cross bar.

6. Roll the roof material to the 2nd frame cross bar.
7. Repeat step 6 and 7.

The material with the sticky surface goes over and down around the cross bar

8. Feed the side tension cables through the roof lining and install the end of the cables to the header rail. Ensure that the two cable securing clips are installed.



5. Locate the roof lining strip to the cross bar and secure with screws x5.

9. Install the front of the roof material to the header rail. Secure with screws.


The outer screws on both sides of the header plate are not currently used.




10. Place the material with the sticky pads into position. Remove the sticky pads protection and affix to the header rail.



12. Install the window tension cord (if not install).
12.1 Thread the tension cord through the center hole.



- 12.2 Install the three tension cord mounts.




11. Roll the roof material to the 3rd cross bar. Repeat steps 6 and 7.

The material with the sticky surface goes over and down around the cross bar


Ensure that the heated window cable goes under the adhesive strip.

13. Install the ends of the tension cord.

Install the spring, on the end of the tension cord, facing forward.





- 14. Raise the tension bow to 90°.
- 15. Slide the roof material over the rear of the tension bow.



- 16. Install the trim strip. Do not tighten the screws.



- 17. Raise the roof to the open position and lock into place.



Locking the roof manually may require the assistance of a second person to push down so the catches engage while the allen key is turned.

- 18. Check that the roof material is correctly installed.



- 19. Tighten 4 or 5, evenly, trim strip screws while the roof is in the open position.



20. Unlock the roof and lower to enable access to the trim strip. Tighten the remaining screws.



21. Install the roof material over the roof side frame.



The screw holes in the roof material are used when the sealing strip is installed.



Weather Seals

Removal

- 1.

Installation

- 1.

Roof Pump

⚠ WARNING ⚠

DO NOT PLACE ANY OBJECTS ON THE TOP OF THE DEPLOYABLE ROLLBAR COVERS BEHIND THE REAR SEAT BACKS.

⚠ WARNING ⚠

DO NOT ALLOW ANY PERSON TO SIT ON THE DEPLOYABLE ROLLBAR COVERS AT ANY TIME.

⚠ WARNING ⚠

IF THE ROOF IS NOT STOWED AND THE DEPLOYABLE ROLLBARS DEPLOY THEY WILL BREAK THROUGH THE REAR GLASS.

Removal

1. Disconnect the vehicle battery at the negative terminal and ensure the ignition key is removed.

⚠ WARNING ⚠

ALLOW A TWO MINUTE POWER DOWN PERIOD BEFORE PROCEEDING. THIS WILL ENSURE THAT THERE IS NO POWER TO THE DEPLOYABLE ROLLBAR SYSTEM.

⚠ WARNING ⚠

DO NOT LEAN OVER THE ROLLBARS. IF THE ROLLBARS DEPLOY WHILE SOMEONE IS LEANING OVER THEM, THEY WILL CAUSE SEVERE INJURY.

2. Remove the ignition key and wait for a minimum of five seconds. The roof can now be moved in any direction.

⚠ WARNING ⚠

KEEP FINGERS CLEAR OF THE ROOF LINKAGE WHEN MOVING THE ROOF MANUALLY.

During this time the roof hydraulics will relax allowing manual movement of the roof. Some hydraulic fluid resistance will still be present in the operating rams. It may take considerable effort to fully raise the roof manually.

3. Disconnect the vehicle battery.
4. Remove the LH road wheel and arch liner.

The fuel filler drain off pipe is attached to the arch liner. Ensure that the fuel filler drain off pipe does not disconnect from its stub pipe.

5. Remove bolts (x6). Support the pump plate as the screws are removed.

The pump is attached to the pump plate.



6. Disconnect two wiring harness plugs.





7. Manually raise the tension bow to 90°.

For access to the hydraulic pipes and wiring harness plugs.



8. Remove the rollbar trim cover.

9. Remove the rear closing panel.




10. Disconnect the hydraulic pipes.


Connect feed and return hydraulic pipes to create an hydraulic loop.

Creating hydraulic loops will enable the hydraulic rams to continue to operate.

Connect the hydraulic pipes, feed to return.




11. Disconnect the two wiring harness plugs from inside the boot area.




12. Withdraw the hydraulic pipes and the wiring harness cables through the vehicle body, while lowering the pump.

Installation


1. Feed the hydraulic pipes through the vehicle body. Feed the wiring harness plugs into the boot area.



2. Connect the two boot wiring harness plugs.



3. Connect the two pump wiring harness plugs.





4. Raise the pump and pump plate assembly into position and secure. Torque bolts to **7-10 Nm**.

Take care not to trap hydraulic pipes and wiring harness cables.

5. Connect the hydraulic pipes.

The hydraulic pipes are numbered, i.e. connect pipes numbered 32 together, etc.

6. Install the rear closing panel.



7. Install the rollbar trim cover.

8. Install the road wheel arch liner and road wheel.
(Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).

Roof Module

Removal

1. Remove the ignition key and wait for a minimum of five seconds. The roof can now be moved in any direction.

⚠ **WARNING** ⚠
KEEP FINGERS CLEAR OF THE ROOF LINKAGE WHEN MOVING THE ROOF MANUALLY.


During this time the roof hydraulics will relax allowing manual movement of the roof. Some hydraulic fluid resistance will still be present in the operating rams. It may take considerable effort to fully raise the roof manually.

2. Disconnect the vehicle battery.
3. Remove the LH road wheel and arch liner.


The fuel filler drain off pipe is attached to the arch liner. Ensure that the fuel filler drain off pipe does not disconnect from it's stub pipe.

4. Remove bolts (x4). Support the module plate as the screws are removed.

The roof module is attached to the plate.



5. Lower the module plate to access the two wiring harness plugs. Disconnect the two wiring harness plugs and withdraw the roof module.



Installation

1. Raise the roof module into position and connect the two wiring harness plugs.
2. Install the roof module and plate assembly. Torque bolts to 7-10 Nm.

Roof Lid Hydraulic Rams

Removal

1. Remove the ignition key and wait for a minimum of five seconds. The roof can now be moved in any direction.

⚠ **WARNING** ⚠
KEEP FINGERS CLEAR OF THE ROOF LINKAGE WHEN MOVING THE ROOF MANUALLY.

During this time the roof hydraulics will relax allowing manual movement of the roof. Some hydraulic fluid resistance will still be present in the operating rams. It may take considerable effort to fully raise the roof manually.

2. Disconnect the vehicle battery.
3. Raise the tension bow to 90° to the vehicle.
4. Raise the roof lid and support.
5. **LH ram only.**
 - 5.1 Withdraw the pump and pump plate unit.
 - 5.2 Connect the vehicle battery. Open the boot lid.
 - 5.3 Disconnect the wiring harness plug. Feed the wiring harness cable through into the pump area.

⚠ **WARNING** ⚠
TAKE CARE TO AVOID SHARP EDGES.

- 5.4 Close the boot lid. Disconnect the vehicle battery.
- 5.5 Disconnect the wiring harness plugs.
6. Disconnect the hydraulic pipes.
Connect feed and return hydraulic pipes to create an hydraulic loop.

Creating hydraulic loops will enable the hydraulic rams to continue to operate.

The hydraulic pipes are numbered, i.e. connect pipes, feed to return, numbered 32 together, etc.

7. Disconnect both ends of the hydraulic ram and withdraw the ram.

Installation

1. Connect the ram to it's mounts.
2. Connect the hydraulic pipes.

The hydraulic pipes are numbered, i.e. connect pipes, feed to return, numbered 32 together, etc.

3. **LH ram only.**
 - 3.1 Connect the wiring harness plug (x1).
 - 3.2 Feed the wiring harness cable (x1) through into the boot area.

⚠ **WARNING** ⚠
TAKE CARE TO AVOID SHARP EDGES.




- 3.3 Install the pump and pump plate unit.
4. Remove the roof lid support.
5. Connect the vehicle battery. Open the boot lid.
6. Connect the boot area wiring harness plug.

Body System (01.00)

Bumpers (01.19)

Front Bumper



01-01-073

Specifications

Torque Figures

Description	Nm	lb. / ft.
Bumper to bumper bracket	4-5	3-4

Maintenance

Repair Operation Time (ROT)

Item	Code
Bumper Remove / Install	01.19.AB


Removal

1. Remove the road wheel and arch liner.
2. Remove the bolts (x6) that secure the under tray to the bumper.

The air intake for the alternator is located in the front under tray.

3. Remove the LH and RH air boxes (Refer to 'Air Filter Box', page 3-12-3).

4. Remove bolts (x8 (x4 each side)) that secure the bumper.



01-01-186



5. Disconnect the retaining clips (x2).


Use a tool, i.e. a long screwdriver, to unclip the bumper from the vehicle body.

6. Pull the bumper from the clips located in the front grill.
Withdraw the bumper from the vehicle.

Installation

1. Place the bumper in position. Push install onto the clips located in the front grill.
2. Locate on the retaining clips (x2).
3. Install bolts (x8 (x4 each side)) to the bumper. Torque to **4-5 Nm**.
4. Install the LH and RH air boxes (Refer to 'Air Filter Box', page 3-12-3).
5. Install the undertray.
6. Install the road wheel arch liner and wheel.

Rear Bumper



Specifications

Torque Figures

Description	Nm	lb. / ft.
Bumper to bumper bracket	2-3	1.5-2.5

Maintenance

Repair Operation Time (ROT)

Item	Code
Bumper Remove / Install	01.19.BB

Removal

1. Remove the light clusters.
 - 1.1 Open the boot and remove the trim from around the light cluster mounts.
 - 1.2 Release and remove nuts (x3).
 - 1.3 Withdraw the rear light cluster unit. Disconnect the wiring harness plug.


2. Remove the bumper tag screw.



3. Remove screws x4 (2 each side).



4. Remove bolt from inside the boot (1 each side).





7. Remove screws (x4 (x2 each side)) from the bumper.



5. Remove the roadwheel and disconnect the rear section of the roadwheel arch liner.
6. Disconnect the wiring harness plugs (x2 (RH side)) and (x2 (LH side)).

8. Remove bolts (x4 (x2 each)) that secure the exhaust mount to the end pipe trim.




9. Disconnect the retaining clips (x2).

Use a tool, i.e. a long screwdriver, to unclip the bumper from the vehicle body.

10. Disconnect the two clips in the top centre of the bumper. Withdraw the bumper from the vehicle.

Installation

1. Place the bumper to the vehicle. Locate the two clips in the center top of the bumper.
2. Locate the retaining clips (x2).
3. Install the bumper 'Tag' screw.
4. Install screws (x4 (x2 each side)). Torque to **2-3 Nm**.
5. Install the screws (x4) in the light cluster opening.
6. Install the light clusters.
 - 6.1 Place a light cluster unit to vehicle and connect the wiring harness plug.
 - 6.2 Insert the light cluster unit into position.
 - 6.3 Ensure the rubber seal is in position. Tighten nuts (x3).
 - 6.4 Repeat for the second light cluster.
7. Install the bolts (x2) to the bumper boot mount.



8. Install the exhaust mounts.
9. Connect the wiring harness plugs.
10. Install the road wheel arch liner and wheel.




ASTON MARTIN

Body System (01.00)

Restraining Devices (01.20)

Seat Belts



This vehicle has four inertia reel safety belts installed. The inertia belt reels automatically tension the belts to provide security with comfort. In the event of a collision or during severe braking, the belt reels will lock.

The driver and front passenger safety belt buckles are installed with a switch, which is connected to a warning indicator housed within the DIM. When the ignition is first turned on the warning indicator will illuminate only if the seat belt is not fastened. If the safety belt is fastened before the ignition is turned on the circuit is broken and the indicator will remain off.

Pre-tensioner and Load Limiting Systems

The driver and front passenger seat belts are equipped with pre-tensioner and load limiting systems.

When required, the front airbag and pre-tensioner systems will deploy simultaneously.

In some moderate frontal or near frontal accidents, only the pre-tensioner system will deploy.

The pre-tensioners take up slack in the front seat belts as the airbags are expanding. The load limiting system releases belt webbing in a controlled manner to reduce belt force on the occupant's chest.

The Restraints Control Module (RCM) receives information on the status of the safety belt buckles from a switch contained in the buckle. Only fastened safety belts will activate.

The safety belt retractors, which are mounted within the base of the B pillars, incorporate a torsion bar load limiting device. This device consists of a retractor reel which is mounted onto a spindle (torsion bar) which once the sensor has locked the retractor reel and a predetermined load is applied, twists and allows additional webbing into the system. The deceleration force required to initiate this sequence is approximately the same as that required to initiate airbag deployment. The torsion bar load limiting device will only react if the safety belt is in use at the time of the impact.

Caution

It should be considered that during any event that utilizes the full capability of the safety belts, the webbing may have been elongated and the torsion bar may have twisted. For this reason, if a vehicle is involved in an accident which results in the deployment of the airbag(s), all the safety belts that were in use at the time of the accident MUST be renewed.

Emergency Locking Retractor (ELR)

The retractors in all seat positions feature ELR. During any period of sudden deceleration, or under lateral load when cornering at speed, a sensor weight within the safety belt retractor moves a locking pawl against the teeth on the retractor reel, which then locks the retractor preventing any further release of webbing. As soon as the load applied onto the retractor through the safety belt webbing is removed the locking pawl releases the retractor reel and normal movement is returned to the retractor.


Automatic Locking Retractor (ALR)

Automatic locking retractors (ALR) are installed to all passenger seat positions.


The safety belt webbing on these are clearly marked to show their operating feature. To initiate the ALR system, fasten the safety belt into its buckle and pull all of the webbing from the retractor, as the safety belt is released the retractor locks allowing travel in only one direction thus producing a fixed length restraint and preventing the safety belt from introducing slack, making any child seat it may be restraining secure. The ALR system of the retractor is disengaged by unfastening the safety belt and allowing the safety belt to fully retract onto the reel.

Specifications


Torque Figures
Description



Torque Figures
Description



Airbag System



The airbag system is designed to provide increased collision protection for front seat occupants in addition to that provided by the safety belt system. Safety belt use is necessary to obtain the best occupant protection and to receive the full advantages of the airbag system.

This vehicle is equipped with driver, passenger, side impact airbags and seat belt pretensioners, which are electrically controlled by a Restraints Control Module (RCM).

The purpose of the driver, passenger and side airbags is to provide **additional** protection for the front seat occupants in the event of a serious impact (front or side impacts). The airbags are supplementary to the seat belts.

Airbag Deployment

⚠ WARNING ⚠

AIRBAGS INFLATE RAPIDLY AND WITH CONSIDERABLE FORCE, THERE IS THEREFORE A RISK OF DEATH OR SERIOUS INJURY SUCH AS FRACTURES, FACIAL AND EYE INJURIES OR INTERNAL INJURIES, PARTICULARLY TO OCCUPANTS WHO ARE NOT PROPERLY RESTRAINED BY SEAT BELTS OR ARE NOT SITTING CORRECTLY WHEN THE AIRBAGS DEPLOY. THE RISK OF INJURY FROM A DEPLOYING AIRBAG IS GREATEST CLOSE TO THE TRIM COVERING THE AIRBAG.

⚠ WARNING ⚠

THE WHOLE SEQUENCE OF AIRBAG DEPLOYMENT, FROM SENSING THE IMPACT TO FULL INFLATION OF THE AIRBAG TAKES PLACE IN A FRACTION OF A SECOND.

Dual Inflation Technology

When activated, the airbags will deploy at either a normal or reduced level of inflation, depending on crash severity. Various sensors determine the direction and severity of an impact. The system analyses this information then deploys the appropriate airbags.

Driver airbag Module

The driver airbag module is installed in the steering wheel, the cover forming the outer surface of the steering wheel boss. The cover has a split line moulded into its surface allowing the airbag to exit through the cover when the system deploys.

No routine maintenance is required and there are no serviceable parts. The driver airbag module is replaced as an assembly.

Passenger Airbag Module

The passenger airbag module is located above the glove compartment behind a deployment panel.

The passenger airbag deployment panel hinges up out of the way during airbag deployment.

The passenger airbag module is replaced as an assembly. There is no routine maintenance required and there are no serviceable parts.

Side Airbag Module

A side impact airbag module is mounted in the outboard bolster of each front seat. In a side airbag module deployment situation, the airbag module deploys from behind a hard trim panel.

Clockspring

The airbag clockspring continuously transfers electrical signals from the driver airbag module to the airbag sensor.

The airbag clockspring is mounted on the steering column, behind the steering wheel and does not contain any serviceable components. Ensure that the steering wheel is locked in the central position before commencing any work on the steering column, wheel or airbag.

Restrains Control Module (RCM)

The primary purpose of the RCM is to discriminate between an event that warrants an airbag system deployment and an event that does not. The RCM governs the operation of the whole system and performs continual system diagnostics. Information on the severity of an impact is received from the impact sensors.

Variations in the deployment of the front airbag modules are dependent on the status of the front safety belt buckles.

Impact Sensors

Side Impact - Side impact sensors are mounted to the base of each B-pillar. In the event of a side impact, the RCM processes the impact data sent by the side impact sensor against stored data. The RCM will deploy both side impact airbags dependant on seat belt buckle status.

Front Impact

Front impact sensors (x2) are located under the grill opening panel.

The SRS module processes the impact data sent by the front impact sensor against stored data, and deploys the front airbags, and the seat belt pre-tensioners.

Specifications

Torque Figures

Description	Nm	lb. / ft.
Drive Airbag	8-10	6-7.5
Passenger Airbag	11.5	8.5
Side Airbag	10	7.5

Maintenance

Driver Airbag

Repair Operation Time (ROT)	
Item	Code
Drivers Airbag Renew	01.20.AB

Removal


1. Remove the earth ('-ve') terminal from the vehicle battery and ensure the ignition key is removed.

⚠ WARNING ⚠

ALLOW A TWO MINUTE POWER DOWN PERIOD BEFORE PROCEEDING. THIS WILL ENSURE THAT THERE IS NO POWER TO THE AIRBAG SYSTEM.

2. Remove bolts (x2) that secure the driver airbag.

Rotate the steering wheel to gain access to the two bolts.



3. Withdraw the driver airbag to gain access to the wiring harness plug. Disconnect the plug.
4. Withdraw the driver airbag.

Installation

1. Place the airbag module to the steering wheel. Connect the wiring harness plug.
2. Install the bolts (x2). Torque to **8-10 Nm**.
3. Connect the vehicle battery with the ignition in the 'Off' position.

Passenger Airbag

Repair Operation Time (ROT)	
Item	Code
Passenger Airbag Renew	01.20.BB

Removal

1. Remove the earth ('-ve') terminal from the vehicle battery and ensure the ignition key is removed.

⚠ WARNING ⚠

ALLOW A TWO MINUTE POWER DOWN PERIOD BEFORE PROCEEDING. THIS WILL ENSURE THAT THERE IS NO POWER TO THE AIRBAG SYSTEM.

2. Remove the glove box.
 - 2.1 Pull of the outer trim panel. Disconnect the glovebox release switch wiring harness plug.
 - 2.2 Release the damper cord.
 - 2.3 Remove screws (x3) from the glovebox door hinge. Remove door.
 - 2.4 Remove screws (x4) from the sight shield. Remove the sight shield and glovebox.

- Remove the airbag trim panel.

Caution
Withdraw the airbag panel carefully. The airbag panel can crease if forced out.


- 3.1 Remove screws (x3).
- 3.2 Lift from the front edge. Withdraw out of clips (x3).



- Disconnect the wiring harness plugs (x2).



- Remove bolts (x4) and withdraw the airbag.



Installation

- Install the airbag. Torque bolts to **11.5 Nm**.
- Connect the wiring harness plugs.
- Install the airbag trim panel. Torque bolts to **11.5 Nm**.
- Install the glovebox.
- Connect the vehicle battery with the ignition in the 'Off' position.


Side Impact Airbag

Removal


- Remove the earth ('-ve') terminal from the vehicle battery and ensure the ignition key is removed.

⚠ WARNING ⚠
ALLOW A TWO MINUTE POWER DOWN PERIOD BEFORE PROCEEDING. THIS WILL ENSURE THAT THERE IS NO POWER TO THE AIRBAG SYSTEM.


- Remove the seat lower side trim.



- Disconnect the wiring harness plug.



- Remove bolt (x1) that secures the airbag module to the seat.



Installation

- Place the airbag to the seat. Torque bolt to **10 Nm**.
- Connect the wiring harness plug.
- Install the seat lower trim panel.
- Connect the vehicle battery with the ignition in the 'Off' position.

Deployable Rollbars

⚠ WARNING ⚠


DO NOT PLACE ANY OBJECTS ON THE TOP OF THE DEPLOYABLE ROLLBAR COVERS BEHIND THE REAR SEAT BACKS.

⚠ WARNING ⚠

DO NOT ALLOW ANY PERSON TO SIT ON THE DEPLOYABLE ROLLBAR COVERS AT ANY TIME.

⚠ WARNING ⚠


IF THE ROOF IS NOT STOWED AND THE DEPLOYABLE ROLLBARS DEPLOY THEY WILL BREAK THROUGH THE REAR GLASS.



Specifications

Torque Figures

Description	Nm	lb. / ft.
Deployable Rollbar Unit	20-30	15-22.5
Deployable Rollbar Sensor Unit	TBA	



Maintenance

Rollbar Unit

Remove

1. Disconnect the vehicle battery at the negative terminal and ensure the ignition key is removed.

⚠ WARNING ⚠

ALLOW A TWO MINUTE POWER DOWN PERIOD BEFORE PROCEEDING. THIS WILL ENSURE THAT THERE IS NO POWER TO THE DEPLOYABLE ROLLBAR SYSTEM.

⚠ WARNING ⚠


DO NOT LEAN OVER THE ROLLBARS. IF THE ROLLBARS DEPLOY WHILE SOMEONE IS LEANING OVER THEM, THEY WILL CAUSE SEVERE INJURY.

2. Remove the rear seat bases and backs (Refer to 'Rear Seats', page 1-10-3).
3. Remove the rollbar trim cover.
4. **LH Rollbar unit only.**
Remove the rear centre console (Refer to 'Rear Trim', page 1-5-5).


To gain access to the LH ROPS unit wiring harness plug.


5. Disconnect the wiring harness plug.
6. Remove the rear closing panel.

7. Drill out the pop rivets (x2) that secure the seat back bracket to the ROPS unit.



8. Remove bolts (x2 on each) that secure the seat back bracket.






9. Remove bolts x6 that secure the deployable rollbar unit. Withdraw the ROPS unit.


Install



1. Install the deployable rollbar unit. Torque bolts (x6) to **20-30 Nm**.
2. Pop rivet (x2) the seat back bracket to the ROPS unit.





3. Install the bolts (x2) that secure the seat back bracket.



4. Install the rear closing panel.

The two center screws are installed when the 3rd center console trim panel is installed.



5. Connect the wiring harness plug.
6. **LH Rollbar Unit Only.**
Install the rear centre console (Refer to 'Rear Trim', page 1-5-5).
7. Install the rear seat bases and backs (Refer to 'Rear Seats', page 1-10-3).



Rollbar Sensor

Remove

1. Disconnect the vehicle battery at the negative terminal and ensure the ignition key is removed.

⚠ **WARNING** ⚠
ALLOW A TWO MINUTE POWER DOWN PERIOD BEFORE PROCEEDING. THIS WILL ENSURE THAT THERE IS NO POWER TO THE DEPLOYABLE ROLLBAR SYSTEM.

2. Remove the boot trim to gain access to the rollbar sensor unit.
3. Remove the bolts (x4) that secure the rollbar sensor and bracket assembly.
4. Withdraw the rollbar sensor and bracket assembly to access the wiring harness plug. Disconnect the wiring harness plug.
5. Remove the rollbar sensor unit from its bracket (screws x3).

Install

⚠ **WARNING** ⚠
DO NOT CONNECT THE VEHICLE BATTERY UNTILL THE ROLLBAR SENSOR IS FULLY INSTALLED.

⚠ **WARNING** ⚠
ALLOW A TWO MINUTE POWER DOWN PERIOD BEFORE PROCEEDING. THIS WILL ENSURE THAT THERE IS NO POWER TO THE DEPLOYABLE ROLLBAR SYSTEM.

1. Install the deployable rollbar sensor unit to it's bracket. Torque bolts (x3) to **TBA Nm**.
2. Connect the wiring harness plug.
3. Install the bolts (x4) that secure the rollbar sensor and bracket assembly. Torque to **TBA Nm**.
4. Install the boot trim.
5. Connect the vehicle battery at the negative terminal.

Frame and Mounting (02.00)

Contents

Subframes (02.01)	2-1-2
Specifications	1-2
Maintenance	1-2
Front Subframe	1-2
<i>Removal</i>	1-2
<i>Installation</i>	1-3
Rear Subframe	1-4
<i>Removal</i>	1-4
<i>Installation</i>	1-8

Frame and Mounting (02.00)

Subframes (02.01)

Specifications

Torque Figures

Description	Nm.	lb. / ft.
Subframe to Front Structure	105-125	77.5-92.5
Subframe to Body	105-125	77.5-92.5
Engine Mounts	47	35
Steering Rack	115	85
Torque tube (rear)	43-57	32-42.5
Drive Plate (auto only)	60-85	45-63
Spring and Damper top mounting (rear)	85	63
Rear subframe to Body	175	129.5
Rear subframe reinforcement plates	62	46

Maintenance

Front Subframe

Repair Operation Time (ROT)

Item	Code
Front Subframe	02.01.AB

Removal

1. Disconnect the vehicle battery.
2. Support the engine from above (Refer to '303-1080 (Engine Support Adaptor)', page 20-1-6).



If using a two post vehicle lift, remove the screws that secure the rear section of the road wheel arch liner. Hold back the rear section of the road wheel arch liner to allow the foot of the vehicle lift to be positioned correctly. (Refer to 'Jacking Points', page I-I-IX)

3. Raise the vehicle and make safe.
4. Remove the front road wheels and road wheel arch liners.
5. Remove the undertray.


Lower the undertray to reveal the air intake for the alternator. Release the jubilee clip and part flex pipe from the undertray. Remove the front undertray.

6. Disconnect the lower suspension arms (Refer to 'Front Suspension (04.01)', page 4-1-1).

Disconnect the anti-roll bar from the lower arms. Leave the anti-roll bar attached to the subframe.




7. Remove bolts (x2) that secure the engine mounts to the subframe.





8. Remove bolts (x3) that secure the steering rack to the subframe.

Cable-tie the steering rack in position.




9. Support the subframe.
10. Ensure that the relation of the subframe to the front structure and the vehicle body is marked (scribed), for accurate installation.


- Remove bolts (x12) that secure the subframe to the body and the front structure.
Withdraw the subframe.



- Torque the bolts that secure the subframe to the body to **105-125 Nm**.



- Torque the bolts that secure the subframe to the front structure to **105-125 Nm**.




Installation

- Raise the subframe to the front structure. Install the subframe mounting bolts (x12).


Ensure that the subframe to the front structure and the vehicle body alignment marks are lined up.

Tighten the bolts in three stages:


- 'Nip-up' the bolts that secure the subframe to the front structure.



- Install the engine mount nuts (x2). Torque nuts to **47 Nm**.



3. Install the steering rack bolts (x3). Torque bolts to **115 Nm**.
Release the 'Ty-wraps' on the steering rack.



4. Install the lower suspension arms (Refer to 'Front Suspension (04.01)', page 4-1-1).

The bolts that secure the lower suspension arm must be torqued only when the vehicle is at normal ride height (Refer to 'Road Wheel Alignment (04.00)', page 4-0-2).

5. Remove the engine support service tool.
6. Install the undertray.
7. Install the road wheel arch liners and road wheels. (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
8. Connect the vehicle battery.
9. Check / Adjust the camber, Toe and Castor settings (Refer to 'Road Wheel Alignment (04.00)', page 4-0-2).

Rear Subframe

Repair Operation Time (ROT)	
Item	Code
Rear Subframe	02.01.CA

Removal

1. Disconnect the vehicle battery.

⚠ WARNING ⚠

IF RASING VEHICLE ON A 'TWO POST' RAMP (VEHICLE SUPPORTED BY UNDERBODY), ENSURE THAT THE REAR END OF THE VEHICLE IS SECURELY STRAPPED TO THE RAMP. FAILURE TO STRAP THE REAR OF VEHICLE DOWN MAY LEAD TO THE VEHICLE FALLING OFF THE RAMP.

Caution

If using a two post vehicle lift, remove the screws that secure the rear section of the road wheel arch liner. Hold back the rear section of the road wheel arch liner to allow the foot of the vehicle lift to be positioned correctly (Refer to 'Jacking Points', page I-I-IX).

2. Raise the vehicle and make safe.
3. Remove the rear road wheels and road wheel arch liners.

The fuel filler drain off pipe is attached to the arch liner. Ensure that the fuel filler drain off pipe does not disconnect from it's stub pipe.


4. Remove the following:

- Front and rear undertrays

Lower the undertray to reveal the air intake for the alternator. Release the spring clip and part the flex pipe from the undertray.


- Shear plate

5. Remove the intermediate exhaust pipe and the rear LH and RH exhaust pipes (Refer to 'Pipes and Supports (09.03)', page 9-3-1).




6. Remove the silencer assembly.
7. **Automatic Gearbox Only.**
Remove the gearbox coolant pipes.
 - 7.1 Remove the coolant thermostat from it's mounting bracket.
 - 7.2 Disconnect the coolant pipes from the gearbox.
 - 7.3 Cap the pipes open ends.


Gearbox ends are self sealing.




8. **Automatic Transaxle Only.**
Disconnect the following from the transaxle:
 - Wiring harness plugs





- Manual override cable



9. **Manual Transaxle Only.**
Disconnect the wiring harness plug.




10. Remove accessible bolts from around the torque tube.
Do not remove the lower bolts (x2) facing towards the gearbox.




11. Automatic Transaxle Only.


Remove the bolts (x3) that secure the torque tube drive plate to the torque converter.




14. Disconnect the brake pipes.



12. Disconnect the subframe wiring harness.



13. Disconnect the handbrake cable from the calipers and subframe (Refer to '206-103 (Handbrake Cable Removal)', page 20-1-4).



Caution
Brake fluid must not be allowed to contact vehicle paint work. Remove spilt brake fluid from paint work by rinsing away with running water.


15. Position the subframe trolley (Refer to '303-F715 (Multi-purpose Trolley) x2', page 20-1-5) under the subframe. Lower the vehicle until the subframe rests on the subframe support.



16. Remove bolts (x4) that secure the spring and damper units.

Ensure the spring and damper assemblies are fully extended to release spring tension. A small amount of tension will remain.

Lever spring and damper mounting turret against spring tension to allow removal of bolts.





17. Remove the subframe securing bolts.

The anti-roll bar must be removed before the two rear bolts can be completely removed.

Remove Bolts M10 x6

Remove Bolts M14 x4



18. **Manual Transaxle only.**

Raise the vehicle to allow access to disconnect the gear selector cables.


Use the service tool (Refer to '501-F116 (IP Removal)', page 20-1-8) to remove the horseshoe clips (x2) and lever the cables from the ball joints.

Caution

There is a risk of bending the end of the cable. Lever cable from ball joint at a point closest to the ball joint.


Ensure the vehicle raises without catching pipes, cables, etc.

Disconnect Gear Lever Linkage



19. Raise the vehicle for access and remove the bolts that secure the torque tube to the gearbox.

Ensure the vehicle raises without catching pipes, cables, etc.



20. Move the subframe rearwards on its support to give a clearance between the torque tube and the gearbox. Slowly raise the vehicle from the subframe.

Ensure the vehicle raises without catching pipes, cables, etc.

21. Automatic Gearbox Only.

Install a torque converter transit bracket.

22. Retain the spacers from each rear subframe mounting pad. These should be installed in the same positions when the subframe is installed.
23. If required, remove the transaxle from the subframe (Refer to 'Transmission (07.00)', page 7-1-1)

Installation

1. If removed, install the transaxle.
 - Automatic (Refer to 'Automatic Transaxle (07.01)', page 7-1-2)
 - Manual (Refer to 'Manual Transmission (07.03)', page 7-3-1).
2. Ensure the spacers from each rear subframe mounting pad are located correctly.
3. Lower the vehicle to the subframe.


Ensure the vehicle lowers without catching pipes, cables, etc.

Ensure the suspension assembly is placed slightly to the rear of the final position. This will enable installation to the torque tube.

4. Manual Gearbox Only.

Install the gearbox to the torque tube.

- 4.1 Lower the vehicle to enable the gearbox to line up with the propshaft splines.
- 4.2 Move the subframe forward. Engage the gearbox to the propshaft splines.
- 4.3 Install the bolts around the torque tube. Torque to **43-57 Nm**.




5. Manual Gearbox Only.

Install the gear selector cables.

6. Automatic Gearbox Only.

Install the gearbox to the torque tube.


- 6.1 Remove the torque converter transit bracket.
- 6.2 Move the subframe forward. Place the torque converter to the torque tube drive plate.
- 6.3 Install the bolts around the torque tube. Torque to **43-57 Nm**.




7. Automatic Gearbox Only.

Connect the drive plate.


- 7.1 Install bolts (x3). Torque bolts to **60-85 Nm**.



8. Install the handbrake cable to the subframe and the calipers.



9. Install the spring and damper units.
 - 9.1 Lower the vehicle to line up the spring and damper mounts to the body.
 - 9.2 Install bolts (x4) to each mount. Torque to **85 Nm**.




10. Lower the vehicle to meet the subframe mounts. Install bolts (x4) that secure the subframe to the body. Torque bolts to **175 Nm**.

If the anti-roll bar was removed ensure the two rear bolts are installed.

Torque 62 Nm x6

Torque 175 Nm x4



11. Install the subframe reinforcement plates. Torque bolts to **62 Nm**.
12. Connect the subframe wiring harness plugs.

13. Automatic Gearbox Only.

Install to the gearbox:

- Manual override cable
- Coolant pipes
- Wiring harness plugs
- Breather pipe

14. Manual Gearbox Only.

Install the wiring harness plugs.

Caution

Brake fluid must not be allowed to contact vehicle paint work. Remove spilt brake fluid from paint work by rinsing away with running water.

15. Connect the brakes pipes.
16. Install the exhaust system.
17. Install the front and rear undertrays and the shear plate.
18. Bleed the brakes. (Refer to 'Brake Bleeding - AMDS', page 6-6-4).
19. Install the road wheel arch liners.

The fuel filler drain off pipe is attaches to the arch liner.
20. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
21. Remove the vehicle securing strap, if installed.
22. Connect vehicle battery.



ASTON MARTIN

Engine System (03.00)

Contents


Engine Assembly (03.00)	3-1-3	Maintenance	4-3
Description	1-3	Coolant Drain / Fill	4-3
Maintenance	1-4	Pressure Tests	4-3
Engine	1-4	Cooling System	4-3
Removal	1-4	Pressure Cap	4-3
Installation	1-11	Radiator	4-4
Engine Removal from the Frame	1-13	Removal	4-4
Removal	1-13	Installation	4-5
Installation	1-14	Thermostat	4-5
Engine Structure (03.01)	3-2-1	Removal	4-5
Description	2-1	Installation	4-6
Engine Block	2-1	Water Pump	4-6
Cylinder Heads	2-2	Removal	4-6
Inlet / Exhaust Manifolds	2-2	Installation	4-6
Specifications	2-2	Fuel Charging System (03.04)	3-5-1
Maintenance	2-3	Description	5-1
Cylinder Head	2-3	Safety Precautions	5-1
Removal	2-3	Maintenance	5-2
Installation	2-4	Depressurising	5-2
Inlet Manifold	2-7	Fuel Rails	5-2
Removal	2-7	Removal	5-2
Installation	2-9	Installation	5-2
Exhaust Manifold	2-10	Injectors	5-3
Removal	2-10	Removal	5-3
RH manifold	2-10	Installation	5-3
LH Manifold	2-11	Accessory Drive System (03.05)	3-6-1
Installation	2-13	Description	6-1
Lubrication System (03.02)	3-3-1	Auxiliary Drives	6-1
Description	3-1	Automatic Belt Tensioner	6-1
Oil flow	3-1	Maintenance	6-1
Specifications	3-2	Drive Belt	6-1
Engine Oil Specification	3-2	Removal	6-1
Maintenance	3-2	Installation	6-1
Oil Drain	3-2	Engine Cranking System (03.06)	3-7-1
Oil Filter	3-2	Starting System	7-1
Removal	3-2	Specifications	7-1
Installation	3-3	Maintenance	7-1
Sump	3-3	Starter Motor	7-1
Removal	3-3	Removal	7-1
Installation	3-4	Installation	7-2
Oil Pump	3-6	Ignition System (03.07)	3-8-1
Removal	3-6	Description	8-1
Installation	3-6	Specifications	8-1
Cooling System (03.03)	3-4-1	Maintenance	8-2
Description	4-1	Spark Plugs	8-2
Coolant Circuit	4-1	Removal	8-2
Water Pump	4-2	Installation	8-2
Thermostat	4-2	Emission Control (03.08)	3-9-1
Radiator	4-2	System Description	9-1
Cooling Fans	4-2		
Coolant Reservoir	4-2		
Engine Oil Cooler	4-2		
In-Vehicle Heating	4-2		
Specifications	4-2		

Valve Train (03.09).....	3-10-1	Air Charging (03.12)	3-13-1
Description	10-1	Description	13-1
Camshafts	10-1	Air Induction System	13-1
Specifications	10-1	Specifications	13-1
Maintenance	10-1	Maintenance	13-2
Valve Timing Chains.....	10-1	Air Filter.....	13-2
Removal	10-1	Removal.....	13-2
Installation	10-2	Installation	13-2
LH Cylinder Head (Cylinders 7-12).....	10-2	Air Filter Box	13-3
RH Cylinder Head (Cylinders 1-6)	10-3	Removal.....	13-3
Valve Timing Check	10-4	Installation	13-3
Camshafts / Camshaft Followers / Lash Adjusters... 10-4		Engine Management System (03.14)	3-14-1
Removal	10-4	Schematic Diagram.....	14-1
Installation	10-5	Specifications	14-2
Engine Sealing (03.10)	3-11-1	Powertrain Control Modules (PCMs).....	14-2
Specifications	11-1	PCM A	14-2
Maintenance	11-1	PCM B	14-3
Camshaft Cover.....	11-1	Maintenance	14-4
Removal	11-1	WDS Connection	14-4
Installation	11-2	PCM	14-5
Timing Cover	11-3	Removal.....	14-5
Removal	11-3	Installation	14-5
Installation	11-4	Evaporative Emissions (03.13)	3-15-1
Crankshaft Rear Oil Seal.....	11-6	Description	15-1
Removal	11-6	System Operation	15-1
Installation	11-6	Throttle Control (03.16).....	3-16-1
Crankshaft Front Oil Seal.....	11-7	Description	16-1
Removal	11-7	Motorised Throttles	16-1
Installation	11-7	Specifications	16-1
Power Conversion (03.11)	3-12-1	Maintenance	16-1
Description	12-1	Throttle Body.....	16-1
Crankshaft.....	12-1	Removal.....	16-1
Pistons and Connecting Rods.....	12-1	Installation	16-2
Specifications	12-1		
Piston Skirt Grading Chart	12-2		
Main Bearing Grade Chart.....	12-2		
Maintenance	12-3		
Crankshaft.....	12-3		
Removal	12-3		
Component Checks	12-5		
Installation	12-5		
Pistons and Connecting Rods.....	12-8		
Overhaul.....	12-8		
Reassembly.....	12-8		
Flywheel	12-9		
Removal	12-9		
Installation	12-10		

Engine (03.00)

Engine Assembly (03.00)

Description



001-3-001

The engine is an all aluminium 6.0 litre 60° V12 configuration. The cylinder heads have dual overhead camshafts and four valves per cylinder. An electronic engine management system controls the sequential multi-port fuel injection and distributor-less ignition systems.

The engine uses the latest 'fast-burn' combustion technology. Heated oxygen sensors monitor the oxygen content of exhaust gasses. The engine management system uses the oxygen sensor signals together with other engine information to 'fine tune' fuelling levels and ignition timing. This helps to achieve the best possible fuel burn with minimum exhaust emissions. The exhaust system incorporates six catalytic converters to minimise the levels of harmful gasses passing into the atmosphere. Additional oxygen sensors are placed after the catalysts so that long term catalyst efficiency can be monitored.

The engine runs on unleaded fuel only.


Maintenance Engine

Repair Operation Time (ROT)	
Item	Code
Engine Remove and Install	03.00.AA
Including engine Remove from the frame	

Remove

To remove the engine from the vehicle, the complete power train will be removed.


1. Disconnect the earth ('- ve) terminal from the vehicle battery.
2. Evacuate the A/C unit (Refer to 'Air Conditioning (A/C) System (12.03)', page 12-3-1).
3. Disconnect the A/C pipes.



6. Remove the washer bottle neck bracket.
7. Remove the 'slam' panel.
8. Withdraw the plastic cover and disconnect the forward wiring harness plugs.



Side Marker Light (FED Only)





4. Drain the coolant (Refer to 'Coolant Drain / Fill', page 3- 9. 3-3).

Remove the bonnet release cable.

Caution

Before removing the engine bay corner cross-braces ensure that the at the vehicle is resting on it's roadwheels.

5. Remove the engine bay **corner** cross-braces. Do not remove the engine bay cross brace.



10. Disconnect the following from the forward cross member.

- The reinforcement struts



- The 'Jump start' plug



- The power steering reservoir



11. Manual Gearbox Only.

Disconnect the clutch pipe.

12. Remove the bolts and the reinforcement brackets from the inner wing.

Remove the header tank to gain access. There is a wiring harness plug connected to the header tank on the under side.




13. Centre the steering wheel. Remove the ignition key and engage the steering lock with the wheel as accurately centred as possible.

If you do not centre the steering wheel, the restraint bag clock-spring can be damaged and it can be difficult to align the steering wheel in the straight-ahead position.

14. From inside the cabin, pull back the steering column bulkhead seal. Remove the pinch bolt that attaches the upper column to the intermediate shaft.

15. Disconnect the engine harness from inside the vehicle cabin.




16. Lift the vehicle and make it safe.

Remove the screws that attach the rear section of the road wheel arch liner. Hold back the rear section of the road wheel arch liner to allow the foot of the vehicle lift to be positioned correctly.
 (Refer to 'Jacking Points', page I-I-IX).

Caution

MAke sure that the vehicle is 'strapped' to the lift.



17. Remove the undertrays and the shear plates.

Record the positions of the (x4) spacers when removing the front shear plate.

18. Remove all of the road wheels and the arches.


19. Remove the air filter boxes.

20. Remove the front bumper.



21. Disconnect the lower mount for the headlight units.

22. Disconnect the forward wiring harness plugs that follow:

- Fan pack
- Headlight levelling sensor
- MAF sensor
- ABS speed sensor
- Header tank level sensor



24. Remove the engine bay fusebox and bracket.



Remove harness plugs.

Remove Power cable.


25. Disconnect the earth points from the bulkhead. Make a mark on the leads at the clean earth studs.

These are 'Clean Earths' labelled 'Bank A' and 'Bank B'.
 Reconnect to the correct stud.

- Right Hand side



- Left Hand Side




- 26. Remove the PCMs. Disconnect the engine wiring harness plugs and remove the three screws that secure the PCM (each side).
- 27. Move the removed engine wiring harness plugs into the engine bay and attach them to the engine cross brace.



- 28. Remove the brake booster vacuum pipe
- 29. Disconnect the heater coolant pipes.


On LH drive vehicles, the heater coolant pipes go into the bulkhead on the right side.



- 30. Disconnect the front brake pipes:

Caution
Do not let brake fluid touch the vehicle paint work.
Flush all spilled brake fluid from paint work with water.

- 30.1 Disconnect the brake pipe from the brake modulator to the left front brake caliper.




- 30.2 Disconnect the brake pipe in the right wing.




- 31. Remove the intermediate steering shaft.
 - 31.1 Remove the lower pinch bolt. Open the lower mount.
 - 31.2 Pull the intermediate steering shaft downwards and remove.



32. Disconnect the fuel lines.



33. Remove the VMV to the inlet manifold pipe from the VMV.



34. Disconnect the torque tube to the body (engine) earth lead.

35. Disconnect the Starter/Alternator/Jump terminal cable from the chassis.



36. Disconnect the silencer from the two rear exhaust pipes.




37. Disconnect the handbrake cable from the rear subframe (Refer to 'Hand Brake (06.05)', page 6-5-1).


Use the brake cable release tool (Refer to '206-103 (Handbrake Cable Removal)', page 20-1-4).



38. Disconnect the subframe wiring harness.



39. Disconnect the rear brake pipes.



Caution
Do not let brake fluid touch the vehicle paint work.
Flush all spilled brake fluid from paint work with water.

40. Remove the rear brake pipe brackets.




41. Automatic Gearbox Only.

Disconnect the manual override cable.



42. Put the front and rear subframe trolleys (Refer to '303-F715 (Multi-purpose Trolley) x2', page 20-1-5) in position under the subframes. Lower the vehicle until the front and rear subframes are on the subframe trolleys.

Connect the two trolleys together (Refer to '303-F715-06 (Trolley Brace Bars)', page 20-1-5).




Rear Pin Image to Follow

- 43. Put scribe marks to show the relation of the front subframe and front structure to the vehicle body for accurate Install.
- 44. Remove the bolts (x12) that attach the front subframe and front structure to the body.

Image to Follow


45. Remove the bolts (x3) that attach the emmissions filter unit. This will give access to the top mount of the spring and damper unit.



46. Remove the bolts (x4) that attach the rear spring and damper units.

Make sure that the rear spring and damper assemblies are fully extended to release spring tension. A small amount of tension will remain.

Lever the mounting turret of the rear spring and damper against the spring tension to let you remove the bolts.





47. Remove the bolts that attach the rear subframe.

You must remove the anti-roll bar before the two rear bolts can be fully removed.

Remove Bolts M10 x6

Remove Bolts M14 x4



48. **Manual Transaxle only.**

Lift the vehicle to get access to disconnect the gear selector cables.


Use the service tool (Refer to '501-F116 (IP Removal)', page 20-1-8) to remove the horseshoe clips (x2) and then prise the cables from the ball joints.

Caution

Prise the cable from the ball joint close the ball joint. If you do not do this, you can bend the end of the cable.

When you raise the vehicle, make sure that all cables and pipes do not catch.

Disconnect Gear Lever Linkage



01-02-028

49. Slowly lift the vehicle.

When the vehicle lifts, disconnect the wings from the front grill.




When you raise the vehicle, make sure that all cables and pipes do not catch.

On LH drive vehicles - make sure that the coolant pipe is in front of the brake booster.

50. Keep the spacers from each rear subframe mounting pad. You must install them in the same positions when you install the subframe.

Install


1. Lower the vehicle on to the powertrain assembly. Make sure that all pipes and cables are not caught as you lower the vehicle. While the vehicle lowers, pull the wings from the front grill.




2. Install the rear spring and damper assemblies. Do not tighten the bolts.
3. Install the front subframe and front structure mounting bolts (x12). Do not tighten.
4. Install the rear subframe mounting bolts (x4). Do not tighten.

Install the spacers from rear subframe mounting pads in the same positions that you removed them.

5. Install the reinforcement plates for the rear subframe.
6. Torque-tighten the rear spring and damper assemblies to **85.5 Nm**.




7. Install the emissions filter unit.



8. Torque-tighten the front subframe and front structure bolts:

Align the marks on the front subframe and front structure to the body.



Torque-tighten the bolts (x12) to **105-125 Nm**.



9. Torque-tighten the rear subframe mounting bolts:
 - 1 Torque-tighten the bolts that attach the subframe to the body to **175 Nm**.
 - 2 Torque-tighten the bolts that attach the subframe reinforcement plates to **62 Nm**.

Torque 62 Nm x6

Torque 175 Nm x4



10. Connect the rear subframe wiring harness.

11. Automatic Gearbox Only.

Install the manual override cable.

12. Manual Gearbox Only.

- Install the gear change linkage
- Install the wiring harness plugs

13. Manual Gearbox Only.

Caution

**Do not let clutch fluid touch the vehicle paint work.
Flush all spilled clutch fluid from paint work with water.**

Install the clutch pipe.

14. Install the brake pipes:

Caution

**Do not let brake fluid touch the vehicle paint work.
Flush all spilled brake fluid from paint work with water.**

- Install the LH front brake caliper pipe to the modulator
- Install the rear brake pipe brackets.
- Install the brake pipes to all remaining brake calipers.

15. Install the handbrake cable to the handbrake lever

16. Connect the earth lead from the torque tube to the body.

17. Connect the Starter/ Alternator/ Jump terminal cable to the body.



18. Install the heater coolant pipes.

19. Connect the VMV.

20. Connect the fuel lines.

21. Install the headlight units (Left and Right).

22. Install the two air filter boxes.

23. Install the PCMs. Connect the engine wiring harness plugs.

24. Connect the forward wiring harness plugs that follow.

- Fan pack
- Headlight levelling sensor
- MAF sensor
- ABS speed sensor
- Header tank level sensor

25. Connect the earth points to the bulkhead.

- Right side



- Left Side



26. Install the steering intermediate shaft.

27. Install the fusebox.

27.1 Connect the wiring harness plugs.

27.2 Connect the main power feed.

27.3 Install the fusebox bracket and the fusebox.

28. Install the power steering reservoir.

29. Install the jump-start cable.

30. Install the A/C pipes.

31. Install the bolts and the reinforcement struts along the inner wings.

32. Install the header tank.

Caution

Before you install the engine bay cross-braces, the vehicle must be on it's roadwheels.

33. Install the engine bay corner cross braces. Do not tighten at this step.

34. Install the front bumper.

35. Install the arch liners for the road wheels.

36. Install the items that follow:

- The front and rear undertrays
- The shear plates

Install the spacers (x4) on the front shear plates in the positions recorded during Remove.

37. Bleed the brakes (Refer to 'Brake Bleeding - AMDS', page 6-6-4).

38. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).

39. Torque-tighten the engine bay cross-braces to 49 Nm.

40. Fill the coolant (Refer to 'Coolant Drain / Fill', page 3-3-3)


41. Charge the A/C unit (Refer to 'Air Conditioning (A/C) System (12.03)', page 12-3-1).
42. Check the road wheel alignment (Refer to 'Road Wheel Alignment (04.00)', page 4-0-2).

Always use WDS to check the steering angle sensor after you do work on the steering or the suspension systems or the yaw rate sensor.


43. Connect the vehicle battery.

Engine Remove from the Frame Remove


1. Release the exhaust manifolds from the catalysis.
2. Remove the hoses that follow:




3. Disconnect the A/C pipe from the condenser.
4. Remove the hose from the header tank.




5. Disconnect the cables from the starter motor and the alternator.
6. Remove the power steering pump hoses.



7. Attach the lifting eyes (x4) to the cylinder heads.
8. Attach the engine lifting gear to an applicable hoist.
9. Lift the hoist to tension the lifting gear.
10. Remove the torque tube.
 - 10.1 Make sure that the torque tube is supported.
 - 10.2 Remove the bolts that attach the torque tube to the engine block.
 - 10.3 Make sure that the torque tube and the engine are correctly supported. Move the engine frame and the hoist forward until there is room to move the torque tube away from the engine block and the exhaust manifolds.




11. Remove the engine mount nuts (x2).



12. Lift the engine until it is away from the frame assembly. Attach the engine to an applicable stand. Remove the lifting gear.

Install

1. Install the engine lifting gear to an applicable hoist.
2. Raise and move the engine to the frame.
3. Make sure that the torque tube is adequately supported and move the engine to the torque tube.
4. Engage the propshaft splines and align the engine block to the torque tube.
5. Install the bolts that attach the torque tube to the engine block. Torque-tighten the bolts to:
 - M8 - **25 Nm**.
 - M10 - **50 Nm**.
6. Install the engine mounts. Torque-tighten the nuts (x2) to **47 Nm**.
7. Remove the lifting equipment and lifting eyes.
8. Install the hose to the header tank.
9. Connect the A/C pipe to the condenser.
10. Install the hoses that follow:




11. Install the hoses for the power steering pump.
12. Install the cables to the starter motor and the alternator.
13. Install the exhaust manifolds to the catalyts. Torque-tighten the nuts and bolts to **25.5 Nm**.

Engine (03.00)

Engine Structure (03.01)

Description

Engine Block



Dowels are installed to the principal mating faces of the block to ensure accurate alignment of cylinder heads, front timing cover, auxiliaries, etc.


The 60° V12 aluminium engine block incorporates paths for water cooling, oil distribution and positive crankcase ventilation. The seven main bearing caps supporting the crankshaft are bolted laterally as well as vertically to provide additional crankcase stiffening whilst keeping engine weight to a minimum. Each bearing cap is numbered to identify its position in the engine block. The 12 cast iron cylinder liners are inserted and machined during block production and require specialist equipment for replacement.

The crankshaft is mounted in 7 main bearings with end loads absorbed by thrust washers at number 4 main bearing. Main bearing bolts are of the 'torque to yield' type and must be renewed if removed.

A twin sprocket installed to the front end of the crankshaft drives the camshaft chains. A damper pulley installed on the crankshaft nose drives the engine auxiliaries via a polyvee drive belt. Also at the front of the engine a timing disc is installed together with two crankshaft sensors. The sensors provide engine position signals to the two Engine control modules.

Cylinder Heads

Each cylinder has two inlet and two exhaust valves. The valves are operated by cam followers below each camshaft. Valve clearances are kept at zero by a hydraulic tappet system (lash adjuster) that is pressurised from the main engine lubrication system.




01-03-005

Inlet / Exhaust Manifolds

Two six-branch exhaust manifolds have four primary catalytic converters and eight oxygen sensors attached.

Four engine management oxygen sensors are installed before the primary catalysis. Four oxygen sensors to monitor the catalysis are mounted after the primary catalysis.



001-3-006

Air from the intake is filtered. The air then goes through mass air-flow meters (MAF) and into the throttle bodies. It then goes into the six-branch inlet manifolds.

Specifications

Block	MM
Cylinder Bore Grade 2	89.010 - 89.020
Main Bearing Bore (without shells)	72.400 - 72.424
Cylinder Heads	MM
Head Face-Roof Button	14.75 - 15.25
Valve Seat Width - Inlet	1.10 - 1.40
Valve Seat Width - Exhaust	1.40 - 1.70
Camshaft Bore	26.987 - 27.012
Camshaft Journals	26.936 - 26.962
Head Volume	46.70 - 49.70 ml.

Camshaft End Play

0.025 - 0.165 mm (using a force of 30-50 lbs - do not exceed 50 lb. as damage may occur to the thrust washer).

Camshaft Sensors	MM
Air Gap	1 (±0.5)

Torque Figures

Description		Nm.	lb./ft.
Cylinder head	1. Bolts 1 to 14	37-43	27.5-32
	2. Bolts 15-16	15-20	11.5-15
	3. Bolts 1-14	85°-95°	
	4. Release bolts 1-14	Min. 360°	
	5. Bolts 1 to 14	37-43	27.5-32
	6. Bolts 15-16	23-27	17-20
	7. Bolts 1 to 14	85°-95°	
	8. Bolts 1 to 14	85°-95°	
Camshaft bearing caps		8-12	6-9

Maintenance Cylinder Head

Remove

1. Remove the engine from vehicle (Refer to 'Engine', page 3-0-4)
2. Remove the inlet manifold (Refer to 'Inlet Manifold', page 3-1-7).
3. Remove the exhaust manifold (Refer to 'Exhaust Manifold', page 3-1-11).
4. Drain the engine coolant (Refer to 'Coolant Drain / Fill', page 3-3-3).
5. Remove the accessory drive belt (Refer to 'Drive Belt', page 3-5-1).
6. Remove the thermostat housing (Refer to 'Thermostat - Remove and Install', page 3-3-5).
7. Remove the camshaft cover (Refer to 'Camshaft Cover', page 3-10-1).
8. Remove the timing cover (Refer to 'Timing Cover', page 3-10-3).
9. Remove the timing chains (Refer to 'Valve Timing Chains', page 3-9-1)
10. Remove both camshafts.



- 10.1 Gradually release all bolts that attach each bearing cap.

Caution

You must remove the thrust camshaft bearing cap of each camshaft (No.1 and No. 8 cap) first and install it last.



- 10.2 Remove the bearing caps. Keep them in the sequence that they are removed. Remove the camshafts.

11. Remove the camshaft followers and lash adjusters. Keep them in the sequence that they are removed.



12. Remove the two M8 bolts and the 14 M10 bolts from the cylinder head in the sequence shown in the figure below.

13. Remove the cylinder head. Discard the cylinder head gasket.
Cover the engine block to prevent contamination.



14. Remove the second cylinder head if required.

15. Overhaul the cylinder head(s) as required (Refer to 'Cylinder Head', page 3-1-3).

Install

Make sure that all mating surfaces are clean, smooth and do not have any contamination.

1. Put a new cylinder head gasket in position over the location dowels.
2. Apply a thin layer of engine oil below the heads of the 14 M10 and two M8 cylinder head bolts. **Do not lubricate the threads.**


Loosely install the bolts into the cylinder head.

Caution

Do the following "Torque - Release - Torque" sequence exactly as specified, to make sure that the cylinder head seals to the engine block correctly.

- Do the procedure that follows to torque-tighten the cylinder head bolts in steps:

Left Side Shown



3.1 Initial Torque

- Torque-tighten the M10 bolts 1-14 to **37-43 Nm**, in the sequence shown.
- Torque-tighten the M8 bolts 15-16 to **15-20 Nm**.
- Torque-tighten the M10 bolts 1-14 an angle of **85-95 degrees** more in the sequence shown.

3.2 Release

- Loosen the M10 bolts 1-14 a minimum of **one full turn** (360 degrees).

3.3 Final Torque

- Torque-tighten the M10 bolts 1-14 to **37-43 Nm**, in the sequence shown.
 - Torque-tighten the M8 bolts 15-16 to **23-27 Nm**.
 - Torque-tighten the M10 bolts 1-14 an angle of **85-95 degrees** more in the sequence shown.
 - Torque-tighten the M10 bolts 1-14 an angle of **85-95 degrees** more in the sequence shown.
- Do the procedure again for the second cylinder head.
 - Install all lash adjusters.

Soak the lash adjusters in engine oil.


Install each lash adjuster into its correct recess in the cylinder head.

- Install the camshaft followers to their correct valves.

Caution

Make sure that the dimpled end of the camshaft followers are installed to the lash adjusters.

Soak the cam followers in engine oil.



- Lubricate the camshaft journals and camshaft bearing caps with engine oil.
- Make sure that the crankshaft key is vertical.


Caution

The crankshaft key must stay in the vertical position until the camshaft chains are correctly installed and tensioned. If the crankshaft moves before the valve timing is completed, valves and pistons can be damaged.

The crankshaft key is exactly in line with No.1 crankshaft throw. With the crankshaft key vertical, No.1 piston is 30° ATDC and all of the pistons are below the engine block surface.


9. Put the camshafts in position with the timing marks in the positions shown in the figure below.

In the positions shown, the camshafts will be at their lowest in the journals.



10. In the steps that follow, do work on one cylinder head at a time.
11. Install all camshaft bearing caps except the two thrust camshaft bearing caps (No.1 and No. 8 cap) at the front of each camshaft. Loosely install each cam cap.

Bearing Caps




The bearing caps are numbered and agree with the numbers that are stamped on the cylinder head adjacent to the journal.

12. Install No.1 and No. 8 bearing caps over their thrust flanges. If the bolt holes do not correctly align, move the camshafts forward or rearward as required until the bearing caps engage correctly. Loosely install the bearing cap attachment bolts.


13. Do the steps that follow to torque-tighten the camshaft attachment bolts:-

- 13.1 Gradually tighten all of the bolts in the sequence shown. Make sure that the mating faces of the camshaft bearing caps correctly touch the cylinder head.
13.2 In the sequence shown, torque-tighten the attachment bolts for the camshaft bearing caps to 8-12 Nm.



14. Do steps 10 to 13 again for the second cylinder head.
15. Install the timing chains. Do the camshaft timing procedure (Refer to 'Valve Train (03.09)', page 3-9-1).

16. Install the timing cover (Refer to 'Timing Cover', page 3-10-3).
17. Install the accessory drive belt (Refer to 'Drive Belt', page 3-5-1)
18. Install the camshaft cover (Refer to 'Camshaft Cover', page 3-10-1).
19. Install the thermostat housing (Refer to 'Thermostat - Remove and Install', page 3-3-5).
20. Fill the engine coolant system (Refer to 'Coolant Drain / Fill', page 3-3-3).
21. Install the exhaust manifold (Refer to 'Exhaust Manifold', page 3-1-11).
22. Install the inlet manifold (Refer to 'Inlet Manifold', page 3-1-7).
23. Install the engine to the vehicle (Refer to 'Engine', page 3-0-4).




Inlet Manifold

Repair Operation Time (ROT)	
Item	Code
Inlet Manifold Renew	LH 03.01.BB
	RH 03.01.DB






Remove

1. Depressurise the fuel system (Refer to 'Fuel System - Depressurise', page 10-1-10).
2. Disconnect the vehicle battery.
3. Remove the engine bay corner braces (x2), engine bay cross brace and the manifold brace.




4. Remove the air intake pipe.


5. Remove the items that follow from the inlet manifold:-



6. Remove the thermostat housing by-pass hose. Seal the open ends.




7. Remove the connectors that follow:
 - The harness plug for the temperature sender wiring on the fuel rail
 - The harness plug for the pressure sensor wiring on the fuel rail
 - The plugs for the injector wiring harness



⚠ **Warning** ⚠

If the fuel system is pressurised, fuel will be released and can contaminate eyes and the skin.

8. Remove the fuel rails and the injectors:-
 - 8.1 Remove the bolts (x6) that attach the fuel rails.
 - 8.2 Remove the fuel rails sufficiently to remove the injectors.
 - 8.3 Remove and discard the injector O-rings.




9. Disconnect the fuel rails from the fuel supply hoses.

The hose unions on the fuel supply for the left and right fuel rails are different sizes.

- 9.1 Remove the secondary latch clip from each fuel line.
- 9.2 Install the correct size of service tool around the union.
 - (Refer to '412-038 (Quick Disconnect Tool)', page 20-1-7)
 - (Refer to '412-040 (Quick Disconnect Tool)', page 20-1-7)
- 9.3 Push back on the tool. While the tool is pushed back, remove the fuel rail.

Special Tool



Remove Secondary Latch Clips



01-03-146

Special Tool




10. Remove the inlet manifold:-
 - 10.1 Remove the bolts (x7) that attach the inlet manifold to the cylinder head.
 - 10.2 Remove the inlet manifold sufficiently to gain access to its rear and disconnect the vacuum harness.
 - 10.3 Withdraw the inlet manifold. Discard the gaskets.
11. Put a cover on the inlets to the cylinder head to prevent contamination of the cylinders.

Install

Make sure that all mating faces are clean and there is no damage or contamination.

1. Install a new inlet manifold gasket to the inlet manifold.
Engage the two 'lipped' holes in the gasket through the two corresponding bolt inserts in the inlet manifold.
2. Install the inlet manifold:-
 - 2.1 Install the vacuum harness to the rear of the inlet manifold.
 - 2.2 Put the inlet manifold in position on the cylinder head. Make sure that the gasket stays in position.
 - 2.3 Install the bolts that attach the inlet manifold to the cylinder head.
 - 2.4 Torque-tighten the bolts (x7), in the order shown in the figure below, to **8 - 12 Nm**.



3. Install new O-rings on the injectors.

Note position of O-rings

- Blue (top)
- Green (bottom)

4. Install the injectors to the inlet manifold.
5. Install the fuel rails:-
 - 5.1 Install the fuel rails over the injectors.
 - 5.2 Install the bolts (x3) that attach the fuel rail to the injectors.
 - 5.3 Torque-tighten the bolts to **8-12 Nm**.
6. Connect the fuel rails to fuel supply lines.

Ensure each fuel rail and fuel supply line are 'in-line' before connection.

7. Install the secondary latch clips to the fuel lines.
8. Connect the wiring harness plugs that follow:-
 - The temperature sender to the fuel rail
 - The pressure sensor to the fuel rail
 - To the injectors
9. Connect the thermostat housing by-pass pipe.
10. Install the air intake hose.
11. Install the engine bay corner braces (x2), the engine bay cross brace and the manifold brace.
12. Tighten the bolts to these torques:-
 - Engine cross brace - **49 Nm**.
 - Manifold brace - **8-12 Nm**.
 - Corner braces - **49 Nm**.




Exhaust Manifold

Repair Operation Time (ROT)	
Item	Code
Exhaust Manifold Renew	LH 09.03.DB
	RH 09.03.EB

Remove


1. Disconnect the vehicle battery.
2. Raise the vehicle and make safe.
3. Remove the front roadwheels and the wheel arch liners.
4. Remove the undertray.
5. Remove the lower suspension arms.




6. Disconnect the anti-roll bar links.
7. Remove the front subframe (Refer to 'Front Subframe', page 2-1-2).

Right manifold


1. On RH drive vehicles, remove the steering column.




2. Remove the starter motor.



3. Disconnect the heated oxygen sensors (x2) and the Catalyst Monitor sensors (x2).
4. Remove the exhaust heat shields.




5. Disconnect the heated oxygen sensors (x2) and the Catalyst Monitor sensors (x2).




6. Remove the exhaust manifold:-


6.1 Remove the manifold nuts (x12).




2. Remove the exhaust heat shields.



6.2 Remove the nuts and bolts (x3) (refer to the figure below).



3. Remove the dip stick.





6.3 Remove the manifold.

6.4 Discard the manifold gasket.

4. Disconnect the heated oxygen sensors (x2) and the catalyst monitor sensors (x2).


Left Manifold

1. Remove the lower steering column (LH drive only).




5. Remove the exhaust manifold:-

- 5.1 Remove the manifold nuts (x12).



- 5.2 Remove the nuts and bolts (x3) (refer to the figure below).




- 5.3 Remove the manifold.
5.4 Discard the manifold gasket.

Install

Use new gaskets.

1. Put a new gasket and the exhaust manifold in position on the cylinder head.
2. Install the nuts (x12) that attach the exhaust manifold.
3. Torque-tighten the nuts, in sequence shown, to **18-22 Nm** (refer to the figure below).



4. Install the Heated Oxygen sensors (x2) and the Catalyst Monitor sensors (x2).
5. Install the exhaust heat shields.
6. Install the parts that follow:-
 - 6.1 **Left Manifold.**
 - The dip-stick
 - The lower steering column (LH drive only)
 - 6.2 **Right Manifold.**
 - The Alternator
 - The Starter motor
 - The Lower steering column (RH drive only)
7. Install the front subframe (Refer to 'Front Subframe', page 2-1-2).
8. Install the lower suspension arms and the anti-roll bar links (Refer to 'Front Suspension (04.01)', page 4-1-1).
9. Install the undertray.
10. Install the road wheels. (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).




ASTON MARTIN

Engine (03.00)

Lubrication System (03.02)

Description




The engine has a wet-sump lubrication system.

The oil pump is driven by the crankshaft. The oil pump gets oil from the sump and pumps it through a pick-up tube to an oil strainer. Pressure from the oil pump is controlled by a built in oil-pressure relief valve. Pressurised oil then flows from the left side of the engine through a filter and a cooler and then back into the engine main oil gallery.

Oil pressure at the entrance point is approximately 60 psi with the engine hot and should reach at least 100 psi when cold.

Oil flow



Specifications

Engine oil	Mobil 1
Europe / Aus	0W-40
USA	0W-30 or 0W-40

To achieve the required high performance of synthetic lubricants, do not mix with mineral oils.

Capacity	Europe (Litres)	UK (Pints)	USA (Qts.)
Engine sump (incl. filter)	10.40	18.3	11
Engine sump (excl. filter)	9.46	16.6	10

Torque Figures

Description		Nm.	lb. / ft.
Sump plug		23-27	17-20
Sump bolts (two stage)	1.	15	11.5
	2.	A further 90° (same sequence)	
Oil pump bolts	M8	23-27	17-20
	M6	8-12	6-9

Engine Oil Specification

An oil of 0W-30 viscosity that is equal to Aston Martin specification WSS M2C913-A/B or 0W-40 viscosity that is equal to Aston Martin specification WSS-M2C937-A is recommended. Where this is not possible, oil that is equal to the following standards can be used.

0W-30

Authority	Standard
API	SL / SJ / EC / CF
ACEA	A1 / A5 / B1 / B5
ILSAC	GF3

0W-40

Authority	Standard
API	SL / SJ / EC / CF
ACEA	A3 / B3 / B4
ILSAC	GF3

Maintenance

Oil Drain

1. Remove the front undertray.
2. Remove the sump plug. Drain the oil into an applicable container.
3. Install a new sump plug. Torque-tighten the sump plug to **23-27 Nm**.

Caution

Always install a new oil sump plug.

4. Clean the area before you install the front undertray. Install the front undertray.

Oil Filter


Repair Operation Time (ROT)

Item	Code
Oil Filter Renew	LHD TBA
	RHD 03.02.AB

Remove

RH Drive.

1. Remove the front undertray.
2. Remove the oil filter.



To help prevent spilled engine oil, cover the oil filter with a plastic bag.

3. Clean all unwanted oil from around and below the oil filter.


Caution

Engine oil can drain onto the steering rack and rubber hoses. Make sure that unwanted engine oil is removed before you install the undertray.


Remaining engine oil can drip onto the undertray and can incorrectly show an engine oil leak.

LH Drive.

1. Remove the front undertray.
2. Remove the air intake from the throttle body.
3. Remove the throttle body.



4. Remove the oil filter.



To help prevent spilled engine oil, cover the oil filter with a plastic bag.

5. Clean unwanted oil from around and below the oil filter.

Caution

Engine oil can drain onto the steering rack and rubber hoses. Make sure that unwanted engine oil is removed before you install the undertray.

Remaining engine oil can drip onto the undertray and can incorrectly show an engine oil leak.

Install


1. Apply a thin layer of clean engine oil to the lip of the oil filter.
2. Install the oil filter to the engine block. Tighten the oil filter hand-tight.
3. **LH drive only.**
Install the throttle body and air intake pipe.
4. Install the front undertray.

Sump


Repair Operation Time (ROT)		
Item	Code	
Sump Remove / Install	LH	03.02.BN

Remove


1. Drain the engine oil.
2. Remove the lower suspension arms (from the front subframe) and the anti-roll bar (Refer to 'Front Suspension (04.01)', page 4-1-1).



3. Use the correct support to hold the engine from above (Refer to '303-1080 (Engine Support Adaptor)', page 20-1-6).
4. Remove the front subframe (Refer to 'Front Subframe', page 2-1-2).
5. Remove the coolant pipe from the sump.



6. Remove the bolts (x15 M8) and (x5 M6) that attach the sump. Remove the sump.
7. Discard the sump gasket and the oil seal for the oil pump.



8. Clean the sump and the engine block mating surfaces.


Install

1. Make sure the sump is clean.
2. Install a new sump gasket. Make sure that the gasket is above its groove equally all around the sump.

Make Sure The Gasket Protrudes Evenly From Its Groove




3. Install a new oil seal for the oil pump to the sump.



4. Apply dots (10 mm Dia approximately) of sealant to the sump sealing surface in the positions shown in the figure below.


Installed and attach the sump in less than 6 minutes after you apply the beads of sealant.



5. Install the sump.

Make sure that the oil outlet seal for the sump correctly engages with the oil pump inlet before you put the sump in position on the engine block.

Do not use a mallet etc. to align the sump to the engine block.




Make sure that the sump is flush to 0.25mm underflush to the rear face of the cylinder block.

Install the bolts (x15 M8) and (x5 M6) to attach the sump.

Do the steps that follow to tighten the bolts:-

- 1 Tighten all of the bolts to **15 Nm.** in the sequence shown in the figure.
- 2 Follow the sequence again and tighten all of the bolts an angle of **90 degrees** more.



6. Install the coolant pipe.

7. Install the front subframe (Refer to 'Front Subframe', page 2-1-2).

8. Install the lower suspension arms (Do not torque-tighten the bolts at this step).

9. Install the anti-roll bar. Torque-tighten the stabiliser nut to **110 Nm.**

10. Remove the support from the engine.

11. Fill the engine with the recommended quantity and grade of engine oil (Refer to 'Specifications', page 3-2-2).

12. Torque-tighten the suspension fixings with the vehicle at the normal ride height (Refer to 'Front Suspension (04.01)', page 4-1-1):

- Lower suspension arms to the subframe - **115 Nm.**

13. Do a check of the the front wheel alignment and adjust it if necessary (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).


14. Lift the vehicle and install the front undertray.

Oil Pump

Repair Operation Time (ROT)	
Item	Code
Oil Pump Renew	TBA


Remove

1. Drain the engine oil.
2. Remove the engine from the vehicle (Refer to 'Remove', page 3-0-4).
3. Remove the sump (Refer to 'Sump', page 3-2-3). Discard the sump gasket and the oil seal for the oil pump.
4. Remove the timing chains (Refer to 'Valve Timing Chains', page 3-9-1).
5. Remove the bolts (x1 M6) and (x3 M8) that attach the oil pump. Remove the oil pump.



Install

1. Locate the oil pump on the crankshaft.
Install the oil pump.
 - Torque-tighten the bolts (M8 x3) to **23-27 Nm.**
 - Torque-tighten the bolts (M6 x1) to **8-12 Nm.**




2. Install the timing chains (Refer to 'Valve Timing Chains', page 3-9-1).

3. Install the timing cover (Refer to 'Timing Cover', page 3-10-3).
4. Install the sump (Refer to 'Sump', page 3-2-3) with a new gasket and a new oil seal for the oil pump.

Make sure that the oil outlet seal for the sump correctly engages with the oil pump inlet before you put the sump in position on the engine block.

Do not use a mallet etc. to align the sump to the engine block.




Make sure that the sump is flush to 0.25mm underflush to the rear face of the cylinder block.

5. Install the engine in to the vehicle (Refer to 'Engine', page 3-0-4).
6. Fill the engine with the recommended quantity and grade of engine oil (Refer to 'Specifications', page 3-2-2).
7. Do a check of the the front wheel alignment and adjust it if necessary (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).

Engine (03.00)


Cooling System (03.03)

Description



- | | | | |
|------------|--------------|----------------------------|----------------------------------|
| Water pump | Radiator | Coolant Reservoir | Cooling fan motor control module |
| Thermostat | Pressure cap | Electric cooling fans (x2) | Engine oil cooler |

Coolant Circuit



Water Pump

The water pump is of a standard design and it is installed at the front of the engine. It is driven by the accessory drive belt.

Thermostat

The thermostat lets the engine warm-up quickly by keeping the coolant flow through the engine below 88.3°C (190.9°F). The thermostat also helps to keep the engine operating temperature between 88.3 - 92.2°C (190.9 - 198°F). It is fully open at 103.9°C (219°F).

Cold Engine (By-pass Circuit) - When the engine is cold and the thermostat is closed, coolant flows from the water pump through the engine and then directly back to the water pump.

Warm Engine - When the engine is warm and the thermostat is open, coolant flows from the water pump, then through the engine, to the thermostat. After the thermostat, the coolant flows into the radiator top coolant-hose and into the radiator. The coolant then goes back to the water pump through the radiator bottom coolant-hose.

Note: Because the heater core is on a parallel circuit, the position of the thermostat does not have an effect on the heater core.

Radiator

The radiator core is made from aluminium with plastic end tanks. There are foam seals installed on the radiator so that the cooling air does not bypass the radiator core. The radiator is installed on four isolator mountings and it is supported by the radiator support beam. A coolant drain plug is provided in the lower RH side for the draining of the coolant. The Cooling fan shroud is attached to the radiator.

Cooling Fans

Two variable-speed electric fans are housed in the cooling-fan pack to cool the radiator. The speed of the fans is adjusted by the Powertrain Control Module (PCM).

Coolant Reservoir

A pressurized Coolant Reservoir system is used that continuously removes air from the cooling system. A vent from the engine and radiator to the coolant expansion tank prevents air-locks in the cooling system. There are no manual bleed points in the system.

The Coolant Reservoir should be at the "MAX" level mark when the coolant system is cold.

Engine Oil Cooler

Coolant for the engine oil cooler is supplied from the water pump outlet and returns to the water pump inlet. A heat exchanger enables the engine oil temperature to be cooled by the engine coolant.

In-Vehicle Heating

A hose from the front of the thermostat housing directs coolant to the heater water valve which remains closed below 30°C ± 10°C (86°F ± 50°F). Above this temperature, the heater water valve will open and warm water will be available to the heater water pump. This pump will only run when the temperature is > 10°C (50°F) and will supply warm water to the air conditioning heater matrix. The A/C heater matrix outlet is connected through the return side of the water valve, back to the rear of the engine water pump.

Specifications

Antifreeze Mix	50% OAT coolant / 50% water.
Pressure Cap	150 kpa.
Thermostat	Starts to opens between 88.3 - 92.2°C (190.9 - 198°F). Fully open at 103.9°C (219°F).
Leakage Rates	30 cm / Min. 150 - 180 kpa. 60 cm / Min. 10 kpa Man. Up to 75 kpa @ 150 c m / h.

The anti-freeze is unique and cannot be mixed with other anti-freeze solutions. The OAT coolant/water mixture has a life of 150,000 miles or 5 years (which ever comes first).

Torque Figures

Description	Nm.	lb./ft.
Condenser A/C pipes	8-10	6-7.5
Thermostat housing	8-12	6-9
Thermostat housing support bracket	23-27	17-20
Water pump	23-27	17-20
Water pump pulley	23-27	17-20

Maintenance

Caution
'Spring-Band' Clips
Install 'Spring-band' clips As shown below:

Remove all grease from coolant hoses and spigots before assembly.


Coolant Drain / Fill

Repair Operation Time (ROT)	
Item	Code
Drain / Fill	03.03.BE

1. Remove the front undertray.

⚠ WARNING ⚠
DO NOT REMOVE THE PRESSURE CAP WHEN THE COOLANT IS HOT. LET THE ENGINE AND COOLANT COOL BEFORE YOU DO WORK. IF YOU DO NOT, PERSONAL INJURY CAN OCCUR.

2. Remove the pressure cap from the coolant reservoir.
3. Loosen the drain plug. Drain the coolant into an applicable container.



01-03-112

4. Install the drain plug.

5. Fill the cooling system with the specified coolant to the maximum level mark in the coolant reservoir.
6. Install the pressure cap.

⚠ WARNING ⚠
DO NOT REMOVE THE PRESSURE CAP WHEN THE COOLANT IS HOT. LET THE ENGINE AND COOLANT COOL BEFORE YOU DO WORK. IF YOU DO NOT, PERSONAL INJURY CAN OCCUR.

7. Operate the engine until it is fully warm. Stop the engine and let it cool. Coolant that expands out of the coolant reservoir will go back back when the system cools.
8. Do a check of the level at the coolant reservoir again. Fill as necessary to the maximum level.
9. Make sure that you correctly install the filler cap after you have filled the coolant reservoir.

Caution
Do not tighten the filler cap too much.

10. Install the front undertray.

Pressure Tests Cooling System

1. Use the correct pressure tester adaptors and install the pressure tester on the coolant reservoir.
2. Operate the engine until it is at the normal operating temperature.
3. Follow the pressure tester manufacture's instructions to do a test of the cooling system.
Pressure leakage (Refer to 'Specifications', page 3-3-2).

Pressure Cap

1. Use the correct pressure tester adaptors and install the pressure tester on the pressure cap.

Rinse the pressure cap with water to remove all sediment

2. Follow the pressure tester manufacture's instructions to do a test of the cooling system.
3. Pressure leakage (Refer to 'Specifications', page 3-3-2).
If you need to replace a pressure cap, make sure that the replacement has the same pressure specification as the original equipment.

Radiator - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Radiator - Remove and Install	03.03.EB


Remove

1. Drain the engine coolant.
2. Discharge the A/C system.
3. Remove the 'Slam' panel.
4. Remove the A/C pipes from the condenser.

Caution

Seal all open ends of the air conditioning parts after you disconnect them.


If you get moisture or contamination in the air conditioning system, it can cause damage or malfunction.




5. Remove the front crossmember.

Move the vehicle wings to get access to remove the crossmember.


Remove the bolts (x4) and loosen the bolts (x2) from the wings (Refer to the figure below). Carefully pull the wings to let you remove the crossmember.




- 5.1 Disconnect the wiring harness plug from the crash sensors (x2).
- 5.2 Remove wiring harness locators (x2).




- 5.3 Remove the bolts (x6).




- 5.4 Remove the bolts (x2).
Remove the front crossmember.



6. Remove bolts (x2) that secure the fan pack to the radiator.
7. Remove the fan pack from the radiator.



- Remove the hoses (shown in figure below) from the radiator.



- Remove the radiator with the condenser.

Install


- Install the radiator, complete with the condenser. Connect the radiator hoses.
- Install the fan pack.
- Install the front crossmember.
- Install the screws that attach the wings.
- Install the condenser A/C pipes. Torque the bolts to **8-10 Nm**.
- Install the 'Slam' panel.
- Fill the coolant system.
- Fill the A/C system.

Thermostat - Remove and Install


Repair Operation Time (ROT)	
Item	Code
Thermostat - Remove and Install	03.03.GB

Remove

- Drain the engine coolant.
- Disconnect the hoses shown in the figure below.



- Remove the bolt (x1) that attaches thermostat housing support bracket from the timing cover.
- Remove the bolts (x3) to release the thermostat housing.



- Discard the gasket from thermostat housing.
- Remove the thermostat from the thermostat housing.

Install


- Clean the mating surfaces and install a new gasket for the thermostat housing.
- Install the thermostat into the thermostat housing.
- Install the bolts to attach the thermostat housing support bracket, do not tighten at this step.
- Install the thermostat housing. Torque the bolts (x3) to **8-12 Nm**. Torque the bolt (x1) that attaches thermostat housing support bracket to **23-27 Nm**.
- Fill the cooling system.

Water Pump - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Water Pump - Remove and Install	03.03.LB



Remove

- Drain the cooling system.
- Remove the accessory drive belt (Refer to 'Drive Belt', page 3-5-1).



3. Attach the water pump pulley to the water pump with the bolts (x4). Torque bolts (x4) to **23-27 Nm**.
4. Install the accessory drive belt (Refer to 'Drive Belt', page 3-5-1).
5. Fill the cooling system.

3. Remove the water pump (Refer to the Figures that follow).



4. Remove and discard the water pump O-ring.

Install

1. Clean the mating surface of the water pump and install a new O-ring.
2. Put the water pump in position in the water pump body. Install the bolts (x4) that attach the water pump. Torque the bolts (x4) to **23-27 Nm**.


Engine (03.00)

Fuel Charging System (03.04)

Description

The fuel system is an electronic return-less that has the advantages that follow: there is less fuel tank vapour, it needs less electrical power and it does not need a fuel return line. Fuel is supplied at high-pressure to the injectors through two fuel rails (primary and secondary). Each fuel rail has six fuel injectors and a fuel pressure regulator. A fuel temperature sensor is installed in the primary fuel rail. Powertrain Control Modules (PCMs) keep 280 kPa in the injectors by increasing the pulse-width modulation signal to the fuel pump controller. This controls the voltage output to the fuel pump.

Fuel rails and injectors are included in this chapter. For the fuel delivery to the fuel rails and injectors, refer to Chapter 10 (Fuel System).



Safety Precautions

When you do work on the fuel system, fuel liquid and vapour will be in the work area. This can a very dangerous risk. Obey the precautions that follow:

⚠ WARNING ⚠

ONLY APPROVED PERSONNEL MUST WORK ON THE FUEL SYSTEM.

⚠ WARNING ⚠

DO NOT SMOKE NEAR THE WORKING AREA. PUT "NO SMOKING" NOTICES AROUND THE WORK AREA.

⚠ WARNING ⚠

DO NOT DO WORK NEAR THE WORK AREA THAT CAN CAUSE SPARKS OR NAKED LIGHTS (FOR EXAMPLE:- BATTERY TESTING, WELDING, METAL GRINDING, ETC.).

⚠ WARNING ⚠

KEEP A CO2 FIRE EXTINGUISHER NEAR TO THE WORK AREA.

⚠ WARNING ⚠

KEEP DRY SAND NEAR TO THE WORK AREA TO SOAK-UP SPILLED FUEL.

⚠ WARNING ⚠

IF YOU NEED TO DRAIN FUEL FROM THE VEHICLE, USE FIREPROOF FUEL HANDLING EQUIPMENT TO EMPTY THE FUEL INTO AN EXPLOSION PROOF CONTAINER.

⚠ WARNING ⚠

THERE MUST BE A GOOD AIRFLOW IN THE WORK AREA.

⚠ WARNING ⚠

DISCONNECT THE BATTERY BEFORE YOU DO WORK ON THE FUEL SYSTEM.

⚠ WARNING ⚠

DEPRESSURISE THE FUEL SYSTEM BEFORE YOU DISCONNECT A FUEL LINE.

⚠ WARNING ⚠


MAKE SURE THAT THE ENGINE IS COOL BEFORE YOU DO WORK ON THE FUEL SYSTEM.

Maintenance

Depressurising the Fuel System

Repair Operation Time (ROT)	
Item	Code
Fuel System Depressurising	10.01.EK

- Obey the fuel system safety precautions (Refer to 'Safety Precautions', page 3-4-1).
- Remove the fuel pump relay from the CEM.



- Try to start the engine.
The engine will operate for approximately 11 seconds and then stop. This will depressurise the fuel lines.

Two fault codes will show on each bank:

- P0087 'fuel pressure too low'
- P1233 'fuel pump driver module disabled or off line'.

You can erase these codes from each bank after the repairs to the fuel system are complete.

⚠ WARNING ⚠

Disconnect the earth lead from the vehicle battery before you do work on the fuel system. If you do not, an explosion or a fire can occur that can cause injury to personnel.

- Switch off the ignition
- Install the fuel pump relay to the CEM.

Fuel Rails


Repair Operation Time (ROT)	
Item	Code
Fuel Rail Renew	x1 03.04.AB
	x2 03.04.BB

Remove

- Depressurise the fuel lines.
- Disconnect the earth (-ve) lead from the vehicle battery.
- Remove the engine bay cross-brace and the inlet manifold brace.

To help injector and fuel rail Remove it is possible that you will need to disconnect the coolant pipe from the thermostat housing. This is installed between the two inlet manifolds.

- Disconnect the wiring harness plugs that follow:
 - Temperature sender plugs
 - Pressure sensor plugs
 - Injector harness plugs
- Remove the bolts (x3) that attach the fuel rail to the inlet manifold.



- Remove the secondary latch clip from each fuel line.
- Disconnect the fuel rails from their supply pipes.

Use a cloth to collect fuel that spills from the opened fuel pipe.

The hose unions from the left and right fuel rails to fuel-supply are different sizes.

Install the correct size of service tool around the union. (Refer to '412-038 (Quick Disconnect Tool)', page 20-1-7)

(Refer to '412-040 (Quick Disconnect Tool)', page 20-1-7)

Push back on the tool. While you push the tool back, pull out the fuel rail. Record the left and right hand fuel rail for the Install procedure.

Install

- Put the the fuel rails in position over the injectors.
- 'Pull down' the fuel rails onto the injectors by tightening bolts (x3). Tighten bolts to **8-12 Nm**.
- Connect the fuel rails to their supply pipes.

Make sure that the fuel rail and the fuel supply line are aligned before you connect them.

- Install the secondary latch clip to each fuel line.
- Connect the wiring harness plugs that follow:
 - Temperature sender plugs
 - Pressure sensor plugs
 - Injector harness plugs
- If necessary, connect the coolant pipe to the thermostat housing.
- Install the inlet manifold brace and the engine bay cross-brace.

Injectors

Repair Operation Time (ROT)		
Item		Code
Fuel Injectors	x1	03.04.GB
	x12	03.04.FB

Remove

1. Remove the fuel rails.
2. Remove the injectors. Discard the O-rings.

Install

1. Install the injectors, complete with new O-rings.

<p><i>Put the O-rings in the positions that follow: Blue at the top, Green green at the bottom.</i></p>

2. Install the fuel rails.




ASTON MARTIN

Engine (03.00)

Accessory Drive System (03.05) Maintenance

Description




Auxiliary Drives

A damper pulley is installed on the front of the crankshaft that drives a 'polyvee' drive belt to drive the engine auxiliaries that follow:

- The air conditioning compressor
- The alternator
- The power steering pump
- The water pump

Automatic Belt Tensioner

The automatic belt tensioner has an idler-pulley that can rotate on a bearing. It is attached to the end of a spring-loaded pivot arm. The pivot arm can be turned clockwise (seen from the front of the engine) to let you remove or install the belt.




Drive Belt

Repair Operation Time (ROT)	
Item	Code
Drive Belt Renew	03.05.AB

Remove

1. Remove the undertray.
2. Use a 3/8 in. ratchet handle 'T'-bar to rotate the drive belt tensioner clockwise and remove the drive belt from the idler pulley.
Remove the drive belt from the remaining drive pulleys.
3. Examine the drive belt. If necessary, replace the belt.



Install

1. Install the drive belt around all drive pulleys but not the idler pulley.
2. Rotate the tensioner assembly clockwise. Install the drive belt to the idler pulley then release the tensioner.
3. Do a check that the belt is correctly installed around all of the pulleys.



ASTON MARTIN

Engine (03.00)

Engine Cranking System (03.06) Maintenance

Starting System

The starting system has the parts that follow:

- A pre-engaged type starter motor
- A battery
- A remote control switch (ignition switch)
- A relay.

The starter relay is controlled by the Powertrain Control Module (PCM).

To prevent damage to the starter motor, the PCM prevents the starter from being engaged when the engine operates. To do this, the PCM prevents operation of the starter relay. The PCM will only operate the starter relay if the conditions that follow are met:

- The ignition switch has been in the start position for the correct time
- There is an approved condition between the the PCM and the Driver Information Module (DIM).
- The engine is not running
- The transmission range switch is in the Neutral or Park position (on vehicles that have automatic transmission installed)
- The clutch pedal is operated (on USA vehicles that have a manual transmission installed).

The starter relay remains energized until one of the conditions occur that follow:

- The PCM senses a signal that the engine is in operation
- The starter button has been pushed for a longer period
- The transmission range switch is not in the Neutral or Park position (vehicles installed with an automatic transmission)
- The clutch pedal is released (USA vehicles with a manual transmission installed).

With the ignition switch in the start position, if the PCM start conditions are correct, the starter relay is energized. The starter relay causes the engagement lever to move the pinion into mesh with the flywheel ring-gear teeth. The electrical contacts in the solenoid complete the high-power circuit and the starter motor operates to turn the engine.

Specifications

Torque Figures		
Description	Nm.	lb./ft.
Starter motor	50	37


Starter Motor

Repair Operation Time (ROT)	
Item	Code
Starter motor Renew	03.06.AB


Remove

1. Disconnect the vehicle battery.
2. Raise the vehicle and make safe.
3. Remove the R/H road wheel, road wheel arch liner and the front undertray.
4. Remove the oxygen gas sensors. Disconnect the oxygen gas sensors electrics.


This may provide better access to remove the starter motor.




5. Remove the VMV valve.



6. Remove the heat shield.
7. Disconnect the starter motor electrics.




8. Remove bolts (x2) that secure the starter motor.




9. Remove the starter motor and the bracket for the oxygen gas sensors.

Install

1. Put the starter motor and the bracket for the oxygen gas sensors in position on the bell housing. Torque the bolts to 50 Nm.



2. Connect the electrical connections for the starter motor.



3. Install the heat shield.
4. If required, install the oxygen gas sensors.
5. Install the front under-tray and road wheel-arch liner.
6. Install the road wheels and install road wheel nuts. Do not fully tighten the wheel nuts at this step.
7. Lower the vehicle. Tighten the road wheel nuts (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).

Engine (03.00)

Ignition System (03.07)

Description


There is an ignition coil attached to each spark-plug. Each cylinder has one spark-plug and ignition coil assembly.

There are two crankshaft sensors installed on the front of the engine - only the right sensor is used. The second crankshaft sensor is installed on the left side of the flywheel housing.

The Powertrain Control Modules (PCMs) convert the alternating voltage signal from the two Crankshaft Position Sensors (CPS) into a digital signal. This digital signal is then used to set the 'On' and 'Off' time of the primary circuit of the ignition coil. The range for control of the ignition timing is increased because there are no parts that rotate. The PCMs refer to the engine speed and load inputs to give the correct ignition timing. This function also uses other inputs. For example:- The engine temperature, the throttle position and the transmission control module (TCM) inputs.

- A short circuit to ground between the fusebox and the coil, or the coil and the PCM will cause the fuse to blow. This will cause all of the ignition coils on that bank to stop.
- If an ignition coil has an internal short-circuit, the ignition coil will fail and not its fuse. This will let the remaining ignition coils continue to operate.
- If the wiring harness fails between the PCM and the ignition coil, the ignition coil will fail and not its fuse. This will let the remaining ignition coils continue to operate.

The twelve spark plugs are fired in sequence by the two PCMs. The Ignition timing can vary from 55 degrees before TDC to 10 degrees after TDC.



Specifications

Spark Plugs	
Firing order	1 - 7 - 5 - 11 - 3 - 9 - 6 - 12 - 2 - 8 - 4 - 10.
Type	Dual Platinum Fine Wire
Gap	1.2 - 1.3 mm
Torque	16-20 Nm
Camshaft Sensors	
Air Gap	1 ±0.5 mm

Torque Figures		
Description	Nm	lb./ft.
Spark plugs	16-20	12-15
Ignition coils	5-7	4-5.5
Spark plug cover	2.5-3.5	2-3

Maintenance


Spark Plugs

Repair Operation Time (ROT)		
Item	Code	
Spark Plug Renew	All	03.07.DB
	LH Bank	03.07.EB
	RH Bank	03.07.FB


Remove

1. Remove the inlet manifold (Refer to 'Inlet Manifold', page 3-1-7).
2. Remove the spark plug cover.


Remove Spark Cover



3. Disconnect the ignition coils.
4. Remove the ignition coils.



5. Remove the spark plugs.



Install

1. Install the spark plugs. Torque to **16-20 Nm**.
2. Install the ignition coils. Torque the bolts to **5-7 Nm**.
3. Connect the wiring harness plugs to ignition coils.
4. Install the spark plug cover. Torque the bolts to **2.5-3.5 Nm**.
5. Install the inlet manifold (Refer to 'Inlet Manifold', page 3-1-7).

Engine (03.00)

Emission Control (03.08)

System Description

To prevent pollution, the crankcase gases (blow-by) go into the engine intake system. All poisonous fumes will be burned when the engine operates.


There is a part-load (1) and a full-load (2) breather system that vents the engine correctly during all conditions of operation. The crankcase gases are released through channels in the walls of the cylinder block. The gases then go into oil-separators (6) to remove the oil. At part-load, the gases from the oil-separators (6) go into the intake manifold. At full-load, the gases go into the intake system.

In part-load conditions, the system is controlled by the PCV (Positive Crankcase Ventilation) valve (5), which supplies a constant flow of vent gases. The flow through the PCV valve (5) is balanced by the 'make-up air' pipes (3) to the cam covers. The PCV valve (5) is operated by the pressure difference across the ends of the 'make-up air' pipes (3).

At full-load, the gases flow through a 1-way valve to the right inlet system (before the throttle) only.

The diameter of the pipes in the system is important for the control of the full-load and part-load operation.

Vacuum Pipework Layout



- | | |
|--|-------------------|
| 1. Part-load Breather Pipe - After the throttle body. | 4. One-way Valves |
| 2. Full-load Breather Pipe - Before the throttle body. | 5. PCV Valve |
| 3. Make-up-air. | 6. Oil Separators |



ASTON MARTIN

Engine (03.00)

Valve Train (03.09)

Description Camshafts

The Inlet and exhaust camshafts in each cylinder head are chain-driven by the crankshaft.

The twin crankshaft sprocket has 18 teeth and each camshaft sprocket has 36 teeth. The timing chains have 61 links. Three chain links are marked and are aligned with timing marks on the crankshaft and the camshaft sprockets during valve-timing. Because the timing chains have an odd number of links, the timing marks and the marked links will only align once every 122 revolutions of the engine.

Specifications

Valves, Guides & Springs		Nm.
Spring Force at 40mm Spring Height		290
		MM
Installed Spring Height (Exhaust/Inlet)		39.69-40.29
Valve Guide Internal Diameter		6.015 - 6.044
Valve Guide Maximum Runout		0.030
Valve Stem Diameter - Inlet		5.975 - 5.995
Valve Stem Diameter - Exhaust		5.950 - 5.970
Valve Stem Clearance - Inlet		0.020-0.069
Valve Stem Clearance - Exhaust		0.046-0.095
Valve Face Maximum Runout		0.050
Valve Lash Adjusters		
Bore		16.018 - 16.057
Outside Diameter		15.988 - 16.000
Clearance		0.018 - 0.069
Torque Figures		
Description	Nm	lb. / ft.
Timing chain guide	20-30	15-22.5
Tensioners	20-30	15-22.5
Timing cover bolts	23-27	17-20

Maintenance

Valve Timing Chains

Repair Operation Time (ROT)	
Item	Code
Timing Chain Renew LH RHD	0309AA
Timing Chain Renew RH RHD	0309AB
Timing Chain Renew LH LHD	0309AC
Timing Chain Renew RH LHD	0309AD

Remove

1. Remove the camshaft covers (Refer to 'Camshaft Cover', page 3-10-1).
2. Remove the timing cover (Refer to 'Timing Cover', page 3-10-3).
3. Remove the crankshaft timing disc.


Record the correct position of the disc for the Install procedure.

4. Turn the crankshaft until the crankshaft key is in the vertical position.

Caution

The crankshaft key must stay in the vertical position until the camshaft chains are correctly installed and tensioned. If the crankshaft moves before the valve timing is completed, valves and pistons can be damaged.

The crankshaft key is exactly in line with No.1 crankshaft throw. With the crankshaft key vertical, No.1 piston is 30° ATDC and all pistons are below engine block surface.



5. Insert the camshaft set tool (Refer to '303-713 (Camshaft Set)', page 20-1-5).

With the crankshaft Key in the vertical position the flats on the camshaft will accept the camshaft set tool.

6. Remove the right or left timing chain tensioner, the tensioner arm and the timing chain guides:-
Do not remove the timing chain.
 - 6.1 Compress the timing chain tensioner and install the locking pin (Refer to '303-1072 (Timing Chain Tensioner Pins)', page 20-1-6). Remove the bolts (x2) and release the timing chain tensioner.
 - 6.2 Remove the floating tensioner arm.

- 6.3 Remove the fixed timing chain guide (bolts x2).
Repeat steps 6.1 to 6.3 for the second timing chain tensioner and timing chain guides.
7. Remove the two timing chains and the crankshaft twin sprocket from the crankshaft.

Left Cylinder Head (Cylinders 7-12)

2. Engage the camshaft timing service tool (Refer to '303-713 (Camshaft Set)', page 20-1-5) to the flats on the camshafts.
3. Install the fixed timing chain guide.



Install

Caution


The crankshaft key must stay in the vertical position until the camshaft chains are correctly installed and tensioned. If the crankshaft moves before the valve timing is completed, valves and pistons can be damaged.

1. Do a check that the crankshaft key is vertical and that all camshafts are in the initial positions shown.

The crankshaft key is exactly in line with No.1 crankshaft throw. With the crankshaft key vertical, No.1 piston is 30° ATDC and all pistons are below engine block surface.




4. Install the timing chain with the marked links (x3) aligned with the marks on the crankshaft and the camshaft sprockets.




5. Install and tension the timing chain arm and tensioner. Remove the lock-pin for the timing chain tensioner.
6. Make sure that all of the three marked links on the timing chain, align with the timing marks on the camshaft and crankshaft sprockets.

Right Cylinder Head (Cylinders 1-6)


7. Make sure that the crankshaft key is in the vertical position (No.1 cylinder at 30° ATDC). Make sure that the camshafts are in the initial positions shown in the figure below.



8. Engage the camshaft timing service tool (Refer to '303-713 (Camshaft Set)', page 20-1-5) to the flats on the camshafts.
9. Install the fixed timing chain guide.




10. Install the timing chain with the marked links (x3) aligned with the marks on the crankshaft and the camshaft sprockets.



11. Install the timing chain tensioner arm.
12. Install the timing chain tensioner. Remove the lock-pin.
13. Make sure that all of the three marked links on the timing chain, align with the timing marks on the camshaft and crankshaft sprockets.
14. Remove the camshaft timing service tool.
15. Install the crankshaft timing disc in the same position recorded during removal.
16. Check the valve timing (Refer to 'Valve Timing Check', page 3-9-4).
17. Install the timing cover (Refer to 'Timing Cover', page 3-10-3).

Valve Timing Check

1. Rotate the crankshaft counter-clockwise at least 60°, then rotate clockwise to TDC for No. 1 cylinder (with the crankshaft key 30 degrees before vertical).
2. At TDC for No.1 cylinder, the timing marks on the REAR of the camshaft sprockets should be accurately aligned as shown.



On a correctly timed engine, when No. 1 cylinder is at TDC compression, the timing marks on the rear of the camshaft sprockets will always align.

The timing marks on the timing chains, camshaft and crankshaft sprockets will only align once every 122 crankshaft revolutions on a correctly timed engine.

Note that engine oil will leak from timing chain tensioner.

6. Remove the camshaft cover (Refer to 'Camshaft Cover', page 3-10-1).
7. Remove the timing cover (Refer to 'Timing Cover', page 3-10-3).
8. Remove the timing chains (Refer to 'Valve Timing Chains', page 3-9-1).
9. Gradually release all of the bolts that attach each bearing cap.

The thrust camshaft bearing cap, of each camshaft (No.1 and No. 8 cap), must be removed first and installed last.



10. Remove the bearing caps. Keep them in the sequence they were removed.
11. Removed the camshafts.
12. Remove the camshaft followers and lash adjusters. Keep them in the sequence removed.



Camshafts / Camshaft Followers / Lash Adjusters

Repair Operation Time (ROT)	
Item	Code
Camshafts / Camshaft Followers / Lash Adjusters	TBA

Remove

1. Remove the engine from the vehicle (Refer to 'Engine', page 3-0-4).
2. Remove the inlet manifold (Refer to 'Inlet Manifold', page 3-1-7).
3. Drain the engine coolant (Refer to 'Coolant Drain / Fill', page 3-3-3).
4. Remove the accessory drive belt (Refer to 'Drive Belt', page 3-5-1).
5. Remove the thermostat housing (Refer to 'Thermostat - Remove and Install', page 3-3-5).

13. Put a cover on the engine block to prevent contamination.

Install

Make sure that all mating surfaces are clean and smooth.

1. Install all of the lash adjusters.


Soak the lash adjusters in engine oil. Operate the adjusters to fill them with oil.

Insert each lash adjuster into its correct recess in the cylinder head.

2. Install the camshaft followers to their correct valves.

Caution
Make sure that the dimpled end of the camshaft followers are installed to the lash adjusters.

Soak the cam followers in engine oil.



3. Lubricate the camshaft journals and the camshaft bearing caps with engine oil.


4. Make sure that the crankshaft key is vertical.

Caution
The crankshaft key must stay in the vertical position until the camshaft chains are correctly installed and tensioned. If the crankshaft moves before the valve timing is completed, valves and pistons can be damaged.

The crankshaft key is exactly in line with No.1 crankshaft throw. With the crankshaft key vertical, No.1 piston is 30° ATDC and all pistons are below engine block surface.

5. Put the camshafts in position, with the timing marks in the positions shown.


In the positions shown, the camshafts will be at their lowest in the journals.



6. Do work on one cylinder head at a time.

7. Install all camshaft bearing caps except the two thrust camshaft bearing caps (No.1 and No. 8 cap) at the front of each camshaft. Loosely install each cam cap.

Bearing Caps



The bearing caps are numbered and agree with the numbers that are stamped on the cylinder head adjacent to the journal.


8. Install No.1 and No. 8 bearing caps over their thrust flanges. If the bolt holes do not correctly align, move the camshafts forward or rearward as required until the bearing caps engage correctly. Loosely install the bearing cap attachment bolts.

9. Do the steps that follow to torque-tighten the camshaft attachment bolts:-

- 9.1 Gradually tighten all of the bolts in the sequence shown. Make sure that the mating faces of the camshaft bearing caps correctly touch the cylinder head.
- 9.2 In the sequence shown, torque-tighten the attachment bolts for the camshaft bearing caps to **8-12 Nm**

12. Install the timing cover (Refer to 'Timing Cover', page 3-10-3).

- 13. Install the accessory drive belt (Refer to 'Drive Belt', page 3-5-1)
- 14. Install the camshaft cover (Refer to 'Camshaft Cover', page 3-10-1).
- 15. Install the thermostat housing (Refer to 'Thermostat - Remove and Install', page 3-3-5).
- 16. Fill the engine coolant system (Refer to 'Coolant Drain / Fill', page 3-3-3).
- 17. Install the inlet manifold (Refer to 'Inlet Manifold', page 3-1-7).
- 18. Install the engine to vehicle (Refer to 'Engine', page 3-0-4).



- 10. Do steps 6 to 9 again for the second cylinder head.
- 11. Install the timing chains. Do the camshaft timing procedure (Refer to 'Valve Train (03.09)', page 3-9-1).

Engine (03.00)

Engine Sealing (03.10)

Specifications

Torque Figures		
Description	Nm.	lb. / ft.
Camshaft cover	8-12	6-9
Timing cover	23-27	17-18.5
Idle pulley	25-27	18.5-20
Spark plug bolts	1. 15	11.5
	2. 90°	
Crankshaft damper	1. 120	89
	2. Back out a minimum of 360°	
	3. 47-53	35-39.5
	4. 85°-95°	
Camshaft sensor	8-12	6-9
Ignition coils	5-7	4-5.5
Spark plug cover	2.5-3.5	2-3


Maintenance

Camshaft Cover


Repair Operation Time (ROT)	
Item	Code
Camshaft Covers	TBA

Remove


1. Remove the inlet manifold (Refer to 'Inlet Manifold', page 3-1-7).
2. Disconnect the camshaft cover ventilation-pipe and the wiring-harness connector for the camshaft sensor.



3. Remove the spark plug cover.




4. Disconnect the ignition coil electrical connectors. Remove the ignition coils.



5. Lower the rear suspension (Refer to 'Rear Suspension (04.02)', page 4-2-1).

To get access to the bolts (x2) that attach the wiring harness carrier to the camshaft covers.


6. Remove the bolts (x2) that attach the wiring harness carrier and the electrical device. Lift the wiring harness carrier off the camshaft studs.



7. Remove the bolts (x15) that attach the camshaft cover. Remove the camshaft cover. Discard all of the seals from the camshaft cover.
8. Do steps 1 to 7 for the second camshaft cover.

Install


1. Apply a bead of sealant where shown in the figure below.



03-01-216


RTV Sealant ●

2. Install new camshaft cover gaskets.



01-03-222

3. Install the camshaft cover. Torque the bolts (x15) to **8-12 Nm.** in the sequence shown below.



01-03-214


4. Put the wiring harness carrier and the electrical device over the camshaft studs. Torque the bolts (x2) to **8-12 Nm.**
5. Install the rear suspension (Refer to 'Rear Suspension (04.02)', page 4-2-1).
6. Install the ignition coils. Torque the bolts to **5-7 Nm.** Connect the wiring-harness connectors for the ignition coils.
7. Install the spark plug cover. Torque the bolts to **2.5-3.5 Nm.**
8. Connect the camshaft cover ventilation pipe and the wiring-harness connector for the camshaft sensor.
9. Install the inlet manifold (Refer to 'Inlet Manifold', page 3-1-7).

Timing Cover


Repair Operation Time (ROT)	
Item	Code
Timing Chain Cover	0310AF

Remove


1. Drain the engine oil.
2. Drain the engine coolant.
3. Remove the accessory drive belt (Refer to 'Drive Belt', page 3-5-1).
4. Remove the top idler pulley and the accessory drive belt from the timing cover.




5. Remove the bolts (x4) to release the power steering pump.




6. Remove the bolts (x2) that attach the water pump to the timing cover. Remove the pump.



7. Use the special tool (No. 303-1360) to hold the crankshaft and remove the bolt and the washer to release the crankshaft damper.




8. Use a universal puller to remove the crankshaft damper.
9. Remove the crankshaft position sensors (x2).




10. Remove the camshaft covers (Refer to 'Camshaft Cover', page 3-10-1).


11. Remove the thermostat housing:
 - 11.1 Remove the hoses (x4).
 - 11.2 Remove the bolts (x3).
 - 11.3 Remove the bolt (x1) from the timing cover.



12. Remove the bolts (x2) that attach the sump to the timing cover.




13. Remove the remaining bolts (x14) that attach the timing cover. Remove the timing cover. Discard the timing cover gaskets.




Install

1. Make sure that the mating surfaces of the timing cover and the crankcase are clean and smooth. Install new timing cover seals.



2. Apply RTV sealant at the cylinder head joints as shown in the figure below.

Install the timing cover no longer than 6 minutes after you apply the beads of sealant.



RTV Sealant Gasket Trimming

3. Install the bolts (x14).


The shorter bolt is installed at position 2.

Do not install the thermostat bracket.


Torque the bolts in sequence to **23-27 Nm**.

If the ends of the timing cover seals are not level with the ends of the joints, cut the seal flush with a sharp knife.


4. Install the thermostat housing with the thermostat and a new O-ring (Refer to 'Thermostat - Remove and Install', page 3-3-5). Torque the bolts (x3) to **8-12 Nm**. Torque the thermostat housing support bracket bolt (x1) to **23-27 Nm**.



5. Install the upper idler pulley. Torque the bolt to **25-27 Nm**.
6. Install the accessory drive belt tensioner. Torque the bolt to **25-27 Nm**.




7. Install the sump bolts (x2). Torque to **15 Nm**. and then turn **90 degrees** more.
8. Install the crankshaft damper.
 - 8.1 Clean all sealant from the crankshaft key-way.
 - 8.2 Oil the crankshaft damper seal surface.
 - 8.3 Apply silicone sealant to seal the end of the key-way.



- 8.4 Make sure that the crankshaft does not turn (use tool 303-1360) and torque the crankshaft damper bolt in four stages:

- 1 Tighten to **120 Nm**.
- 2 Loosen a minimum of **360 degrees**.
- 3 Tighten to **47-53 Nm**.
- 4 Tighten **85 degrees to 95 degrees** more.



9. Install the crankshaft sensors (x2). Torque the bolts to **8-12 Nm**. Connect the wiring harness connectors.
10. Attach the power steering pump and the water pump to the timing cover. Torque the bolts to **23-27 Nm**.
11. Install the accessory drive belt (Refer to 'Drive Belt', page 3-5-1).
12. Install the camshaft cover (Refer to 'Camshaft Cover', page 3-10-1).
13. Fill the coolant system (Refer to 'Cooling System (03.03)', page 3-3-1).
14. Fill the engine with the recommended quantity and grade of engine oil (Refer to 'Specifications', page 3-2-2).

Crankshaft Rear Oil Seal

Repair Operation Time (ROT)	
Item	Code
Crankshafts Rear Oil Seal	TBA

Remove

1. Automatic Gearbox Only

Remove the rear subframe complete with the transaxle (Refer to 'Rear Subframe', page 2-1-4).

2. Manual Gearbox Only

Remove the transaxle (Refer to 'Manual Transmission (07.03)', page 7-3-1)

3. Remove the torque tube (Refer to 'Torque Tube', page 5-1-2).
4. Remove the flywheel (Refer to 'Flywheel', page 3-11-9).
5. Use the service tools (Refer to '303-1173 (Crankshaft Rear Oil Seal and Slinger Removal)', page 20-1-4) to remove the oil seal slinger and oil seal from the oil seal retainer.

For the Remove procedure: (Refer to 'Crankshaft Rear Oil Seal Remove (TBA)', page 20-1-11)

6. Clean the recess for the oil seal and the mating surface of the oil seal retainer. Clean the mating surfaces on the engine block and sump. Make sure that there is no oil on mating surfaces.

Install

Caution

During this procedure, all parts must stay clean.


1. Apply engine oil to the seal recess and seal surface.
2. Install the rear crankshaft oil seal (Refer to '303-664 (Crankshaft Rear Oil Seal Install)', page 20-1-4).

The spring side must be to the engine.

When the oil seal install tool touches the seal housing the new oil seal has been installed to the correct depth.

Insert the seal ensuring it sits squarely into the retainer recess.

Insert Rear Seal




01-03-132

3. Install the oil seal slinger (Refer to '303-1174 (Crankshaft Rear Oil Seal Slinger Install)', page 20-1-4).

The oil seal slinger only installs one way on the oil seal slinger install tool.

When the oil seal install tool touches the seal housing the new oil seal has been installed to the correct depth.

Install the seal. Make sure that it installed equally into the recess for the retainer.



01-03-132z

4. Install the flywheel (Refer to 'Flywheel', page 3-11-9).
5. Install the torque tube (Refer to 'Torque Tube', page 5-1-2).
6. **Manual Gearbox Only**
Install the transaxle (Refer to 'Manual Transmission (07.03)', page 7-3-1)
7. **Automatic Gearbox Only**
Install the rear subframe with the transaxle (Refer to 'Rear Subframe', page 2-1-4).

Crankshaft Front Oil Seal

Repair Operation Time (ROT)	
Item	Code
Crankshafts Front Oil Seal	TBA

Remove


1. Remove the timing cover (Refer to 'Camshaft Cover', page 3-10-3).
2. Remove the oil seal from the timing cover.

Install

1. Clean the recess for the seal in the timing cover.
Apply engine oil to the outside of the new seal and the seal recess.
2. Install the timing cover (Refer to 'Camshaft Cover', page 3-10-3).
3. Loosely put a new seal in the seal recess.

The spring side must be to the engine.

Install the seal (Refer to '303-664 (Crankshaft Rear Oil Seal Install)', page 20-1-4).



Apply engine oil to surface of the seal before you install the crankshaft damper.



ASTON MARTIN

Engine (03.00)

Power Conversion (03.11)

Description

Crankshaft

The crankshaft is installed in 7 main-bearings. The end loads are absorbed by thrust washers that are installed at the number 4 main-bearing. The main-bearing bolts are of the 'torque to yield' type and they must be renewed if they are removed.

There is a twin sprocket installed on the front end of the crankshaft that drives the camshaft timing chains. A damper pulley attached to the crankshaft, uses the accessory belt to drive the engine auxiliaries.

Also at the front of the engine there is a timing disc installed and a crankshaft sensor (right side).


The sensor gives engine position signals to the PCMs

A second crankshaft sensor is installed at the left side of the front of the engine - but it is not used.

Pistons and Connecting-Rods

Each connecting-rod is attached to the crankshaft with a connecting-rod cap that attaches the bearing shells. The connecting-rod cap attachment bolts are of the 'torque to yield' type and must be renewed if they are removed. The connecting-rods are made in one piece with a fracture line at the connecting-rod bearing. Each connecting-rod cap is cracked from the connecting-rod after they are machined and drilled. Thus each connecting-rod cap can only be installed in one direction, to its correct connecting-rod.

The cap attachment bolts are of the 'torque to yield' type and must be renewed if they are removed.



Each piston has two compression rings and one oil control ring. The arrow on each piston crown must point to the front of the engine during install.

Specifications

Crankshaft		MM
Main-bearing diameter		67.480 - 67.504
Main-bearing clearance		0.025 - 0.050
<i>Refer to the main-bearing grade chart for bearing shell selection.</i>		
Connecting-rod Bearing diameter		49.97 - 49.99
Connecting-rod Bearing clearance		0.028 - 0.066
Crankshaft end float		0.130 - 0.301
Turning Torque		Nm.
Guideline figures only		
Crankshaft and rear seal only		6
Crank, rear seal + pistons & rods		16 - 20
Crank, rear seal, pistons & rods + camshafts & tensioned chains		36 - 44
Crankshaft Sensors		MM
Air Gap		1 (±0.5)
Piston Ring Gaps at 89.000		
Cylinder Bore Diameter		MM
Upper compression ring		0.100 - 0.250
Lower compression ring		0.270 - 0.420
Oil control rings		0.150 - 0.650
Compression Ring Vertical Clearance		MM
Upper compression ring		0.040 - 0.075
Lower compression ring		0.040 - 0.885
Piston Pin		MM
Piston pin to rod clearance		
Interference		0.005
Clearance at 20°C (68°F)		0.001
Connecting-Rods		MM
Piston pin to connecting-rod clearance		0.004 - 0.020
Piston pin to piston interference		-0.005 - 0.001
Big End Side Clearance (2 rods)		0.225 - 0.625
Piston Height Above the Block Face at TDC		MM
An average of two readings taken along the crankshaft axis. A straight line must pass between the two readings and the center of the piston.		
		0.415 (Below)
		0.115 (Above)



Torque Figures		
Description		Nm. lb./ft.
Engine block spread tool		25 18.5
Main-bearings	1. Bolts 1 to 14.	37-43 27.5-32
	2. Bolts 15 to 28.	22-28 16.5-21
	3. Bolts 1 to 28.	85°-95°
Main cap side bolts	1. Bolts 29 to 42.	22-28 16.5-21
	2. Bolts 29 to 42.	85°-95°
Connecting-rods	1.	20-25 15-18.5
	2.	40-45 30-33.5
	3.	105°-120°
Windage tray	1.	5-7 4-5.5
	2.	45°
Sump	1.	15 11.5
	2.	90°
Flywheel		75-81 55.5-60
Damper plate (Auto only)		30 22.5

Main-Bearing Grade Chart

The finished diameter of the crankshaft main-bearing bores is shown by letters stamped on the cylinder block face. The first letter, for example 'D', refers to the No.1 journal. The second letter element refers to the No.2 journal and so on.

The finished diameters of the seven crankshaft main-bearing journals are shown by seven letters stamped in the sequence of the bearing number on the No.1 counterweight.

The first letter in the sequence refers to the No.1 journal. The second letter refers to the No.2 journal and so on.

1. Read and record the first letter on the cylinder block face.
2. Read and record the first letter on No. 1 crankshaft counterweight.
3. Using the letters, make a selection of the correct bearing grade for No. 1 journal.
4. Repeat steps 1-3 to find the correct bearing grades for journals 2-7.

Piston Skirt Grading Chart

Piston Diameter 'A1' Prior to Skirt		
Grade	Coating	Cylinder Bore Diameter
1	88.970 / 88.980	89.000 / 89.010
2	88.978 / 88.992	89.008 / 89.022
3	88.990 / 89.000	89.020 / 89.030

Skirt Coating adds 0.020 - 0.030 to the diameter as follows:

Piston Diameter (Coated)		
Grade	Coating	Clearance with Coating
1	88.990 / 89.010	New Build -0.014 (interference)
2	88.998 / 89.022	New Build + 0.024 (clearance)
3	89.010 / 89.030	Service Limit + 0.050 (clearance)

		Minimum Block Diameter																									
		A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X		
		72.400	.401	.402	.403	.404	.405	.406	.407	.408	.409	.410	.411	.412	.413	.414	.415	.416	.417	.418	.419	.420	.421	.422	.423	.424	
Max Crankshaft Diameter	X	67.504	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	
	W	67.503	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2
	V	67.502	1	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2
	U	67.501	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2
	T	67.500	1	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2
	S	67.499	1	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2	2
	R	67.498	1	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2	2	2
	Q	67.497	1	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3
	P	67.496	1	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3
	O	67.495	1	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3
	N	67.494	1	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3
	M	67.493	1	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3
	L	67.492	1	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3
	K	67.491	1	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3
	J	67.490	1	1	1	2	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3
	I	67.489	1	1	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3
	H	67.488	1	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3
	G	67.487	2	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3
	F	67.486	2	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3
	E	67.485	2	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3
D	67.484	2	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	
C	67.483	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	
B	67.482	2	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	
A	67.481	2	2	2	2	2	2	2	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	3	

Bearing Grade 1 = Orange
 Bearing Grade 2 = Blue
 Bearing Grade 3 = Green

There are ink marks on the inside of the bearing to show the grade of the bearing.


- Remove the windage baffle.

Maintenance Crankshaft

Repair Operation Time (ROT)	
Item	Code
Crankshaft Renew	03.11.CF

Remove

- Remove the engine from the vehicle (Refer to 'Engine', page 3-0-4).
- Remove the cylinder heads (Refer to 'Cylinder Heads', page 3-1-2).
- Remove the sump (Refer to 'Sump', page 3-2-3).




5. Remove the bolts (x6) that attach the rear oil seal retainer and withdraw the seal retainer and oil seal.



6. Remove the oil pump.




7. Remove the piston and the connecting-rod assemblies:
7.1 Remove the connecting-rod bolts to release the connecting-rod caps and the bearings.



- 7.2 Remove the piston and the connecting-rod assemblies, with the bearings, from the top of the bore.

Make sure that each piston, connecting-rod and connecting-rod cap set remain together to install to their original locations.

The connecting-rods and the caps have identification marks which must agree and align on assembly.



There is an arrow stamped on the piston upper face that must point towards the front of the engine when assembled.


The connecting-rods are symmetrical and can be installed in one direction or the other.

The initial connecting-rod bolts have ferrules pressed into the caps to hold the bolts. New bolts do not have the captive ferrule. Use a rubber mallet to tap the initial bolts out of the cap.

8. Remove the main-bearing caps and the bearing shells.

To remove the bearing caps, spread the engine block side walls using the engine block spreading tool (Refer to '303-664 (Crankshaft Rear Oil Seal Install)', page 20-1-4), tensioned to **25 Nm**.


Do not exceed 25 Nm. on engine block spreader bolt. If you do, you can damage the engine block.



- 8.1 Remove the side bolts (x14).
- 8.2 Remove the outer bolts (x14) from the main-bearing caps.

Record the positions of the stud bolts at No. 3 and 6 main-bearing caps.

- 8.3 Remove the inner bolts (x14) from the main-bearing caps.



Keep all of the components in the same sequence for Install to their initial locations, if they are serviceable.

- 9. Remove the crankshaft from the engine.
- 10. Remove the thrust washers from No. 4 main-bearing.
- 11. Remove the upper bearing shells from all the main-bearings.

Keep all of the bearings in the same sequence for Install to their initial locations, if they are serviceable.

Examine the Components

1. Examine the crankshaft journals for wear, scuffing or other defects. Replace the crankshaft if it is unserviceable.
2. Examine all of the bearing shells and the thrust washers for wear, scuffing or other defects. Replace them if they are unserviceable.
3. If necessary, measure the diameter of the crankshaft main and big end bearings.
Compare the results with the data in the engine specifications.
 - The finished diameter of crankshaft main-bearing bores is shown by numbers stamped on engine-block face
 - The finished diameter of crankshaft main-bearing journals are shown by seven letters, stamped in bearing number sequence, on the No.1 counter weight.
4. Refer to the main-bearing grade chart in the engine specifications if you need to replace the main-bearings.


Install

Caution

Lubricate all bearing surfaces with SAE 50 Assembly Oil. If you do not, the bearings can be damaged when the engine is first operated.

Make sure that all components are clean and are not damaged before assembly.

1. Install the upper bearing shells and thrust washers (No 4 bearing). Make sure that the oil feed holes are aligned.
the thrust washers are installed with the groove facing the crankshaft.
2. Install the crankshaft into the upper main-bearings.



3. Install the main-bearings and caps.

Caution


Apply oil below the heads of the main-bearing bolts. Do not get oil on the threads. Loosely install them into their holes with your hand.

Install the stud bolts for No. 3 and 6 main-bearing caps in the positions you recorded during Remove.

- 3.1 Install the inner and outer bolts to all of the main-bearing caps.
- 3.2 Tighten the bolts sufficiently to correctly install the main-bearing caps.
- 3.3 Release all of the bolts approximately one turn.

*To install the bearing caps, spread the engine block side walls using the engine block spreading tool(Refer to '303-664 (Crankshaft Rear Oil Seal Install)', page 20-1-4), tensioned to **25 Nm**.*

Do not exceed 25 Nm. on engine block spreader bolt. If you do, you can damage the engine block.




4. Set the No. 4 main-bearing so the end loads are on both the upper and lower bearing thrust faces.
 - 4.1 Move the crankshaft rearward against the upper thrust bearing.
 - 4.2 With the crankshaft fully rearward, move the No. 4 bearing cap rearward against the crankshaft thrust face.
 - 4.3 Move the crankshaft forward.
5. Torque the main-bearing cap bolts, in the sequence shown in the figure below, to:
 - 1 Bolts 1 to 14 - **37-43 Nm**.
 - 2 Bolts 15 to 28 - **22-28 Nm**.
 - 3 Bolts 1 to 28 - **85 degrees to 95 degrees more**.

Do a check and, if required, adjust No. 1 main-bearing cap so that the front face is not forward of the oil pump mounting face.

The main-bearing bolts are torqued to yield. You must obey the specified procedure.

6. Install the side bolts for the main caps . Torque the side bolts for the main caps, in the sequence shown in the figure, to:
 - 1 Bolts 29 to 42 - **22-28 Nm**.
 - 2 Turn **40 degrees to 50 degrees** more.
8. Do a check the torque required to turn the crankshaft. The torque must not be more than **6 Nm**.
9. Install each piston and connecting-rod with its upper big end bearing shell, in their correct positions. If you are installing new pistons or connecting-rods, do a check of the piston height (Refer to 'Specifications', page 3-11-1).

↑ Front of Engine




Make sure that the piston rings are installed correctly (Refer to 'Pistons and Connecting-Rods', page 3-11-1).

The arrows that are stamped on the piston top surface must point towards the front of the engine.


Use cylinder protectors when you install the pistons and connecting-rods (Refer to '303-535 (Cylinder Bore Protectors)', page 20-1-4).

10. Install the connecting-rod bearing caps and shells, make sure the caps are in the correct direction. Check that the connecting-rod and cap identification marks agree and align. Attach the caps with two new bolts to each cap. Torque all of the connecting-rod bolts in three steps:
 - 1 To **20-25 Nm**.
 - 2 To **40-45 Nm**.
 - 3 Turn **105 degrees to 120 degrees** more.



7. Do a check the end-play of the crank shaft.


FRONT OF ENGINE



11. Install the windage tray. Torque the nuts (x4) to **5-7 Nm** then turn them 45 degrees more .
12. Install new a O-ring to the oil pick-up pipe.

13. Install the sump.

*Make sure that the sump oil outlet goes into to the oil pump inlet before the sump is installed up to the engine block.
Do not use a mallet etc. to install the sump to engine block.*




Make sure that the sump is flush to 0.25mm below the rear face of the cylinder block.

Attach the sump with the bolts bolts (x15 M8) and (x5 M6).

Tighten the bolts in the two steps that follow:

- 1 Tighten all of the bolts to **15 Nm.** in the sequence shown.
- 2 Tighten all of the bolts **90 degrees more** in the same sequence.



Caution

Make sure that the crankshaft key is in the vertical position.

14. Install the cylinder heads and the camshafts (Refer to 'Cylinder Heads', page 3-1-2).
15. Install the timing chains. Check and ensure that the valve timing is correct (Refer to 'Valve Timing Check', page 3-9-4).
16. Install the timing cover (Refer to 'Timing Cover', page 3-10-3).
17. Install the camshaft cover (Refer to 'Camshaft Cover', page 3-10-1).
18. Install the engine auxiliaries.
19. Install and tension the accessory drive belt.
20. Complete engine reassembly and prepare to install to vehicle.

Pistons and Connecting-Rods

Repair Operation Time (ROT)	
Item	Code
Connecting Rod - Engine Set - Renew	03.11.CN
Piston - Engine Set - Renew	03.11.CG
Piston Ring - Engine Set - Renew	03.11.CK

Overhaul

Keep all of the components in the same sequence for Install to their initial locations, if they are serviceable.

1. Remove the piston pin circlips. Discard the circlips.

⚠ WARNING ⚠

THE PISTONS ARE HEATED TO APPROX. 70° C. PUT ON PROTECTIVE CLOTHING WHEN YOU HANDLE THE HOT PISTONS. IF YOU DO NOT, PERSONAL INJURY CAN OCCUR.

2. Heat the piston to approx. 70°C and push out the piston pin. Let the parts cool.
3. Use a ring spreader to remove the piston rings from the piston.
4. Clean all of the components. Replace all parts that have wear or other signs of deterioration.
Measure the parts and make sure that they are not too worn (Refer to 'Specifications', page 3-11-1).
5. Repeat steps 1 to 4 for all of the pistons.

Reassembly

The pistons are graded for each cylinder bore. If you are going to install the pistons and/or connecting-rods again, you must keep them in their initial sets and in their initial positions.

The grade of a cylinder bore (1, 2 or 3) is marked on outside of the engine block, adjacent to the bore. The pistons have an equivalent grade (1,2 or 3) on their top surface. When you install a new piston, make sure that the new piston is the correct grade.


Make sure that a connecting-rod and its cap are a set.

- Heat the piston to approximately 70°C and install the connecting-rod and piston pin.

⚠ **WARNING** ⚠


PISTONS ARE HEATED TO APPROX. 70°C. WEAR PROTECTIVE CLOTHING, E.G. GLOVES, TO AVOID BURNS.

Install the connecting-rod to the piston with the 'notch' in the little end bearing (3) facing the same direction as the arrow stamped on the piston head (4).



Secure the piston pin (2) with new circlips (1).
Allow the pistons cool.

- Before installing to the engine, rotate the piston rings as necessary to the positions shown on the following diagram.



Flywheel

Repair Operation Time (ROT)	
Item	Code
Clutch and Flywheel Renew	08.00.HA

Remove

- Disconnect the vehicle battery.

⚠ **WARNING** ⚠


IF YOU LIFT THE VEHICLE ON A 'TWO POST' RAMP (VEHICLE SUPPORTED BY ITS UNDERBODY), MAKE SURE THAT YOU USE A STRAP TO SAFELY ATTACH THE VEHICLE TO THE RAMP. IF YOU DO NOT, THE VEHICLE CAN FALL OF THE RAMP.

If you use a two post vehicle lift, remove the screws that secure the rear section of the road wheel arch liner. Hold back the rear section of the road wheel arch liner to let you put the foot of the vehicle lift in the correct position (Refer to 'Jacking Points', page I-I-IX).

- Raise the vehicle and make it safe.
- Remove the rear road wheel(s) and the road wheel arch liners.
- Remove the front and rear undertrays and the shear plate.

Lower the front undertray to reveal the air intake for the alternator. Release the spring clip and part the flex pipe from the undertray.


- Remove the rear subframe and torque tube.
 - (Refer to 'Rear Subframe', page 2-1-4)
 - (Refer to 'Torque Tube', page 5-1-2)
- Manual Gearbox Only.**
Remove the clutch assembly (Refer to 'Clutch (08.00)', page 8-1-1).
- Automatic Gearbox Only.**
Remove the drive damper plate (bolts x8). Keep for the Install procedure.



8. Put a support under the flywheel.
9. Remove the flywheel attachment bolts.
Install flywheel bolts (x2) into the threaded 'jacking' holes in the flywheel. Discard the remaining bolts

⚠ WARNING ⚠


THE FLYWHEEL IS HEAVY. MAKE SURE YOU USE THE APPLICABLE SUPPORT WHEN YOU REMOVE OR INSTALL IT.



10. Tighten the bolts in steps to carefully remove the flywheel from its location on the crankshaft. When you have removed the flywheel, discard the bolts.

Install

1. Put an applicable support under the flywheel. Install the flywheel on to the crankshaft and align the attachment holes.
2. Loosely install new flywheel mounting bolts (x8) and tighten them with your hand.
3. Tighten the bolts in half-turn steps in the sequence shown. Continue until the flywheel face fully touches the crankshaft flange.
4. Loosen the bolts one turn.
5. Torque to **75-81 Nm** in the same sequence.
6. **Manual Gearbox Only.**
Install the clutch assembly (Refer to 'Clutch (08.00)', page 8-1-1).
7. **Automatic Gearbox Only.**
8. Install the drive damper plate. Torque the bolts (x8) to **30 Nm**.



The damper plate will only install in one position on the dowels.

9. Install the torque tube and the rear subframe.
 - (Refer to 'Torque Tube', page 5-1-2)
 - (Refer to 'Rear Subframe', page 2-1-4)
10. Install the front and rear undertrays.
11. Install the road wheel arch liners.
12. Bleed the brakes. (Refer to 'Brake Bleeding - AMDS', page 6-6-4).
13. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
14. If necessary, remove the vehicle attachment strap.
15. Connect the vehicle battery.


Engine (03.00)

Air Charging (03.12)

Description

Air Induction System

The intake air is filtered and then goes through two mass air flow (MAF) meters. The signals from the MAF meters are supplied to the PCMs and are used with other signals to calculate the correct amount of fuel. The correct air/fuel ratio is approximately 14.3 parts of air to 1.0 part fuel, by weight. The air then passes through the two throttle bodies into the six-branch inlet manifolds.



01-03-055

Specifications

Torque Figures		
Description	Nm	(lb. / ft.)
Air box cover	1.5-2.0	1.5
Outlet pipe	1.5-2.0	1.5
Air box mountings	2.5-3.5	2-2.5

Maintenance

Air Filter

Repair Operation Time (ROT)		
Item	Code	
Air Filter Renew	LH	03.12.CB
	RH	03.12.DB


Remove

If you use a two-post vehicle lift, remove the screws that attach the rear part of the road wheel arch liner. Hold back the rear part of the road wheel arch liner to let you put the foot of the vehicle lift in the correct position. (Refer to 'Jacking Points', page I-I-IX)


16. Raise the vehicle and make it safe.
17. Remove the road wheel(s).
18. Remove the front undertray.
19. Remove the screws (x3). Pull the front part of the wheel arch liner down to get access to the air filter box.



20. Remove the bolts (x7) and remove the filter box cover.




21. Remove the air filter.



22. Do steps 18 to 20 again for the second air filter.

Install

1. Push the air filter onto the filter adaptor. Install the box cover. Torque bolts to **1.5-2.0 Nm**.



2. Install the front section of the wheel arch liner.
3. Install the front undertray.
4. Install the road wheel(s) (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).


Air Filter Box

Repair Operation Time (ROT)		
Item		Code
Air Box Renew	LH	03.12.AB
	RH	03.12.BB


Remove

*If you use a two-post vehicle lift, remove the screws that attach the rear part of the road wheel arch liner. Hold back the rear part of the road wheel arch liner to let you put the foot of the vehicle lift in the correct position.
(Refer to 'Jacking Points', page I-I-IX)*


1. Raise the vehicle and make it safe.
2. Remove the front undertray.
3. Remove the road wheel and the arch liner for the correct air filter box.
4. Disconnect the electrical connector.





5. Disconnect the air outlet and inlet pipes.



For the outlet pipe: - Remove the attachment screw. Twist the outlet pipe and pull away.





6. Remove the air filter box mounting bracket (x1) and mounting bolts (x2). Withdraw the air filter box.



7. Repeat steps 3 to 6 for the second air filter.

Install

1. Put the air filter box into position and install the attachment bolts.



2. Connect the outlet and the inlet pipes.

For the outlet pipe: - Insert and twist then install the attachment screw.

3. Connect the electrical connector.
4. Install the wheel arch liner and the front undertray.
5. Install the road wheel(s) (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).



ASTON MARTIN

Engine (03.00)

Evaporative Emissions (03.13) System Operation



Description

The evaporative loss system prevents the release of fuel fumes into the air. The fumes from the fuel are forced out of the fuel tank when it is filled. Fumes are also released in higher temperatures because of evaporation.

There is a carbon filter (1) on top of the fuel tank that absorbs the fuel fumes. When the engine operates normally, the fuel fumes in the carbon filter (1) are mixed with the fuel and air mixture in the inlet manifold.

When the fuel fumes are forced from the fuel tank, they go through a fill level vent-valve (3) (that is normally open) and the roll-over valves (2). The fumes then go through the carbon canister (1) that absorbs the hydrocarbons from the fuel fumes.

The canister vent-valve releases clean air from the system. It closes when the fuel system is pressure tested. When the engine operates normally, the vapour management valve (4) (in the engine bay) is opened at intervals. This lets fresh air flow into the open canister vent-valve. The fresh air then flows through the carbon canister (1) and the vapour management valve (4) and into the primary inlet manifold. The fresh air flow gradually forces the absorbed fumes out of the carbon filter (1).





ASTON MARTIN

Engine (03.00)

Engine Management System (03.14)


The electronic engine control system has two Powertrain Control Modules (PCMs) and a number of sensors and devices that do operations. The sensors supply the PCMs with input signals. These input signals change because of the conditions of operation for the engine and the driver's requirements. The PCMs use the data from the sensors to operate the different devices and give the correct performance from the engine. Also, the PCMs are connected to other vehicle systems through the Controller Area Network (CAN).

The system gives the necessary engine control to:

- Keep the the exhaust emissions and the fuel consumption to a minimum
- Give the best control for the driver in all conditions
- Keep fuel fume emissions to a minimum
- Find system faults

Refer to the Vehicle OBDII manual for the inputs / outputs and the data to find faults.


Schematic Diagram



- | | | |
|---------------------------------|-------------------------------------|--------------------------------|
| 1. Fuel Tank | 12. Vapour Management Valve | 23. Exhaust Manifold |
| 2. Fuel Pump Drive Module | 13. Carbon Filter | 24. Crankshaft Position Sensor |
| 3. Fuel Tank Pressure Sensor | 14. Motorised Throttle | 25. Coolant Temperature Sensor |
| 4. Fuel Level Sensor | 15. Intake Temperature Sensor | 26. Spark Plug |
| 5. Fuel Pump | 16. Air Filter | 27. Ignition Coil |
| 6. Fuel Filter | 17. Exhaust | 28. Camshaft Position Sensor |
| 7. Filler Neck | 18. Oxygen Sensor | 29. Fuel Injector |
| 8. Drain Tube | 19. Throttle Pedal | 30. Inlet Manifold |
| 9. To Air | 20. Powertrain Control Module (PCM) | A Fuel |
| 10. To Other Half of the Engine | 21. Catalytic Converter | B Vacuum |
| 11. Canister Vent Valve | 22. Oxygen Sensor | C Vapour |

Specifications

Powertrain Control Modules (PCMs)




LH and RH Drive

PCM A

View when you look into the connectors on the PCM..

Caution
Do a check to make sure the connectors are correct.



(Refer to 'Circuit Diagrams', page 18-1-18)

T - Transmission

C0634-	Description	I / O	Circuit Page
45	Park TT	0	8
47	HTR 12	0	43
48	HTR 22	0	43
50	CNVNT	0	68

C - Cowl

C0635-	Description	I / O	Circuit Page
2	Start enable	0	70
3	ISO-K		9
4	App1 Ref. voltage		72
5	App 1	I	72
6	App 1 Return		72
7	Brake pedal switch	I	39
8	Brake On / Off switch	I	39
9	Fuel tank pressure	I	68
10	Case ground		56
11	CB 1+		16
12	Motor fuel pump	0	41
14	Power steering pressure	I	65
15	Accs (Aircon demand)	I	6
16	App 2 Ref. voltage		72
17	App 2	I	72
18	App 2Return		72
19	Sccs (Speed Con Demand)	I	71
20	Restraint deploy Ind	I	2
21	Fuel pump monitor	I	41
22	Oil Pressure	I	65
23	CB 1-		16
24	Power hold	0	50, 56, 63
25	Aircon clutch relay	0	6
26	Aircon pressure	I	6
29	Clutch (Top of travel)	I	70
30	Sccs (Speed Con Return)		71
31	TX out (PATS Comms)	0	63
32	Vehicle speed sensor+	I	68
33	Vehicle speed sensor-	I	68
34	EVMV	0	65
35	Power		56
36	Power		56
37	PATIL (PATS LED)	0	30
38	PBI (Start button ILL)	0	70
39	Clutch (Bottom of travel)	I	70
40	Ref. voltage B		6, 65, 68
41	Signal return B		6, 65, 68, 70
42	RXIN (PATS Comms)	I	63
43	EBV	0	68
44	FEPS		16
45	Keep alive power		56

T - Transmission

C0634-	Description	I / O	Circuit Page
4	PRND	I	8
9	MAF+	I	67
10	MAF-	I	67
14	CB2+		13
17	Drive TT	0	9
18	Sport TT	0	8
19	Tip up	I	9
20	Tip down	I	9
21	MIL	0	30
24	HEGO 12	I	43
25	HEGO 22	I	43
26	CB2-		13
28	Rev TT	0	8
29	PRND 2	I	8
30	CB 3+		16
31	CB 3-		16
32	Neutral TT	0	9
33	Sport SW	I	8
36	Bap	I	68
38	Engine off	I	9
40	Ref. voltage C		9, 68
41	Signal return C		43, 68
43	Park ST	I	9

C - Cowl

C0635-	Description	I / O	Circuit	Page
47	Power ground			56
48	Power ground			56
49	Power ground			56
50	IGNSNS	I		56


E - Engine

C0636-	Description	I / O	Circuit	Page
1	(CD1) Cylinder 1	0		47
2	Injector 1	0		48
3	Injector 6	0		48
4	Injector 4	0		48
5	Injector 3	0		48
7	Throttle pot return			72
8	Injector 5	0		48
9	Injector 2	0		48
10	Injector 7	0		48
11	Injector 8	0		48
12	(CD5) Cylinder 5	0		47
13	Inlet air temperature	I		67
14	Fan Control	0		21
15	Camshaft / Crankshaft Return			65
18	Throttle Pot Reference Volume			72
19	TP1-NS	I		72
24	(CD3) Cylinder 3	0		47
25	CID 1	I		65
29	TP2-PS	I		72
30	HEGO 11	I		43
31	Hego21	I		43
33	Engine Coolant Temperature	I		65
34	Crankshaft Position	I		65
35	(CD6) Cylinder 6	0		47
36	Fuel Rail Temperature	I		65
37	Fuel Rail Pressure Tran	I		65
38	(CD2) Cylinder 2	0		47
39	(CD4) Cylinder 4	0		47
40	Ref. Voltage A			65
41	Signal Return		43, 65, 67	
45	Crankshaft Positive	I		65
47	Throttle Mtr +	0		72
48	Throttle Mtr -	0		72
49	HTR11	0		43
50	HTR21	0		43

PCM B

View when you look into the connectors on the PCM.

Caution
Do a check to make sure the connectors are correct.



(Refer to 'Circuit Diagrams', page 18-1-18)

E - Engine

C2464-	Description	I / O	Circuit	Page
1	(CD7) Cylinder 1	0		47
2	Injector 1	0		48
3	Injector 6	0		48
4	Injector 4	0		48
5	Injector 3	0		48
7	Throttle pot return			72
8	Injector 5	0		48
9	Injector 2	0		48
10	Injector 7	0		48
11	Injector 8	0		48
12	(CD11) Cylinder 5	0		47
13	Inlet air temperature	I		67
15	Camshaft / Crankshaft Return			66
18	Throttle Pot Reference Volume			72
19	TP1-NS	I		72
24	(CD9) Cylinder 3	0		47
25	CID 1	I		66
29	TP2-PS	I		72
30	HEGO 11	I		44
31	HEGO 21	I		44
34	Crankshaft Position+	I		66
35	(CD12) Cylinder 6	0		47
37	Fuel tank pressure tran	I		66
38	(CD8) Cylinder 2	0		47
39	(CD10) Cylinder 4	0		47
40	Ref. Voltage A			66
41	Signal Return		44, 66, 67	
45	Crankshaft Positive -	I		72
47	Throttle Mtr +	0		72
48	Throttle Mtr -	0		72
49	HTR11	0		44
50	HTR21	0		44

T - Transmission

C0637-	Description	I / O	Circuit	Page
4	Engine coolant level	I		66
6	PRI / Sec switch	I		44
9	MAF +	I		67
10	MAF -	I		67
14	CB 2 +			13
24	HEGO 12	I		44
25	HEGO 22	I		44
26	CB 2 -	I		13
30	CB 3 +			16
31	CB 3 -			16
38	Altmon	I		69
41	Signal return C			44
47	HTR 12	0		44
48	HTR 22	0		44




C -Cowl

C0638-	Description	I / O	Circuit	Page
4	App 1 Ref. voltage			72
5	App 1	I		72
6	App 1 return			72
7	Brake pedal switch	I		39
8	Brake On / Off switch	I		39
10	Case ground			56
11	CB 1+			16
12	Motor fuel pump	0		41
16	App 2 Ref. voltage			72
17	App 2	I		72
18	App 2 Return			72
20	Restraint deploy Ind	I		2
21	Fuel pump monitor	I		41
23	CB 1-			16
24	Power hold	0		56
32	Vehicle speed sensor+	I		68
33	Vehicle speed sensor-	I		68
34	EVMV	0		66
35	Power			56
36	Power			56
44	FEPS			16
45	Keep alive power			56
47	Power ground			56
48	Power ground			56
49	Power ground			56
50	IGNSNS	I		56

Maintenance

WDS Connection

The port for WDS connection is located in the drivers side footwell on the transmission tunnel.



Powertrain Control Module - Left Side - Remove and Install

Torque Figures


Description	Nm.	lb./ft.
PCM mount	8-10	6-7.5

Repair Operation Time (ROT)

Item	Code
Powertrain Control Module - Left Side - Remove and Install	03.14.NA


Remove

1. Raise the vehicle and make it safe.
2. On Roadster vehicles, remove the centre undertray.
3. Remove the left side front wheel.
4. Remove the five or six M6 Torx-head screws that attach the rear of the wheelarch liner.
5. Remove the self-tapping screw that attaches the rear of the wheelarch liner into the wheelarch.
6. Turn the steering fully to the left.
7. Release the four clips and disconnect side repeater harness.
8. Disconnect the electrical connector from the side repeater.



A03-14-1193


9. Release the three clips that attach the powertrain control module (module) harness to the bracket.



A03-14-1194

10. Remove the three M6 screws that attach the module and the bracket.

11. Disconnect the three electrical connectors and remove the module.



A03-14-1196

Install

1. Connect the three electrical connectors to the module.
2. Put the module in position in the housing.
3. Put the bracket in position and attach it with the three M6 screws.
4. Attach the harness to the bracket with the clips.
5. Attach the side repeater harness to the bracket with the four clips.
6. Connect the electrical connector to the side repeater.
7. Put the wheelarch liner back into position.
8. Turn the steering to the centre position.
9. Install the self-tapping screw that attaches the rear of the wheelarch liner into the wheelarch.
10. Install the five or six M6 Torx-head screws that attach the rear of the wheelarch liner.
11. Install the front left roadwheel.
12. On Roadster vehicles, install the centre undertray.
13. Lower the vehicle.


Powertrain Control Module - Right Side - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Powertrain Control Module - Right Side - Remove and Install	03.14.NB

Remove

1. Raise the vehicle and make it safe.
2. On Roadster vehicles, remove the centre undertray.
3. Remove the right side front wheel.
4. Remove the five or six M6 Torx-head screws that attach the rear of the wheelarch liner.
5. Remove the self-tapping screw that attaches the rear of the wheelarch liner into the wheelarch.
6. Turn the steering fully to the right.
7. Release the four clips and disconnect side repeater harness.


8. Disconnect the electrical connector from the side repeater.



A03-14-1193 (Left Side Shown)

3. Put the bracket in position and attach it with the three M6 screws.
4. Attach the harness to the bracket with the clips.
5. Attach the side repeater harness to the bracket with the four clips.
6. Connect the electrical connector to the side repeater.
7. Put the wheelarch liner back into position.
8. Turn the steering to the centre position.
9. Install the self-tapping screw that attaches the rear of the wheelarch liner into the wheelarch.
10. Install the five or six M6 Torx-head screws that attach the rear of the wheelarch liner.
11. Install the front right roadwheel.
12. On Roadster vehicles, install the centre undertray.
13. Lower the vehicle.

9. Release the three clips that attach the powertrain control module (module) harness to the bracket.



A03-14-1194 (Left Side Shown)

10. Remove the three M6 screws that attach the module and the bracket.
11. Disconnect the three electrical connectors and remove the module.



A03-14-1196 (Left Side Shown)

Install

1. Connect the three electrical connectors to the module.
2. Put the module in position in the housing.

Engine (03.00)

Throttle Control (03.16)

Description


Motorised Throttles

There are two motorised throttles (1), one installed on each inlet manifold. They accurately control the flow of air into the engine. There is a Throttle Position Sensor (TPS) in each motorised throttle unit (1).

During normal operation of the engine, the TPS signals are used by the PCMs to show the power necessary from the engine. If required, the PCMs will operate the throttle motors to open or close the throttles by the necessary amount. At idle, the throttle butterflies are almost closed and the idle speed is controlled by small throttle movements.

If a throttle motor becomes unserviceable, a spring will cause the butterfly to go to the idle position. If a spring breaks, the airflow will cause the butterfly to go to the idle position.

The motorised throttles (1) do not need to be initially set.



01-03-142

Specifications

Torque Figures

Description	Nm.	lb./ft.
Throttle body	8-12	6-9


Maintenance Throttle Body

Repair Operation Time (ROT)


Item	Code	
Throttle Body Renew	LH	03.04.HB
	RH	03.04.JB

Remove

1. Disconnect the air intake pipe (1).
2. Disconnect the electrical connector (2).




3. Remove the four bolts (1).




4. Remove the throttle body complete with the gasket. Discard the O-ring.

Install

1. Put the throttle body in position with a new O-ring.
2. Install the four bolts (1) and torque to **8-12 Nm**.



3. Install the air intake pipe (1) and the electrical connector (2).



Suspension (04.00)

Contents

Road Wheel Alignment (04.00)	4-1-2	Shock Absorber System (04.03)	4-4-1
Specifications	1-2	Description	4-1
Maintenance	1-2	Specifications	4-1
Caster Angle	1-3	Maintenance (Front)	4-1
Adjustment (Front)	1-3	Spring and Damper Assembly	4-1
Camber Angle	1-3	Removal.....	4-1
Adjustment	1-3	Installation	4-2
Toe	1-3	Maintenance (Rear)	4-3
Adjustment (Front)	1-3	Spring and Damper Assembly	4-3
Adjustment (Rear).....	1-3	Removal.....	4-3
Front Suspension (04.01)	4-2-1	Installation	4-3
Description	2-1	Road Wheels and Tyres (04.04)	4-5-1
Suspension Arms.....	2-1	Specifications	5-1
Anti-roll Bar	2-1	USA Tyre Gradings	5-2
Vertical link.....	2-1	Tread Wear	5-2
Specifications	2-1	Temperature.....	5-2
Symptoms	2-2	Maintenance	5-2
Maintenance	2-3	Safety	5-2
Road Wheel Bearing.....	2-3	Tyre Replacement and Wheel Interchanging	5-3
Inspection	2-3	Winter (Snow) tyres	5-3
Ball Joints.....	2-4	Inspection and Verification	5-3
Inspection	2-4	Visual Inspection Chart.....	5-3
Front Suspension	2-4	Tyre Wear	5-3
Removal.....	2-4	Tyre Wear Diagnosis.....	5-3
Installation	2-6	Road Test.....	5-4
Anti-roll Bar	2-8	Symptoms.....	5-4
Removal.....	2-8	Tyre Damage	5-5
Installation	2-8	Repairs	5-6
Vertical Link.....	2-9	Care of Alloy Road Wheels	5-6
Removal.....	2-9	Road Wheel Alignment.....	5-6
Installation	2-9	Misalignment Effects.....	5-7
Rear Suspension (04.02)	4-3-1	Alignment Precautions.....	5-7
Description	3-1	Road Wheel and Tyre Balance.....	5-7
Suspension Arms.....	3-1	Static Balance	5-7
Anti-roll Bar	3-1	Dynamic Balance	5-7
Vertical Link.....	3-1	Road Wheel Nut Torque Tightening.....	5-7
Specifications	3-2	Tyre Pressure Sensing (Option)	5-8
Maintenance	3-2	Pressure Sensing with Winter Wheels and Tyres.....	5-8
Rear Suspension.....	3-2	Warnings	5-8
Removal.....	3-2	Display Unit	5-9
Installation	3-4	Display Panel	5-9
Anti-roll Bar	3-6	Connection and Normal Operation	5-9
Removal.....	3-6	System Programming	5-9
Installation	3-6	Level 1 Programming.....	5-9
Vertical link.....	3-7	Level 2 Programming.....	5-11
Removal.....	3-7	Level 3 Programming.....	5-11
Installation	3-8		

Suspension (04.00)

Road Wheel Alignment (04.00) Maintenance

Specifications

	Front	Rear
Toe (in)	2.5' ($\pm 2'$)	10' (+5' / -0')
Total Toe	5' ($\pm 4'$)	20' (+10' / -0')
Camber	-15' ($\pm 5'$)	-1° 30' ($\pm 5'$)
Cross Camber	0' ($\pm 10'$)	0' ($\pm 10'$)
Caster	5° (+30' / -15')	N/A
Cross Castor	0° ($\pm 15'$)	N/A
KPI	10° 51'	N/A
Bumpstop free travel	12.0 mm	14.5 mm
Normal Ride Height	2 x 68 kg (driver and passenger seat) + 14 kg in the boot + full fuel tank.	

Repair Operation Time (ROT)

Item	Code
All Wheel Alignment	04.00.AD

Refer to the geometry setup tool manufacture operating instructions.

Check vehicle geometry in the following order:

- 1 Caster Angle
- 2 Camber Angle
- 3 Toe

Adjustments to caster, camber and toe settings may impact each other. After checking/adjusting each setting, minor adjustments to caster, camber and toe may have to be made to reach the correct set up for the vehicle.


Both LH and RH Toe need to be adjusted when adjusting caster and camber.

Ride height is measured from the centre of the road wheel, vertically, up to the road wheel arch.

Check tyre pressures before checking road wheel alignment.

	Front	Rear
Ride Height	378.5mm (± 15 mm)	376.5mm (± 15 mm)

Wheel centre to wheel arch (front and rear)



Over time this vehicle's ride height will settle (up to 20mm). Therefore, as the vehicle ages, it's ride height will tend to sit towards the lower end of the ride height tolerance band. This needs to be taken into account when checking vehicle ride height.

Caster Angle

Adjustment (Front)

Check and if required adjust the camber angle. If the camber angle is correct but the caster angle is still incorrect, suspect damage to the suspension components.

*Ensure that the vehicle is at normal ride height.
Check tyre pressures.*

1. Check the caster settings. Follow the equipment manufacturer's instructions.
2. Release the cam bolt lock nuts.
3. Rotate the lower arm caster adjustment cam bolts.
4. When the caster angle is correct, tighten the cam bolt lock nuts.
5. Re-check alignment settings. Adjust if required.

Camber Angle

Adjustment

*Ensure that the vehicle is at normal ride height.
Check tyre pressures.*

1. Check the camber settings. Follow the equipment manufacturer's instructions.
2. Release the cam bolt lock nuts.
3. Rotate the lower arm camber adjustment cam bolt to adjust the camber angle.
4. Tighten the cam bolt lock nuts.
5. Re-check alignment settings. Adjust if required.

Toe

Adjustment (Front)


*Ensure that the vehicle is at normal ride height.
Check tyre pressures.*

1. Start the engine and centre the steering rack.
2. Turn the engine off. Lock the steering position.
3. Check the Toe settings. Follow the equipment manufacturer's instructions.

If Adjustment is Required.

4. Clean the lock nuts and the threads of the track-rod ends.

Do not allow the steering gear boot to twist when the track-rod ends are rotated. If required release the steering gear boot clamps.



01-11-003

5. Loosen the lock nuts and rotate the track-rod ends (in equal amounts) to adjust the Toe.
6. Tighten the lock nuts to **70 Nm.**, and re-check the Toe. Adjust if required.

When correct, secure the steering gear boot clamps (if released).

Adjustment (Rear)

*Ensure that the vehicle is at normal ride height.
Check tyre pressures.*

1. Check the toe settings. Follow the equipment manufacturer's instructions
2. Release the cam bolt lock nuts.
3. Rotate the toe control rod adjustment cam bolt to adjust the rear toe.
4. Tighten the lock nut.
5. Re check the Toe settings. Adjust if required.



ASTON MARTIN

Suspension (04.00)

Front Suspension (04.01)

Description

Suspension Arms

The upper suspension arm is attached to the body structure. The lower suspension arm is attached to the front subframe.

Each upper suspension arm has a press-fit ball joint, and two interleaved rubber bushes. Two bolts attach the upper suspension arm to the body structure.

Each lower suspension arm has a press fit ball joint and metal-to-rubber bonded bushes which are attached to the front subframe by two eccentric cam bolts (Camber and castor settings).

Anti-roll Bar

The anti-roll bar, is attached to the subframe in two positions by rubber bushes and clamps. The outer ends of the anti-roll bar are attached to the lower suspension arms by drop links. The anti-roll bar provides the required stiffness to control body roll.

Vertical link

The Vertical link (Knuckle Joint) swivels on the upper and lower suspension arms via ball joints, and carries the hub, a unit 3 wheel bearing (including the ABS encoder ring), the wheel speed sensor, the brake caliper, and the brake disc and shield. The position of the Vertical link is determined by the movement of the steering rack, which is connected to the Vertical link by the steering track rod.

Specifications

Torque Figures

Description		Nm	lb. / ft.
Brake dust shield.		9	7
Bearing Assembly to the Vertical link.		55	41
Vertical Link to the Lower Suspension Arm.		90	66.5
Vertical Link to the Upper Suspension Arm.		90	66.5
Track-rod End Lock Nut.		70	52
Vehicle Ride Height Sensor.	M8	22.5	17
	M5	9	7
Anti-roll Bar Link Nuts		110	81.5
Anti-roll Bar Mounting Bolts		22.5	17
Torque bolt 1, then bolt 2, then bolt 1 again (to allow for rubber compression)			

Torque the following suspension fixings with the vehicle at normal ride height

Lower Suspension Arm front bush to the Subframe	M14	185	137
Lower Suspension Arm rear bush to the Subframe.	M12	115	85
Upper Suspension Arm to the Front Structure		115	85
Spring and Damper Bolts	Top	22.5	17
	Lower	175	129.5

Normal ride height 2 x 68 kg + 14kg in the boot + full fuel tank.

Symptoms

Symptom	Possible Cause	Action
Crabbing	Front or rear suspension components / road wheel alignment	Inspect front and rear suspension systems. Check / adjust road wheel alignment
	Drive axle damaged	New drive axle.
Front 'Bottoming' or Riding Low	Spring(s)	Check ride height.
	Dampers	Check dampers.
Drift / Pull	Unequal tyre pressure	Check / adjust tyre pressures. Inspect tyre for excessive wear.
	Incorrect road wheel alignment	Check / adjust road wheel alignment.
	Tyres	Check / adjust tyre pressures. Inspect tyre for excessive wear.
	Unevenly loaded or overloaded vehicle	Notify customer of incorrect vehicle loading.
	Damaged steering components Brake drag	Check steering system for mechanical or hydraulic bias. Check brakes. Check steering system for mechanical or hydraulic bias.
Rough Ride	Spring(s)	Check springs.
	Shock absorber(s)	Check shock absorbers.
Incorrect Tyre Wear	Incorrect tyre pressure	Check and adjust tyre pressure. Inspect tyre for excessive wear.
	Excessive front or rear Toe (rapid inner or outer edge wear)	Check and adjust road wheel alignment (Refer to 'Road Wheel Alignment (04.00)', page 4-0-2).
	Excessive negative or positive camber (rapid or outer edge wear)	Check and adjust road wheel alignment (Refer to 'Road Wheel Alignment (04.00)', page 4-0-2).
	Tyres out of balance (tyres cupped or dished)	Balance tyres.
'Shimmy' or 'Road Wheel Tramp'	Loose road wheel nut(s)	Check and tighten road wheel nuts to specification.
	Loose front suspension	Check and tighten suspension fixings to specification.
	Front road wheel bearing(s)	Check road wheel bearings.
	Road wheel / tyres	Check road wheels / tyres.
	Shock absorber(s)	Check shock absorbers.
	Spring(s)	Check springs.
	Loose, worn or damaged ball joint(s)	Check ball joint(s) (Refer to 'Ball Joints', page 4-1-4).
	Loose, worn or damaged steering components	Check components.
Front road wheel alignment	Check and adjust road wheel alignment (Refer to 'Road Wheel Alignment (04.00)', page 4-0-2).	
	Worn or damaged suspension bushes	Check suspension bushes
Poor 'Return ability' of Steering	Ball joints	Check ball joint(s).
	Steering components	Check for excessive friction in steering system. Check tyre pressures
Steering Wheel Off-Centre	Unequal front or rear Toe settings	Check and adjust road wheel alignment.
	Steering components	Check and install new components as required.
Sway or Roll	Overloaded, unevenly or incorrectly loaded vehicle	Notify customer of incorrect vehicle loading
	Loose road wheel nut(s)	Check. Tighten road wheel nut(s) to specification
	Spring(s)	Check. Install new springs as required.
	Shock absorber(s)	Check. Install new shock absorbers as required.
	Loose front stabilizer bar or rear stabilizer bar	Check. Tighten anti-roll bar to specification.

Symptom	Possible Cause	Action
Vibration / Noise	Tyres / road wheel Road wheel bearing assemblies Brake components Suspension components Spring and damper units Steering components	Check. Install new components as required.
Vehicle Leans to One Side	Unevenly loaded or overloaded vehicle Front or rear suspension components Spring and damper assemblies Incorrect ride height. Lateral tilt out of specification Suspension bushes not torqued at ride height	Notify customer of incorrect vehicle loading. Inspect front and rear suspension systems. Check spring and damper assemblies. Check ride height. Check / adjust suspension bushes torque.
Wander	Unevenly loaded or overloaded vehicle Ball joint(s) Front road wheel bearing(s) Loose, worn or damaged suspension components Loose suspension fasteners Steering components Road wheel alignment (excessive total front Toe-out)	Notify customer of incorrect vehicle loading. Check ball joint(s) (Refer to 'Ball Joints', page 4-1-4). Check road wheel bearings. Check suspension components. Check and tighten suspension fasteners to specification. Check steering components for wear and / or free play. Check / adjust road wheel alignment (Refer to 'Road Wheel Alignment (04.00)', page 4-0-2).

Maintenance

Caution

Treat the suspension components with care. The suspension components are liable to damage if struck with, e.g. a metal faced hammer.

Road Wheel Bearing

Inspection

1. Raise and support the vehicle.
2. Make sure the road wheel rotates freely and that the brake pads are sufficiently retracted, allowing free movement of the road wheel.
3. Firmly grasp the road wheel at the top and bottom. Attempt to move the road wheel inward / outward while lifting the weight of the road wheel off the road wheel bearing.
Observe upper and lower ball joints for movement.
4. If there is any excess movement in the road wheel bearing, replace the bearing assembly.



01-04-127


Ball Joints

Inspection

1. Raise and support the vehicle.

Prior to carrying out any inspection of the ball joints, inspect the road wheel bearings.

2. Pull and push the bottom of the road wheel. Check for any relative movement between the ball joint and the lower suspension arm.
Install new components if required.



01-04-128

3. Pull and push the top of road wheel. Check the relative movement between the ball joint and the upper suspension arm.
Install new components as required.
4. Lower the vehicle.

Front Suspension


Repair Operation Time (ROT)	
Item	Code
Upper Suspension Arm	(LH) 04.01.NB
	(RH) 04.01.PB
Lower Suspension Arm	(LH) 04.01.LB
	(RH) 04.01.MB
Vertical link	(LH) 04.01.GB
	(RH) 04.01.HB
Spring and Damper Unit	(LH) 04.03.AB
	(RH) 04.03.BB
Anti-roll Bar	04.01.AB

Caution

Treat the suspension components with care. The suspension components are liable to damage if struck with, e.g. a metal faced hammer.


Removal

1. Raise the vehicle and make safe.
2. For each affected wheel station remove the road wheel(s).
3. Remove the brake caliper (bolts x2). Move the brake caliper to one side and secure.




01-04-006

4. Disconnect the ABS sensor wiring harness plug.



01-04-007

5. Disconnect the vehicle ride height sensor.




01-04-008


6. Using service tool (Refer to '204-523 (Ball Joint Splitter)', page 20-1-3), remove the track rod-end.
8. If required, remove the hub from the vertical link.

Caution
Do not use a hammer, etc., to 'shock' the track rod-end.


Take care not to damage the ball joint boot.



7. Remove the upper suspension arm and vertical link as a unit.
- 7.1 Remove bolts (x2) that secure the upper suspension arm to the body structure.



- 7.2 Using service tool (Refer to '204-523 (Ball Joint Splitter)', page 20-1-3), remove the vertical link from the lower suspension arm.




- 7.3 If required separate the upper suspension arm from the vertical link.

- 8.1 Remove bolts (x4).



- 8.2 Press the hub from the vertical link.
- 8.3 Remove the brake dust shield (bolts x4).




9. Remove the spring and damper assembly.

Caution
Ensure the damper is fully extended.


If removing both spring and damper units - the engine bay cross brace will be released.

9.1 Remove nuts (x3) from the top of the spring and damper assembly.


Remove Nuts x3




9.2 Remove the spring and damper assembly lower mounting bolt.



10. Disconnect the anti-roll bar link assembly.



11. Remove bolts (x2) that secure the lower suspension arm to the subframe. Withdraw the lower suspension arm.




Installation

Caution


Final tightening of the suspension components must be carried out with the suspension arms at normal ride height. Failure to do this will over stress the suspension bushes when the suspension is deflected to max. upward travel.

1. Install the lower suspension arm to the subframe. Do not torque.
2. Place the engine bay cross brace, complete with mounts, in position. Install the spring and damper assembly. Do not torque bolts.



3. Install the bearing assembly to the vertical link (if removed).

3.1 Install the brake dust shield. Torque bolts (x3) to **9 Nm**.




3.2 Install the bearing assembly. Torque bolts to **55 Nm**.



4. Install the anti-roll bar link assembly to the lower arm. Torque to **110 Nm**.

Ensure that the washer installs as shown below.



5. Install the upper suspension arm to the vertical link, if removed. Torque nut to **90 Nm**.

6. Install the vertical link to the lower suspension arm. Torque nut to **90 Nm**.

7. Install the upper suspension arm to the body structure. Do not torque.

8. Install the track-rod end. Torque nut to **70 Nm**.



9. Install the vehicle ride height sensor (LH side). Torque nut to **22.5 Nm**.

10. Install the ABS sensor wiring harness plug.

11. Install the brake caliper (Refer to 'Brake Caliper (Front and Rear)', page 6-3-2).

Torque bolts to **20 Nm + 66°-70°**

12. Torque the suspension fixings with the vehicle at normal ride height (Refer to 'Specifications', page 4-1-1):

- Lower suspension arm to the subframe (rear bush) - **185 Nm**.
- Lower suspension arm to the subframe (front bush) - **115 Nm**.
- Upper suspension arm to the front structure - **115 Nm**.
- Spring and damper bolts to (top) **25.5 Nm**. (bottom) **175 Nm**.

The engine bay cross brace must be torqued with the weight of the vehicle on the roadwheels.

13. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).

14. Check / adjust the Camber, Castor and Toe settings.


Anti-roll Bar

Repair Operation Time (ROT)

Item	Code
Anti-roll Bar Renew	04.01.AB

Removal


1. Raise the vehicle and make safe.
2. For each affected wheel station remove the road wheel(s).
3. Remove the front undertray.
4. Remove the anti-roll bar from the anti-roll bar drop links.



5. Remove the anti-roll bar mountings (strap and bush) from the subframe and withdraw the anti-roll bar.

Installation

1. Place the anti-roll bar in position and install the stabiliser mountings.





2. Connect the anti-roll bar to the anti-roll bar drop links. Torque the fixings.

- Anti-roll bar mounting bolts to **22.5 Nm**.

Torque bolt 1, then bolt 2, then bolt 1 again (to allow for rubber compression)

- Anti-roll bar link nuts to **110 Nm**.

Ensure that the washer installs as shown below.




3. Install the front undertray.
4. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).

Vertical Link


Repair Operation Time (ROT)	
Item	Code
Vertical link Renew	(LH) 04.01.GB
	(RH) 04.01.HB

Removal

1. Raise the vehicle and make safe.
2. For each affected wheel station remove the road wheel(s).
3. Remove the brake caliper bolts (x2). Move the brake caliper to one side and secure.



4. Disconnect the ABS sensor wiring harness plug.
5. Remove the track-rod end.



6. Separate the lower suspension arm from the vertical link
 - 6.1 Install service tool (Refer to '204-524 (Front Suspension Support)', page 20-1-3). Lower the vehicle until the lower suspension arm is horizontal.
 - 6.2 Using a service tool (Refer to '204-523 (Ball Joint Splitter)', page 20-1-3) part the lower suspension arm from the Vertical link.


Caution

Do not use a hammer, etc., to 'shock' the track rod-end.

Take care not to damage the ball joint boot.

- 6.3 Raise the vehicle and remove the service tool (Refer to '204-524 (Front Suspension Support)', page 20-1-3).

7. Disconnect the upper suspension arm from the vertical link.



Installation

1. Install the vertical link to the lower suspension arm. Torque bolt to **90 Nm**.
2. Install the vertical link to the upper suspension arm. Torque bolt to **90 Nm**.
3. Install the track-rod end. Torque nut to **70 Nm**.
4. Connect the ABS sensor wiring harness plug.
5. Install the brake caliper (Refer to 'Brake Caliper (Front and Rear)', page 6-3-2). Torque bolts to **20 Nm + 66°-70°**.
6. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
7. Check / adjust the Camber, Caster and Toe settings.




ASTON MARTIN

Suspension (04.00)

Rear Suspension (04.02)

Description



Suspension Arms

The upper suspension arms are each installed with a press-fit ball joint, and two interleaved rubber bushes. Two bolts attach each upper suspension arm to the rear subframe.

The lower suspension arms each have press fit ball joints installed and metal-to-rubber bonded bushes which are attached to the rear subframe by two eccentric cam bolts.

The camber setting is adjusted by rotating the lower suspension arm rear eccentric cam bolt.

Anti-roll Bar

An anti-roll bar, mounted on the rear subframe connects to the LH and RH lower suspension arms via drop links. The drop links, with a ball joint at either end, transmit vertical movement of the rear suspension to the anti-roll bar, minimising body roll.

Vertical Link

The vertical link carries the hub, the cartridge wheel bearing, the ABS rotor, the wheel speed sensor, the brake caliper, the hand brake caliper and the brake disc and shield.

A toe control (track-rod) arm secures the rear of the vertical link to the subframe. The toe control arm is adjustable, on an eccentric cam, to alter the rear road wheel toe alignment.

Specifications

Torque Figures

Description	Nm	lb. / ft.
Brake Dust Shield.	9	7
Bearing Assembly to the Vertical link.	50	37
Halfshaft Nut	300	221.5
Spring and Damper Bracket Mounting	75-80	55.5-59.5
Spring and Damper Top Mounting to Bracket	22.5	17
Spring and Damper Lower Mounting	175	129.5
Track rod Arm to Vertical Link	115	85
Anti-roll Bar Link	110	81.5
Anti-roll Bar Mounting Bolts	30	22.5
Torque bolt 1, then bolt 2, then bolt 1 again (to allow for rubber compression)		
Ride Height Sensor	M8 22.5	
Torque the following suspension fixings with the vehicle at normal ride height		
Vertical Link to the Lower Suspension Arm.	175	129.5
Vertical Link to the Upper Suspension Arm.	90	66.5
Lower Suspension Arm to the Subframe.	115	85
Upper Suspension Arm to the Subframe	115	85
Track-Rod Arm to Subframe	115	85

Normal ride height: 2 x 68 kg + 14kg in the boot + full fuel tank.

Maintenance

For details on:


- Alignment (Refer to 'Road Wheel Alignment (04.00)', page 4-0-2)
- Inspections (Refer to 'Suspension (04.00)', page 4-1-1)
- Symptoms
- Road Wheel Bearing Procedures
- Ball Joints Procedures

Rear Suspension


Repair Operation Time (ROT)	
Item	Code
Upper Suspension Arm Renew	(LH) 04.02.RB
	(RH) 04.02.SB
Lower Suspension Arm Renew	(LH) 04.02.NB
	(RH) 04.02.PB
Vertical link Renew	(LH) 04.02.GB
	(RH) 04.02.HB
Spring and Damper Unit Renew	(LH) 04.03.CB
	(RH) 04.03.DB
Anti-roll Bar Renew	04.02.AB

Removal


1. Raise the vehicle and make safe.
2. For each affected wheel station remove the road wheel(s).
3. Remove the bolts securing the service brake and handbrake calipers to the vertical link. Move the calipers to one side and secure.




01-04-130




- Remove the halfshaft nut.




- Disconnect the ABS sensor wiring harness plug.



- Remove the anti-roll bar drop links.



- Disconnect the vehicle height sensor (LH side).




- Remove the bolt that secures the track-rod arm to the vertical link.
- Remove the bolt that secures the upper suspension arm to the vertical link.
- Press the halfshaft from the vertical link.
- Remove the bolt that secures the vertical link to the lower suspension arm.


12. If required, remove the bearing assembly from the vertical link.

12.1 Remove bolts (x4) that secure the bearing assembly to the vertical link.


12.2 Press the bearing assembly from the vertical link.



14. Remove the upper suspension arm.




15. Remove the lower suspension arm.




13. Remove the spring and damper assembly.

Ensure the damper is fully extended.

13.1 Remove the bolts (x4) from the spring and damper assembly upper mounting bracket.



13.2 Remove the bolt from the lower spring and damper mounting. Withdraw the spring and damper assembly.




Installation

1. Install the lower suspension arm to the rear subframe. Do not torque.
2. Install the spring and damper assemblies. Torque to:
 - Top mounting bracket bolts (x4) - **75-80 Nm.**
 - Bottom mounting bolt - **175 Nm.**
3. Install the upper suspension arm to the subframe. Do not torque.

4. Install the bearing assembly (if removed).

- Bearing bolts to **50 Nm**.
- Dust shield bolts to **9 Nm**.





9. Install the service brake and the handbrake calipers. Torque bolts to:


- Service brake caliper to **20 Nm. + 66°-70°**
- Handbrake caliper to **15 Nm. + 90°-94°**

10. Install the anti-roll bar drop link. Torque to **110 Nm**.

Ensure that the washer is installed between the nut and the anti-roll bar.



5. Install the vertical link. Do not torque bolts.



11. Install the vehicle ride height sensor (LH side).

Torque nut to - **22.5 Nm**.

12. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).

6. Install the track-rod end. Do not torque.

7. Connect the ABS sensor wiring harness plug.



8. Install the halfshaft nut. Torque to **300 Nm**.

Caution

Final tightening of the suspension components must be carried out with the suspension arms at normal ride height. Failure to do this will over stress the suspension bushes when the suspension is deflected to max. upward travel.

13. Torque the suspension fixings with the vehicle at normal ride height (Refer to 'Specifications', page 4-0-2).

- Lower suspension arm to the subframe - **115 Nm.**
- Vertical link to the lower suspension arm - **175 Nm.**
- Upper suspension arm to the vertical link - **115 Nm.**
- Upper suspension arm to the subframe - **115 Nm.**
- Track-rod end to vertical link - **115 Nm.**
- Track-rod arm to subframe - **115 Nm.**




Anti-roll Bar

Repair Operation Time (ROT)	
Item	Code
Anti-roll Bar Renew	04.02.AB

Removal

1. Remove the rear under tray.
2. Disconnect the anti-roll bar link assembly from the lower arm (x2).



3. Remove the bolts (x2) from the bush strap (x2).
4. Withdraw the anti-roll bar.

Installation


Caution

Final tightening of the suspension components must be carried out with the suspension arms at normal ride height. Failure to do this will over stress the suspension bushes when the suspension is deflected to max. upward travel.

1. Place the anti-roll bar in position.
 - 1.1 Install both bush straps (bolts x4). Do not torque.

Caution

The anti-roll bar must be installed with the cut off section at the top.



- 1.2 Secure both ends of the anti-roll bar link assembly to the lower arm (bolts x2).

Torque the fixings.


- Anti-roll bar mounting bolts to **30 Nm.**

Torque bolt 1, then bolt 2, then bolt 1 again (to allow for rubber compression)

14. Check / adjust the Camber and Toe settings.

- Anti-roll bar link nuts to **110 Nm**.

Ensure that the washer installs between the stud and the suspension arm.



2. Install the rear undertray.




Vertical link

Repair Operation Time (ROT)	
Item	Code
Vertical link Renew	(LH) 04.02.GB
	(RH) 04.02.HB


Removal

1. Raise the vehicle and make safe.
2. For each affected wheel station remove the road wheel(s).
3. Remove the service brake and handbrake calipers. Move the calipers to one side and secure.

5. Disconnect the ABS sensor wiring harness plug.




6. Disconnect the track-rod arm.




4. Remove the halfshaft nut.

7. Disconnect the upper suspension arm.




7. Install the halfshaft nut. Torque to **300 Nm**.



8. Press the halfshaft from the vertical link.
9. Remove the Vertical link from the lower suspension arm.

Installation

1. Install the vertical link to the lower suspension arm.
2. Install the halfshaft through the vertical link.
3. Install the vertical link to the upper suspension arm.
4. Torque the following:
 - Vertical link to the **lower** suspension arm - **175 Nm**.
 - Vertical link to the **upper** suspension arm - **115 Nm**.
5. Install the track-rod arm. Torque to - **115 Nm**.



8. Install the service brake and the handbrake calipers (Refer to 'Brake Caliper (Front and Rear)', page 6-3-2). Torque bolts to:
 - Service brake caliper to **20 Nm. + 66°-70°**
 - Handbrake caliper to **15 Nm. +90°- 94°**
9. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
10. Check / adjust the Camber and Toe settings.

6. Connect the ABS sensor wiring harness plug.

Suspension (04.00)

Shock Absorber System (04.03)

Description

Movement of each road spring is independently damped by a telescopic, hydraulically-controlled shock absorber. Each shock absorber is installed coaxially within the road spring. Front spring and damper assemblies are located between the upper suspension arm and attach to the lower suspension arm and the body structure.

Rear spring and damper assemblies attach to the lower suspension arm and the rear subframe, via a mounting bracket, laying to the rear of the upper suspension arm.

Specifications

Torque Figures		
Description	Nm	lb. / ft.
Front		
Spring and Damper Top Mounts	22.5	17
Spring and Damper Bottom Mount	175	129.5
Upper Suspension Arm	115	85
Rear		
Spring and Damper Bracket Mounting	75-80	55.5-59.5
Spring and Damper Top Mounting to Bracket	22.5	17
Spring and Damper Lower Mounting	175	129.5
Vertical Link to Lower Suspension Arm	175	129.5
Track-rod Arm to Lower Suspension Arm	115	85

Maintenance (Front)

Spring and Damper Assembly

Repair Operation Time (ROT)	
Item	Code
Spring and Damper Unit Renew	(LH) 04.03.AB
	(RH) 04.03.BB

Removal

1. Raise the vehicle and make safe.
2. For each affected wheel station remove the road wheel(s).
3. Disconnect the ABS sensor wiring harness plug.

4. Remove the upper suspension arm from the body structure.

Allow the upper suspension arm and the Vertical link to fall back, giving access to the spring and damper assembly.

Caution


Ensure the brake flex hose is not over stretched.

Ensure the spring and damper assembly is fully extended.

5. Remove the spring and damper top mount nuts (x3).

If removing both spring and damper units - the engine bay cross brace will be released.

6. Remove the lower mounting nut and bolt. Withdraw the spring and damper assembly.



Installation

If removed, place the engine bay cross brace, complete with mounts, in position.

Caution

Ensure the brake flex hose is not over stretched.

1. Install the spring and damper unit. Do not torque bolts.

The engine bay cross brace mount must be torqued with the weight of the vehicle on the roadwheels.

2. Install the upper suspension arm. Do not torque.
3. Connect the ABS sensor wiring harness plug.
4. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).



Caution

Final tightening of the suspension components must be carried out with the full weight of the vehicle on its road wheels. Failure to do this will over stress the suspension bushes when the suspension is deflected to max. upward travel.

5. Torque the suspension fixings with the vehicle at normal ride height:

- Upper suspension arm to the front structure - **115 Nm**.
- Spring and damper bolts to (top) **22.5 Nm**.
(bottom) **175 Nm**.

The engine bay cross brace must be torqued with the weight of the vehicle on the roadwheels.




Maintenance (Rear) Spring and Damper Assembly

Repair Operation Time (ROT)	
Item	Code
Spring and Damper Unit Renew	(LH) 04.03.CB
	(RH) 04.03.DB


Removal

1. Raise the vehicle and make safe.
2. For each affected wheel station remove the road wheel(s).
3. Remove the track-rod arm bolt.




Ensure the spring and damper assembly is fully extended.


4. Remove the bolt from the lower spring and damper mounting.




5. Disconnect the ABS sensor wiring harness plug.



6. Remove the vertical link lower bolt.




7. Remove the bolts (x4) from the spring and damper assembly upper mounting.




8. Withdraw the spring and damper assembly.

Installation


1. Install the spring and damper assembly upper mounting bracket. Torque bolts (x4) to 75-80 Nm.



2. Install the spring and damper assembly to the lower suspension arm. Torque bolt to **175 Nm**.



3. Install the vertical link to the lower suspension arm. Torque to **175 Nm**.
4. Install the track-rod arm. Torque to **115 Nm**.



5. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
6. Check / adjust the Camber and Toe settings.

Suspension (04.00)

Road Wheels and Tyres (04.04) Specifications

⚠ WARNING ⚠
DO NOT MIX DIFFERENT TYPES OF TYRES ON THE SAME VEHICLE SUCH AS RADIAL, BIAS OR BIAS BELTED TYRES EXCEPT IN EMERGENCIES (TEMPORARY SPARE USAGE).

⚠ WARNING ⚠
NEVER RUN THE ENGINE WITH ONE WHEEL OFF THE GROUND, FOR EXAMPLE WHEN CHANGING A WHEEL. THE WHEEL RESTING ON THE GROUND MAY CAUSE THE VEHICLE TO MOVE.

⚠ WARNING ⚠
AFTER MARKET AEROSOL TYRE SEALANTS ARE EXTREMELY FLAMMABLE. ALWAYS QUESTION THE CUSTOMER TO MAKE SURE THESE PRODUCTS HAVE NOT BEEN USED.

⚠ WARNING ⚠
ALWAYS WEAR SAFETY GOGGLES OR A FACE SHIELD WHEN PERFORMING ANY WORK WITH WHEEL AND TYRE ASSEMBLIES.

⚠ WARNING ⚠
CHECK ROAD WHEEL NUTS TORQUE AT 32 KM (20 MILES) AFTER ANY WHEEL CHANGE OR ANY TIME THE WHEEL NUTS ARE LOOSENEED.

⚠ WARNING ⚠
WHEN CHANGING A WHEEL, MAKE SURE THAT THE VEHICLE CANNOT MOVE. ALWAYS APPLY THE PARKING BRAKE AND SELECT THE TRANSMISSION PARK POSITION (AUTOMATIC TRANSMISSION ONLY).

⚠ WARNING ⚠
REDUCE AIR PRESSURE AS MUCH AS POSSIBLE BY PUSHING THE VALVE CORE PLUNGER IN BEFORE REMOVING THE VALVE CORE.

⚠ WARNING ⚠
EACH INDIVIDUAL AXLE, ROAD WHEEL AND TYRE HAS ITS OWN MAXIMUM WEIGHT OR TYRE INFLATION RATING. DO NOT OVERLOAD OR OVER-INFLATE BEYOND THE CAPACITY OF THE LOWEST RATED COMPONENTS OF THE SYSTEM.

Caution
Do not clean the aluminium alloy wheels with steel wool, abrasive type cleaners or detergents. Failure to follow these instructions may result in damage to the vehicle.

Caution
Paraffin (kerosene) must not be used as a cleansing agent on tyres.

Tyres

The tyres recommended by Aston Martin meet the high speed performance of this vehicle. Only tyres of identical specification may be installed as replacements. Under no circumstances must cross-ply tyres be installed.

⚠ WARNING ⚠
CORRECT TYRE INSTALLATION IS CRITICAL TO PERSONAL AND VEHICLE SAFETY. THE RECOMMENDED TYRES FOR THIS VEHICLE ARE ASYMMETRICAL AND MUST BE INSTALLED TO THE WHEEL WITH THE TYRE MARK 'OUTSIDE' ON THE OUTSIDE OF THE WHEEL RIM.

Unique Aston Martin lightweight aluminium alloy road wheels.

- Front - 8.5J x 19
- Rear - 9.5J x 19

The tyres are made exclusively for Aston Martin.

- Front - Bridgestone 235/40 ZR 19
- Rear - Bridgestone 275/35 ZR 19

Tyre Pressures

Tyre pressures must be checked with the tyres cold.

⚠ WARNING ⚠
PDI INSPECTION.
TYRE PRESSURES MUST BE REDUCED TO NORMAL LEVEL DURING PDI. THE VEHICLE MUST NEVER BE RUN ON ROAD WITH ELEVATED TYRE PRESSURES, DRIVEABILITY MAY BE SERIOUSLY COMPROMISED.

Caution
In order to protect tyres against flat spots during storage and transportation, tyre pressures should be increased to 65 - 70 psi (450 - 500 kPa). Ensure that the tyre pressure are set to the recommended tyre pressures before driving.

- Front - 2.5 bar (250 kpa / 36 psi)
- Rear - 2.6 bar (260 kpa / 38 psi)

Torque Figures

Description	Nm	lb/ft
Road wheel nuts:		
Step 1 for all Wheel Nuts	80	60
Step 2 for 22 mm Wheel Nuts	135	100
Step 2 for Titanium Wheel Nuts	150	111
Step 2 for 21 mm Wheel Nuts	180	133

USA Tyre Gradings

The following information relates to the tyre grading system developed by the National Highway Traffic Safety Administration which grades tyres by tread wear, traction and temperature performance.

Tread Wear

Tread wear grade is a comparative rating based on the wear rate of the tyre when tested under controlled conditions (specified government test course). For example, a tyre graded 150 would wear one and a half times less on the government course than a tyre graded 100. Relative performance of the tyres depends upon actual conditions of use and may depart significantly from normal due to variations in driving habits, service practices and differences in road characteristics and climate.

Traction

Traction grades, A (highest), B and C represent a tyre's ability to stop in wet conditions measured on specified government test surfaces of asphalt and concrete.

⚠ WARNING ⚠
PDI INSPECTION.
TRACTION GRADE IS BASED ON BRAKING (STRAIGHT AHEAD) TRACTION TESTS AND DOES NOT INCLUDE CORNERING (TURNING) TRACTION.

Temperature

Temperature grades, A (highest), B and C, represent a tyre's resistance to the generation of wear and its ability to dissipate heat when tested under controlled conditions (specified indoor laboratory test road wheel). Sustained high temperature can cause the material of a tyre to degenerate and reduce tyre life; excessive temperatures can lead to sudden tyre failure. Grade 'C' corresponds to a level of performance which all passenger vehicle tyres must meet under Federal Motor Vehicle Safety Standard No. 109. Grades 'B' and 'A' represent higher levels of performance than the minimum required by law.

⚠ WARNING ⚠
TEMPERATURE GRADE IS ESTABLISHED FOR A TYRE THAT IS PROPERLY INFLATED AND NOT OVERLOADED. EXCESSIVE SPEED, UNDER INFLATION OR EXCESSIVE LOADING, WHETHER SEPARATELY OR IN COMBINATION, CAN CAUSE HEAT BUILD-UP AND POSSIBLE TYRE FAILURE.

Maintenance

Factory installed tyres and road wheels are designed to operate satisfactory when inflated to the recommended inflation pressures (Refer to 'Inspection and Verification', page 4-4-3). The recommended pressures apply to vehicle loads up to and including the full-rated load capacity.

Correct tyre pressures and driving technique have an important influence on tyre life. Heavy cornering, excessively rapid acceleration and unnecessary sharp braking increase tyre wear.

Replacement tyres should follow the recommended:

- Size
- Load range
- Speed rating
- Radial construction type

The use of any other size or type may seriously affect:

- Safety
- Vehicle ground clearance
- Ride
- Tyre clearance between body and chassis
- Handling
- Wheel bearing life
- Speedometer and Odometer calibration
- Brake cooling

Wheels need to be renewed when:

- Impact damaged
- Wheel stud holes or seats become damaged
- Heavily corroded
- They have excessive radial or lateral runout.
- Porous

Safety

⚠ WARNING ⚠
DO NOT MIX DIFFERENT TYPES OF TYRES ON THE SAME VEHICLE. HANDLING MAY BE SERIOUSLY AFFECTED RESULTING IN LOSS OF CONTROL.

⚠ WARNING ⚠
ENSURE THAT TYRES ARE MOUNTED WITH THE SIDEWALL MARKING 'OUTSIDE' SHOWING ON THE OUTER SIDEWALL FACE.
CORRECT TYRE ROTATIONAL DIRECTION IS CRITICAL.

⚠ WARNING ⚠
A TYRE AND WHEEL MUST ALWAYS BE CORRECTLY MATCHED. WIDER OR NARROWER TYRES THAN RECOMMENDED COULD CAUSE DANGER THROUGH SUDDEN DEFLATION.

⚠ WARNING ⚠
WHEN CHANGING A WHEEL, MAKE SURE THAT THE VEHICLE CANNOT MOVE. ALWAYS APPLY THE PARKING BRAKE AND SELECT THE TRANSMISSION PARK POSITION (AUTOMATIC TRANSMISSION ONLY).

⚠ WARNING ⚠
NEVER RUN THE ENGINE WITH ONE WHEEL OFF THE GROUND, FOR EXAMPLE, WHEN CHANGING THE WHEEL. THE WHEEL RESTING ON THE GROUND MAY CAUSE THE VEHICLE TO MOVE.

⚠ WARNING ⚠

ALWAYS TIGHTEN THE WHEEL NUTS TO SPECIFICATION. TOO TIGHT MAY CAUSE DAMAGE, TOO LOOSE MAY ALLOW THE WHEEL TO BECOME DETACHED.

⚠ WARNING ⚠

USE ONLY WHEELS AND WHEEL NUTS SUPPLIED BY ASTON MARTIN. AFTER MARKET WHEELS OR WHEEL NUTS MAY NOT INSTALL OR FUNCTION CORRECTLY AND COULD CAUSE INJURY OR DAMAGE.

Tyre Replacement and Wheel Interchanging

Caution

When a new tyre is installed, always renew the tyre valve.

When replacement of tyres is required it is preferable to install a complete vehicle set. Should either the front or rear tyres only show excessive wear, new tyres must be installed to replace worn ones. Under no circumstances interchange tyres from side to side, front to rear or vice versa as individual tyre wear produces unique characteristics depending upon their position. If the position is changed after wear has occurred, the performance of the tyre will be adversely affected.

New tyres must be balanced before installing to the vehicle.

Winter (Snow) tyres

Winter tyres must only be installed in complete four-wheel sets of the same type. The maximum speed with winter tyres installed (without snow chains) is 210 km/h (131 mile/h) for H rated tyres or 240 km/h (149 mile/h) for V rated tyres.

When using snow chains, note that:

- Snow chains must only be installed to the rear wheels
- Only Aston Martin snow chains should be used
- Snow chains must not be used on roads which are clear of snow
- The maximum speed with winter tyres and snow chains fitted is 48 km/h (30 mile/h)
- Traction control must be switched Off when using snow chains

Inspection and Verification

Verify the customer's concern by driving the vehicle.

Visually inspect for obvious signs of damage:

Visual Inspection Chart

- | | |
|---|--|
| • Incorrect tyre pressure | • Ply separation |
| • Wheel imbalance | • Embedded objects |
| • Bulges (blister) | • Impact damage |
| • Cuts | • Incorrect speed rating |
| • Abrasions | • Incorrect load rating |
| • Tyres worn beyond tread wear indicators | • Tyres installed with the 'Outside' marking not shown |

- 1 If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.
- 2 If the concern is not visually evident, verify the symptom and refer to Symptom Chart.

Tyre Wear

Tread wear indicators (A) are moulded into the bottom of the tread grooves across the width of the tyre. When the tread wear indicators become visible at the surface of the tread, in two or more adjacent tread grooves, only 1.6 mm of tread remains.



Tyre tread depth and condition must comply with prevailing local legislation.

To maximize tyre performance, inspect the tyres for signs of incorrect inflation and uneven wear which may indicate a need for balancing, rotation or front suspension alignment. Tyres should also be checked frequently for cuts, stone bruises, abrasions, blisters, and for objects that may have become embedded in the tread. More frequent inspections are recommended when rapid or extreme temperature changes occur or when road surfaces are rough or occasionally littered with debris.

Tyre Wear Diagnosis

New tyres should be installed if the wear indicators are exposed or if there is severe shoulder wear. Shoulder wear is usually caused by either excessive camber or excessive toe on radial tyres.

Sometimes incorrect rear toe settings or damaged struts will cause severe 'cupping' or 'scalloped' tyre wear on non-drive wheels.

Incorrect rear toe alignment will also cause other unusual wear patterns.

Road Test

A tyre vibration diagnostic procedure always begins with a road test. The road test and customer interview (if available) will provide much of the information needed to find the source of a vibration.

During the road test, drive the vehicle on a road that is smooth and free of undulations. If vibration is apparent, note and record the following:

- The speed at which the vibration occurs
- What type of vibration occurs in each speed range
- How the vibration is affected by changes in the following types of vibration-sensitivity:

Torque Sensitive - This means that the condition may be improved or made worse by accelerating, decelerating, coasting, maintaining a steady vehicle speed or applying engine torque.

Vehicle Speed Sensitive - This means that the vibration always occurs at the same vehicle speed and is not affected by engine torque, engine speed or the transmission gear selected.

Engine Speed Sensitive - This means that the vibration occurs at varying vehicle speeds when a different transmission gear is selected. It may sometimes be isolated by increasing or decreasing engine speed with the transmission in NEUTRAL or by stall testing with the transmission in gear. If the condition is engine speed sensitive, the cause is probably not related to the tyres.

If the road test indicates that there is tyre whine, but no shake or vibration, the noise originates with the contact between the tyre and the road surface.

A thumping noise usually means that the tyre has a flat or soft spot making a noise as they slap the roadway. Tyre whine may be distinguished from axle noise. Tyre whine remains the same over a range of speeds.

Symptoms

Symptom	Possible Source(s):	Action(s)
Tyres show excess wear on edge of treads	Tyres under-inflated Vehicle overloaded	Correct pressure to specification. Correct as required.
Tyres show excess wear on edge of treads (having the correct tyre pressures)	Incorrect toe setting	Set to specification.
Tyres show excess wear in center of tread	Tyres over-inflated	Correct pressure to specification.
Other excessive tyre wear problems	Incorrect tyre pressure Incorrect tyre and wheel usage Geometry out of alignment Loose, worn or damaged suspension components Wheel and tyre assembly out of balance Excessive lateral or radial runout of wheel or tyre	Correct pressure to specification. Install correct tyre and wheel combination. Check and adjust. Inspect, repair or install new suspension components as necessary. Balance wheel and tyre assembly. Check, repair or install a new wheel or tyre as necessary.
Wheel mounting is difficult	Incorrect application or mismatched parts, including wheel studs and wheel nuts. Corroded, worn or damaged parts	Clean or install new parts.
Wobble or shimmy affecting wheel runout	Damaged wheel (eventually damaging wheel bearings and causing uneven tyre wear)	Inspect wheel rims for damage and runout. Install a new wheel rim as necessary.
Excessive vibration, rough steering or severe tyre wear	Loose or incorrect attaching parts	Tighten or install new parts.

Symptom	Possible Source(s):	Action(s)	
Vehicle vibrations	Tyres and wheels mismatched	Install correct tyre and wheel combination.	
	Inflation pressure too high or too low	Correct pressure to specification	
	Uneven tyre wear	Refer to Diagnosis and Testing.	
	Out-of-balance wheel, tyre, wheel hub or disc assembly	Determine the out-of-balance component and balance or install a new part.	
	Damaged or distorted wheel from road impact hazard or incorrect handling	Install a new wheel.	
	Excessive radial runout	Install a new wheel or tyre. Check for incorrect wheel and tyre specifications.	
	Excessive lateral runout	Install a new wheel or tyre.	
	Incorrectly seated tyre	Remount the tyre.	
	Loose wheel mountings - damaged wheel studs, wheel nuts, worn or broken wheel hub face or foreign material on mounting faces	Tighten or install new parts. Clean mounting surfaces.	
	Defective wheel bearings	Install a new bearing set.	
	Brake disc imbalance		
	Water in tyres	Remove water.	
		Loose engine or transmission mounts	Install new mount nuts / install new mounts.
		Incorrect front end alignment	Align front end.
	Loose or worn driveline or suspension parts	Repair or install new parts.	
	Excessive driveshaft runout or imbalance	Install a new driveshaft.	
	Worn or damaged flexible drive joint	Install a new driveshaft.	
Damaged wheel hub stud threads	Sliding wheel across the wheel studs during installation. Loose wheel nuts	Install new wheel studs.	
Broken wheel studs	Loose or over tightened wheel nuts	Install new wheel studs.	
Corrosion and contamination streaks from the wheel hub wheel stud holes	Loose wheel nuts	Check complete assembly. Install new parts.	
Damaged wheel nuts	Loose wheel assembly	Install new wheel nuts.	
	Over-tightened wheel nuts	Install new wheel nuts.	
Frozen wheel nuts	Corrosion or galling	If corrosion is light, wire brush away corrosion. If corrosion is excessive install new wheel studs and wheel nuts.	

Tyre Damage

Symptom	Description
Age Deterioration	Cracking and crazing of the tread and sidewall rubber, sometimes accompanied by carcass deformation. An indication that the tyres have been in service for a very long time.
Neglected Cut	Damage through accidental cuts or penetrations will extend in use due to continued flexing and / or ingress of moisture and road matter.
Impact Fracture	Resultant damage from impact fractures is not always visible externally and, therefore, as a safety precaution the tyre should be removed and examined.
	Casing fracture caused by severe localized impact through driving over kerbs, hitting potholes and / or objects in the road.
	A double fracture caused by crushing the side wall of the tyre between an object and the rim flange.
	In both instances, such damage can lead to sudden and dangerous tyre deflation some time after the impact occurred.

Repairs

In view of the high performance capability of the vehicle, damaged tyres should be renewed and not repaired.

Caution

When a new tyre is installed, always renew the tyre valve.

Care of Alloy Road Wheels

Aluminium alloy road wheels are covered with a protective coating. To prevent corrosion it is essential that this coating is not damaged. When removing or installing tyres only equipment utilizing spigot or stud hole clamping must be used. The equipment must not have any moving parts which contact the road wheel, and tyre levers must not be used.

To clean road wheels use warm soapy water; stubborn stains can be removed using a soft brush or by using a proprietary alloy road wheel cleaner.


Road Wheel Alignment

It is important that correct road wheel alignment be maintained. Misalignment causes tyre tread to be scrubbed off laterally because the natural direction of the road wheel differs from that of the vehicle.

A sharp 'fin' protrusion on the edge of each pattern rib is a sure sign of misalignment.

- 'Fins' on the inside edges of the pattern ribs, particularly on the nearside tyre, indicate Toe-in.
- 'Fins' on the outside edges, particularly on the offside tyre, indicate Toe-out.

With minor misalignment, the evidence is less noticeable and sharp pattern edges may be caused by road camber even when the road wheel alignment is correct. In such cases it is better to make sure by checking with an alignment gauge. Road camber affects the direction of the vehicle by imposing a side thrust and, if left to follow its natural course, the vehicle will drift towards its nearside. This is instinctively corrected by steering towards the road centre and, as a result, the vehicle runs crabwise. The diagram shows why nearside tyres are very sensitive to too much Toe-in and offside tyres to Toe-out.



It also shows why sharp 'fins' appear on one tyre but not on the other, and why the direction of misalignment can be determined by noting the position of the 'fins'. Severe misalignment produces clear evidence on both tyres.

Front road wheels on a moving vehicle should be parallel. Tyre wear can be affected noticeably by quite small variations from this condition. It will be noted from the diagram that even with parallel road wheels, the vehicle is still out of line with its direction of movement, but there is less tendency for the wear to be concentrated on one tyre.

The near front tyre sometimes persists in wearing faster and more unevenly than the other tyres, even when the mechanical condition of the vehicle and tyre maintenance are satisfactory. The more severe the average road camber, the more marked this tendency will be.

Misalignment Effects

Misalignment	Effect
Road wheels are correctly aligned but crabbing due to road camber	All tyres will wear equally.
Shows road wheels 'Toed-out' in motion	RH front tyre will wear faster.
Shows road wheels 'Toed-in' in motion	LH front tyre will wear faster.

Alignment Precautions

The following alignment precautions should be observed:

1. The vehicle should have come to rest from a forward movement. This ensures, as far as possible, that the road wheels are in natural running positions.
2. It is preferable for alignment to be checked with the vehicle laden (Refer to 'Specifications', page 4-0-2).

Road Wheel and Tyre Balance

Static Balance

For smooth riding, precise steering and the avoidance of high speed 'tramp' or 'road wheel hop', all tyres are balance checked to predetermined limits. To ensure the best degree of tyre balance, the tyres are marked with yellow spots on the outer sidewall and these indicate the lightest balance point of the cover.

The original degree of balance is not necessarily maintained. It can be affected by uneven tread wear, tyre removal or refitting, by road wheel damage or eccentricity. The vehicle may also become sensitive to imbalance due to normal wear of moving parts. If roughness or high speed steering troubles develop and mechanical investigation fails to disclose a possible cause, road wheel and tyre balance should be suspected.

⚠ WARNING ⚠

IF BALANCING EQUIPMENT IS USED TO DYNAMICALLY BALANCE ROAD WHEELS, ALWAYS JACK BOTH REAR ROAD WHEELS OFF THE GROUND WHEN REAR ROAD WHEEL BALANCING, OTHERWISE DAMAGE MAY BE CAUSED TO DIFFERENTIAL. THIS IS DOUBLY IMPORTANT IN CASE OF VEHICLES INSTALLED WITH A LIMITED SLIP DIFFERENTIAL, AS IN ADDITION TO POSSIBLE DAMAGE TO THE DIFFERENTIAL, THE VEHICLE MAY DRIVE ITSELF OFF THE JACK OR STAND.

Dynamic Balance

Static imbalance can be measured when the tyre and road wheel assembly is stationary. There is another form known as dynamic imbalance which can be detected only when the assembly is revolving.

There may be no heavy spot, i.e. there is no natural tendency for the tyre and road wheel assembly to rotate about its centre due to gravity, but the weight may be unevenly distributed each side of the tyre centre line. Laterally, the eccentric road wheels give the same effect. During rotation, the offset weight distribution sets up a

situation which tends to steer the road wheel to the right and left alternately.

Dynamic imbalance of the tyre and road wheel assemblies can be measured on suitable tyre balancing equipment, and corrections implemented. Where it is clear that a damaged road wheel is the primary cause of severe imbalance, it is advisable for the road wheel to be renewed.


Torque Tightening of Road Wheel Nuts

Repair Operation Time (ROT)	
Item	Code
Road Wheel	(LHF) 04.04.AB
	(RHF) 04.04.CB
	(LHR) 04.04.BB
	(RHR) 04.04.DB

WARNING

ONLY TIGHTEN THE WHEEL NUTS WHEN THE WHEELS ARE COLD. IF THE WHEELS ARE NOT COLD THE TORQUE CAN BE INCORRECT AND CAUSE FAILURE OF THE WHEEL NUTS.

Tightening Order - Torque tighten the nuts in the pattern shown in the figure in the two steps that follow:



1. To 80 Nm (60 lb. / ft) in one continuous movement.
2. Refer to the Table that follows:

Vehicle	Torque
with 22 mm Wheel Nuts	135 Nm (100 lb/ft)
with Titanium Wheel Nuts	150 Nm (111 lb/ft)
with 21 mm Wheel Nuts	180 Nm (133 lb/ft)

Note: Tell the customer that the wheel nuts must be torque checked after 32km (20 miles).

Tyre Pressure Sensing (Option)

⚠ WARNING ⚠

TYRE PRESSURE SENSING IS NOT INTENDED TO REPLACE DRIVER AWARENESS OF TYRE PERFORMANCE OR THE NEED FOR RECOMMENDED WEEKLY CHECKS ON TYRE CONDITION AND PRESSURE.

Tyre pressure sensing monitors the vehicle tyre pressures and feeds-back this information to the driver.

Each road wheel is installed with a tyre pressure sensing device which sends tyre pressure information to a control unit mounted in the centre, rear wall of the boot.

Each pressure sensing device has a colour coded collar. Ensure the coloured collars are always installed in their original positions, i.e. after new tyres are installed.

Road wheel	Colour
Front right	Green
Front Left	Red
Rear Right	Blue
Rear Left	Yellow

The control unit provides a visual warning by illuminating the tyre pressure warning lamp (A) on the instrument panel if any tyre pressure falls below specification.



Pressure Sensing with Winter Wheels and Tyres

If the tyre pressure sensing option is installed on the vehicle, the winter road wheel and tyre option with the tyre pressure sensing system should be installed. The tyre pressure sensing system will need to be programmed to recognize additional tyres.

Warnings

Instrument Cluster	Lamp constant / Message 'Check Tyres'.
Control module	Tyre LED constant red .
Fault	Tyre pressure below specification.

Action
Reduce speed to 48 km/h (30 mph). Stop in safe place as soon as possible.
One of the coloured LEDs on the control module will illuminate to indicate which tyre requires inflating. The LED colour corresponds to the colour of the band below each tyre valve cap. Inspect affected tyre. Re-inflate if necessary. If on inspection the tyre is found to be OK, continue at 48 km/h (30 mph) maximum.

Ensure that the coloured band remains in position.

Instrument Cluster	Lamp constant / Message 'Check Tyres'.
Control module	Tyre LED constant amber .
Fault	Tyre transmitter fault.

Action
Reduce speed to 48 km/h (30 mph). Stop in safe place as soon as possible.
Inspect affected tyre. Re-inflate if necessary.
If on inspection the tyre is found to be OK, continue at 48 km/h (30 mph) maximum.


Instrument Cluster	Lamp constant / Message 'Tyre system Fault'
Control module	Module LED constant amber .
Fault	Control module fault.

Action
Stop in safe place as soon as possible.
Check all tyres for flats. If OK, continue at 48 km/h (30 mph) maximum.

Display Unit


The display unit provides additional features when correctly connected to a previously installed 'Smartyre' system. The display unit connects directly to the front of the basic 'Smartyre' receiver and is powered from the vehicle circuits. The display will be fully illuminated during use but will go into 'Energy Saver' mode when no activity is detected.

Display Panel



Connection and Normal Operation

1. Remove the front bezel of the Pressure Sensor Receiver. Install the extension lead to the display unit and to the receiver module. Turn on the ignition. All icons will illuminate briefly and then extinguish leaving only the vehicle outline.



2. When tyre pressure data is received, (drive the vehicle or spin the road wheels), all the road wheel icons will appear. Press the Tyre icon to access the recorded data for each of the four road wheels.
3. Press the Mode button to scroll through the pressure, temperature and pressure deviation readings for the selected tyre.

4. If any tyre pressure sensor is defective, the display will show three dashes to indicate the absence of data for that tyre.
5. To return to normal mode, press the SET button.

System Programming

The system may be programmed by the user on three different levels. Enter Programming Mode by pressing the 'Set' button:


- 2 seconds to enter level 1
- 5 seconds to enter level 2
- 10 seconds to enter level 3

The following parameters may be set in each level:

- | | |
|----------------|---|
| Level 1 | <ul style="list-style-type: none"> • Cold Pressure • Tyre Rotation • Low Pressure Warning • Pressure Deviation • High Temperature Alert • Units Selection |
| Level 2 | <ul style="list-style-type: none"> • Slope • Learn Transmitter ID |
| Level 3 | <ul style="list-style-type: none"> • Low Pressure Alert |

Level 1 Programming

Cold inflation pressure




1. Press 'Set' for 2 seconds to enter level 1 programming.
2. Press 'Tyre' to select the front or rear axle. Front or rear tyres will be highlighted.
3. Press 'Mode' to show the current value. Press 'Tyre' to increase or 'Mode' to decrease the current value.
4. Press 'Set' to save the new values.
5. Repeat steps 2 - 4 to set the cold inflation pressure for other the axle.

Tyre Rotation

⚠ **WARNING** ⚠

THE ROAD WHEELS AND TYRES ARE ASYMMETRICAL AND DIFFERENT SIZES FRONT AND REAR. THEY MUST NOT BE ROTATED FRONT TO REAR. THIS FUNCTION SHOULD BE USED ONLY TO VERIFY CORRECT TYRE POSITION. DO NOT CHANGE THE PROGRAMMED DATA.



1. Press 'Set' for 2 seconds to enter level 1 programming.
2. Press 'Mode' repeatedly until 'Tyre Rotation' icon is displayed.
3. Press 'Tyre' to scroll to a tyre position. Press 'Mode' to display the current sensor identity.


Each sensor is identified by the colour of a washer on the tyre valve. Tyres are always installed in fixed positions and must remain as follows:

- Right Front - Green (Code 1)
- Left Front - Red (Code 2)
- Right Rear - Blue (Code 3)
- Left Rear - Yellow (Code 4)

If the current data is incorrect, revise as follows:

4. Ensure that the road wheels and tyres are installed in the correct locations (see the colour code list above). Note the correct code number for each road wheel.
5. Use 'Tyre' or 'Mode' to correct the sensor identity code if required.
6. Repeat for the remaining tyres.
7. Press 'Set' twice to exit the programme.


Low Pressure Warning



1. Press 'Set' for 2 seconds to enter level 1 programming.
2. Press 'Mode' repeatedly until 'Flat Tyre' icon is displayed.
3. Press 'Tyre' to scroll to the desired axle. Press 'Mode' to display the current low pressure warning value.

4. Press 'Tyre' to increase or 'Mode' to decrease current value.
5. Press 'Set' to enter the new value into memory.


Pressure Deviation Alert



This function sets the threshold for warning of a deviation from normal tyre pressures.


1. Press 'Set' for 2 seconds to enter level 1 programming.
2. Press 'Mode' repeatedly until the '+-' icon is displayed.
3. Press 'Tyre' to display the current value.
4. Press 'Tyre' to increase or 'Mode' to decrease the current value
5. Press 'Set' to save the amended value.
6. Press 'Set' again to revert to normal operation.

High Temperature Alert



1. Press 'Set' for 2 seconds to enter level 1 programming.
2. Press 'Mode' until 'alert' icon is displayed.
3. Press 'Tyre' to display the current value of the high temperature alert.
4. Press 'Tyre' to increase or 'Mode' to decrease current value
5. Press 'Set' to save the amended value.
6. Press 'Set' again to return to normal mode.

Units Selection




Use this function to select the combination of units for pressure and temperature.

1. Press 'Set' for 2 seconds to enter level 1 programming.
2. Press 'Mode' until pressure / temperature units are displayed.
3. Press 'Tyre' to enter 'Units Selection' mode.
4. Use 'Tyre' or 'Mode' to scroll through four combinations of pressure / temperature units.
5. Press 'Set' to save the selected combination of units.
6. Press the 'Set' button again to revert to normal mode.

Level 2 Programming

Slope



Sets rate of pressure change for tyres in use. This parameter is set at manufacture and is specific only to the recommended tyres for DB9.

1. Press 'Set' for 5 seconds to enter level 2 programming.
2. Press 'Tyre' until the desired vehicle axle is displayed.
3. Press 'Mode' to display the current SLOPE entry (DB9 is set at?)
4. If required, use 'Tyre' to increase or 'Mode' to decrease current value.
5. Press 'Set' to save the final value.
6. Press 'Set' again to return to normal mode.

Transmitter Learn Mode

This mode is used to add or delete transmitters from the system memory. It is vital that transmitter signals are correctly recognised to avoid system reaction to other transmitters (e.g. from passing vehicles with similar sensors).

1. Remove a Redundant Transmitter
 - 1.1 Press 'Set' for 5 seconds to enter level 2 programming.
 - 1.2 Press 'Mode' to select 'Transmitter Learn' mode.
 - 1.3 Press 'Tyre' to display possible tyre positions (filled rectangles represent currently programmed transmitters).
 - 1.4 Press 'Tyre' to scroll to the desired position.
 - 1.5 To delete a transmitter, press the 'Mode' once.
 - 1.6 If required, scroll to other positions using 'Tyre' and, if required, delete any other transmitters using 'Mode' button.


2. Add new Transmitters.
 - 2.1 Press 'Set' for 5 seconds to enter level 2 programming.
 - 2.2 Press 'Mode' to select 'Transmitter Learn' mode.
 - 2.3 Press 'Tyre' to display possible tyre positions (filled rectangles represent currently programmed transmitters).
 - 2.4 Press 'Tyre' to scroll to the desired position. The chosen road wheel icon will flash.
 - 2.5 Program a new transmitter by either:
 - 2.6 Vigorously shaking the transmitter (bounce the road wheel on the ground) to promote a transmission.
 - 2.7 Inflate or deflate the tyre by more than 3 psi (0.2 bar).

The unit will 'beep' when new transmitter is recognised.

- 2.8 Press 'Tyre' to scroll to the next position. Repeat steps 4 and 5 as required to programme additional transmitters.
- 2.9 Press 'Set' to save the new transmitter data and to exit 'learn' mode. If no error is found, the system will return to 'normal' mode.

Level 3 Programming

Low Pressure Alert



1. Press 'Set' for 10 seconds to enter level 3 programming.
2. Press 'Tyre' button to scroll to the desired axle.
3. Press 'Mode' to view the current low pressure alert value.
4. Press 'Tyre' to increase the current value or press 'Mode' to the decrease current value.
5. Press 'Set' to save when the desired value is reached.
6. Repeat steps 2 to 5 until the Low Pressure Alert Level has been set for all road wheels.
7. Press 'Set' button to exit this mode.
8. Press the 'Set' button again to return to normal mode.



ASTON MARTIN

Driveline (05.00)

Contents


Driveshaft (05.01)	5-1-2
Description	1-2
Specifications	1-2
Maintenance	1-2
Torque Tube.....	1-2
<i>Remove</i>	1-2
<i>Installation</i>	1-5
Halfshafts (05.05)	5-2-1
Specifications	2-1
Maintenance	2-1
Halfshaft	2-1
<i>Removal</i>	2-1
<i>Installation</i>	2-1

Driveline (05.00)

Driveshaft (05.01)

Description

The driveshaft consists of a torque tube assembly, incorporating the propshaft, transferring drive from the power unit to the gearbox.



01-5-001

Engine power is transmitted to the rear wheels via a carbon fibre prop shaft. To prevent any shunting of the engine under high acceleration, the engine and transaxle are connected with an aluminium torque tube which surrounds the prop shaft. This arrangement is used on both the automatic and manual transmission cars.

Specifications

Torque Figures

Description		Nm.	lb. / ft.
Torque Tube (front)	M8	25	18.5
	M10	50	37
Torque Tube (rear)		43-57	32-42.5
Exhaust Manifold		18-22	13.5-16.5
Starter Motor		50	37
Drive Plate (Auto only) - Torque converter to prop shaft		72	53.5

Maintenance

Torque Tube

Repair Operation Time (ROT)	
Item	Code
Torque Tube Renew	05.01.AB

Remove

1. Disconnect the vehicle battery. Raise the vehicle and make safe.



Caution

On a two post ramp ensure vehicle is 'strapped' to the lift.

If using a two post vehicle lift, remove the screws that secure the rear section of the front road wheel arch liners. Hold back the rear section of the road wheel arch liner to allow the foot of the vehicle lift to be positioned correctly. (Refer to 'Jacking Points', page I-I-IX)

2. Remove the front road wheels and road wheel arch liners.
3. Remove the shear panel and both undertrays.
4. Remove the exhaust system (Refer to 'Exhaust System', page 9-3-1).

5. Remove the heat shields.



- 6. Remove the lower steering column (LH drive only).
- 7. Remove the dip stick tube.
- 8. Remove the LH exhaust heat shields and manifold.

Remove the manifold and lay to one side.

9. Automatic Gearbox Only.

Remove the rear subframe complete with the transaxle (Refer to 'Rear Subframe', page 2-1-4).


10. Manual Gearbox Only.

Remove the transaxle (Refer to 'Manual Transmission (07.03)', page 7-3-1).

11. Allow the torque tube to lower until the engine is resting on the front subframe rear crossmember.


12. Automatic Gearbox Only.

Remove the transmission oil coolant pipes from the torque tube.



13. Automatic Gearbox Only.


Remove the drive plate.



14. Automatic Gearbox Only.

Remove the propshaft.

Remove the wire clip and pull the propshaft from the torque tube.




15. Manual Gearbox Only.

Remove the propshaft.

Remove the horseshoe clip and pull the propshaft from the torque tube.

Suggestion: To pull the prop shaft from the torque tube install a jubilee clip around the end of the prop shaft and use this to lever against.



01-5-005

16. Manual gearbox Only.

⚠ Warning ⚠

Avoid skin / eye contact or ingestion of clutch fluid. If skin or eyes are splashed with clutch fluid, rinse the affected area immediately with plenty of water and obtain medical attention. If clutch fluid is ingested, obtain immediate medical attention.

Caution


Clutch fluid must not be allowed to contact the vehicle paint work. Remove spilt clutch fluid from the paint work by rinsing away with running water.

Place suitable absorbent material around the affected area to absorb any possible clutch fluid spillage.

Disconnect the clutch slave cylinder bleed and supply pipes. Pull the wire clips back to release the unions.

Caution

Ensure that the seal on the 'male' end remains connected to the 'male' end when disconnecting.



01-5-007

⚠ Warning ⚠

The torque tube is heavy. To avoid personal injury or damage to the torque tube, torque tube removal is at least a two person operation.

17. Remove the bolts (x2) that secure the starter motor. Withdraw the starter motor and place to one side.

18. Disconnect the earth cable.




19. Loosen and undo the engine mount nuts sufficiently to allow the front of the engine to be raised.

Do not remove the nuts - leave them in place, one or two threads only.

20. Raise the front of the engine. This then provides access to the two top bolts of the torque tube and enables move movement of the torque tube.

21. Ensure the torque tube is supported. Remove the bolts (x9) that secure the torque tube to the engine block. Withdraw the torque tube.




01-05-008

Installation

⚠ Warning ⚠


The torque tube is heavy. To avoid personal injury or damage to the torque tube, torque tube removal is at least a two person operation.

1. Feed the torque tube into position against the engine block.
2. Secure the torque tube to the engine block.
 - M8 25 Nm.
 - M10 50 Nm.



3. Lower the engine onto its mounts. Torque the two engine mount nuts to **47 Nm**.

4. Install the exhaust manifold. Torque the nuts, in sequence shown, to **18-22 Nm**.




5. Install the exhaust heat shields.
6. Install the lower steering column (LH drive only) and the dip stick tube.
7. Install the earth cable.
8. Install the starter motor. Torque bolts to **50 Nm**.
9. **Automatic Gearbox Only.**
Install the propshaft to the torque tube. Install the wire clip.


*When installing the propshaft use a lever through the opening in the bell housing to manoeuvre the splines of the propshaft to the crankshaft.
Use a soft face hammer to fully locate the propshaft*

10. Automatic Gearbox Only.

Install the drive plate. Torque bolts to **72 Nm**.



Push the wire clip back into position on the female end, then connect the male to the female.




11. Manual Gearbox Only.

Install the propshaft to the torque tube. Install the horseshoe clip.

When installing the propshaft use a lever through the opening in the bell housing to manoeuvre the splines of the propshaft to the crankshaft.

Use a soft face hammer to fully locate the propshaft.



12. Manual gearbox Only.

⚠ Warning ⚠

Avoid skin / eye contact or ingestion of clutch fluid.
If skin or eyes are splashed with clutch fluid, rinse affected area immediately with plenty of water and obtain medical attention.
If clutch fluid is ingested, obtain immediate medical attention.

Caution

Clutch fluid must not be allowed to contact the vehicle paint work. Remove spilt clutch fluid from the paint work by rinsing away with running water.

Place suitable absorbent material around the affected area to absorb any possible clutch fluid spillage.

Install the clutch slave cylinder bleed and supply pipes.

13. Automatic Gearbox Only.

Install the transmission oil coolant pipes to the torque tube.

14. Install the heat shield brackets to the torque tube.

15. Automatic Gearbox Only.

Install the rear subframe complete with the transaxle (Refer to 'Rear Subframe', page 2-1-4).

16. Manual gearbox Only.

Install the transaxle (Refer to 'Manual Transmission (07.03)', page 7-3-1).

17. Manual gearbox Only.

Bleed the clutch.

18. Install the heat shields.

19. Install the exhaust system (Refer to 'Exhaust System', page 9-3-1).

20. Install the shear panel and both undertrays.

21. Install the road wheel arch liners and road wheels. (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).

22. Connect the vehicle battery.

Driveline (05.00)

Halfshafts (05.05)

Specifications

Torque Figures

Description	Nm.	lb. / ft.
Halfshaft nut	300	221.5
Halfshaft to differential	70	52


Maintenance Halfshaft

Repair Operation Time (ROT)


Item	Code
Halfshaft Renew	(LH) 05.05.AB
	(RH) 05.05.BB

Removal

1. Raise the vehicle and make safe.
2. For each affected wheel station remove the road wheel(s).
3. Remove the halfshaft nut.



4. Remove bolts (x6) and washer tabs (x3). Discard bolts.



5. Withdraw the halfshaft.


Installation

1. Position the halfshaft through the vertical link.



01-05-013

2. Place the halfshaft up to the differential output.



01-05-014

3. Install the washer tabs (x3) and **new** bolts (x6). Torque bolts to **70 Nm**.

New bolts should have a thread lock coating.

4. Install the halfshaft nut. Torque nut to **300 Nm**.
5. Install the road wheel(s) (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).



ASTON MARTIN

Brake System (06.00)

Contents

Front Disc Brake (06.03)	6-3-1	Brake Booster	7-1
Description	3-1	Panic Brake Assist	7-1
Specifications	3-1	Specifications	7-2
Maintenance	3-2	Maintenance	7-2
Brake Caliper (Front and Rear)	3-2	Brake Booster	7-2
<i>Removal</i>	3-2	<i>Removal</i>	7-2
<i>Installation</i>	3-2	<i>Installation</i>	7-2
Brake Discs (Front and Rear)	3-4	Anti-lock Braking System (ABS) (06.09)	6-9-1
<i>Removal</i>	3-4	Dynamic Stability Control	9-1
<i>Installation</i>	3-4	9-1
Brake Pads (Front and rear)	3-5	Concept	9-1
<i>Removal</i>	3-5	System Overview	9-2
<i>Installation</i>	3-5	Operation Summary	9-2
Brake Pad 'Bedding-in'	3-6	Traction Control	9-2
<i>Procedure</i>	3-6	Functional Description.....	9-2
Rear Disc Brakes (06.04)	6-4-1	Engine Intervention.....	9-3
Description	4-1	Brake Intervention	9-3
Specifications	4-2	ABS / DSC Circuit	9-3
Maintenance	4-2	Specifications	9-3
<i>Brake Calipers</i>	4-2	Maintenance	9-4
<i>Brake Discs</i>	4-2	ABS Modulator - Remove and Install.....	9-4
<i>Brake Pads</i>	4-2	<i>Remove</i>	9-4
Hand Brake (06.05)	6-5-1	<i>Install</i>	9-5
Description	5-1		
Specifications	5-2		
Maintenance	5-2		
Brake Caliper	5-2		
<i>Remove</i>	5-2		
<i>Install</i>	5-2		
Brake Pads	5-3		
<i>Remove</i>	5-3		
<i>Install</i>	5-3		
Handbrake Cable	5-4		
<i>Remove</i>	5-4		
<i>Install</i>	5-5		
<i>Adjustment</i>	5-5		
Brake Actuation System (06.06)	6-6-1		
Description	6-1		
Tandem Master Cylinder	6-1		
Brake Fluid Reservoir	6-1		
Specifications	6-1		
Maintenance	6-2		
Master Cylinder	6-2		
<i>Removal</i>	6-2		
<i>Installation</i>	6-2		
Brake Fluid Reservoir	6-3		
<i>Removal</i>	6-3		
<i>Install</i>	6-4		
Brake Bleeding - AMDS	6-4		
Brake Bleed - Manual	6-5		
<i>Preparation</i>	6-5		
<i>Procedure</i>	6-5		
Power Brake System (06.07)	6-7-1		




ASTON MARTIN

Brake Systems (06.00)

Front Disc Brake (06.03)

Description



001-6-001

Figure 06.03.01

Key to Figure 06.03.01

1. Brake Hose Assembly.
2. Caliper Bolt
3. Brake Pad Sensor
4. Brake Pad Kit
5. Front Caliper
6. Grooved Brake Disc
7. Front Brake Disc Shield

The front disc brake has a caliper that is attached to the vertical link with two bolts. The caliper body is one-piece and has four pistons. The two-pairs of pistons in the caliper operate directly on the brake pads that are installed, one each side of the disc.

The Brake discs are ventilated and are made of steel and they have grooves to remove surface water. The discs are attached to the wheel hub with two bolts.

Specifications

Oils/Greases

Brake Fluid	Castrol Super Response DOT 4 (Not silicon based brake fluid).
Qty.	2.5 ltrs

Brake discs

	Front
Initial Thickness	32 mm
Minimum Thickness	30 mm
Brake Disc 'Runout'	<70 μm measured @ 2 mm in from the brake disc edge.

Brake pads

New pad thickness 9.4 mm
Minimum lining thickness 2.5 mm

Torque Figures

Description	Nm.	lb. / ft.
Brake Hose Unions	22	16.5
Brake Hose Bracket to Body	9	6.6
Brake Caliper to Vertical Link	20 + 66°-70°	15 + 66°-70°
Handbrake Caliper to Vertical Link	15 + 90°-94°	11.5 + 90°-94°
Brake Disc Screws	10.5	8

Replace the brake pad if there are the conditions that follow:
There less than one-third of the friction material remains on the brake pad, the vehicle is used regularly and there is a long period before the next service.

⚠ WARNING ⚠
DO NOT USE COMPRESSED AIR TO REMOVE BRAKE PAD DUST. THE DUST CAN BE DANGEROUS. ALWAYS USE A VACUUM BRUSH OR AQUEOUS BRAKE CLEANER TO REMOVE BRAKE PAD DUST.

⚠ WARNING ⚠
BRAKE FLUID IS POISONOUS. DO NOT DRINK THE BRAKE FLUID OR LET IT TOUCH YOUR SKIN OR EYES. IF YOU GET BRAKE FLUID IN YOUR MOUTH, GET MEDICAL AID IMMEDIATELY. FLUSH ALL BRAKE FLUID FROM YOUR EYES OR SKIN WITH WATER AND GET MEDICAL AID.

CAUTION
DO NOT LET BRAKE FLUID TOUCH THE VEHICLE PAINT WORK. IF YOU DO THE PAINTWORK CAN BE DAMAGED. FLUSH ALL SPILLED BRAKE FLUID FROM THE PAINTWORK WITH WATER.

5. Disconnect the brake hose union.
6. Install sealing plugs into the hose and the port in the caliper to prevent contamination.
7. Remove and discard the two bolts to release the caliper from the vertical link.



Installation

1. Put the caliper in position on the vertical link.

⚠ WARNING ⚠
ALWAYS INSTALL NEW BOLTS WHEN YOU INSTALL THE BRAKE CALIPER. IF YOU DO NOT THE BOLTS CAN BREAK AND CAUSE FAILURE OF THE BRAKE.

2. Install two new bolts and torque them to **20 Nm**.
3. Tighten the caliper bolts **66 degrees to 70 degrees** more.

Maintenance

Brake Caliper (Front and Rear)

Repair Operation Time (ROT)	
Item	Code
Brake Caliper - Front - Renew	(Left) 06.03.AC
	(Right) 06.03.AB
Brake Caliper - Rear - Renew	(Left) 06.04.AC
	(Right) 06.04.AB


Removal


Front calipers shown.

1. Put a cloth around the brake reservoir filler neck to absorb all brake fluid spillage.
2. Raise the vehicle and make it safe.
3. Remove the applicable wheels.

Retract the caliper pistons to help release the caliper. When you retract the caliper pistons, the brake fluid reservoir can overflow.

4. Disconnect the brake pad wear sensor (1) from the brake pad..





4. Remove the sealing plug from the brake-pipe port.

CAUTION
MAKE SURE THAT THE ALIGNMENT LINE ON THE BRAKE HOSE STAYS IN A STRAIGHT LINE. IF THE ALIGNMENT LINE IS NOT STRAIGHT, THE BRAKE HOSE IS TWISTED. THIS CAN CAUSE IT TO FAIL.

CAUTION
ON LEFT AND RIGHT CALIPERS, THE BRAKE HOSE MUST GO TOWARDS THE FRONT OF THE CAR.


- 4.1 Loosely install the brake hose union into the caliper.
- 4.2 Make sure that the brake hose alignment line is straight. Adjust the hose if necessary.
- 4.3 Install the alignment tool (206-100).



- 4.4 Use the tool to align the hose and tighten the union to **22 Nm**.
 - 4.5 Do a check of the hose alignment again. If the hose is not correctly aligned, loosen the union and adjust the hose. Tighten the union to **22 Nm**.
 - 4.6 Make sure that the brake pipe is in the correct position:
 - Flexible hose alignment line is straight.
 - 4.7 If the alignment is **not** correct, carefully loosen the pipe union at the brake caliper until you can turn the pipe backwards to allow forward movement when being re-torqued. Re torque the brake pipe union to **22 Nm** then re check alignment as listed above.
5. Install the brake pads.

6. Install the brake pad wear sensor. Install the left and right shims as recorded at removal.

When you install new brake pads, install a new brake pad wear sensor.



7. Bleed the brakes (Refer to 'Brake Bleed - Manual', page 6-6-5).
8. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-8).
9. "Bed-In" the brakes (Refer to 'Brake Pad 'Bedding-in'', page 6-3-6).

Brake Discs (Front and Rear)

Repair Operation Time (ROT)	
Item	Code
Brake Disc Renew	(Front) 06.03.CB
	(Rear) 06.04.CB

Removal


Put a cloth around the brake reservoir filler neck to absorb spilled brake fluid.

1. Raise the vehicle and make it safe.
2. Remove the applicable roadwheels.


Retract the caliper pistons to help release the caliper. When you retract the caliper pistons, the brake fluid reservoir can overflow.

3. **On Rear Road Wheels Only.**
Remove the park brake caliper (Refer to 'Brake Caliper', page 6-5-2).
4. Remove and discard the two bolts to release the caliper.
5. Use a cable tie to attach the caliper to the suspension spring.

CAUTION
DO NOT LET THE CALIPER HANG ON THE HOSE. IF YOU DO THE HOSE CAN BE DAMAGED.



6. Remove the two attachment screws to release the brake disc from the hub.



001-6-005

Installation

1. Make sure that the surfaces of the disc and the hub are clean.
2. Install the brake disc on the hub.
3. Install and torque the two disc attachment screws to **10.5 Nm**.
4. Do a check of the brake disc "run-out" (Refer to 'Specifications', page 6-3-1).
5. Put the caliper in position.

⚠ WARNING ⚠

ALWAYS INSTALL NEW BOLTS WHEN YOU INSTALL THE BRAKE CALIPER. IF YOU DO NOT THE BOLTS CAN BREAK AND CAUSE FAILURE OF THE BRAKE.

6. Install two new caliper attachment bolts and torque the bolts to **20 Nm**.
7. Tighten the bolts **66 degrees to 70 degrees Nm** more.
8. On the rear wheels only, install the handbrake caliper.
9. Torque the two handbrake caliper bolts to **15 Nm**.
10. Tighten the bolts **90 degrees to 94 degrees Nm** more.
11. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-8).

⚠ WARNING ⚠

BEFORE YOU DRIVE THE VEHICLE, OPERATE THE FOOT BRAKE PEDAL 2 OR 3 TIMES TO MAKE SURE THAT THE FOOT BRAKE OPERATES CORRECTLY. YOU MUST OPERATE BRAKE CALIPER PISTONS TO CLOSE THE SPACE BETWEEN THE BRAKE PADS AND THE DISC.

12. "Bed-in" the brake pads (Refer to 'Brake Pad 'Bedding-in'', page 6-3-6).

Brake Pads (Front and Rear)

Repair Operation Time (ROT)	
Item	Code
Brake Pads Renew	(Front) 06.03.DB
	(Rear) 06.04.DB

Removal


The front calipers are shown.

Put a cloth around the brake reservoir filler neck to absorb spilled brake fluid.

1. Raise the vehicle and make it safe.
2. Remove the applicable road wheels.

Retract the caliper pistons to help release the caliper. When you retract the caliper pistons, the brake fluid reservoir can overflow.

3. Disconnect the brake pad wear sensor.




4. Remove the brake pads. Record the left and right shims for the assembly procedure.

⚠ WARNING ⚠
DO NOT USE COMPRESSED AIR TO REMOVE BRAKE PAD DUST. THE DUST CAN BE DANGEROUS. ALWAYS USE A VACUUM BRUSH OR AQUEOUS BRAKE CLEANER TO REMOVE BRAKE PAD DUST.

5. Use approved materials to clean the brake caliper area.

Installation

1. Install the left and right shims (1) to the pads (2) in the positions recorded at removal.
2. Install the brake pads (2) with the shims (1).
3. Install the pad retaining pins.



When you install new brake pads, you must install a new brake pad wear sensor.

4. Connect the brake pad wear sensor to the brake pads.
5. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-8).

⚠ WARNING ⚠
BEFORE YOU DRIVE THE VEHICLE, OPERATE THE FOOT BRAKE PEDAL 2 OR 3 TIMES TO MAKE SURE THAT THE FOOT BRAKE OPERATES CORRECTLY. YOU MUST OPERATE BRAKE CALIPER PISTONS TO CLOSE THE SPACE BETWEEN THE BRAKE PADS AND THE DISC.

6. "Bed-in" the brake pads (Refer to 'Brake Pad 'Bedding-in'', page 6-3-6).



Brake Pad 'Bedding-in'

Repair Operation Time (ROT)	
Item	Code
Bedding-in	TBA

CAUTION

IF YOU DO NOT "BED-IN" NEW BRAKE PADS, THE PERFORMANCE OF THE BRAKES CAN BE DECREASED AND YOU CAN GET BRAKE JUDDER OR SQUEAL.

After you install new brake pads, the brake performance can be decreased because the brake discs and pads must be "Bedded-in".

Procedure

This procedure will take approximately 17 minutes if you do it in a controlled environment. It is recommended that you use an analogue decelerometer for this procedure.

Make sure that the brakes are cold (Less than 80° C) before you do this procedure.

Only apply the brakes lightly, if possible, when the vehicle is driven to a suitable location to carry out this procedure.

If possible, use light brake applications only during all cool-down periods.


The cool-down periods are the minimum needed and can be longer.

1. Slow the vehicle three times from 100 km/h to 32 km/h at 0.3g. Increase the speed normally after you have slowed down.
2. Drive 3 km to let the brakes cool.
3. Slow the vehicle three times from 100 km/h to 32 km/h @ 0.5g. Increase the speed normally after you have slowed down.
4. Drive 4 km to let the brakes cool.
5. Use the ABS and slow the vehicle three times from 100 km/h to 0 km/h. Increase the speed normally after you have slowed down.
6. Drive 8 km to let the brakes cool.

Brake system (06.00)

Rear Disc Brakes (06.04)

Description



01-06-024

Figure 06.04. 01

Key to Figure 06.04.01		
8. Brake Hose Assembly	11. Rear Caliper	14. Brake Pad Sensor Assembly
9. Rear Brake Disc Shield	12. Caliper Bolt	
10. Grooved Brake Disc	13. Brake Pad Kit	

The rear disc brake has a caliper that is attached to the vertical link with two bolts. The caliper body is one-piece and has four pistons. The two-pairs of pistons in the caliper operate directly on the brake pads that are installed, one each side of the disc.

The Brake discs are ventilated and are made of steel and they have grooves to remove surface water. The discs are attached to the wheel hub with two bolts.

Specifications

Oils/Greases

Brake Fluid	Castrol Super Response DOT 4 (Not silicon based brake fluid)
-------------	--

Brake discs

Brake Disc Initial Thickness	28.0 mm
Brake Disc Minimum Thickness	26.0 mm
Brake Disc 'Runout'	<70 μm measured @ 2 mm in from the brake disc edge.

Brake pads

Minimum Lining Thickness	2.5
--------------------------	-----

Torque Figures

Description	Nm.	lb. / ft.
Brake Hose Unions	22	16.5
Service Brake Caliper to Vertical Link	20 then 66° to 70° more	15 then 66° to 70° more
Handbrake Caliper to Vertical Link	15 then 90° to 94° more	11.5 then 90° to 94° more

Maintenance

For symptoms and maintenance of the rear brake system (Brake Discs, Pads and Calipers) follow the same procedures as detailed for the front brake system.

Brake Calipers (Refer to 'Brake Caliper (Front and Rear)', page 6-3-2)


Brake Discs (Refer to 'Brake Discs (Front and Rear)', page 6-3-4)

Brake Pads (Refer to 'Brake Pads (Front and rear)', page 6-3-5)

Brake Systems (06.00)

Hand Brake (06.05)

Description



01-06-011

Figure 06.05.01

Key to Figure 06.05.01	
15. Handbrake Lever	18. Handbrake Cable
16. Handbrake Caliper and Pad Assembly	19. Stop Assembly
17. Trunnion	20. Unlock Button

The hand brake control lever is installed at the outer side of the driver's seat. When the lever is operated, a cable applies mechanical brakes to each rear wheel. Each mechanical caliper applies brake pads to a brake disc installed on each rear road wheel hub. The calipers are bolted to the vertical links. When the parking brake is released, the pads are retracted by springs. Each caliper has a mechanism that automatically adjusts for wear in the pads. There are adjusters to tension the cable if it stretches.

There is a switch installed on the lever assembly that has contacts that are normally closed. When the handbrake is off, the contacts in the switch are open. The contacts close when the handbrake is applied. This causes the hand brake warning light in the instrument panel to come on.

Specifications

Brake pads

Minimum lining thickness 6 mm

Torque Figures

Description	Nm.	lb. / ft.
Brake Caliper to Vertical Link	15 then 92° more.	11.5 then 92° more.


Maintenance Brake Caliper

Repair Operation Time (ROT)


Item	Code	
Handbrake Caliper Renew	LH	06.05.AB
	RH	06.05.BB

Remove

1. Raise the vehicle and make it safe.
2. Remove the applicable road wheels.
3. Remove the handbrake cable from the caliper:
 - 3.1 Turn the cable adjusters on both handbrake calipers to release the tension from the cables.
 - 3.2 Remove the handbrake cable eyelet from the caliper actuator arm.
 - 3.3 Use service tool 206-103 (Refer to '206-103 (Handbrake Cable Remove)', page 20-1-4) to disconnect the handbrake cable outer from the caliper mount.



4. Remove the two bolts that attach the caliper to the vertical link. Discard the two bolts.



⚠ WARNING ⚠

DO NOT USE COMPRESSED AIR TO REMOVE BRAKE PAD DUST. THE DUST CAN BE DANGEROUS. ALWAYS USE A VACUUM BRUSH OR AQUEOUS BRAKE CLEANER TO REMOVE BRAKE PAD DUST.


5. Carefully clean all contamination from the parking brake system components.
6. If required, remove the handbrake pads (Refer to 'Brake Pads', page 6-5-3)
7. Check the caliper moves easily on its mounting pins. Repair it if necessary.

Install

1. Install the handbrake pads if you removed them, (Refer to 'Brake Pads', page 6-5-3).


Always renew the handbrake pads in axle sets.

2. Put the caliper in position on the vertical link and attach it with new bolts. Torque the two bolts to **15 Nm**.
3. Tighten the bolts **92 degrees** more.



4. Operate the caliper lever a minimum of three times with your hand.

This will close up the space between the pistons, the pads and the brake disc.




⚠ WARNING ⚠
DO NOT USE COMPRESSED AIR TO REMOVE BRAKE PAD DUST. THE DUST CAN BE DANGEROUS. ALWAYS USE A VACUUM BRUSH OR AQUEOUS BRAKE CLEANER TO REMOVE BRAKE PAD DUST.

- Carefully clean all contamination from the handbrake system components.

Install

- Use a standard service tool to turn the the caliper piston in.




- Install the handbrake cable to the caliper:
 - Install the handbrake cable through the bracket on the caliper.
 - Install the handbrake cable eyelet on the caliper actuator arm.
- Adjust the handbrake cable (Refer to 'Adjustment', page 6-5-5).

⚠ WARNING ⚠
BEFORE YOU DRIVE THE VEHICLE, OPERATE THE HAND BRAKE LEVER 2 OR 3 TIMES TO MAKE SURE THAT THE HAND BRAKE OPERATES CORRECTLY. YOU MUST OPERATE BRAKE CALIPER PISTONS TO CLOSE THE SPACE BETWEEN THE BRAKE PADS AND THE DISC.

- Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).

- Install the brake pads.



Brake Pads



Repair Operation Time (ROT)	
Item	Code
Handbrake Pads Renew	06.05.DB

Remove

- Raise the vehicle and make it safe.
- Remove the applicable road wheels.
- Remove the handbrake brake pads.

- Operate the caliper lever a minimum of three times with your hand.

This will close up the space between the pistons, the pads and the brake disc.



4. Adjust the handbrake cable (Refer to 'Adjustment', page 6-5-5).

⚠ WARNING ⚠

BEFORE YOU DRIVE THE VEHICLE, OPERATE THE HAND BRAKE LEVER 2 OR 3 TIMES TO MAKE SURE THAT THE HAND BRAKE OPERATES CORRECTLY. YOU MUST OPERATE BRAKE CALIPER PISTONS TO CLOSE THE SPACE BETWEEN THE BRAKE PADS AND THE DISC.

5. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).


Handbrake Cable

Repair Operation Time (ROT)


Item	Code
Handbrake Cable Renew	06.05.DB

Remove

1. Loosen the cable adjustment on each caliper.
2. Remove the driver's seat (Refer to 'Seating (01.10)', page 1-10-1).
3. Remove the clevis pin and the washers. Remove the handbrake cable from the vehicle body. Discard the clevis pin and the spring clip.



4. Remove the handbrake cable from the caliper:
 - 4.1 Turn the cable adjusters on both handbrake calipers to release the tension from the cables.
 - 4.2 Remove the handbrake cable eyelet from the caliper actuator arm.
 - 4.3 Use service tool 206-103 (Refer to '206-103 (Handbrake Cable Remove)', page 20-1-4) to disconnect the handbrake cable outer from the caliper mount.



5. Disconnect the cable from the subframe.





Image - Left Hand Drive vehicle

Caution
Do not try to disconnect the handbrake cables from the equaliser unit.

Use service tool 206-103 (Refer to '206-103 (Handbrake Cable Removal)', page 20-1-4) to disconnect the handbrake cable outer from the subframe mounts.



6. Remove the cable through the vehicle body and the subframe.

Install

1. Put the handbrake cable through the vehicle body and the subframe.

Make sure that all snap install clips are correctly installed.


2. Install the handbrake cable to the caliper:
 - 2.1 Install the handbrake cable through the bracket on the caliper.
 - 2.2 Install the handbrake cable eyelet on the caliper actuator arm.

Make sure that the handbrake lever is fully released.

3. Connect the handbrake cable to the handbrake lever with a new clevis pin, new washers and a new spring clip.
4. Adjust the handbrake cable.

Adjustment

1. Make sure that the handbrake lever is fully released.
2. Release the handbrake cable lock nuts (1) and turn the adjustment fully in.



3. Turn the adjustment out or in, on each caliper, by an equal quantity until there is 4 clicks when you operate the handbrake lever.

⚠ WARNING ⚠
BEFORE YOU DRIVE THE VEHICLE, OPERATE THE HAND BRAKE LEVER 2 OR 3 TIMES TO MAKE SURE THAT THE HAND BRAKE OPERATES CORRECTLY. YOU MUST OPERATE BRAKE CALIPER PISTONS TO CLOSE THE SPACE BETWEEN THE BRAKE PADS AND THE DISC.

4. Do a check that the handbrake system operates correctly:
 - 4.1 When the handbrake lever is in the fully down position (handbrake released), the brake warning light should be off.
If the brake warning light stays on, adjust the handbrake cable until the brake warning light operates correctly
Drive the vehicle and make sure that the rear wheels turn freely.

If the pads touch the discs you will hear squeal from the rear brakes

If the pads touch the discs, the handbrake cable adjusters are over-adjusted. Loosen the adjusters as necessary, then do a check that the brake warning light operates correctly.




ASTON MARTIN

Brake System (06.00)


Brake Actuation System (06.06)

Description Tandem Master Cylinder



01-06-031

The brake pedal operates a tandem master cylinder that controls two separate brake circuits. If there is a serious leak in one system, the other system will continue to operate. The two systems have the same brake fluid reservoir.




01-06-036

There is a sensor installed in the master cylinder that gives brake pressure data to the ABS/DSC module. This data tells the system how hard the driver operates the brakes and is used to help the ABS/DSC accurately control the brake pressure.

Brake Fluid Reservoir

The brake fluid reservoir is installed on the tandem master cylinder (master cylinder). It is attached by a pin. There are two stub-pipes on the bottom of the reservoir that engage in the primary and secondary chambers of the master cylinder. A fluid level switch is installed in the reservoir. If the fluid level in the reservoir becomes low, the brake warning light in the Driver Information Module (DIM) will come on. If this happens, a "LOW BRAKE FLUID" message is displayed in the message centre.



01-06-013

Specifications

Oils/Greases

Brake Fluid Castrol Super Response Dot 4

Torque Figures

Description	Nm.	lb. / ft.
Master Cylinder Mount	25 (+/- 4)	18.5 (+/- 3)
Brake Pipe Unions	17	13
Brake fluid reservoir securing pin	4	3
Pressure Sensor	35 (+/- 2)	26 (+/- 1.5)

Maintenance


Master Cylinder

Repair Operation Time (ROT)	
Item	Code
Master Cylinder Renew	06.06.EB


Removal

1. Remove the coolant reservoir (LH drive only).

*This is to give better access.
Note that there is an electrical connector on the bottom of the coolant reservoir.*




01-03-050



01-6-014

3. Disconnect the pressure sensor electrical connector.
4. Remove the two nyloc nuts that attach the master cylinder to the brake booster. Remove the master cylinder. Discard the O-ring and the nyloc nuts.



01-6-014

⚠ WARNING ⚠

BRAKE FLUID IS POISONOUS.

DO NOT DRINK THE BRAKE FLUID OR LET IT TOUCH YOUR SKIN OR EYES. IF YOU GET BRAKE FLUID IN YOUR MOUTH, GET MEDICAL AID IMMEDIATELY. FLUSH ALL BRAKE FLUID FROM YOUR EYES OR SKIN WITH WATER AND GET MEDICAL AID.

Caution

Do not let brake fluid touch the vehicle paint work. If you do the paintwork can be damaged. Flush all spilled brake fluid from the paintwork with water.


Put a cloth around the brake reservoir filler neck to absorb all brake fluid spillage.

2. Disconnect the two outlet pipes. Seal the ports and pipe ends to prevent brake fluid leakage and contamination in the brake system

Put a label on each pipe for the correct installation.


Installation

1. Install a new O-ring.




01-6-015

- Attach the master cylinder with new nyloc nuts (x2). Torque the nuts to **25 Nm +/- 4 Nm**.



- Install the two outlet pipe unions in their initial positions on the tandem master cylinder.
- Connect the pressure sensor electrical connector.



- Install the coolant reservoir (LH drive only). Top up the coolant system if necessary.
- Bleed the brake system (Refer to 'Brake Bleeding - AMDS', page 6-6-4).

Caution
Do not bleed the brake system at the brake master cylinder.

Brake Fluid Reservoir

Repair Operation Time (ROT)	
Item	Code
Brake Fluid Reservoir Renew	06.06.AB


Removal

⚠ WARNING ⚠
BRAKE FLUID IS POISONOUS.
DO NOT DRINK THE BRAKE FLUID OR LET IT TOUCH YOUR SKIN OR EYES. IF YOU GET BRAKE FLUID IN YOUR MOUTH, GET MEDICAL AID IMMEDIATELY. FLUSH ALL BRAKE FLUID FROM YOUR EYES OR SKIN WITH WATER AND GET MEDICAL AID.

Caution
Do not let brake fluid touch the vehicle paint work. If you do the paintwork can be damaged. Flush all spilled brake fluid from the paintwork with water.

Put a cloth around the brake reservoir filler neck to absorb all brake fluid spillage.

- Remove the master cylinder (Refer to 'Master Cylinder', page 6-6-2).
- Drain as much brake fluid as possible from the brake fluid reservoir.
- Remove the brake fluid reservoir attachment pin.
- Remove the brake fluid reservoir. try not to spill the brake fluid. Remove all spilled brake fluid immediately.
- Discard the brake fluid reservoir O-rings.



Install

1. Install new O-rings to the brake fluid reservoir.
Apply a thin layer of brake fluid to lubricate the O-rings.
2. Install the brake fluid reservoir to the master cylinder.
Ensure correct location of the 'O' rings.
3. Install the brake fluid reservoir attachment pin.
Torque to **4 Nm. (+/- 0.5 Nm.)**.

⚠ WARNING ⚠

BRAKE FLUID THAT CONTAINS WATER CAN AFFECT THE PERFORMANCE OF THE BRAKES AND CAUSE CORROSION IN THE BRAKE SYSTEM. IF YOU KEEP BRAKE FLUID IN OPEN CONTAINERS, IT WILL ABSORB WATER VAPOUR. USE ONLY BRAKE FLUID FROM NEW CONTAINERS WHEN YOU TOP-UP THE BRAKE FLUID RESERVOIR.

4. Fill the brake fluid reservoir with the specified brake fluid from a new, sealed container (Refer to 'Specifications', page 6-3-1).
5. Bleed the brake system (Refer to 'Brake Bleeding - AMDS', page 6-6-4).

Brake Bleeding - AMDS

Repair Operation Time (ROT)	
Item	Code
Brake Bleed with AMDS	06.07.AD

⚠ WARNING ⚠

BRAKE FLUID IS POISONOUS. DO NOT DRINK THE BRAKE FLUID OR LET IT TOUCH YOUR SKIN OR EYES. IF YOU GET BRAKE FLUID IN YOUR MOUTH, GET MEDICAL AID IMMEDIATELY. FLUSH ALL BRAKE FLUID FROM YOUR EYES OR SKIN WITH WATER AND GET MEDICAL AID.

Caution


Do not let brake fluid touch the vehicle paint work. If you do the paintwork can be damaged. Flush all spilled brake fluid from the paintwork with water.

Use the AMDS to bleed the brakes if you are bleeding the brake system after you replaced a major component, for example: a modulator or a master cylinder or when filling from empty.


If you are bleeding a caliper, you can use a manual brake-bleed procedure.

1. Connect the AMDS.

The diagnostic sockets, Body and Engine, are different for LHD and RHD vehicles (Refer to 'Diagnostic Ports', page 20-1-2).



2. Clean each caliper around the bleed screws.
Remove the dust caps.



⚠ WARNING ⚠

BRAKE FLUID THAT CONTAINS WATER CAN AFFECT THE PERFORMANCE OF THE BRAKES AND CAUSE CORROSION IN THE BRAKE SYSTEM. IF YOU KEEP BRAKE FLUID IN OPEN CONTAINERS, IT WILL ABSORB WATER VAPOUR. USE ONLY BRAKE FLUID FROM NEW CONTAINERS WHEN YOU TOP-UP THE BRAKE FLUID RESERVOIR..

3. Prepare a bleed tube and a bottle that contains a small quantity of clean brake fluid.
4. If necessary, top up the brake fluid reservoir with brake fluid from a new container.
5. Switch on the AMDS and load the 'Anti-lock braking diagnostics' software.

When you bleed a brake caliper, always bleed the inner bleed screw first, followed by the outer bleed screw, then bleed the inner bleed screw again.

6. Select 'Brake Bleed' and follow the AMDS instructions.

Brake Bleed - Manual

After a Caliper Replacement

Preparation

1. Connect the bleed-bottle tube to the bleed screws of front left and rear left calipers. Open the front left and rear left caliper's bleed screws.
2. Actuate the brake pedal (>60mm) and use a pedal support to hold it.

This will close the TMC central valves and prevents fluid leakage from the opened brake system.

3. Close the front left and rear left caliper's bleed screws and remove the bleed bottle tubes.
4. Remove the caliper. Install the new caliper.
5. Remove the pedal support.
6. Remove the brake fluid reservoir cap and fill the reservoir to 'MAX' with **new** DOT 4 brake fluid.
7. Bleed the brake system.

You only need to bleed the new caliper. Make sure that there is always sufficient brake fluid in the reservoir.

Procedure

8. Connect a bleed-bottle tube to the caliper inner bleed screw.
9. Operate the brake pedal to the floor and hold it tightly down. Open the inner bleed screw until pressure is released. Close the inner bleed screw, then release the brake pedal.

Wait 2 seconds between brake pedal actuations for the brake fluid level to settle.

Repeat this procedure until clear brake fluid that contains no air flows out of the inner bleed screw (10 to 20 times).

Watch the brake fluid level of the reservoir and refill if necessary.

10. When there is no air in the brake fluid, push down on the brake pedal, hold down and tighten the inner bleed screw. Remove the bleed bottle tube.
11. Do the procedure again on the outer bleed screw.
12. When there is no air in the brake fluid from the outer bleed screw, do the check again on the inner bleed screw for air.
13. Fill the reservoir to the 'MAX' level and install the reservoir cap.

Take note of brake pad wear.

14. Start the engine to generate a vacuum in the booster.
15. Check brake pedal travel and pedal 'feel'.

If the pedal travel is too long after bleeding, check the brake system for leaks. If there are no leaks, do the brake bleed procedure again.




ASTON MARTIN

Brake System (06.00)

Power Brake System (06.07)

Brake Booster



01-06-019

The brake booster comprises a chamber divided by a diaphragm plate and is secured to the brake pedal housing.

As the brake pedal is pressed, a poppet valve opens allowing atmospheric pressure into the drivers side of the diaphragm. Atmospheric pressure builds up on the drivers side of the diaphragm and pushes against the partial vacuum on the other side. This additional force boosts the applied brake pedal force up to 6.5 times.

When the brake pedal is released, the poppet valve closes. The pressure on the diaphragm reduces and the compression spring returns the diaphragm to the release position.

Panic Brake Assist

In an emergency braking situation, a driver presses down on the brake pedal much faster than in normal braking conditions, but often without sufficient force. The initial application of the brake pedal is a reflex reaction. After the initial application, many drivers do not brake hard enough because of concerns that they might cause the vehicle to skid. To aid the driver, the panic brake assist (PBA) intervenes in bringing the vehicle to a halt, sooner and in a controlled manner, in emergency braking situation. The PBA system monitors the speed of brake pedal activation, and at a calibrated pedal activation speed, the PBA provides maximum brake force and makes full use of the ABS.

PBA is controlled by the ABS / DSC module, which monitors a travel sensor attached to the internal vacuum diaphragm of the brake booster. The sensor determines the position of the diaphragm and the speed of the diaphragm movement. If the sensor's signal indicates an emergency braking situation, the

ABS / DSC module will open an electric solenoid on the brake booster. The solenoid directs atmospheric pressure into the rear of the brake booster, causing the booster diaphragm to move forward to fully apply the brakes. PBA takes full benefit of ABS to stop the vehicle in a controlled manner and in the shortest distance possible. When the brake pedal is released the ABS / DSC module instantly releases the brakes.

Specifications

Torque Figures

Description	Nm.	lb. / ft.
Brake Booster Mount	21-24	15.5-18


Maintenance Brake Booster

Repair Operation Time (ROT)

Item	Code
Brake Booster Renew	RHD 06.07.AB


Removal

1. Remove the master cylinder (Refer to 'Master Cylinder', page 6-6-2).
2. Remove the oil dip-stick.
3. Remove the clevis pin.




01-6-020

4. Remove nuts (x4).



01-6-021

5. Disconnect the wiring harness plugs (x2).
6. Withdraw the brake booster.



01-6-022

7. Remove and discard the brake light switch (mounted on the brake pedal block).

Installation

1. Install a new brake light switch.

After installing a new brake booster a new brake light switch, mounted on the brake pedal block, must be installed.

2. Place the brake booster through the bulkhead.
3. Secure using bolts (x4). Torque to **21-24 Nm**.
4. Install the clevis pin.
5. Connect the wiring harness plugs (x2).
6. Install the master cylinder (Refer to 'Master Cylinder', page 6-6-2).
7. Bleed the brake system (Refer to 'Brake Bleeding - AMDS', page 6-6-4).

Brake system (06.00)

Anti-lock Braking System (ABS) (06.09)

The Anti-lock Braking System (ABS) is a four-channel system that has inputs independently from all four of the wheel speed sensors. The ABS module monitors the signals from the sensors to calculate the brake slip and the acceleration or deceleration of the wheels. When the brake pedal is operated, and the ABS module senses a possible wheel lock-up from the signals that it receives, it starts the recirculation pump inside the module's hydraulic modulator. At the same time, it opens the solenoid valves for the applicable wheels. Brake pressure is then modulated to increase, decrease or stay constant at the applicable wheels until the wheel lock-up is stopped.



The ABS has self-fault-finding. If a malfunction of the system is found, the brake warning light will come on and 'ABS FAULT' will be displayed in the message centre right to tell the driver. If there is a fault in the ABS, the brake system will operate normally and with the same standard of performance as a vehicle that does not have ABS.

Dynamic Stability Control

Dynamic Stability Control (DSC) is a closed-loop system to make driving safer. It does this by making the vehicle handle better when the tyres are at the limits of their grip. To do this, the engine torque is decreased by electronic control and the brakes are correctly applied at the applicable wheels.

When the brakes are controlled independently, you can steer the vehicle by a small amount.



To make driving safer, this procedure can be used to correct the yaw moment (turning force) if the vehicle does not follow the direction that the driver steers.



01-06-032a

21. Yaw Rate and Acceleration Sensor.

- A. Longitudinal Acceleration.
- B. Yaw.
- C. Lateral Acceleration.
- D. Wheel Roll.
- E. Steering Motion



01-06-032

Concept

Satisfactory handling of the vehicle is:

- a vehicle that keeps to a path that accurately follows the driver's input (steering wheel angle)
- at the same time remains stable.

The ABS/DSC module uses the sensors listed below to measure the vehicle's movement. The module uses the data to keep the vehicle control and stability in its maximum control limits, which are given by the limits of the tyre's grip.

Wheel speed sensors - Longitudinal acceleration.

Lateral acceleration sensor - Lateral acceleration.

Yaw rate sensor - Yaw rate, given as the rotation around the vertical axis.

When there is not sufficient tyre grip for the driving situation (for example: the driver has driven into a corner too fast) the DSC will keep stability and give the best cornering and stopping performance. But the DSC cannot always prevent the vehicle from running wide. The steering wheel angle sensor and the vehicle speed are used to calculate the best driver-demand yaw rate. This is compared to the actual measured yaw-rate and a yaw-rate that is calculated from the lateral acceleration and the vehicle speed. If the difference between these measurements is too much, an understeer or oversteer correction is done. The first step in



this process is to find how the vehicle should respond to driver demand (the ideal response) and how it actually does respond (the actual response). Hydraulic control valves are operated to generate brake pressure and / or engine torque reduction. They can be used to keep the difference between the ideal and actual response in a tolerance band. This directly controls the forces on the tyres to generate a corrective yaw moment to reduce the side forces of the tyres where applicable.

System Overview

The DSC system has much more functions than ABS, or ABS and traction control combined, but it uses the components of these systems. It also has the sensors that follow to measure the vehicle's motion and brake system pressure:

Yaw rate sensor - Installed centrally on the transmission tunnel.

Lateral acceleration sensor - This is part of the yaw rate sensor.

Steering angle sensor - Installed on the upper steering column.

Pressure transducer - Installed on master cylinder.

The ABS/DSC module supports data exchange with other vehicle electronic systems through the CAN network. You can also use WDS to do check for faults on the module. The components that follow are ones that show the demand from the driver. The ABS/DSC module processes their signals to give an ideal solution:

PCM - This gives the position of the accelerator pedal.

Brake master cylinder pressure transducer - This gives the driver's braking effort.

Steering angle sensor - This gives the position of the steering wheel.

There are many other sources of data that are also included in the processing calculations. These include the coefficient of friction and the vehicle speed.

The ABS/DSC module monitors these factors based on signals that are transmitted by the sensors for:

- Wheel speed
- Lateral acceleration
- Brake pressure
- Yaw rate

The ABS/DSC uses all these sources of data to find the position of the vehicle. It makes sure that the vehicle stays in tolerance of the 'normal' behaviour that is easily controlled by the driver. To give the correct yaw behaviour, the ABS/DSC module uses the ABS hydraulic system and the engine control system to control the selected wheels. If the engine interrupts, the ABS/DSC module calculates the torque that should be given to the wheels by the engine. It gives this signal to the PCM which increases the torque from the engine.

The PCM receives signals from the DSC system through the CAN bus then it does the steps that follow to decrease the engine torque:

The throttle is put in the correct position to give the correct torque.

There is a short time interval before the torque decreases because of mechanical and combustion delays. During this time, other procedures are used to decrease the torque. This gives a quicker response. The ignition is retarded and/or the fuel is cut-off at the injectors at some cylinders. When the engine torque reaches the correct value, ignition and fuelling is reinstated.

Operation Summary

- The DSC is set to on when the engine is started.
- When the system operates, the DSC light in the instrument cluster will flash twice every second.
- The DSC is set off or on when the DSC switch is pushed.
- The DSC light in the instrument cluster will come on continuously when the system operates.
- "DSC OFF" will be displayed in the message centre right to show when the system is not in operation.
- If there is a malfunction in the traction control system, the system will tell the driver as follows:
 - The DSC light in the instrument cluster will come on continuously
 - The message "DSC NOT AVAILABLE" will be displayed in the message centre right.
- If vehicle speed control is engaged, it will automatically disengage when the traction control operates.

Traction Control

The traction control is a function of DSC, and is operated with DSC. Traction control prevents too much wheel-spin when the vehicle starts to move or during acceleration. Wheel-spin is usually caused by too much use of the accelerator pedal, or slippery, loose or bumpy road surfaces. The traction control system prevents too much wheel-spin and keeps the vehicle stable. To do this it:

- Brakes a driven-wheel when it starts to slip
- Adjusts the amount of engine torque for the traction available on the road surface.


Functional Description

Traction control uses the ABS electronic and mechanical/hydraulic hardware with other valves to control the pressure at the calipers that apply the brakes. There is also an interface with the engine that lets the traction control reduce the engine torque. The signals from the wheel-speed sensors are sent to the ABS module, where they are used to calculate the wheel-slip of each wheel. The traction control will start to operate when one or more of the wheels starts to slip too much.

Engine Intervention

If wheel-slip occurs the ABS/DSC module calculates the torque that needs to be applied by the engine to reduce the wheel-slip (this torque will not exceed the driver's demand). The PCM sends a signal through the CAN bus to tell the engine to reduce torque. When the PCM receives this signal, it controls the ignition and fuelling to reduce the torque. When the traction control is on, a traction control gearshift pattern is selected automatically in the automatic transmission software.

ABS / DSC Circuit



- | | | |
|-----------------------------|--------------------------------|---------------------------------|
| 1. Underbonnet Fusebox | 6. Front ABS Sensor - Left | 11. Brake Pedal Travel Sensor |
| 2. ABS Module | 7. Yawrate/Acceleration Sensor | 12. Brake Pressure Sensor |
| 3. Rear ABS Sensor - Left | 8. Brake Boost Switch | 13. Steering Angle Sensor Earth |
| 4. Rear ABS Sensor - Right | 9. ABS Module Earth | 14. Steering Angle Sensor |
| 5. Front ABS Sensor - Right | 10. Body (B) OBD2 | |

Specifications

Oils/Greases

Brake Fluid Castrol Response Super Dot 4

Torque Figures

Description	Nm.	lb. / ft.
Modulator to Bracket	5	4
Modulator/Bracket to body	9	7
Brake hose unions	17	13
	14	10.5

Torque Figures

Description	Nm.	lb. / ft.
	17 Nm.	14 Nm.
	14 Nm.	17 Nm.

Maintenance

ABS Modulator - Remove and Install

Repair Operation Time (ROT)	
Item	Code
ABS Modulator - Remove and Install	RHD 06.06.CB

Remove

⚠ WARNING ⚠
BRAKE FLUID IS POISONOUS.
DO NOT DRINK THE BRAKE FLUID OR LET IT TOUCH YOUR SKIN OR EYES. IF YOU GET BRAKE FLUID IN YOUR MOUTH, GET MEDICAL AID IMMEDIATELY. FLUSH ALL BRAKE FLUID FROM YOUR EYES OR SKIN WITH WATER AND GET MEDICAL AID.


WARNING
HYDRAULIC FLUID ABSORBS WATER VAPOUR. ONLY USE BRAKE FLUID FROM NEW CONTAINERS WHEN YOU FILL THE BRAKE FLUID RESERVOIR. IF YOU DO NOT, IN THE FLUID CAN CAUSE THE PERFORMANCE OF THE BRAKES TO DECREASE.

Caution
Do not let brake fluid touch the vehicle paint work. If you do the paintwork can be damaged. Flush all spilled brake fluid from the paintwork with water.


1. Disconnect the vehicle battery.
2. Raise the vehicle and make it safe.
3. Remove the passenger-side road wheel and the road wheel arch liner.

Note: Put a cloth around the brake reservoir filler neck to absorb spilled brake fluid.


4. Record the pipe locations for assembly.
5. Remove the six brake pipe unions from the top of the modulator valve block. Seal each pipe and seal each valve block outlet to prevent leakage and contamination.



6. Remove the three bolts (1) that attach the modulator mounting (see the figure below).



7. Disconnect the modulator electrical connector (1) (refer to the figure that follows).




8. Remove the three bolts (2) that attach the modulator to its bracket.



You can change the ABS/DSC control module independently from the modulator. You do not need to disassemble the hydraulic circuit when you change it.

Install

1. Install the modulator to its mounting bracket. Attach it with the three bolts (2)(Refer to the Figure that follows).
2. Torque the three M6 bolts (2).



3. Connect the electrical connector.
4. Install the modulator and the bracket assembly. Attach it with the three M8 screws (1).
5. Torque the M8 screws (1).
6. Remove the sealing materials from the brake pipes and the valve block.
7. Install the six brake pipes to their correct outlets on the valve block.
8. Torque the unions as shown in the figure that follows:



9. Remove all signs of brake fluid from the modulator and adjacent area.
10. Put the wheel arch liner back in the correct position.
11. Install the self-tapping screw that attaches the rear of the wheelarch liner into the wheelarch.
12. Install the five or six screws to attach the wheel arch liner.
13. Bleed the brake system (Refer to 'Brake Bleeding - AMDS', page 6-6-4).
14. Connect the vehicle battery.
15. Lower the vehicle.

WARNING

BEFORE YOU DRIVE THE VEHICLE, OPERATE THE FOOT BRAKE PEDAL 2 OR 3 TIMES TO MAKE SURE THAT THE FOOT BRAKE OPERATES CORRECTLY. YOU MUST OPERATE BRAKE CALIPER PISTONS TO CLOSE THE SPACE BETWEEN THE BRAKE PADS AND THE DISC.



ASTON MARTIN

Transmission (07.00)

Contents

Automatic Transaxle (07.01).....	7-1-2	<i>Remove</i>	3-3
Description	1-2	<i>Install</i>	3-4
Cooling.....	1-2	Differential Output Seal (Left Side).....	3-5
Mechatronic module	1-2	<i>Remove</i>	3-5
Specifications.....	1-3	<i>Install</i>	3-6
Gearbox	1-3	Differential Output Seal (Left Side).....	3-7
Differential.....	1-4	<i>Remove</i>	3-7
Maintenance	1-4	<i>Install</i>	3-8
Transmission Oil Check/Fill.....	1-4	Differential (Limited Slip)	3-8
Differential Oil Check/Fill	1-4	<i>Remove</i>	3-8
Automatic Transaxle.....	1-5	<i>Install</i>	3-9
<i>Remove</i>	1-5	Automatic Control System (07.05)	7-5-1
<i>Install</i>	1-6	Description	5-1
Mechatronic Unit.....	1-6	Transmission Controls	5-1
<i>Remove</i>	1-6	Gearshift Procedures.....	5-1
<i>Install</i>	1-7	Parking Lock	5-2
Differential	1-9	Hydraulic Shift Control Unit.....	5-3
<i>Remove</i>	1-9	<i>TCM Monitoring Functions</i>	5-5
<i>Install</i>	1-9	TCM Supply Voltage	5-8
Differential Output Seal (Left)	1-10	Shift-by-Wire	5-8
<i>Remove</i>	1-10	Transmission Plug Pin Assignment	5-10
<i>Install</i>	1-11	Maintenance.....	5-10
Differential Output Seal (Right)	1-11	<i>TouchTronic Paddleshift Selector - Remove</i>	
<i>Remove</i>	1-11	and <i>Install</i>	5-10
<i>Install</i>	1-12	<i>Remove</i>	5-10
Differential Oil Filter	1-14	<i>Install</i>	5-10
<i>Remove</i>	1-14		
<i>Install</i>	1-14		
Differential Speed Sensor.....	1-14		
<i>Remove</i>	1-14		
<i>Install</i>	1-14		
Transmission Cooling (07.02)	7-2-1		
Specifications.....	2-1		
Maintenance	2-1		
Oil Cooler (Automatic Gearbox).....	2-1		
<i>Remove</i>	2-1		
<i>Install</i>	2-2		
Thermostat (Automatic Gearbox).....	2-2		
<i>Remove</i>	2-2		
<i>Install</i>	2-3		
Oil Cooler (Automatic Transaxle Differential)	2-3		
<i>Remove</i>	2-3		
<i>Install</i>	2-3		
Oil Cooler (Manual Transaxle).....	2-4		
<i>Remove</i>	2-4		
<i>Install</i>	2-4		
Manual Transmission (07.03).....	7-3-1		
Description	3-1		
Cooling.....	3-1		
Specifications.....	3-2		
Maintenance	3-2		
Oil Check and Fill	3-2		
Drain/Fill	3-2		
Transaxle	3-3		



Transmission (07.00)

Automatic Transaxle (07.01)

Description

The ZF 6HP26 automatic gearbox has the following features:

- Six forward speeds and One reverse
- A torque converter with an integral converter lock-up clutch
- Electronic shift and pressure controls
- A single planetary gear set
- A double planetary gear set
- Two fixed multi-disc brakes
- Three multi-plate clutches

All hydraulic functions are directed by electronic solenoids for control:

- Engagement feel
- Shift feel
- Shift scheduling
- Modulated torque converter clutch (TCC) applications
- Engine braking utilizing the coast clutch

The ZF 6HP26 Automatic Transmission is a six-speed electronically controlled transmission that has the parts that follow:

- A Mechatronik module (Transmission Control Module (TCM) and a main control valve body assembly)
- A torque converter
- One solenoid valve and six pressure regulators.

To select the gears, transmission oil flow is used to operate the different internal clutches

The TCM operates the electrical components and gives control of the shift pressure for the gear selection. This gives better control of the torque converter slip.

If there is a system malfunction, the TCM has Failure Mode Effect Management (FMEM) to make sure that the transmission gives the maximum available performance. At the same time it makes sure there is the minimum possible effect on driver, passenger or vehicle safety.

If there is a total loss of control or electrical power, the transmission keeps the basic functions of Park, Reverse, Neutral and Drive.

The hydraulic system will also keep 3rd or 5th gear if these are selected at the time of the failure.

The transmission also has turbine and output shaft speed sensors, an internal P, R, N, D selector position sensor, and a transmission oil temperature sensor.

The TCM also needs information from the shift selector module to show if the driver has selected manual gears.

The TCM talks to other electronic control modules through the Controller Area Network (CAN).

To obey the CARB OBDII legislation, the TCM does

transmission fault-finding.

This monitors all components that can effect vehicle emissions.

There are also more fault-find functions to make sure that that all malfunctions can be repaired quickly by maintenance staff.

A torque converter supplies the engine power to the transmission. The torque converter has a lock-up clutch.

There are six forward gears and one reverse gear. A single planetary gear set is followed by a double planetary gear set to give the six forward gears. This is named a 'Lepelletier' type gear set.

Cooling

The Auto transmission has an external cooling circuit that prevents overheating of the transmission oil.

A pump is installed in the gearbox that pumps the transmission oil around the radiator and back to the transmission. It operates on changes in the engine speed.

A wax and poppet type thermostat is installed close to the gearbox inlet and outlet to control the oil temperature. The range of operation is 74° C - 88° C.


Mechatronik module

The Mechatronik module is installed in the sump of the automatic gearbox.

It has electrical actuators and sensors and also hydraulic valves which operate with the TCM to change the changes.

The parts are installed so that they can be replaced while the automatic gearbox is still installed in the vehicle.

(Refer to 'Automatic Control System (07.05)', page 7-5-1)



- | | | |
|------------------------|-------------------------|------------------|
| 1. Hydraulic Module | 5. Position Switch | 9. Adaptor |
| 2. Electronic Module | 6. Turbine Speed Sensor | 10. Suction Port |
| 3. Output Speed Sensor | 7. Solenoid Valve | |
| 4. Temperature Sensor | 8. Discharge Port | |

Specifications Gearbox

Type

6 speed ZF 6HP26 automatic transmission and torque converter

Weight

Complete with transmission oil - 89 kg (196.25 lbs) approx.

Control System

Electrohydraulic (Mechatronic)
Controlled on-load shifts
Various shift programs available

Torque Converter

Controlled-slip lock-up clutch in gears 1 - 6 and reverse.

Transmission oil

Shell ATF

Transmission Qty. 10 Ltr (17.06 pt. / 10.57 US qts.)

Coolant system Qty. 1.6 Ltr (2.8 pt. / 1.7 US qts.)

Transmission oil

The ZF 6HP26 automatic transmission is 'filled for life' at manufacturer and will not normally need to be serviced.

Gear Ratios

1st	2nd	3rd	4th	5th	6th
4.17:1	2.34:1	1.52:1	1.14:1	0.87:1	0.69:1
Reverse					
3.40:1					

Maximum Towing Distance

150 km (93 miles) at a maximum speed of 70 km/h (43 mph)

Torque Figures

Description	Nm.	lb. / ft.
Transaxle to Mounting Brackets	20-30	15-22.5
Mechatronics Unit	8	6
Sump	7-9	5.5-7
Gearbox to Differential Adaptor Plate	52-75	38.5-55.5
Subframe cross-member	85	63

Differential

Type

Graziano AM803D

Weight

Complete with differential oil - 47.25 kg (104 lbs) approx

Differential oil

Shell 'Transaxle' oil 75W/90

Gearbox Qty. 1.7 Ltr (3 pt. / 1.8 US qts.)

Coolant system Qty. 0.7 Ltr (1.2 pt. / 0.7 US qts.)

Torque Figures

Description	Nm.	lb. / ft.
Differential Housing Cover (bolts smeared with Loctite 242)	35	26
Output Shaft Cover	10	7.5
Sump Plug	49	36.5
Fill Plug	49	36.5
End Cover	30	22.5

Maintenance

Transmission Oil Check/Fill

The ZF 6 HP26 automatic transmission is 'filled for life' when it is made and it will not usually need to be serviced.

If there is an oil leak from the transmission cooling system, you must repair the leak and then do the steps that follow to add oil to the transmission:

⚠ WARNING ⚠

OBEY ALL TRANSMISSION OIL MANUFACTURERS SAFETY INSTRUCTIONS WHEN YOU DRAIN AND REFILL THE AUTOMATIC TRANSMISSION.

Before you do a check of the transmission oil level, make sure that:

- The car is on a horizontal ramp
- The rear wheels do not move for a minimum of 2 minutes before you start the oil level check and during the process, for example: operate the hand brake
- The transmission sump temperature is between 30° C and 50° C (86° F and 122° F) when you open the filling plug and while you do a check of the oil level
- You have engaged the Reverse and Drive gear positions for a minimum of 3 seconds with **rear wheels braked** before you do a check
- The TCM is not in "limp-home" mode.

1. Remove the rear under tray.


⚠ WARNING ⚠

WHEN THE ENGINE OPERATES, MAKE SURE THAT AN EXHAUST EXTRACTOR SYSTEM IS ATTACHED TO THE EXHAUST SYSTEM.

⚠ WARNING ⚠

DO NOT BREATHE EXHAUST FUMES. EXHAUST FUMES CONTAIN CARBON MONOXIDE. CARBON MONOXIDE IS A DANGEROUS GAS THAT IS COLOURLESS AND ODOURLESS. IT CAN CAUSE UNCONSCIOUSNESS AND CAN KILL.

2. Remove the right exhaust pipe.
3. Operate the engine at between 600 and 750 rpm.
4. Put an applicable container under the fill hole to collect oil that may spill from the opening.
5. Remove the fill plug (1) (at the rear-right side of the transmission) immediately after you start the engine (see Figure below).



6. Add transmission oil to the transmission (Refer to 'Specifications', page 7-1-3), until transmission oil drains out of the bore. Do not add more oil.
7. Wait until the oil that flows from the transmission slows to a dribble for at least one minute or the oil has reached 50° C (122° F).
8. Install the fill plug and make sure that the sump temperature has not gone higher than 50° C (122° F).
9. Install the right exhaust pipe.
10. Install the rear under tray.
11. To make sure that the gearbox and coolant system has been fully filled, do a test drive. Make sure that the transmission cooling thermostat fully opens (75° C (167° F)).
12. Do a check of the transmission oil level.

Differential Oil Check/Fill

If there is an oil leak from the differential cooling system, first you must repair the leak and then you must do the steps that follow to add oil to the differential:

⚠ WARNING ⚠

OBEY ALL DIFFERENTIAL OIL MANUFACTURERS SAFETY INSTRUCTIONS WHEN YOU DRAIN AND REFILL THE DIFFERENTIAL.

Before you do a check of the differential oil level, make sure that:

- The car is on a horizontal ramp


- The rear wheels do not move for a minimum of 2 minutes before you do the oil level check and during the procedure, for example: operate the hand brake
 - Drive the vehicle a short distance to make sure that the differential cooling system has been completely filled
1. Remove the rear under tray.
 2. Place an applicable container under the filler hole to collect the differential oil that may spill from the opening.
 3. Remove the fill plug. With the fill plug removed, the differential oil should just dribble from the opening in the side of the differential.
 4. If necessary, add the specified oil to the differential until it dribbles from the fill hole (Refer to 'Specifications', page 7-1-3).
 5. Install the rear under tray.

Automatic Transaxle


Repair Operation Time (ROT)	
Item	Code
Automatic Transaxle Renew	07.01.AB

Remove

1. Remove the rear subframe with the transaxle (Refer to 'Rear Subframe', page 2-1-4).
2. Remove the six bolts and the three washer tabs from each half-shaft. Discard the bolts.
3. Remove the half-shafts.




4. Use applicable lifting equipment, for example: a hydraulic ramp and sling to hold the transaxle from above.
5. Remove the four bolts to release the transaxle from it's mounts.




6. Remove the transaxle from the subframe.

Install

1. Use applicable lifting equipment, for example: a hydraulic ramp and sling, to hold the transaxle from above.
2. Put the transaxle in position in the subframe.
3. Install the transaxle to its mounting brackets and attach it with the four bolts.
4. Torque the four bolts on each mount to **20-30 Nm**.



5. Put the half-shafts on the differential outputs.



6. Install the three washer tabs and six **new** bolts on each half-shaft.
7. Torque the six bolts to **70 Nm**.

The correct new bolts have a layer of thread lock.


8. If removed. Install the torque converter.
9. Install the rear subframe with transaxle on the vehicle (Refer to 'Rear Subframe', page 2-1-4).
10. Fill the transmission oil (Refer to 'Transmission Oil Check/Fill', page 7-1-4).
11. Start the engine and put the gear selector lever in each position for a minimum of 10 seconds. Stop the engine.
12. Check and if required, fill the transmission oil.

Mechatronik Unit


Repair Operation Time (ROT)	
Item	Code
Mechatronik Unit Renew	07.00.AD

Remove


1. Remove the rear undertray.




2. Remove the four bolts (1) to release the subframe crossmember.




3. Drain the gearbox oil.
4. Remove left rear exhaust pipe (2).
5. Disconnect the coolant pipes (1 and 2) from the gearbox (see Figure below).



- Remove the oil thermostat with the gearbox side coolant pipes (Refer to 'Thermostat (Automatic Gearbox)', page 7-2-2).




- Remove and discard the seals for the the Mechatronik unit.



- Remove the gearbox Capacitor.


The images that follow are taken from the ZF repair manual.

- Remove the 21 screws that attach the sump. Remove the sump. Discard the O-ring seal and the gasket.




Install

- Install new seals for the Mechatronik unit.





- Remove the electrical connector.




- Push the Mechatronik unit into position with your hand.
- Install the 10 screws and torque them, in the sequence shown below, to **8 Nm**.


- Remove the 10 screws (large head, M6) and lift the Mechatronik unit off.




4. Push in the new electrical connector socket into position with the Mechatronik unit screw plug attached. Attach it with the retaining clip.




5. Install a new O-ring seal onto the stub-pipe of the transmission oil filter.
6. Push a new seal into the sump.




7. Install the gearbox capacitor.
8. Install the sump and attach it with the 21 screws. Torque the screws to **7-9 Nm**.




9. Install a new drain plug and torque plug to **9 Nm**.
10. Install the oil thermostat with gearbox side coolant pipes.



11. Connect the coolant pipes (1 and 2) to the gearbox. Torque the bolt to **20-25 Nm** (see Figure below).



12. Install the left rear exhaust pipe (2).
13. Put the subframe crossmember in position and attach it with the four bolts (1).
14. Torque the four bolts (1) to **85 Nm**.



15. Fill the gearbox oil (Refer to 'Transmission Oil Check/Fill', page 7-1-4).
16. Start the engine and put the gear selector lever in each position for at least 10 seconds.
17. Stop the engine.
18. If necessary, fill the gearbox oil.
19. Install the rear undertray.

Differential


Repair Operation Time (ROT)	
Item	Code
Differential Renew	05.02.AB

Remove


1. Remove the rear subframe with the transaxle (Refer to 'Rear Subframe', page 2-1-4).
2. Use applicable lifting equipment, for example: a hydraulic ramp and a sling to hold the transaxle from above.
3. Remove the transaxle from its mounts.
4. Remove the transaxle from the subframe.



5. Remove the four bolts that attach the differential to the gearbox. Remove the differential.




6. Remove the O-ring (1).




Install

1. Install a new O-ring (1).

Look at the line along the O-ring and make sure that the O-ring (1) is not twisted when it is installed.





2. Install the differential and attach it with the four bolts.
3. Torque the bolts to **52-75 Nm**.



4. Use applicable lifting equipment, for example: a hydraulic ramp and a sling to hold the transaxle from above.
5. Put the transaxle in position in the subframe.

6. Install the transaxle to its mounting brackets.
7. Attach the transaxle with the four bolts.
8. Torque the four bolts on each mount to **20-30 Nm**.



9. Remove the four bolts that attach the output shaft cover.

9. If removed, install the torque converter.
10. Install the rear subframe with the transaxle to the vehicle (Refer to 'Rear Subframe', page 2-1-4).
11. If necessary, fill the differential oil (Refer to 'Differential Oil Check/Fill', page 7-1-4).
12. If necessary, fill the transmission oil.

Differential Output Seal (Left)

Repair Operation Time (ROT)	
Item	Code
Differential Output Seal (Left) Renew	07.00.AC

If you need to replace both left and right seals, change the left seal first.

When you replace the right seal, the left output shaft will hold the differential unit in position.

Remove

1. Disconnect the vehicle battery.
2. Raise the vehicle and make it safe.
3. Remove the left road wheel and the road wheel-arch liner.
4. Remove the rear undertray.
5. Remove the service brake and the handbrake calipers (Refer to 'Brake Caliper (Front and Rear)', page 6-3-2).
6. Remove the vertical link (Refer to 'Rear Suspension (04.02)', page 4-2-1).
7. Drain the differential oil.
8. Remove the six bolts and the three washer tabs to release the half-shaft.



10. Attach a slide hammer and remove the output shaft cover complete with the output shaft and the bearing. Discard the O-ring.

The oil pump impeller ring can come out with the output shaft. Make sure that the oil pump impeller ring is in the correct position at installation.

11. Remove the circlip and remove the bearing.





12. Remove the seal.

Install

1. Install a new seal. Push the seal in until it is against the lip in the casing. Apply a small amount of grease to the lip of the seal.
2. Put the output shaft through the seal casing.
3. Install the bearing and attach it with the circlip.




4. Install a new O-ring to the seal casing.
5. Install the output shaft cover complete with the output shaft and the bearing.
6. Install the four bolts and torque to **10 Nm**.

Put the output shaft through the inner oil pump ring. Take care to engage the splines of the output shaft through the oil pump inner ring.

7. Install the half-shaft.
8. Attach it with the six bolts and torque to **70.5 Nm**.
9. Install the vertical link (Refer to 'Rear Suspension (04.02)', page 4-2-1).
10. Install the service brake and the handbrake calipers (Refer to 'Brake Caliper (Front and Rear)', page 6-3-2).

11. Make sure that the drain plug is installed. Torque the drain plug to **49 Nm**. Fill the differential with the specified oil (Refer to 'Specifications', page 7-1-3).



12. Install the road wheel-arch liner and the road wheel (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
13. Drive the vehicle a short distance to make sure that the differential cooling system has been fully filled. Do a check of the oil level and fill if necessary.
14. Install the undertray.

Differential Output Seal (Right)

Repair Operation Time (ROT)	
Item	Code
Differential Output Seal (Right) Renew	07.00.AC

Remove

1. Disconnect the vehicle battery.
2. Raise the vehicle and make it safe.
3. Remove the right road wheel and the road wheel-arch liner.
4. Remove the rear undertray.
5. Remove the brake and the handbrake calipers (Refer to 'Brake Caliper (Front and Rear)', page 6-3-2).
6. Remove the vertical link (Refer to 'Rear Suspension (04.02)', page 4-2-1).
7. Drain the differential oil.
8. Remove the six bolts and three washer tabs that attach the half-shaft .
9. Remove the half-shaft.
10. Remove the 12 bolts that attach the differential housing.
11. Use a slide hammer and remove the differential housing cover with the output shaft.
12. Discard the O-ring.



13. Remove the circlip.

14. Remove the output shaft with the bearing.



15. Remove the two O-rings.



16. Remove the oil seal.



Install

1. Install a new oil seal. Push the seal in until it is against the lip in the casting. Apply a thin layer of grease to the lip of the seal.
2. Put the output shaft through the differential housing cover.
3. Install the bearing circlip.

Put an applicable support under the casting bearing race and press the output shaft to its seat. Make sure that the bearing race does not move. If it does, the shims can be moved.

4. Install two new O rings.




14. Install the undertray.

5. Install the differential housing cover.

6. Apply Loctite 242 to the threads of the 12 bolts. Install the 12 bolts and torque the bolts to **35 Nm**.

7. Make sure that the drain plug is installed. Torque the plug to **49 Nm**. Fill the differential with the specified oil (Refer to 'Specifications', page 7-1-3).



8. Install the half-shaft.

9. Install the six bolts and torque Torque to **70.5 Nm**.

10. Install the vertical link (Refer to 'Rear Suspension (04.02)', page 4-2-1).

11. Install the service brake and the handbrake calipers (Refer to 'Brake Caliper (Front and Rear)', page 6-3-2).

12. Install the road wheel-arch liners and the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).


13. Drive the vehicle for a short distance to make sure that the differential cooling system is correctly filled. Fill the cooling system if necessary.

Differential Oil Filter

Repair Operation Time (ROT)	
Item	Code
Differential Oil Filter Renew	TBA

Remove

1. Remove the rear undertray.



2. Drain the differential oil.
3. Remove the two bolts that attach the oil filter.
4. Remove the oil filter.



Install

1. Install the oil filter with a new O-ring. Install the two bolts and Torque to **5 Nm**.
2. Make sure that the drain plug is installed. Torque the drain plug to **49 Nm**.
3. Fill the differential with the specified oil (Refer to 'Specifications', page 7-1-3).

Drive the vehicle a short distance to make sure that the differential cooling system has been completely filled. Fill the cooling system if necessary.


4. Install the undertray.

Differential Speed Sensor


Repair Operation Time (ROT)	
Item	Code
Differential Speed Sensor Renew	TBA

Remove

1. Remove the rear undertray (1).



2. Put an applicable container under the fill hole to collect all differential oil that may flow from the fill hole.
3. Disconnect the electrical connector from the speed sensor.
4. Remove the bolt to release the speed sensor.



Install

1. Install the speed sensor.
2. Install the bolt that attaches the speed sensor. Torque the bolt to **10 Nm**.
3. Connect the electrical connector to the speed sensor.
4. Do a check of the differential oil level. Add oil if necessary (Refer to 'Differential Oil Check/Fill', page 7-1-4).
5. Install the undertray.

Transmission (07.00)

Transmission Cooling (07.02)

Specifications

Thermostat	°C	°F
Oil cooler thermostat range (Auto only)	74°- 88°	165° - 190°

Torque Figures		
Description	Nm.	lb. / ft.
Cooler Matrix (auto)	8-10	6-7.5
Cooler to subframe (manual)	8-10	6-7.5

Maintenance

Oil Cooler (Automatic Gearbox)


Repair Operation Time (ROT)	
Item	Code
Oil Cooler (Automatic Gearbox) Renew	07.02.AB

Remove

1. Remove the front undertray.

The air intake for the alternator is in the front under tray.


2. Remove the front bumper (Refer to 'Front Bumper', page 1-19-1).
3. Remove the 18 screws to release the 'Slam' panel.



01-02-007


4. Remove the four screws (1) that attach the top of the grill divider.

This gives access to the cooler top hose.




01-07-011

6. Remove the two bolts that attach the PAS cooler. Move the PAS cooler to one side.



7. Remove the cooler matrix air duct.




⚠ WARNING ⚠
THE TRANSMISSION OIL WILL BE HOT AFTER OPERATION. LET THE TRANSMISSION OIL COOL BEFORE YOU REMOVE THE COOLER MATRIX PIPES. IF YOU DO NOT, PERSONAL INJURY CAN OCCUR.

8. Disconnect the two cooler matrix pipes (1 and 2). Seal the open ends.


Some oil will drain when the pipes are removed.

The air intake pipe will decrease access to the cooler matrix pipes.



01-07-010

- Remove the four bolts (1) that attach the cooler matrix. Remove the cooler matrix.



Install

- Put the cooler matrix in position and attach it with the four bolts (1). Torque the four bolts (1) to **8-10 Nm**.
- Put new 'Oetiker' hose clips on the two cooler matrix hoses.

The air intake pipe will decrease access to the cooler matrix pipes.

You can get access to the top cooler matrix pipe through the grill divider.

- Connect the two cooler matrix hoses.
- Install the four screws that attach the top of the grill divider.
- Install the cooler air duct.
- Install the PAS cooler.
- Install the bumper (Refer to 'Front Bumper', page 1-19-1).
- Install the undertray.
- Operate the engine to prime the cooling circuit.
- Do a check of the transmission oil level. If necessary, fill the transmission oil with the specified transmission oil (Refer to 'Transmission Oil Check/Fill', page 7-1-4).

Thermostat (Automatic Gearbox)

Repair Operation Time (ROT)	
Item	Code
Thermostat (Automatic Gearbox) Renew	07.02.FF


Remove

⚠ WARNING ⚠


THE TRANSMISSION OIL WILL BE HOT AFTER OPERATION. LET THE TRANSMISSION OIL COOL BEFORE YOU REMOVE THE COOLER MATRIX PIPES. IF YOU DO NOT, PERSONAL INJURY CAN OCCUR.

- Remove the screw that attaches the clamp for the cooling pipes.


Some oil will drain when the pipes are removed.



- Remove the gearbox cooling pipes (1). Seal the open ends of the pipes (1) and the ports in the gearbox.




- Remove the thermostat and the bracket assembly from the gearbox.




Install

1. Install the thermostat and thermostat bracket assembly to the gearbox.
2. Connect the four cooling pipes (1). Make sure that the O-ring is correctly installed in each pipe union.
Torque each union to **20 Nm**.



3. Install the pipe clamp and attach it with the screw.
Torque the screw to **20-25 Nm**.



4. Start and operate the engine to prime the cooling circuit.
5. Do a check of the transmission oil level. If necessary, fill the transmission oil with the specified transmission oil (Refer to 'Transmission Oil Check/Fill', page 7-1-4).

Oil Cooler (Automatic Transaxle Differential)


Repair Operation Time (ROT)	
Item	Code
Oil Cooler (Automatic Transaxle Differential) Renew	07.02.BA

Remove


1. Disconnect the quick-release coolant pipes.

Some oil will drain when the pipes are removed.

Seal the open ends of the pipes to prevent contamination.



2. Remove the bolt that attaches each of the coolant pipe brackets. Remove the oil cooler.



Install

1. Clip the coolant pipes into their brackets and install the coolant pipe brackets.
2. Connect the coolant pipes.
3. Start and operate the engine to prime the cooling circuit.
4. Do a check of the differential oil level. If necessary, fill the differential oil with the specified differential oil (Refer to 'Specifications', page 7-1-3).



Oil Cooler (Manual Transaxle)

Repair Operation Time (ROT)	
Item	Code
Oil Cooler (Manual Transaxle) Renew	07.02.FC

Remove

1. Disconnect the coolant pipes.

Some oil will drain when the pipes are removed.


Seal the open ends of the pipes to prevent contamination.

2. Remove the two bolts that attach the oil cooler to the subframe. Remove the oil cooler.

Install

1. Put the oil cooler in position on the subframe.
2. Attach the oil cooler with the two bolts and torque bolts to **8-10 Nm**.
3. Connect the coolant pipes.
4. Start and operate the engine to prime the cooling circuit.
5. Do a check of the transmission oil level. If necessary, fill the transmission oil with the specified transmission oil (Refer to 'Transmission Oil Check/Fill', page 7-1-4).

Transmission (07.00)

Manual Transmission (07.03)**Description**

11. Speed Sensor

12. Breather Pipes

13. Sump Plug

The Graziano AM803T transaxle installed to this vehicle has a six speed transmission with synchromesh on all gears. Gear selection is by a twin cable system (shift and select) that operates a bellcrank and H-gate.

Cooling

The manual transaxle has an external cooling circuit. This operates continuously and has a fixed displacement pump that is driven by the input shaft.

The cooler is attached at the rear on the subframe.

Specifications

Type

Graziano AM803T transaxle with:

- Integrated Bellcrank Assembly
- Integrated Reverse Switch
- Plate Type Limited Slip Differential

Synchronisers

Triple Cone Syncros on 1st and 2nd, double cone on all other gears including reverse.

Lubrication

Forced Lubrication system with an integral pump and filter (The filter is a serviceable item)

Transaxle Oil

Shell Transaxle Oil, Fully Synthetic 75W 90

Transaxle Qty. 4 ltr. (7 pt. / 4.2 US qts.)

Coolant System Qty. 0.5 ltr (0.9 pt. / 0.53 US qts.)

Transaxle + Coolant Qty. 4.5 ltr (7.9 pt. / 4.6 US qts.)

Gear Ratios

1st	2nd	3rd	4th	5th	6th
3.154:1	1.947:1	1.435:1	1.148:1	0.935:1	0.758:1
Reverse					
2.385:1					

Differential Locking Ratio

20% Drive, 60% Coast

Torque Figures

Description	Nm.	lb. / ft.
Speedo sensor to cover plate	7	5.5
Sump plug	49	36.5
LH Output shaft housing	10	7.5
half-shaft	70	52
Differential Cover	35	26

Maintenance

Oil Check and Fill

If there is an oil leak from the transaxle cooling system you must:

- repair the leak
- do the procedure below to fill the transaxle oil:

⚠ Warning ⚠

Obey all of the transaxle oil manufacturers safety instructions when you drain and fill the manual transaxle.

Before you do a check of the transmission oil level, make sure that:

- The car is on a horizontal ramp
- The engine is not operating
- The rear wheels do not move for a minimum of 2 minutes before you start the oil level check and during the process, for example: operate the hand brake

1. Put an applicable container under the fill hole to collect transaxle oil that may spill from the fill hole.
2. Remove the fill plug.
If the oil is at the correct level, with the fill plug removed, the oil will just dribble from the hole.
3. If necessary fill the transaxle with the specified oil until oil dribbles from the hole (Refer to 'Specifications', page 7-3-2).

Drain/Fill

1. Put a suitable container under the drain plug to collect the transaxle oil.
2. Remove the drain plug. Let the oil drain into the container.
3. Disconnect the oil cooling pipes and allow the oil in the cooling system to drain in to the container.
4. Install the drain plug with a new sealing washer. Torque the plug to **49 Nm**.
5. Connect the oil cooling system pipes.
6. Fill the transaxle with the correct oil.
7. Drive the vehicle for a short distance to make sure that the transaxle cooling system is filled. If necessary, fill the transaxle again.

Transaxle


Repair Operation Time (ROT)	
Item	Code
Manual Transaxle Renew	07.03.CB

Remove

1. Raise the vehicle and make it safe.

Caution
On a two-post ramp make sure that the vehicle is strapped to the lift.



2. Remove both rear road wheels.
3. Remove the silencer and rear left and right exhaust pipes (1).
4. Remove the four bolts (2) to release the subframe crossmember.




5. Do the steps that follow to remove the half-shafts from the differential:
 - 5.1 Remove the six bolts and the three washer tabs. Discard the bolts.
 - 5.2 Withdraw the half-shafts from the final drive.



6. Disconnect the electrical connector (1) on the right side of the transaxle.
7. Disconnect the electrical connector (2) on the left side of the transaxle.



8. Remove the two bolts (1) that attach the oil cooler to the subframe. Remove oil cooler.



9. Disconnect the breather pipe from the transaxle.


Keep the breather pipe in position on the vehicle to avoid incorrect routing at installation.

10. Use the applicable lifting equipment, for example: a hydraulic jack and a sling to hold the transaxle.
11. Remove the four bolts from each side that attach the transaxle to the two mounts. Discard the bolts.
12. Use the lifting equipment to lower the transaxle until you can access the gear selector cables.
13. Use the service tool (Refer to '501-F116 (IP Removal)', page 20-1-8) to remove the two horseshoe clips and lever the cables from the ball joints.


Caution

Make sure that you use the service tool to remove the ball-joints. If you do not, you can bend the end of the cable. Lever cable from ball joint at a point closest to the ball joint.

14. Do the steps that follow to disconnect the torque tube from the gearbox:
 - 14.1 Use an applicable support to hold the torque tube.
 - 14.2 Remove the eight bolts (1) that attach the torque tube.




15. Remove the transaxle rearward and move the transaxle out from rear subframe.




Install

1. Use the applicable lifting equipment, for example: a hydraulic jack and a sling to hold the transaxle.
2. Put the transaxle in position in the subframe.


3. Move the transaxle to align with the torque tube.
4. Install the eight bolts and torque to **43-57 Nm**.



5. Connect the gear selector cables.
6. Install the transaxle to its mountings. Use four **new** bolts at each mounting.
7. Torque the bolts to **20-30 Nm**.
8. Remove the support.



9. Install the breather pipe.
10. Install the oil cooler.



11. Install the half-shafts. Torque the bolts to **70.5 Nm**.
12. Put the subframe crossmember in position.
13. Attach it with the four bolts and Torque the bolts to **85 Nm**.
14. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
15. Drive the vehicle to test for correct operation.
16. Do a check of the gearbox oil level.

Differential Output Seal (Left Side)


Repair Operation Time (ROT)	
Item	Code
Differential Output Seal (Left) Renew	TBA

If you need to replace both left and right seals at the same time, change the LH seal first.

When replacing the right seal the left output shaft will hold the differential unit.

Remove

1. Disconnect the vehicle battery.
2. Raise the vehicle and make it safe.
3. Remove the left road wheel and road wheel-arch liner.
4. Remove the rear undertray.
5. Remove the service brake and handbrake calipers (Refer to 'Brake Caliper (Front and Rear)', page 6-3-2).
6. Remove the vertical link (Refer to 'Rear Suspension (04.02)', page 4-2-1).
7. Drain the differential oil.



8. Remove the six half-shaft bolts and the three washer tabs. Remove the half-shaft.



9. Remove the four bolts that attach the output shaft cover. **Install**



1. Install a new seal. Push the seal in until it is against the lip in the casing. Apply a thin layer of grease to the lip of the seal.
2. Put the output shaft through the seal casing. Install the bearing and circlip.



10. Attach a slide hammer use it to remove the output shaft cover complete with the output shaft and bearing. Discard the O-ring.

11. Remove the circlip and remove the bearing.



3. Install a new O-ring to the seal casing.
4. Install the output shaft cover with output shaft and bearing. Install the four bolts and torque them to **10 Nm**.
5. Install the half-shaft.
6. Install the six bolts and torque to **70.5 Nm**.
7. Install the vertical link (Refer to 'Rear Suspension (04.02)', page 4-2-1).
8. Install the service brake and the handbrake calipers (Refer to 'Brake Caliper (Front and Rear)', page 6-3-2).
9. Make sure that the drain plug is installed (Torque **49 Nm**). Fill the differential with the specified oil (Refer to 'Specifications', page 7-3-2).
10. Install the undertray.
11. Install the road wheel-arch liner and the road wheel (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
12. Connect the vehicle battery.



12. Remove the seal.

Differential Output Seal (Left Side)

Repair Operation Time (ROT)	
Item	Code
Differential Output Seal (Right) Renew	TBA

Remove

1. Disconnect the vehicle battery.
2. Raise the vehicle and make safe.
3. Remove the right road wheel and road wheel arch liner.
4. Remove the rear undertray.
5. Drain the differential oil.



6. Remove the six half-shaft bolts and three washer tabs. Remove the half-shaft.
7. Remove the 12 bolts that attach the differential housing cover.
8. Attach a slide hammer and remove the differential housing cover with the output shaft.



9. Remove the two O-rings.



10. Remove the circlip. Remove the output shaft with bearing.



11. Remove the seal.

Install

1. Install a new seal. Push the seal in until it seats against the lip in the casting. Smear the lip with a small amount of grease.
2. Put the output shaft through the differential housing cover. Install the bearing circlip.

Place a support under the casting bearing race and press the output shaft to its seat. Make sure that the bearing race does not move or the shims can be moved.

3. Install two new O-rings.



4. Install the differential housing cover.
5. Apply a thin coat of Loctite 242 to the 12 bolts. Install the 12 bolts and torque to **35 Nm**.
6. Make sure that the drain plug is installed. Torque the drain plug to **49 Nm**.
7. Fill the differential with the specified oil (Refer to 'Specifications', page 7-3-2).
8. Install the half-shaft. Torque the six bolts to **70 Nm**.
9. Install the vertical link (Refer to 'Rear Suspension (04.02)', page 4-2-1).
10. Install the service brake and the handbrake calipers (Refer to 'Brake Caliper (Front and Rear)', page 6-3-2).
11. Install the undertray.
12. Install the road wheel-arch liners and the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
13. Connect the vehicle battery.

Differential (Limited Slip)


Repair Operation Time (ROT)	
Item	Code
Differential (Limited Slip) Renew	TBA

Remove

1. Disconnect the vehicle battery.
2. Raise the vehicle and make it safe.
3. Remove the right road wheel and road wheel-arch liner.
4. Remove the shear plate and the rear undertray
5. Drain the gearbox oil.



6. Remove the right rear exhaust pipe (Refer to 'Pipes and Supports (09.03)', page 9-3-1).
7. Do the steps that follow to remove the right half-shaft:
 - 7.1 Remove the half-shaft nut.



- 7.2 Remove the six bolts and the three washer tabs.
- 7.3 Remove the half-shaft.



8. Remove the differential cover.
 - 8.1 Install service tool (No.) to differential output shaft.
 - 8.2 Remove bolts (x12).



- 8.3 Withdraw the differential cover.
 - 8.4 Discard the 'O' rings (x2).
9. Remove the differential.

The differential may come out with the differential cover or it may remain in the differential housing located on the L/H output shaft.

Install

1. Insert the differential into the differential housing.
2. Complete with new 'O' rings (x2), install the differential cover. Secure with bolts (x12). Torque bolts to **35 Nm**.
3. Install the half-shaft. Torque bolts (x6) to **70.5 Nm**.
4. Install the exhaust pipe (Refer to 'Pipes and Supports (09.03)', page 9-3-1).
5. Install the undertray and shear panel.
6. Install the road wheel arches and road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).



ASTON MARTIN

Transmission (07.00)

Automatic Control System (07.05)

Description

Transmission Controls

The transmission shift console is installed in the centre console. There are four push-buttons installed in the transmission shift console that are used to electrically select P,R,N and D. Electrical and electronic data is transmitted from either the push-buttons or the "TouchTronic" paddles that are installed on the steering wheel. This data is routed through the engine electronics. The left "TouchTronic" paddle changes the gear down and the right paddle changes the gear up.

Gearbox Modes

Automatic - Button "D" pressed. The standard drive program is selected that gives automatic gear changes. The engine gives the most economical performance.

Automatic-Sport - This operates when the sport button is pressed. The engine will give maximum performance and the gears will change at higher engine speeds.

Note: 6th gear will not be available.

TouchTronic - The paddles behind the steering wheel will operate. You can manually change all of the forward gears but the gears will automatically change up or down to keep the engine in its maximum operating limits..

TouchTronic-Sport - •The paddles behind the steering wheel will operate. You can manually change all of the forward gears. The gears will only shift up from fifth to sixth if the engine speed increases to maximum.

Gearshift Procedures

Park (P)

You must only push "P" if the vehicle is stopped or moves at less than 2 km/h.

Note: The Shift-By-Wire (SBW) system also has a mechanical emergency release. This overrides Park so that the vehicle can be towed in some conditions.

If you try to set "P" from the drive position ("D"), if the speed of the vehicle is above 2 km/h, the DIM module will show "CANNOT SELECT PARK AT SPEED" and the transmission will select Neutral (N).

Reverse (R)

Only set "R" when the vehicle is stationary and the engine is at idle. You can only set "R" if the foot brake was applied. If you push the "R" button but did not apply the foot brake, the DIM module will show "PRESS BRAKE PEDAL!"

Note: If the vehicle speed is less than approximately 4 km/h (2.5 mph), from the "R" position, you do not need to operate the brake pedal before you press "D". This will let you rock the vehicle to help move it out of snow or mud etc.

If the speed is more than 4 km/h (2.5 mph) the transmission will automatically set to "N".

Neutral (N)

In neutral, there is no power transmitted from the engine to the automatic transmission. Apply the hand brake so that the vehicle cannot roll when you set the transmission to neutral. You must operate the brake pedal when you set "N" from "P". If you do not, the DIM display will show "PRESS BRAKE PEDAL!". You can set the transmission to neutral from all drive positions.

Drive (D)

You can only set "D" if the foot brake is applied and the vehicle is stopped. If you push the "D" button but did not apply the foot brake, the DIM module will show "PRESS BRAKE PEDAL!". When the transmission is in "D", you can operate one of the paddles behind the steering wheel to immediately set the transmission to D-Touch. This will start the standard drive program that gives automatic changes from gear one to six and then gear six to one. In the DIM, the gear in use is added to the "D" shown in the display. For example: "D1" is first gear in the drive position.

Note: If the speed of the vehicle is less than 4 km/h (2.5 mph), from the "R" position, you do not need to operate the brake pedal before you press "D". This will let you rock the vehicle to help move it out of snow or mud etc. If the speed goes more than 4 km/h (2.5 mph), the transmission will select Neutral (N).

Drive (D) - Sport

The Sport program is operated when you push a separate button on the centre console. It must be operated again if the engine is started again. This program uses all of the available power from the engine and it changes the gears at higher engine speeds. 6th gear will not select in automatic Sport mode to improve performance.

Drive (D) - TouchTronic

The two paddles behind the steering wheel are used to change the gears. The left paddle (-) changes the gear down and the right (+) paddle changes the gear up. The up and down gear change positions are controlled so that the engine cannot go too fast. If you do not operate the "+" paddle at the correct time, the transmission will change up to the next higher gear when the engine is at maximum speed. Also, the transmission will change the gear down to prevent an engine underspeed. If you pull both paddles back at the same time, the gear will set to neutral.

Drive (D) - TouchTronic-Sport

When the transmission is in D-TouchTronic Sport mode, the transmission does not change the gear up automatically when the engine is at maximum speed. In the manual program with the sport button operated, the gear will only change up if the paddle is operated with your hand. Only the engine management system will prevent the engine from operating too fast.

Note: The transmission will not select 6th gear in TouchTronic-Sport mode.

Auto-Park / Auto-Neutral

For safety, the automatic transmission has 'Auto-Park' and 'Auto-Neutral'. In some conditions, the automatic transmission will automatically change to the "P" or "N" position.

Driving conditions:

If the engine stops while the transmission is in "D" or "R", but the ignition is on and the vehicle still moves, the transmission will change to "N".

The transmission will automatically change to "P" if all the conditions that follow apply:

- The engine is stopped
- The ignition is set to off
- The vehicle's speed is less than approximately 10 km/h
- The transmission is in "D" or "R".

The transmission will automatically change to "N" if all the conditions that follow apply:

- The engine is stopped
- The ignition is set to off
- The vehicle's speed is more than approximately 10 km/h
- The transmission is in "D" or "R".

This is done so that no power is transmitted through the automatic transmission when you start the engine again.




Figure 07-05-001

Parking Lock

The parking lock is a device to make sure that the vehicle does not move accidentally. It is engaged when the "P" button is pushed. The parking lock puts a pawl into the teeth of the parking lock gearwheel on the transmission output shaft. The road wheels cannot turn because they are connected to the transmission output shaft by the final drive.

There is a mechanical spring system in the transmission that engages and holds the parking lock. It is released electro-mechanically. All of the drive positions for the transmission are operated electrically. There is no detent disc in the transmission. As an alternative, there is a parking disc and a lock cylinder with a solenoid valve.


To Override the Park Lock

WARNING

OPERATE THE HANDBRAKE BEFORE YOU OPERATE THE PARK OVERRIDE. IF YOU DO NOT, THE VEHICLE CAN MOVE. AFTER YOU STOP THE VEHICLE, APPLY THE HANDBRAKE AND PUSH BACK THE PARK OVERRIDE LEVER

Apply the handbrake. Remove the rear-left seat base or the stowage compartment trim and remove the two screws (1) that attach the cover (2) for the park override lever (3). Remove the cover (2).

Pull the manual park override lever (3) fully up on the ratchet to fully release the parking lock.



Apply the handbrake after the vehicle has been towed or if you have moved the vehicle. Lift the manual park override lever a small distance. Push the ratchet release button (4) and lower the manual park override lever (3) down to the stop. The parking lock is now engaged. Install the cover (2) for the park override lever and tighten the two screws (1). Install the rear-left seat base or the stowage compartment trim.

WARNING

THE MESSAGE IN THE INSTRUMENT DISPLAY MUST GO OFF AND THE POSITION DISPLAY MUST CHANGE FROM "N" TO "P". IF IT DOES NOT, IT IS POSSIBLE THAT THE PARK LOCK IS STILL RELEASED AND THE VEHICLE CAN MOVE.

Hydraulic Shift Control Unit

The Hydraulic Shift Control Unit (Mechatronic unit) has both hydraulic and electronic transmission control modules (TCM). It is in the oil sump of the transmission.

This gives:

- The minimum tolerances
- Better coordination of gear changes
- Good reliability because the amount of electrical connections and the interfaces is decreased.

Electrostatic Discharge (ESD)

CAUTION

WHEN YOU DO WORK ON THE TCM AND THE MAIN CONTROL VALVE BODY, YOU MUST USE THE CORRECT PRECAUTIONS TO PREVENT DAMAGE FROM ELECTROSTATIC DISCHARGE (ESD). IF YOU DO NOT, THE ELECTRONIC PARTS CAN BE DAMAGED BY STATIC ELECTRICITY.

Do the steps that follow to help prevent damage to the equipment from ESD.

Personal Wrist-Band Earthing

Always put on a wrist band to drain static electricity from your body. The wrist band is a strap that you put on your wrist. It has a cable that attaches it to an approved ground. The strap must have a device installed so that it can be released quickly in an emergency.



Shoes and Foot Earthing Straps

Put on electrically conductive shoes when you work in an ESD protection zone. This is very important if you cannot wear a wrist band. Because there is a risk of high contact voltages, the shoes must have a resistance of 0.1 MOhm or less.

Transmission Control Module (TCM)

The transmission control module (TCM) and its input and output network controls the transmission operations that follow:

- The time of the gear changes
- The line pressure. (This has an effect on the feel of the gear change)
- The operation of the torque converter clutch.

The TCM uses the signals from the transmission, the engine and the vehicle.

The control program in the TCM uses the signals and data in its memory to calculate:

- The correct gear
- The correct converter lock-up clutch setting
- The best pressures for the gear shift and control of the lock-up clutch.

There are modules on the output side that the TCM uses to control the solenoid valves and pressure regulators. These control the hydraulics of the automatic transmission. The amount and the length of time of the signals to the engine are sent through the CAN bus to the engine management system.

CAUTION

WHEN YOU HAVE DISCONNECTED OTHER CONTROL MODULES OR THE VEHICLE BATTERY, THERE CAN BE FAULT CODES IN THE TCM MEMORY. AFTER YOU HAVE DONE REPAIRS, MAKE SURE THAT THERE ARE NO CODES THAT REMAIN IN THE TCM MEMORY.

CAUTION

WHEN OTHER CONTROL MODULES OR THE VEHICLE BATTERY ARE DISCONNECTED, THIS WILL CAUSE THE TCM MEMORY TO BE DELETED. THIS CAN SHOW AS A DECREASED PERFORMANCE OF THE TRANSMISSION GEAR CHANGES. THE TCM WILL GRADUALLY MAKE ADJUSTMENTS AUTOMATICALLY FOR THE BEST OPERATION OF THE TRANSMISSION. WHEN THE CONTROL MODULES ARE CONNECTED, THE TCM WILL NEED TO LEARN THE TRANSMISSION OPERATING PROPERTIES AGAIN.

Controller Area Network (CAN) Interface

The TCM needs some external signals to help it control the gear changes correctly. To control the time when the gear is changed, the TCM needs:

- Output speed sensor
- Position of the throttle pedal
- Position of the brake pedal
- Position of the virtual gear selector.

The Controller Area Network (CAN) bus is used to send data between the control modules. The TCM gets most of the data that it needs through the CAN bus from the items that follow:

- The Engine Management System (EMS)
- Driver inputs
- The ABS system
- The instrument pack
- Diagnostic tools.

TCM Inputs

Input Speed Sensor (ISS)

The input speed sensor (ISS) gives data about the speed of the transmission input shaft. An inductive pick-up generates a signal that has 36 pulses each revolution.

Output Speed Sensor (OSS)

The output speed sensor (OSS) gives data about the speed of the transmission output shaft. An inductive pick-up generates a signal that has 36 pulses each revolution.

The Accelerator Pedal Position (APP) sensor

The accelerator pedal position (APP) sensor is a potentiometer on the accelerator pedal. It senses the position of the accelerator pedal and sends this data to the TCM. The APP sensor is used to schedule the gear changes and the Torque Converter Clutch (TCC) lock-up.

Engine Coolant Temperature (ECT) Sensor

The Engine Coolant Temperature (ECT) sensor monitors the temperature of the engine coolant and gives this data to the TCM. The ECT sensor controls the operation of the TCC.

Transmission oil Temperature (TFT) Sensor

A thermistor gives an electrical signal that is related to the oil temperature. The signal is measured as a voltage compared to the analogue ground in the TCM.

Park Lock Sensor

The park lock sensor gives data about the position of the the park lock for the shift-by-wire system.

TCM Monitoring Functions

The TCM monitors all of the input and the outputs to identify possible failures. If a fault is sensed, the TCM will do the correct procedure to make sure that the transmission operates safely. At the same time, it gives protection from damage and gives safety for the driver.

Supply Monitoring

If the battery voltage too high or too low, the TCM will sense that there is a fault. For the TCM to identify this fault the engine must operate and the transmission oil temperature sensor must operate correctly.

Solenoid Supply Monitoring

When the operating transistors for the solenoid are activated, the system will do a check for:

- Open circuits
- Short circuits to ground
- Short circuits to the electrical supply.

All of the outputs from the solenoid have protection.

The processor and the applicable steps can quickly identify open circuit and short circuit faults.

Sensor Supply Monitoring

The supply voltage for the sensor is a stabilised supply. This supply is monitored by the TCM by an Analogue to Digital Converter (ADC). If the voltage is not in the correct tolerance, a diagnostic trouble code (DTC) is set and the system does the applicable steps.

Electronically Erasable Programmable Read Only Memory (EEPROM) Monitoring

To identify errors in the Electronically Erasable Programmable Read Only Memory (EEPROM), the TCM calculates four checksums continuously. If the processor finds a fault in a checksum, the TCM will operate an emergency mode to let the vehicle be driven but with less functions. When the TCM is first started, the system checks for faults. Because the EEPROM is used for the storage of fault codes and transmission calibration adjustments, there is no fail-safe function. If a fault occurs, the TCM shows a message in the DIM message centre, right, to tell the driver.



Watchdog Monitoring

The watchdog monitoring system has two functions:

- It makes sure that control of the output is stopped when the solenoid supply transistor is connected.
- It does a check of the correct operation of the safety circuit.

During initialization, the watchdog operates the solenoid supply transistor to make sure that it is possible to prevent the control of the pressure regulator and the solenoid valves. There is a fault if the watchdog cannot stop the operation of the solenoids.

Note: Electrical supply to the solenoids can still be prevented by the high-side switch that controls each solenoid. This means that one safety path does not operate.

Temperature Sensor Monitoring

The TCM will stop if the temperature of the Mechatronik unit goes too high. Before the TCM stops, it will record a fault code. During the procedure to stop, the transmission will go into an emergency mode that lets the vehicle be driven with less function. There is a temperature dependant resistor installed in the TCM that monitors the temperature.

Transmission oil Temperature Sensor Monitoring

The TCM does a check of the transmission temperature sensor for open and short circuit. The temperature must not change by more than a specific amount between one measurement and the next. The temperature of the transmission oil must increase after the engine is started if the temperature of the oil was low at the start.

Gear Ratio Monitoring

The gear ratio diagnostic makes sure that each gear is correctly engaged. After a gear has been changed, the system makes sure that the transmission has engaged the correct gear in the specified time.

Torque Converter Monitoring

The TCM makes sure that torque converter can be locked correctly. If the torque converter lock-up does not occur correctly, the TCM will open the torque converter clutch.

Plausibility Checking

Transmission oil Temperature

The TCM will sense a fault if there is a sudden change of voltage from one measurement to the next. Also, when the engine is started from cold, the transmission temperature will start to increase. Thus the Mechatronik unit and transmission oil temperatures will also increase because the TCM has transmission oil around it.

A fault will be recorded if:

- The engine speed and the output shaft speed is too high for a specified time, and
- The ambient temperature does not increase above a specified level.

Pressure Regulator/Solenoid Monitoring

The system will monitor each pressure regulator and each solenoid to do a check for open circuits and short circuits. The TCM monitors that the electrical current that each solenoid valve and pressure regulator uses is in approved limits. If the current is too high or too low, an error is recorded and the TCM will do the applicable fail-safe procedure.

Output Speed Monitor

It is possible for the TCM to find electrical errors related to the output speed sensor when the vehicle stops or moves. The sensor output is monitored for the applicable signal when the vehicle moves.

Input Speed Monitor

It is possible for the TCM to find electrical errors related to the speed sensor on the input shaft when the vehicle stops or moves. The sensor output is monitored for the applicable signal when the vehicle moves.

Position Sensor Monitoring

The TCM can identify incorrect transmission position requests. If the TCM reads a code that it cannot identify, it will log a fault.

Torque Converter Lock-up Control

The TCM controls how the torque converter clutch is engaged. To do this it uses data from:

- The position of the accelerator pedal
- The output speed of the torque converter
- The temperature of the transmission oil
- The gear that is in use
- The transmission program that is in use.

The Lock-up function will operate in all gears, but usually it is only used in third, fourth, fifth and sixth gears. When it operates, the lock-up clutch in the torque converter is modulated to let it slip a small amount under control. This gives a better gear change quality.

Safety Functions

The safety functions give protection against driver error and system malfunctions.

The system will:

- Stop the reverse gear from being engaged when the vehicle moves forward too fast and
- Prevents the driver from changing the gear down when the engine speed is too high.

If the transmission is in "limp-home" mode, these safety functions do not operate.

The TCM will constantly monitor the transmission for faults. If there is a problem, the TCM will use a "limp-home" mode. If a fault is sensed in the transmission the TCM shows a warning message in the DIM.

The safety concept is based on the following:

- If the electrical supply to the electro-hydraulic actuators is lost, the transmission will start the "limp-home" mode.
- Monitor the solenoid valve to identify very important gear change operations and use the engine speed and transmission input and output speed to compare.
- Each time the vehicle is started, there is a full check on all the safety hardware and the related program parts and signal paths. If there is a malfunction in this part of the system, or if the safety circuit is operated, a message will be shown in the DIM message centre, right.

Limp-home Modes

If a fault is detected in the 'Shift-by-Wire' system the vehicle can go into 'Limp Home' mode. There are three types of 'Limp Home'.

Electrical - "Gearbox Fault Reduced Function" will be shown in the message centre, right.

The TouchTronic and the Sport mode will be disarmed.

Gear changes will still be possible but the quality of the gear changes will be worse.

Note: In some conditions, "D" can only use a fixed gear.

Reduced Engine Performance - "Reduced Engine Perform" will show in the message centre, right. The engine performance will be reduced.

Mechanical - "Limphome No Gear Change Possible" will show in the message centre, right, and you will hear a warning sound. If the vehicle moves forwards in "**D**" or "**D Touch**", it will stay in a locked gear. This will be 3rd gear at lower speeds or 5th gear at higher speeds. If the transmission goes into "limp home" mode in a different position to "**D**" or "**D Touch**" (the forward gears), the park lock will engage.

CAUTION

DO NOT TRY TO OPERATE THE GEARS WHEN THE TRANSMISSION IS IN "LIMP HOME" MODE. IF YOU DO, AND THE VEHICLE MOVES AT 20 KM/H (12.5 MPH) OR LESS, THE ENGINE WILL STOP AND THE PARKING BRAKE WILL BE ENGAGED. IF THE VEHICLE MOVES AT A SPEED ABOVE APPROXIMATELY 20 KM/H (12.5 MPH), THE TRANSMISSION WILL STAY IN 3RD OR 5TH GEAR AS APPLICABLE.

Torque Converter Operation

The TCM will continually monitor the condition of the torque converter

There are three modes of operation for the converter:

Fully open	Torque converter 'disengaged'.
Fully closed	Torque converter 'engaged'.
Slip control	The TCM monitors slip and can apply sufficient pressure to allow a small amount of slip. This mode reduces the torque converter slip to a minimum to give maximum economy. At the same time, it gives protection from vibration and shocks through the transmission.



Torque Converter Clutch

Hydraulic Pressure Regulation

The TCM gives a +12 V supply to the No. 6 pressure regulator. The regulator operates when the opposite connection of the operating winding is grounded. The hydraulic pressure is operated by pulse width modulation (PWM) of the time that the pressure regulator is switched on and off (the duty cycle).

TCM Supply Voltage

The TCM monitors the voltage of the battery and the ignition electrical supply. There is a permanent electrical supply to charge a battery that keeps the memory of the system. If the electrical supply stops, for example: because the battery is disconnected etc., the gear change quality adjustments that have been saved with time will be erased. This will give a decrease in the quality of the gear changes until the transmission records its new adjustments. If the engine speed is above 1600 rpm, and supply voltage goes higher than 16 V or below 7 V, the TCM will operate in "limp-home" mode. If the ignition supply voltage is between 7 volts and 9 volts, the TCM will keep the gear that is currently engaged. If after 2.5 seconds, and the engine speed is more than 1600 rpm, the voltage stays at this level, "limp-home" mode will be operated. This 2.5 second interval is so that the TCM will not operate "limp home" mode if the voltage only changes momentarily.

Shift-by-Wire

In the shift-by-wire (SBW) system driver intention is transmitted by electrical signals.

The driver request is transmitted over the CAN and the 'Backup Line PSU'. Usually, the TCM sends the signal over the CAN, if there is a CAN failure, the signal is sent by the serial backup line. The signal from the serial backup line can only go in one direction.


The EMS receives, does a check and then transmits to the TCM only if the "Heartbeat" signal operates. The TCM then does a check that the driver request is correct. If the conditions (ignition, engine speed, vehicle speed etc.) are obeyed, the correct position is set and transmitted to the DIM over the CAN.

If needed by the TCM, the DIM also shows messages to warn the driver and messages to recommend driver actions.

The SBW system gives an emergency disengagement mechanism for the park lock system to let the vehicle be towed if the engine is not operating.

Signal Chain-Basic Example for D-Button operation

1. Driver input - through the SBW interface.
2. The EMS receives the input signal.
3. The PSU does a check on the input signal. It then buffers the raw signal from the buttons and paddles and supplies the pressed or no pressed, pulled or no pulled information on CAN.
4. The TCM receives the signal and does a check (in the correct conditions of transmission state, engine speed, vehicle speed etc.), if a change of position is permitted. If it is permitted, the TCM starts a position change in the gearbox. At the same time the TCM supplies updated position information on CAN.
5. This position information is received by the DIM and the EMS. The DIM illuminates the actual position distributed from the TCM and the EMS illuminates the position switch LED. For example: The Drive (D) button light will come on when Drive is distributed from the TCM.




A07-05-003

Figure 7-05-003 - Shift-By-Wire Diagram

Key to Figure 07-05-003 - Shift-By-Wire Diagram		
1. Driver Input	P Park	h Hard wired
2. Centre Console	R Reverse	hp Hard wired Park or No Park
3. Steering Wheel	N Neutral	sp Serial Backup Line
4. SBW Interface	D Drive	CAN HS_CAN / Volcano
5. Engine Control Module with Position Selection Module	S Sport Mode Switch	TCM Transmission Control Module
	U Shift Up (+)	DIM Driver Information Module
	D Shift Down (-)	ABS Anti-Blocking System
		LEDs Display LEDs (PRND)

Transmission Plug Pin Assignment

Pin	Assigned to	Notes
1	Series line	Serial Backup Line EMS
2	CAN L	CAN low
3	ISO K	K line (for example application)
4	Not in use	Digital input
5	Not in use	Digital input
6	CAN H	CAN high
7	S4	Heartbeat Supply
8	Not in use	optional input
9	Terminal 15	Wake-up signal, terminal 15 VIGN
10	P signal	P line for starter inhibit
11	S4	Heartbeat
12	not in use	
13	Terminal 31-1	Earth (ground)
14	Terminal 30	Permanent positive (EGS supply voltage)
15	Not in use	
16	Terminal 31-2	Earth (ground) 2



Maintenance

TouchTronic Paddleshift Selector - Remove and Install

Repair Operation Time (ROT)	
Item	Code
TouchTronic Paddleshift Selector - Remove and Install	07.05.AE

Remove

1. Remove the top and bottom shrouds for the steering column (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-4-4).
2. Remove the self-tapping screw that attaches the paddleshift selector to the steering column.
3. Move the paddleshift selector to get access to the electrical connector.
4. Disconnect the electrical connector for the paddleshift selector.
5. Remove the the paddleshift selector.

Install

1. Connect the electrical connector to the paddleshift selector.
2. Put the paddleshift selector in position on the steering column.
3. Install the self-tapping screw that attaches the paddleshift selector to the steering column.
4. Install the top and bottom shrouds for the steering column (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-4-4).

Clutch (08.00)

Contents

Clutch Assembly (08.01)	8-1-2
Description	1-2
Specifications	1-2
Maintenance.....	1-2
Clutch Assembly	1-2
<i>Remove</i>	1-2
<i>Installation</i>	1-3

Clutch (08.00)

Clutch Assembly (08.01)

Description

The clutch assembly is a balanced unit consisting of a flywheel, clutch friction plates and clutch cover.

The clutch is a twin plate, diaphragm spring type assembly.

A concentric clutch slave cylinder is mounted around the first motion shaft in the torque tube bell housing.

The clutch master cylinder is mounted on the engine bulkhead and is operated directly by the clutch pedal.

A hydraulic connection from the master cylinder feeds pressurised fluid to the slave cylinder. The slave cylinder has an extension tube and bleed nipple extending from the left side of the bell housing for bleeding the system after any major work.

Specifications

Clutch Fluid

Castrol/Girling Universal Brake and Clutch fluid.

Clutch Assembly

Balanced assembly with alignment marks

Clutch Plate

Twin friction plates

Torque Figures

Description	Nm	lb / ft.
Flywheel Bolts	75-81	55.5-60
Tighten the bolts in sequence. Loosen the bolts and then torque, in even stages, in the same sequence.		
Clutch Bolts	29-35	21.5-26
Tighten x3 equally-spaced bolts, in-turn, to pull-down the clutch evenly. Then torque all bolts in sequence.		
Starter Motor Bolts.	30-35	22.5-26

Maintenance

Clutch Assembly

Repair Operation Time (ROT)	
Item	Code
Clutch Renew	TBA

Remove

Note alignment marks on clutch cover.

1. Disconnect the vehicle battery.

⚠ WARNING ⚠

IF RASING VEHICLE ON A 'TWO POST' RAMP (VEHICLE SUPPORTED BY UNDERBODY), ENSURE THAT THE REAR END OF THE VEHICLE IS SECURELY STRAPPED TO THE RAMP. FAILURE TO STRAP THE REAR OF VEHICLE DOWN MAY LEAD TO THE VEHICLE FALLING OFF THE RAMP.

2. Raise the vehicle and make safe.

3. Remove the rear road wheel(s) and road wheel arch liners.
4. Remove the front and rear undertrays and the shear plate.

Lower the front undertray to reveal the air intake for the alternator. Release the spring clip and part the flex pipe from the undertray.

5. Remove the transaxle and the torque tube.
 - (Refer to 'Manual Transmission (07.03)', page 7-3-1)
 - (Refer to 'Torque Tube', page 5-1-2).

⚠ WARNING ⚠

THE CLUTCH ASSEMBLY IS HEAVY. ENSURE THE CLUTCH ASSEMBLY IS SUPPORTED BEFORE REMOVING FINAL BOLTS.

6. Install the crankshaft holding tool (crankshaft holding tool 303-1360) to prevent crankshaft turning.



7. Remove bolts (x6) and lock washers. Withdraw the clutch cover and plates.

Caution


The clutch is replaced as a complete assembly (flywheel, clutch plate and clutch cover). Replacing only the clutch plates will result in clutch non-release.

8. Remove the flywheel.

⚠ WARNING ⚠

THE FLYWHEEL IS HEAVY. ENSURE FLYWHEEL IS SUPPORTED BEFORE REMOVING.

- 8.1 Insert bolts into the bolt holes (x2) provided.
- 8.2 Remove bolts (x6).
- 8.3 Using the inserted bolts 'Jack' the flywheel off the crankshaft.
- 8.4 Discard the bolts.




Installation

- If the new clutch assembly is bolted to the flywheel, remove the new clutch assembly from flywheel. Note position of clutch assembly to flywheel.
- If the new clutch assembly is not assembled - assemble with paint marks in alignment:





1. Check that pilot bearing in the rear end of the crankshaft is 0.0-1.0 mm below the crankshaft end face.



2. Install the crankshaft holding tool (crankshaft holding tool 303-1360) to prevent crankshaft turning.
3. Install the flywheel.
 - 3.1 Using a suitable support surface under the flywheel, offer the flywheel to the crankshaft. Locate the flywheel onto the crankshaft dowel.


- 3.2 Loosely install new flywheel mounting bolts (x8) and hand tighten.
- 3.3 Tighten the bolts in the sequence illustrated. Continue until the flywheel face is in full contact with the crankshaft flange.
- 3.4 Loosen the bolts and then torque, in even stages, to **75-81 Nm** in the same sequence.




4. Insert the clutch alignment tool (Refer to '303-667 (Clutch Alignment)', page 20-1-5) through the clutch assembly. Offer this assembly to the flywheel and insert the alignment tool into the crankshaft pilot bearing.

Caution

The flywheel and pressure plate are a balanced assembly. Ensure alignment marks are aligned.



5. Insert new bolts (x9). Tighten x3 equally-spaced bolts in-turn to pull-down the clutch evenly.
Torque all bolts, in sequence, to **29-35 Nm**.



6. Visually check that marks between the clutch and the flywheel are correctly aligned. If not, the clutch must be removed and installed correctly.
7. Remove the alignment tool.
8. Remove the crankshaft holding tool.
9. Install the torque tube and the transaxle.
 - (Refer to 'Torque Tube', page 5-1-2)
 - (Refer to 'Manual Transmission (07.03)', page 7-3-1)
10. Install the starter motor. Torque the starter motor bolts to **30-35 Nm**.
11. Install the front and rear undertrays.
12. Install the road wheel arch liners.
13. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
14. Remove the vehicle securing strap, if installed.
15. Connect vehicle battery.

Exhaust (09.00)

Contents

Exhaust Overview	9-1-2
Silencer Assembly (09.01)	9-1-3
Variable Flow Silencer Assembly	1-3
Pipes and Supports (09.03)	9-3-1
Specifications.....	3-1
Maintenance	3-1
Exhaust System	3-1
Removal.....	3-1
Installation	3-2


Exhaust System (09.00)

Exhaust Overview

The exhaust system consists of two six-branch manifolds, four primary catalytic converters, eight oxygen sensors, two secondary catalytic converters and a single variable flow silencer assembly.


Exhaust gasses flow from the exhaust manifolds, through the primary catalysts, through the secondary catalysts and on to the rear silencer assembly.

Eight oxygen sensors are installed in the exhaust system. The four engine management oxygen sensors are mounted before the primary catalysts. The four catalyst monitor oxygen sensors are mounted between the primary and secondary catalysts.



01-9-001

Exhaust (09.00)

Silencer Assembly (09.01)**Variable Flow Silencer Assembly**

The rear silencer assembly has a variable flow path controlled by two bypass valves.

The system is intended to enhance top end performance in motor sport applications and will not operate in most normal driving conditions.

By directing exhaust gasses through a modified path at high vehicle speeds, exhaust back pressure is reduced and top end performance is enhanced.

As engine speed increase from idle, the bypass valve is open until the engine speed is 1500 rpm.

From 1500 rpm to 3000 rpm, the valve is closed

Above 3000 rpm the bypass valves state is load dependent (fully open at higher loads).



ASTON MARTIN

Exhaust System (09.00)

Pipes and Supports (09.03)

Specifications

Torque Figures		
Description	Nm	lb. / ft.
Catalyst (nuts / bolts)	25.5-34.5	19-25.5
Catalyst (clamps)	19-22	14.5-16.5
Centre pipe to rear pipe (clamp)	39-51	29-38
Rear Pipe to Silencer (bolt)	28-33	21-24.5


Maintenance

Exhaust System

Repair Operation Time (ROT)	
Item	Code
Exhaust System Renew	09.03.NB


Removal

1. Raise the vehicle and make safe.
2. Remove the shear panel and both undertrays.
3. Disconnect the vacuum lines from the bypass valves.
4. Remove the silencer assembly.
 - 4.1 Release bolts (x4) from LH and RH rear pipes.
 - 4.2 Support the silencer and release the front and rear hangers.
 - 4.3 Withdraw the silencer assembly.




01-9-003

5. Remove LH and RH rear pipes.
 - 5.1 Remove subframe cross brace.
 - 5.2 Release clamps (2)
 - 5.3 Release LH and RH pipe hangers from body.
 - 5.4 Withdraw LH and RH rear pipes through the subframe.




01-9-004

6. Remove the center pipes.
 - 6.1 Release clamps (2).
 - 6.2 Push center pipe rearwards to release from rubber mount.



01-9-005

7. Remove the catalysts.
 - 7.1 Release bolts (x3).
 - 7.2 Withdraw catalyst. Repeat for second catalyst.



Installation

Use a proprietary exhaust sealant around all clamp joints prior to securing loosely. Use new manifold flange gaskets.

1. Install, loosely, the LH and RH catalysts.
2. Install, loosely, the center pipes.
3. Install, loosely, LH and RH rear pipes.
4. Install the silencer and the vacuum lines to the bypass valves.
5. Work from the front and set all bodywork clearances.
6. Tighten all the exhaust fixings.
7. Install the subframe cross brace.

Fuel (10.00)


Contents

Fuel Tank and Lines (10.01)	10-1-2
Description	1-2
Fuel Tank.....	1-3
Fuel Pumps.....	1-4
Jet Pumps	1-4
Filler Neck and Check Valve	1-5
Valves and Sensors.....	1-5
Fuel System Schematic	1-6
Evaporative Loss System	1-6
System Operation	1-6
Fuel Tank Vents and Control Valves	1-6
Safety Precautions	1-8
Specifications	1-8
Maintenance	1-9
Fuel System	1-9
Pressure Test the Fuel System.....	1-9
Fuel Filter Assembly - Remove and Install.....	1-9
Fuel Tank - Remove and Install	1-11
Fuel Pump - Remove and Install.....	1-14
Carbon Cannister Assembly	
- Remove and Install	1-16
Hose Assembly, Fuel Vapour	
- Remove and Install	1-16
Sender Assembly for the Fuel Tank	
- Remove and Install	1-17
Fuel Level Vent-Valve Assembly	
- Remove and Install	1-18
Roll Over Valve Assembly, Fuel Vapour	
- Left-Side - Remove and Install.....	1-19

Fuel (10.00)

Fuel Tank and Lines (10.01)

Description



011-1-008


This vehicle uses a return less fuel system in which two fuel pumps, controlled by the fuel pump driver modules, are run to supply fuel through two in-tank filters to the two fuel rails (Refer to 'Fuel Charging System (03.04)', page 3-4-1). Each fuel rail is installed with six fuel injectors. A pressure sensor and a temperature sensor are fitted on the primary fuel rail. The secondary fuel rail is installed only with a pressure sensor. The fuel pump speeds are varied as required to regulate the fuel pressure in the fuel rails.

The RH fuel pump feeds the engine LH bank fuel rail.


The LH fuel pump feeds the engine RH bank fuel rail.

Fuel Tank

The fuel tank incorporates a single filler neck and check valve, internal fuel pumps, internal fuel filters, a sender unit and an 'on board refuelling vapour recovery' system.



Fuel Pumps



The two modular fuel pumps are immersed in the base of the fuel tank. The pumps can deliver up to 150 litres / hour. The in-tank fuel lines connect to the external lines using two quick-fit connectors in the base of the fuel tank.

During normal running, pressurised fuel from each fuel pump passes from the tank, through an 3 micron in-tank fuel filter to one of the two fuel rails on the engine.

Fuel temperature is measured on the primary fuel rail. If fuel temperature becomes excessive, the fuel pressure is increased to prevent fuel vaporisation (boiling).

Fuel pressure is measured by sensors on each fuel rail. The fuel pressure to each rail is regulated as required by continuously changing the run speed of the associated fuel pump. Maximum pressure in the system is limited to 5.3 bar by in-tank pressure regulators.


A constant head of fuel is maintained in the fuel pump modules to ensure that the pumps cannot run dry in a 'low fuel' situation.

Jet Pumps

Fuel feed from the fuel pumps is split three ways:


1. Feed to the fuel rails.
2. Feed to the swirl pot jet pumps (integral to the FDM).
3. Feed to the externally mounted jet pumps.

These pumps ensure that the appropriate pump swirl pot is maintained with fuel under severe dynamic conditions.



Filler Neck and Check Valve


Incoming fuel passes through a check valve at the base of the filler neck. This valve is normally held closed by light spring pressure. The valve opens under the pressure of incoming fuel and closes again when fuel flow ceases. The check valve prevents surging of fuel in the filler neck.



The filler neck also forms part of the on-board refuelling vapour recovery system. Incoming fuel forms a liquid seal in the filler neck. Thus any air displaced during fuel tank filling cannot escape via the filler neck.



Valves and Sensors



Fuel Limit Vent Valve (FLVV)

This valve contains a float which rises to cut off the path for displaced air when the fuel level rises towards maximum during fuel filling. This causes a rapid pressure build up in the tank which triggers the cut-off valve in the fuel delivery nozzle. This discourages overfilling of the fuel tank.

The FLVV also includes an over pressure relief valve set at about 2 psi to vent the tank if all other vents fail.

Roll Over Valves


The roll over valves purpose is to vent the highest point of the tank. If the tank is grossly overfilled (e.g. many clicks over the normal filler nozzle cut-off), the FLVV will suffer a hydraulic lock. The roll over vent valve allows venting of the tank at the highest possible level in this situation.

All three valves allow the tank to breath until it is inverted when they will close to prevent fuel spill. The fuel level vent valve controls the fuel height of the tank by creating a pressure spike inside the tank which shuts of the fill nozzle. If the vehicle is inverted in an accident, this valve will close to prevent leakage of liquid fuel.

Fuel System Schematic

It includes the positive crankcase ventilation and vapour recovery systems.

1. Oil separator
2. PCV valve
3. Check valve
4. Relief valve
5. Vapour management valve
6. Fuel tank pressure transducer
7. Carbon canister
8. Canister vent valve
9. Fuel limit vent valve
10. Test port



Evaporative Loss System

Fuel vapour is displaced from the fuel tank during filling. Vapour is also displaced due to fuel evaporation in higher temperatures. Displaced fuel vapour is absorbed in the carbon canister filter located on top of the fuel tank.


During normal engine running, absorbed fuel vapour is purged from the carbon canisters and mixed with the normal fuel/air charge in the inlet manifold.



System Operation

Displaced fuel vapour leaves the fuel tank via the normally open fuel level vent valve and the roll over valves. It passes through the carbon canister where fuel hydrocarbons are absorbed. Clean air leaves the system via the normally open canister vent valve. This valve is only closed during diagnostic pressure testing of the fuel system.

During normal engine running, the single vapour management valve in the engine bay is periodically opened, when negative pressure exists in the intake manifold, allowing fresh air flow into the open canister vent valve, through the carbon canister, through the vapour management valve and into the primary inlet manifold. This fresh air flow progressively purges any absorbed fuel vapour from the carbon canister.

Fuel Tank Vents and Control Valves






On-Board Refuelling Vapour Recovery

All of the vapour displaced from the tank by refuelling passes through a series of valves and through a carbon canister. This filters out and stores all the fuel vapour and clean air exits the carbon canister port.

Normal Fuel Fill - Air displaced from the fuel tank during filling can only exit via the fuel level vent valve and be forced through the carbon canister. Any fuel vapour in the displaced air is absorbed in the carbon filter material. No fuel vapour can escape to the atmosphere. Clean air then exits the carbon canister, via an additional filter, to atmosphere.

Excessive Fuel Fill - In the event of overfilling of the fuel tank, the fuel level vent valve will close at normal maximum fuel level. Finally the roll over vent valve will close, completely sealing the tank. Any excess pressure in the fuel tank will 'blow off' via the Over-pressure vent valve (part of the roll over vent valves) in the Fuel Level vent valve assembly.





Safety Precautions

Operations on fuel system result in fuel liquid and vapour being present in the working environment. This presents a very serious risk and the following precautions must be strictly observed:

⚠ WARNING ⚠

FUEL SYSTEMS CAN BE DANGEROUS. YOU MUST ONLY DO WORK ON FUEL SYSTEMS IF YOU ARE CORRECTLY TRAINED.

⚠ WARNING ⚠

DO NOT LET PERSONNEL SMOKE IN THE WORK AREA. PETROL VAPOUR IS VERY FLAMMABLE. PUT "NO SMOKING" SIGNS IN THE WORK AREA.

⚠ WARNING ⚠

MAKE SURE THAT THERE ARE NO OPERATIONS THAT CAN CAUSE SPARKS OR FLAMES NEAR THE WORK AREA. PETROL VAPOUR IS VERY FLAMMABLE.

⚠ WARNING ⚠

A CO2 FIRE EXTINGUISHER MUST BE AVAILABLE CLOSE AT HAND.

⚠ WARNING ⚠

DRY SAND MUST BE AVAILABLE CLOSE AT HAND TO SOAK UP ANY ACCIDENTAL FUEL SPILLAGE.

⚠ WARNING ⚠

IF NECESSARY, EMPTY THE FUEL INTO AN EXPLOSION PROOF CONTAINER USING SUITABLE FIREPROOF FUEL HANDLING EQUIPMENT.

⚠ WARNING ⚠

MAKE SURE THAT THE WORK AREA HAS A GOOD AIRFLOW. PETROL FUMES ARE VERY FLAMABLE.

⚠ WARNING ⚠

DISCONNECT THE BATTERY BEFORE YOU DO WORK ON FUEL SYSTEMS. THE ELECTRICAL SYSTEM CAN CAUSE SPARKS WHICH CAN CAUSE A FIRE.

⚠ WARNING ⚠

DO NOT DISCONNECT A FUEL PIPE WHEN THE ENGINE IS IN OPERATION OR A SHORT TIME AFTER OPERATION. THE FUEL SYSTEM OPERATES AT HIGH PRESSURE. IF YOU DISCONNECT A FUEL PIPE WITH PRESSURE IN, THERE IS A RISK OF FIRE OR INJURY.

⚠ WARNING ⚠

DO NOT BREATHE PETROL FUMES OR GET IT ON YOUR SKIN. PETROL IS HARMFUL. PUT ON THE CORRECT PROTECTIVE EQUIPMENT AND CLOTHING WHEN YOU WORK WITH PETROL.

Specifications

Pump Pressure

Nominal pump pressure 40 psi (2.7 bar) above inlet manifold pressure.

Torque Figures

Description	Nm	lb. / ft.
Tank attachment plate bolts	20-25	15-18.5
Tank cover plate nuts	8	5.9

Maintenance

Fuel System

⚠ WARNING ⚠

NEVER DO WORK ON THE FUEL SYSTEM OF A HOT ENGINE.

CATALYSTS AND EXHAUST SYSTEMS OPERATE AT VERY HIGH TEMPERATURES AND ARE A FIRE RISK IF FUEL IS SPILLED ONTO THEM WHEN HOT.

⚠ WARNING ⚠

THE FUEL SYSTEM IS PRESSURISED WHEN THE ENGINE IS OPERATING. RESIDUAL PRESSURE WILL STAY IN THE FUEL SYSTEM WHEN THE IGNITION IS SWITCHED OFF.

IF YOU DISCONNECT A PRESSURISED FUEL LINE, YOU CAN CAUSE A FUEL LEAK AND A FIRE RISK.

Pressure Test the Fuel System

⚠ WARNING ⚠

FIRE RISK. DEPRESSURISE THE FUEL SYSTEM BEFORE YOU DISCONNECT PIPE WORK. USE A PAN OR ABSORBENT CLOTH TO CATCH FUEL SPILLS WHICH CAN OCCUR BECAUSE OF REMAINING PRESSURE. CLEAN UP SPILLAGES IMMEDIATELY AND DISPOSE OF FUEL CONTAMINATED MATERIALS SAFELY.

- Set the AMDS system to monitor the pressure in each fuel rail.
- Start the engine and monitor the fuel pressure readings.
 - Both fuel rails must show a pressure of more than 40 psi for the engine to function satisfactorily.
 - If one of the two fuel rails is lower than 40 psi, do a check for a blocked or not fully blocked fuel filter or fuel lines on the side that has low pressure.
- If the filter and fuel lines are serviceable, it is possible that the fuel pump is defective.

Fuel Filter Assembly - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Fuel Filter - Remove and Install	(x1) 10.01.AB
	(x2) 10.01.BB

Caution

For Volante models, the procedure that follows is done inside the vehicle cabin area. Make sure that no fuel or fuel vapours touch the vehicle interior. Fuel and fuel vapour can damage the interior trim.

Note: On Volante vehicles, the filter is removed and installed with the tank installed. On Coupe vehicles, the filter is removed and installed with the tank removed.

Remove

Volante Models Only:

- Do the applicable steps of procedure 10.01.FB to get access and drain the fuel tank (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

Note: Some fuel will remain in the tank.

Coupe Models Only:

- Do the applicable steps of procedure 10.01.FB to remove and drain the fuel tank (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

All Vehicles:

⚠ WARNING ⚠

DO NOT TOUCH THE EDGES OF THE TANK SERVICE HOLE WITH YOUR HANDS. THE EDGES OF THE SERVICE HOLE ARE SHARP AND CAN CAUSE INJURY.

- Apply tape to the edges of the service hole of the tank to give protection.
- Remove the M5 screw (item 1) that attaches the fuel filter brackets (items 2 and 3) (refer to Figure 1).




Figure 1 (Right Filter Shown)

- Remove the brackets (items 2 and 3) to release the fuel filter (item 4).
- Do the steps that follow to release the outlet pipe from the right filter (refer to Figure 3):
 - Push and hold in the two buttons on the red connector

- While you hold the two buttons in, pull the connector off the filter.




Figure 2

5. Do step 4 again for the inlet pipe.
6. Remove the fuel filter.
7. If necessary, do steps 1 to 6 again for the second fuel filter.

Install

1. Put a fuel filter through the fuel tank opening.

Caution

Make sure that the arrow on the filter points towards the front of the vehicle. If you do not the fuel flow can be affected

2. Connect the inlet and outlet fuel pipes to the filter.

Note: If the connector is not fully installed onto the filter you will not be able to install the outer filter bracket correctly.

3. Assemble the inner attachment bracket (item 4) for the filter to the filter (item 3) (refer to Figure 4).




Figure 4

4. Engage the tab of the inner bracket (item 4) into the slot in the pump baffle plate (item 2).
5. Put the assembly into position and install an applicable spring clip (item 1) to hold the parts.

6. Put the outer attachment bracket (item 5) for the filter (item 3) over the assembly.
7. Use a bradawl or a similar tool to align the holes for the attachment screw.
8. Install the M5 attachment screw to attach the filter and brackets. Do not tighten the screw at this step.
9. Remove the spring clip (item 1).
10. Tighten the M5 screw.
11. If removed, repeat steps 1 to 10 for the second fuel filter.
12. Remove the tape that you applied for protection from the access hole.
13. Put the clamp plate in position over the studs around the access hole.
14. Put a new seal for the service cover in position on the tank.

Note: When you install the service cover plate always use a new seal.

15. Install and torque the seven M6 nuts to attach the service cover and clamp plate in a diagonal sequence.

On Coupe Vehicles Only:

16. Install the fuel tank in the vehicle (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

On Volante Vehicles Only:

17. Install the top cover for the fuel tank.
18. Install the rear interior trim.

All Vehicles

19. Fill the tank.
20. Do a check of the fuel system for leaks.

⚠ WARNING ⚠

DO NOT CONNECT THE BATTERY AND SET THE IGNITION TO ON UNTIL ALL WORK ON THE FUEL SYSTEM IS COMPLETED AND THE AREA IS CLEARED OF FUEL CONTAMINATION.

Caution

Do not operate the fuel pumps without fuel in the tank. If you do the pumps can be damaged.

21. Connect the vehicle battery.

⚠ WARNING ⚠

DO NOT START THE ENGINE UNLESS THE FUEL SYSTEM IS IN A FULLY SERVICEABLE CONDITION.


22. Set the ignition to on.
23. Make sure that there are no fuel leaks.
24. Start the engine and make sure that the fuel system operates correctly.

Fuel System - Depressurise

Repair Operation Time (ROT)

Item	Code
Fuel System - Depressurise	10.01.EK

1. Read and observe the fuel system safety precautions (Refer to 'Safety Precautions', page 10-1-8).
2. Remove the fuel pump relay from the CEM.



3. Try to start the engine.
The engine will operate for approximately 11 seconds and then stop. With the fuel pumps isolated the fuel lines will depressurise.

Note: Two fault codes will show on each bank.

- P0087 'fuel pressure too low'
- P1233 'fuel pump driver module disabled or off line.'

Both of these codes can be erased from each bank after the repairs to the fuel system

⚠ WARNING ⚠

BEFORE YOU DO WORK ON THE FUEL SYSTEM, DISCONNECT THE EARTH LEAD FROM THE VEHICLE BATTERY. SPARKS FROM THE ELECTRICAL SYSTEM CAN CAUSE A FIRE OR EXPLOSION.

4. Switch off the ignition and install the fuel pump relay.

Priming the Fuel System

⚠ WARNING ⚠

FIRE RISK. DO NOT SWITCH ON THE IGNITION UNTIL ALL WORK ON THE FUEL SYSTEM IS COMPLETED AND AREA IS CLEARED OF FUEL AND FUEL VAPOUR CONTAMINATION.

The fuel system is self priming.

Note: There must be a minimum of 5 litres of fuel in the tank.

Fuel Tank - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Fuel Tank - Remove and Install	10.01.FB
Fuel Tank - Remove for Access and Install	10.01.GA

Remove

⚠ WARNING ⚠

BEFORE YOU DO WORK ON THE FUEL SYSTEM DISCONNECT THE EARTH LEAD FROM THE VEHICLE BATTERY.

⚠ WARNING ⚠

READ AND OBEY ALL FUEL RELATED INSTRUCTIONS AT THE START OF THIS CHAPTER AND IN THE BOWSER MANUFACTURER'S DOCUMENTATION BEFORE YOU DO WORK ON THE FUEL SYSTEM.

⚠ WARNING ⚠

FUEL SYSTEMS CAN BE DANGEROUS. YOU MUST ONLY DO WORK ON FUEL SYSTEMS IF YOU ARE CORRECTLY TRAINED.

Note: On Volante vehicles, the fuel tank is drained before removal. On Coupe vehicles, the tank is drained after removal.

All Vehicles

1. Depressurise the fuel system (Refer to 'Fuel System - Depressurise', page 10-1-10).
2. Disconnect the vehicle battery.

Volante Models Only:

1. Open the roof sufficiently to get access to the trim that covers the access cover for the fuel tank.
2. Remove the parts that follow:

Note: For trim, seat belt and seat removal, refer to the procedures that follow:

(Refer to 'Interior Trim (01.05)', page 1-5-1)

(Refer to 'Seating (01.10)', page 1-10-1)

(Refer to 'Restraining Devices (01.20)', page 1-20-1)

- The passenger front seat
 - The two rear seats.
3. Disconnect the seat belt bottom mounts.
 4. Remove the parts that follow:
 - The passenger rear-quarter panel
 - The rear top panel
 - The two seat belts
 - The satellite navigation module (if installed)
 5. Remove the cover plate from over the fuel tank flange.

⚠ WARNING ⚠

DO THE STEPS THAT FOLLOW IN AN AREA WITH GOOD VENTILATION.

6. Remove the seven M6 nuts that attach the clamp plate and the service cover plate for the fuel tank (Refer to Figure 1).




Figure 1

7. Use a bowser to pump the fuel out of the fuel tank.

Note: Some fuel will remain in the tank.

All Vehicles:

⚠ WARNING ⚠
THE FUEL TANK IS VERY HEAVY WHEN IT IS FULL OF FUEL. USE AN APPLICABLE LIFTING PLATFORM WHEN YOU LOWER THE TANK FROM THE VEHICLE.

⚠ WARNING ⚠
DURING THE PROCEDURE THAT FOLLOWS, FUEL CAN BE SPILLED. OBEY THE PRECAUTIONS TO PREVENT THE RISK OF FIRE OR EXPLOSION.

8. Remove the rear subframe (Refer to 'Rear Subframe', page 2-1-4).
9. Disconnect the fuel tank wiring harness connectors.
10. Remove the nut that attaches the earth strap for the fuel tank harness to the body and release the earth strap from the stud (Refer to Figure 2).




Figure 2

11. Release the two clips that attach the fuel tank harness to the body.
12. Release the left side and right side fuel feed pipes from the body.
13. Use the special tool (Refer to '310-134 (Filler Neck Disconnect Tool)', page 20-1-6) to remove the filler neck from the tank (Refer to Figure 3).



Figure 3

14. Seal the filler neck on the tank.
15. Disconnect the on-board refuelling vapour recovery hose (1) to the filter (Refer to Figure 4).



Figure 4

16. Disconnect the vapour purge (1) and fuel pipes (2) from the tank (Refer to '310-040 (Fuel Pipe Disconnect Tool)', page 20-1-6). Seal the open ends on the tank and on the pipes (Refer to Figure 5).




Figure 5

17. Release the clip that attaches the hose to the DTML and disconnect the hose.

⚠ WARNING ⚠

THE FUEL TANK IS VERY HEAVY WHEN IT IS FULL OF FUEL. USE THE APPLICABLE LIFTING EQUIPMENT AND GET THE AID OF ONE MORE PERSON WHEN YOU REMOVE THE TANK.

18. Use the applicable hydraulic lifting equipment to hold the fuel tank.
19. Remove the 18 screws that attach the fuel tank with the compartment lower panel to the body (Refer to Figure 6).



Figure 6

Note: The tank can stay in position after the retaining plate is removed. Move the tank out from the vehicle body.

20. With the aid of one more person, lower the support and remove the fuel tank from vehicle.

For Coupe Vehicles Only:

⚠ WARNING ⚠

DO THE STEPS THAT FOLLOW IN AN AREA WITH GOOD VENTILATION.

21. Remove the seven M6 nuts that attach the clamp plate and the service cover plate for the fuel tank.
22. Remove the clamp plate and the service cover.
23. Collect the seal.
24. Use a bowser to pump the fuel out of the tank.

Note: Some fuel will remain in the tank.

25. If you are installing a new tank on a pre-07 model year vehicle, do the steps that follow:
- 25.1 Remove the fuel vapour hose (Refer to 'Hose Assembly, Fuel Vapour - Remove and Install', page 10-1-16).
- 25.2 Remove the electrical harness from the tank.

Install

⚠ WARNING ⚠

READ AND OBEY ALL FUEL RELATED INSTRUCTIONS AT THE START OF THIS CHAPTER AND IN THE BOWSER MANUFACTURER'S DOCUMENTATION BEFORE YOU DO WORK ON THE FUEL SYSTEM.

1. If you are installing a new tank on a pre-07 model year vehicle, do the steps that follow:
 - 1.1 Install the fuel vapour hose (Refer to 'Hose Assembly, Fuel Vapour - Remove and Install', page 10-1-16) from the old tank.
 - 1.2 Install the electrical harness from the old tank.
2. Put the fuel tank on to the lower panel for the fuel tank compartment.
3. If the clamp plate and the cover plate is removed, Install the with a new gasket.
4. Install and torque the seven M6 Nuts that attach the clamp plate to the fuel tank.
5. With the aid of one more person, use the hydraulic lifting equipment to lift the fuel tank and the lower panel into position.
6. Install and torque the 18 screws that attach the fuel tank to the body.
7. Remove the lifting equipment.
8. Connect the fuel lines.
9. Install the hose to the DTML and install the clip.
10. Connect the fuel vapour purge hose to the fuel tank.
11. Connect the fuel pipe connections and install the pipes to the body.
12. Install the fuel tank harness earth strap to the stud and install attachment nut..
13. Install the clips that attach the fuel tank harness to the body.
14. Connect the electrical connector for the fuel tank.
15. Remove the sealing materials from the filler neck on the tank.
16. Install the filler neck to the tank.
17. Install the rear subframe (Refer to 'Rear Subframe', page 2-1-4).
18. On Volante models, install the parts that follow:
 - The satellite navigation module (if installed)

Note: For trim, seat belt and seat Install refer to the procedures that follow:

(Refer to 'Interior Trim (01.05)', page 1-5-1)

(Refer to 'Seating (01.10)', page 1-10-1)

(Refer to 'Restraining Devices (01.20)', page 1-20-1)

- The two seat belts
- The rear top panel
- The passenger front seat
- The two rear seats
- The passenger rear-quarter panel.

19. Connect the seat belt bottom mounts.
20. Fill the tank.

21. Do a check of the fuel system for leaks.

⚠ **WARNING** ⚠

DO NOT CONNECT THE BATTERY AND SET THE IGNITION TO ON UNTIL ALL WORK ON THE FUEL SYSTEM IS COMPLETED AND THE AREA IS CLEARED OF FUEL CONTAMINATION.

Caution

Do not operate the fuel pumps without fuel in the tank. If you do the pumps can be damaged.

22. Connect the vehicle battery.

⚠ **WARNING** ⚠

DO NOT START THE ENGINE UNLESS THE FUEL SYSTEM IS IN A FULLY SERVICEABLE CONDITION.

23. Set the ignition to on.

24. Make sure that there are no fuel leaks.

25. Start the engine and make sure that the fuel system operates correctly.

Fuel Pump - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Fuel Pump - Remove and Install	(x1) 10.01.CB
	(x2) 10.01.DB

Caution

For Volante models, the procedure that follows is done inside the vehicle cabin area. Make sure that no fuel or fuel vapours touch the vehicle interior. Fuel and fuel vapour can damage the interior trim.

Note: On Volante vehicles, the fuel pump is removed and installed with the tank installed. On Coupe vehicles, the fuel pump is removed and installed with the tank removed.

Remove

Volante Models Only:

1. Do the applicable steps of procedure 10.01.FB to get access and drain the fuel tank (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

Note: Some fuel will remain in the tank.

Coupe Models Only:

1. Do the applicable steps of procedure 10.01.FB to remove and drain the fuel tank (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

All Vehicles:

⚠ **WARNING** ⚠

DO NOT TOUCH THE EDGES OF THE TANK SERVICE HOLE WITH YOUR HANDS. THE EDGES OF THE SERVICE HOLE ARE SHARP AND CAN CAUSE INJURY.

Note: The Figures in this procedure show the right side pump. The procedure for the left pump is similar.

1. Apply tape to the edges of the service hole of the tank to give protection.

2. Remove the M5 screw (item 1) that attaches the fuel filter brackets (items 2 and 3) of the filter for the applicable fuel pump (pump) side (refer to Figure 1).




Figure 1 (Right Filter Shown)

3. Remove the brackets (items 2 and 3) to release the fuel filter (item 4).

4. Do the steps that follow to release the inlet pipe from the right filter (refer to Figure 3):

- Push and hold in the two buttons on the red connector
- While you hold the two buttons in, pull the connector off the filter.

(Refer to Figure 2).




Figure 2

5. Disconnect the cross-feed fuel pipes. (items 1 and 2) (Refer to Figure 3).




Figure 3

6. Disconnect the two electrical connections (item 1) from the pump (Refer to Figure 3).




Figure 3

7. Using the service tool (Refer to '310-140 (Fuel Pump Install / Remove)', page 20-1-7), turn the fuel pump counterclockwise to release it from the mounting bracket. (Refer to Figure 4)




Figure 4

8. Remove the fuel pump.

Install

1. Put the fuel pump in position in its mounting.
2. Use the service tool (Refer to '310-140 (Fuel Pump Install / Remove)', page 20-1-7) to turn the pump clockwise to attach it.

Note: The fuel pump should make a click into position.

3. Install the two electrical connections to the pump.
4. Install the two cross-feed pipes.
5. Connect the inlet fuel pipes to the filter.

Note: If the connector is not fully installed onto the filter you will not be able to install the outer filter bracket correctly.

6. Assemble the inner attachment bracket (item 4) for the filter to the filter (item 3) (refer to Figure 5).




Figure 5

7. Engage the tab of the inner bracket (item 4) into the slot in the pump baffle plate (item 2).
8. Put the assembly into position and install an applicable spring clip (item 1) to hold the parts.
9. Put the outer attachment bracket (item 5) for the filter (item 3) over the assembly.
10. Use a bradawl or a similar tool to align the holes for the attachment screw.



11. Install the M5 attachment screw to attach the filter and brackets. Do not tighten the screw at this step.
12. Remove the spring clip (item 1).
13. Tighten the M5 screw.
14. Remove the tape that you applied for protection from the access hole.
15. Put the clamp plate in position over the studs around the access hole.
16. Put a new seal for the service cover in position on the tank.

Note: When you install the service cover plate always use a new seal.

17. Install and torque the seven M6 nuts to attach the service cover and clamp plate in a diagonal sequence.

On Coupe Vehicles Only:

18. Install the fuel tank in the vehicle (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

On Volante Vehicles Only:

19. Install the top cover for the fuel tank.
20. Install the rear interior trim.

All Vehicles:

21. Fill the tank.
22. Do a check of the fuel system for leaks.

⚠ WARNING ⚠
DO NOT CONNECT THE BATTERY AND SET THE IGNITION TO ON UNTIL ALL WORK ON THE FUEL SYSTEM IS COMPLETED AND THE AREA IS CLEARED OF FUEL CONTAMINATION.

Caution
Do not operate the fuel pumps without fuel in the tank. If you do the pumps can be damaged.

23. Connect the vehicle battery.

⚠ WARNING ⚠
DO NOT START THE ENGINE UNLESS THE FUEL SYSTEM IS IN A FULLY SERVICEABLE CONDITION.

24. Set the ignition to on.
25. Make sure that there are no fuel leaks.
26. Start the engine and make sure that the fuel system operates correctly.

Carbon Cannister Assembly - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Carbon Cannister Assembly - Remove and Install	10.01.GB

Remove

1. Remove the fuel tank and carbon cannister (cannister) assembly (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).
2. Loosen the worm drive clip that attaches the hose at the left end of the cannister.

3. Disconnect the hose.
4. Push in and hold the two buttons on the quick-release connector and disconnect it from the pipe stub at the right side of the cannister.
5. Remove the cable-tie that attaches the the cannister to the cannister bracket.
6. Release the four clips that attach the cannister to the fuel tank.
7. Remove the cannister.
8. Loosen the hose clamp that attaches the hose to the cannister.
9. Remove the hose.

Install

1. Connect the hose to the cannister.
2. Install the clip that attaches the hose.
3. Push the cannister into position onto the cannister bracket until the four clips engage.
4. Install a new cable tie to attach the cannister to the cannister bracket.
5. Connect the hose to the pipe stub at the right side of the cannister.
6. Connect the hose to the hose at the left end of the cannister.
7. Tighten the worm-drive clip to attach the pipe.
8. Install the fuel tank and carbon cannister assembly (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

Hose Assembly, Fuel Vapour - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Hose Assembly, Fuel Vapour - Remove and Install	10.01.DF

Remove

1. Remove the fuel tank and canister assembly (fuel tank) (Refer to , page 10-1-11).
2. Where applicable, disconnect the electrical connector from the vapour hose (hose).
3. Push in and hold the two buttons on the quick-release connector and disconnect it from the outlet pipe on the fuel tank.
4. Remove the Oetiker pipe clamp that attaches the hose to the canister assembly or do step 2 again for the hose on the cannister as applicable.
5. Pull the hose off of the stub pipe on the canister assembly.

Install

1. If applicable, put a new Oetiker pipe clamp on to the new hose.
2. Push the new hose on to the stub pipe of the cannister.

3. If applicable, use the Oetiker tool to close the pipe clamp.
4. Push the quick-release connector on to the outlet pipe of the fuel tank. Make sure that the quick-release connector has fully engaged.
5. Install the fuel tank (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

2. Cut the "fir-tree" cable-tie (1) that attaches the sender harness (2) and the hose to the bracket (3).

Sender Assembly for the Fuel Tank - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Sender Assembly for the Fuel Tank - Remove and Install	10.01.JB

Caution

For Volante models, the procedure that follows is done inside the vehicle cabin area. Make sure that no fuel or fuel vapours touch the vehicle interior. Fuel and fuel vapour can damage the interior trim.

Note: On Volante vehicles, the fuel pump is removed and installed with the tank installed. On Coupe vehicles, the fuel pump is removed and installed with the tank removed.

Remove

Volante Models Only:

1. Do the applicable steps of procedure 10.01.FB to get access and drain the fuel tank (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

Note: Some fuel will remain in the tank.

Coupe Models Only:

1. Do the applicable steps of procedure 10.01.FB to remove and drain the fuel tank (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

All Vehicles:

⚠ WARNING ⚠

DO NOT TOUCH THE EDGES OF THE TANK SERVICE HOLE WITH YOUR HANDS. THE EDGES OF THE SERVICE HOLE ARE SHARP AND CAN CAUSE INJURY.

1. Apply tape to the edges of the service hole of the tank to give protection.

CAUTION

BE CAREFUL THAT YOU DO NOT CUT THE WIRES FOR THE SENDER UNIT WHEN YOU DO THE STEP THAT FOLLOWS.




Figure 1

3. Disconnect the electrical connector (4) from the sender assembly (5).
4. Release the sender assembly (5) from the bracket (6) and remove it.
5. Remove and discard the cut "fir-tree" cable-tie from the bracket (3).

Install

1. Install a new "fir-tree" cable-tie on the bracket (3).
2. Install the sender assembly (5) to the bracket (6).
3. Connect the electrical connector (4) for the sender assembly (5).
4. Attach the sender harness and the hose to the bracket with the "fir-tree" cable-tie.
5. Remove the tape that you applied for protection from the access hole.
6. Put the clamp plate in position over the studs around the access hole.
7. Put a new seal for the service cover in position on the tank.

Note: When you install the service cover plate always use a new seal.

8. Install and torque the seven M6 nuts to attach the service cover and clamp plate in a diagonal sequence.

On Coupe Vehicles Only:

9. Install the fuel tank in the vehicle (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

On Volante Vehicles Only:

10. Install the top cover for the fuel tank.
11. Install the rear interior trim.

All Vehicles:

12. Fill the tank.

13. Do a check of the fuel system for leaks.

⚠ **WARNING** ⚠

DO NOT CONNECT THE BATTERY AND SET THE IGNITION TO ON UNTIL ALL WORK ON THE FUEL SYSTEM IS COMPLETED AND THE AREA IS CLEARED OF FUEL CONTAMINATION.

Caution

Do not operate the fuel pumps without fuel in the tank. If you do the pumps can be damaged.

14. Connect the vehicle battery.

⚠ **WARNING** ⚠

DO NOT START THE ENGINE UNLESS THE FUEL SYSTEM IS IN A FULLY SERVICEABLE CONDITION.

15. Set the ignition to on.

16. Make sure that there are no fuel leaks.

17. Start the engine and make sure that the fuel system operates correctly.

Fuel Level Vent-Valve Assembly - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Fuel Level Vent-Valve Assembly - Remove and Install	10.01.LG

Caution

For Volante models, the procedure that follows is done inside the vehicle cabin area. Make sure that no fuel or fuel vapours touch the vehicle interior. Fuel and fuel vapour can damage the interior trim.

Note: On Volante vehicles, the fuel pump is removed and installed with the tank installed. On Coupe vehicles, the fuel pump is removed and installed with the tank removed.

Remove

Volante Models Only:

1. Do the applicable steps of procedure 10.01.FB to get access and drain the fuel tank (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

Note: Some fuel will remain in the tank.

Coupe Models Only:

1. Do the applicable steps of procedure 10.01.FB to remove and drain the fuel tank (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

All Vehicles:

⚠ **WARNING** ⚠

DO NOT TOUCH THE EDGES OF THE TANK SERVICE HOLE WITH YOUR HANDS. THE EDGES OF THE SERVICE HOLE ARE SHARP AND CAN CAUSE INJURY.

2. Apply tape to the edges of the service hole of the tank to give protection.
3. Remove the Oetiker pipe clamp that attaches the hose to the valve assembly.
4. Pull the hose off of the stub pipe on the valve assembly.

5. Discard the Oetiker pipe clamp.

6. Release the two tabs that attach the valve assembly to its mounting bracket.

7. Move the valve assembly horizontally to remove it from its mounting bracket.

Install

1. Engage the valve assembly with its mounting bracket and move it horizontally until it locks into position.

2. Put a new Oetiker pipe clamp on to the hose.

3. Push the hose on to the stub pipe of the valve assembly

4. Install the Oetiker pipe clamp (Oetiker ring clamp installation tool - 43-28136).

5. Remove the tape that you applied for protection from the access hole.

6. Put the clamp plate in position over the studs around the access hole.

7. Put a new seal for the service cover in position on the tank.

Note: When you install the service cover plate always use a new seal.

8. Install and torque the seven M6 nuts to attach the service cover and clamp plate in a diagonal sequence.

On Coupe Vehicles Only:

9. Install the fuel tank in the vehicle (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

On Volante Vehicles Only:

10. Install the top cover for the fuel tank.

11. Install the rear interior trim.

All Vehicles:

12. Fill the tank.

13. Do a check of the fuel system for leaks.

⚠ **WARNING** ⚠

DO NOT CONNECT THE BATTERY AND SET THE IGNITION TO ON UNTIL ALL WORK ON THE FUEL SYSTEM IS COMPLETED AND THE AREA IS CLEARED OF FUEL CONTAMINATION.

Caution

Do not operate the fuel pumps without fuel in the tank. If you do the pumps can be damaged.

14. Connect the vehicle battery.

⚠ **WARNING** ⚠

DO NOT START THE ENGINE UNLESS THE FUEL SYSTEM IS IN A FULLY SERVICEABLE CONDITION.

15. Set the ignition to on.

16. Make sure that there are no fuel leaks.

17. Start the engine and make sure that the fuel system operates correctly.

Roll Over Valve Assembly, Fuel Vapour - Left-Side - Remove and Install

Repair Operation Time (ROT)

Item	Code
Roll Over Valve Assembly, Fuel Vapour - Left-Side - Remove and Install	10.01.LH

Caution

For Volante models, the procedure that follows is done inside the vehicle cabin area. Make sure that no fuel or fuel vapours touch the vehicle interior. Fuel and fuel vapour can damage the interior trim.

Note: On Volante vehicles, the fuel pump is removed and installed with the tank installed. On Coupe vehicles, the fuel pump is removed and installed with the tank removed.

Remove

Volante Models Only:

1. Do the applicable steps of procedure 10.01.FB to get access and drain the fuel tank (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

Note: Some fuel will remain in the tank.

Coupe Models Only:

1. Do the applicable steps of procedure 10.01.FB to remove and drain the fuel tank (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

All Vehicles:

⚠ WARNING ⚠

DO NOT TOUCH THE EDGES OF THE TANK SERVICE HOLE WITH YOUR HANDS. THE EDGES OF THE SERVICE HOLE ARE SHARP AND CAN CAUSE INJURY.

1. Apply tape to the edges of the service hole of the tank to give protection.
2. Remove the Oetiker pipe clamp that attaches the hose to the valve assembly.
3. Pull the hose off the valve assembly.
4. Release the latch that locks the valve assembly to its mounting bracket.
5. Move the valve assembly horizontally to remove it from its mounting bracket.

Install

1. Engage the valve assembly with its mounting bracket and move it horizontally until it locks into position. As you move the valve assembly horizontally, keep the latch up to make sure that it does not go below the mounting bracket.
2. Put a new Oetiker pipe clamp on to the hose.
3. Push the hose on to the stub pipe of the valve assembly
4. Install the Oetiker pipe clamp (Oetiker ring clamp installation tool - 43-28136).
5. Remove the tape that you applied for protection from the access hole.

6. Put the clamp plate in position over the studs around the access hole.
7. Put a new seal for the service cover in position on the tank.

Note: When you install the service cover plate always use a new seal.

8. Install and torque the seven M6 nuts to attach the service cover and clamp plate in a diagonal sequence.

On Coupe Vehicles Only:

9. Install the fuel tank in the vehicle (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).

On Volante Vehicles Only:

10. Install the top cover for the fuel tank.
11. Install the rear interior trim.

All Vehicles:

12. Fill the tank.
13. Do a check of the fuel system for leaks.

⚠ WARNING ⚠

DO NOT CONNECT THE BATTERY AND SET THE IGNITION TO ON UNTIL ALL WORK ON THE FUEL SYSTEM IS COMPLETED AND THE AREA IS CLEARED OF FUEL CONTAMINATION.

Caution

Do not operate the fuel pumps without fuel in the tank. If you do the pumps can be damaged.

14. Connect the vehicle battery.

⚠ WARNING ⚠

DO NOT START THE ENGINE UNLESS THE FUEL SYSTEM IS IN A FULLY SERVICEABLE CONDITION.

15. Set the ignition to on.
16. Make sure that there are no fuel leaks.
17. Start the engine and make sure that the fuel system operates correctly.



ASTON MARTIN


Steering (11.00)

Contents

Steering Gear (11.01)	11-1-2
Diagnostics	1-2
Symptom Chart.....	1-2
Specifications	1-4
Maintenance	1-4
Wheel Bearing Inspection	1-4
Ball Joint Inspection	1-4
Track-Rod Ends.....	1-5
<i>Removal</i>	1-5
<i>Installation</i>	1-5
Steering Rack.....	1-6
<i>Removal</i>	1-6
<i>Installation</i>	1-6
Power Steering (11.02)	11-2-1
Description	2-1
Specifications	2-2
Maintenance	2-2
System Bleeding.....	2-2
Steering Column (11.04)	11-3-1
Description	3-1
Specifications	3-1
Maintenance	3-1
Steering Column	3-1
<i>Removal</i>	3-1
<i>Installation</i>	3-2
Steering Column Switches (11.05)	11-4-1
Maintenance	4-1
Column Controls.....	4-1
<i>Removal</i>	4-1
<i>Installation</i>	4-1
Steering Wheel (11.06)	11-5-1
Specifications	5-1
Maintenance	5-1
Steering Wheel	5-1
<i>Removal</i>	5-1
<i>Installation</i>	5-1

Steering (11.00)

Steering Gear (11.01)



01-11-001

Diagnostics Symptom Chart

Symptom	Possible Cause	Action
Vehicle wanders from side to side on the road when driven straight ahead with the steering wheel held firmly.	Incorrect tyre size or pressure.	Check for correct tyre size. Adjust tyre pressures.
	Vehicle unevenly loaded or overloaded.	Adjust load.
	Loose or worn tie-rods or tie-rod ends.	New tie-rod end or steering gear.
	Steering gear bolts loose or damaged.	Tighten. New bolts.
	Loose or worn suspension ball joint(s).	New suspension ball joint assembly.
	Steering column universal joint pinch bolt loose.	Tighten pinch bolt.
	Incorrect toe adjustment.	Adjust as required.
	Loose or worn rear suspension.	Tighten if loose. New rear suspension components.
	Steering gear bushes worn or damaged.	New steering gear.

Symptom	Possible Cause	Action
Vehicle tends to pull to one side when driven on a level surface.	Incorrect tyre pressure.	Adjust tyre pressure.
	Incorrect tyre size.	New tyre as required.
	Different tyre or tread type.	
	Vehicle is unevenly or excessively loaded.	Adjust load evenly.
	Incorrect toe adjustment.	Adjust as required.
	Damaged front or rear suspension components.	New suspension components.
	Steering gear valve effort out of balance.	Shift transmission into neutral while driving at no more than 30 miles/hour (50 km/h) and turn the ignition to position I (engine 'Off'-coasting). a. If the vehicle does not pull to one side with the engine off, install a new steering gear. b. If the vehicle drifts with the engine off, 'cross switch' the front wheel assemblies.
		Test at low speed due to directional tyres. a. If the vehicle pulls to the opposite side, switch the wheels that were on the rear to the same side on the front. b. If the vehicle pull direction is not changed, check the front suspension components and toe adjustments.
		Adjust as required.
		New rear suspension components.
Feedback (whining or knocking noises in the steering gear) Condition where roughness is felt in the steering wheel by the driver when the vehicle is driven over rough surfaces.	Loose or worn tie-rods.	New steering gear.
	Steering gear bolts loose or damaged.	Tighten. New bolts.
	Loose suspension bushing, bolts or ball joints.	Tighten. New components.
	Damaged steering column.	New steering column.
Power steering pump or reservoir leaks	Overfilled system.	Correct fluid level.
	Damaged fluid cap.	New fluid cap.
	Loose or damaged hose fittings.	Tighten. New hose.
	Leakage at power steering pump.	New power steering pump.
Poor returnability of the steering	Incorrect tyre pressure.	Check and adjust tyre pressure.
	Incorrect tyre size or type.	New tyre as required.
	Steering column universal joints binding.	New steering column.
	Steering column shaft floor seal may be torn	New floor seal as required.
	Binding or damaged tie-rods.	New steering gear.
	Damaged or worn front suspension components.	New front suspension components as required.
	Incorrect toe adjustment.	Adjust as required.

Symptom	Possible Cause	Action
Excessive steering efforts required to turn corners and during parking manoeuvres	Low power steering pump fluid.	Fill as required. Check for system leaks.
	Damaged accessory drive belt tensioner.	New accessory drive belt tensioner.
	Hose or oil cooler external leak.	New hose or oil cooler as required.
	Hose or cooler line restriction.	New hose as required.
	Fluid aeration.	Bleed system.
Fluid leakage	Overfilled system.	Correct fluid level.
	Component leak.	Locate suspect component and repair as required.
Accessory drive belt squeal	Check accessory drive belt for correct tension or glazing.	New accessory drive belt.
'Chirp' noise in steering pump	Loose or worn accessory drive belt.	New accessory drive belt.
Power steering pump noisy	Low fluid level.	Top up and check for system leaks.
	Power steering pump.	Check for leaks. Repair as required.
		New power steering pump.
'Swish' noise	Fluid flow into bypass valve of the power steering pump valve housing with fluid temperature below 54°C (130°F).	Normal noise.
'Whine' noise	Aerated fluid.	Bleed system.

Specifications

Torque Figures

Description	Nm.	lb / ft.
Ball Joint (nut)	70	52
Track-Rod (lock nut)	70	52
Steering Rack to Subframe	115	85
Steering Rack Pipe Latch Plate	9-12	7-9
Intermediate Shaft Pinch Bolt	21-29	15.5-21.5

Maintenance

The specifications and adjustments for front and rear road wheel alignment are located in Suspension (Refer to 'Road Wheel Alignment (04.00)', page 4-0-2).

Wheel Bearing Inspection

1. Raise, support and make the vehicle safe.
2. Ensure the road wheel rotates freely and that the brake pads are sufficiently retracted, allowing free movement of the road wheel.


Have a colleague observe upper and lower ball joints for movement during the following check. This will ensure that the cause of any free play is correctly identified.

3. Firmly grasp the road wheel at top and bottom. Attempt to move the road wheel inward and outward while lifting the weight of the road wheel off the road wheel bearings.
4. If there is any excess movement in the wheel bearing, replace the bearing assembly.
5. Remove the safety stand and lower the vehicle.

Ball Joint Inspection

Prior to carrying out any inspection of ball joints, inspect the front wheel bearings.

1. Raise, support and make the vehicle safe.
2. Position a safety stand to support the suspension lower arm.
3. While an assistant pulls and pushes the bottom of the road wheel, check for any relative movement between the ball joint and the suspension lower arm. Any lateral movement indicates a worn or damaged lower ball joint. Install new components if required.



01-11-002

4. While an assistant pulls and pushes the top of the road wheel, observe the relative movement between the ball joint and the suspension upper arm. Any lateral movement indicates a worn or damaged upper ball joint. Install new components as required.
5. Remove the safety stand and lower the vehicle.

Track-Rod Ends

Repair Operation Time (ROT)	
Item	Code
Track-Rod Ends Renew	TBA

Removal

1. Raise, support and make the vehicle safe.
2. Remove the front road wheels.
3. Remove the front undertray.
4. Using service tool (Refer to '204-523 (Ball Joint Splitter)', page 20-1-3), remove the track rod-end from the vertical link.

Take care not to cut / damage the track rod end boot when using the ball joint splitter.

5. Loosen the track-rod end lock nut and remove the track-rod end.


Note the number of complete turns to remove the rod end from the track rod.

Installation

1. Install the track-rod end.

Install the rod end the same number of turns it took to remove.

2. Install the track-rod end to the vertical link. Torque nut to **70 Nm**.



3. Install the road wheel.
4. Lower the vehicle.
5. Check the vehicle Toe (Refer to 'Road Wheel Alignment (04.00)', page 4-0-2).
 - If the vehicle Toe is within specifications - Tighten the track-rod end lock nut(s) (**70 Nm**.)
 - If the vehicle Toe is not within specifications - Raise the vehicle and adjust the vehicle Toe

Steering Rack

Repair Operation Time (ROT)	
Item	Code
Steering Rack Renew	RHD 11.02.DB
	LHD TBA


Removal

1. Disconnect the vehicle battery.

Caution

Failure to centre the steering wheel and rack during reassembly may cause damage to the restraint bag clock-spring and also may cause difficulties in attaining correct alignment of the steering wheel in the straight ahead position.

2. Secure the steering wheel in the centred position. Remove the ignition key and engage the steering lock with the road wheel as accurately centred as possible.
3. Support the engine from above (Refer to '303-1080 (Engine Support Adaptor)', page 20-1-6).
4. Raise, support and make the vehicle safe.
5. Remove the front road wheels.
6. Remove the front undertray.
7. Disconnect the steering rack from the steering intermediate shaft (RH drive shown).




8. Disconnect the L/H and R/H rod ends from the vertical link.

9. RH Drive Only.

- 9.1 Disconnect the power steering fluid pipes.

Caution

Whenever the steering gear unions are disconnected the steering gear valve body ports should be capped to prevent ingress of foreign objects.



001-11-005

- 9.2 Remove the front subframe (Refer to 'Front Subframe', page 2-1-2).
- 9.3 Remove bolts (x3) that secure the steering rack to the subframe. Withdraw the steering rack.

10. LH Drive Only.

- 10.1 'Ty-wrap' the steering rack in position. Remove bolts (x3) that secure the steering rack to the subframe.
- 10.2 Remove the front subframe (Refer to 'Front Subframe', page 2-1-2).
- 10.3 Disconnect the power steering fluid pipes.

Caution

Whenever the steering gear unions are disconnected the steering gear valve body ports should be capped to prevent ingress of foreign objects.


- 10.4 Remove 'Ty-wraps' and withdraw the steering rack.

Installation

Always use new washer seals.



1. RH Drive Only.

- 1.1 Install the steering rack to the subframe (new nyloc bolts x3). Tighten bolts to **115 Nm**.



011-11-006



- 1.2 Install the front subframe (Refer to 'Front Subframe', page 2-1-2).
- 1.3 Connect the steering rack pipe work.



4. Recheck both the steering wheel and rack are accurately centred.
5. Install the steering rack to the steering intermediate shaft.

2. LH Drive Only.

- 2.1 'Ty-wrap the steering rack in position.
- 2.2 Connect the power steering fluid pipes.
- 2.3 Install the front subframe (Refer to 'Front Subframe', page 2-1-2).
- 2.4 Install the steering rack to the subframe (new nyloc bolts x3). Tighten bolts to **115 Nm**.



6. Connect the vehicle battery.
7. Fill and bleed the power steering system (Refer to 'System Bleeding', page 11-2-2).

⚠ Warning ⚠
Do not drive the vehicle until the steering geometry has been set and all fixings have been secured.

8. Install the road wheels (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
9. Check and adjust front wheel alignment (Refer to 'Road Wheel Alignment (04.00)', page 4-0-2).
10. Raise the vehicle and install the front undertray.



ASTON MARTIN

Steering (11.00)


Power Steering (11.02)

The power steering system is hydraulically driven and contains a speed sensitive rack and pinion steering gear (ZF Servotronic II ®). Power assistance is generated by an engine driven vane pump, operating at a constant flow rate.

The level of assistance is controlled electronically via an ECU, which receives a vehicle speed signal from the speedometer. The signal is then converted to a controlled electric current, which is then transmitted to an electro-hydraulic transducer (attached directly to the valve housing). This allows steering efforts to remain lighter at lower speeds to aid parking manoeuvres, whilst at higher speeds, efforts are increased, providing greater directional stability.

Hoses / pipes are used to transmit hydraulic fluid throughout the system. The high-pressure line contains a pressure transducer, which sends an electronic signal to the engine management system. This ensures engine rpm is maintained when the steering system draws higher loads from the engine (i.e. during parking manoeuvres). In order to regulate system temperatures, a wire-wound cooler is incorporated into the return line.

Description



01-11-014

The power steering system uses a rack and pinion type steering gear with servotronic steering assistance. The power steering pump is belt driven and the power steering oil cooler is of a wire bound tube type and is mounted in front of the radiator.

The steering assistance decreases smoothly at a calibrated rate to increase the steering efforts required as vehicle speed increases.

The steering efforts are controlled by the servotronic valve (actuator) position, which in turn is controlled electronically by the servotronic ECU housed in the instrument cluster.

Absolute cleanliness must be observed when replenishing the fluid or dismantling any part of the system. A new power steering reservoir must be installed if the steering gear, pump or fluid cooler is to be replaced. New fluid from a sealed container must be used.

Specifications

Item	Data
Pump Pressure (max)	116 +/-4 bar
Turns lock-to-lock	3
Overall steering ratio	17:1
Turning Circle (Kerb To Kerb)	11.5m
Fluids	33270 Texaco Cold Climate Power Steering Fluid 14315G
Capacity	1.3 ltr.
Toe Settings	(Refer to 'Road Wheel Alignment (04.00)', page 4-0-2)

Maintenance

System Bleeding

When filling the reservoir, make sure that the fluid is clean and not agitated prior to use. Pour the fluid slowly to minimize aeration.

1. Check that the reservoir level is well above the Min. mark. Add fluid if required and install the reservoir cap loosely to avoid fluid splashes during system bleeding.
2. Start the engine and run for several minutes. Check the returning fluid in reservoir. When the air bubbles cease to flow, top up the reservoir. Move to step 3.
3. Turn the steering hard over on one lock. Run the engine for several minutes. Check the returning fluid in reservoir. When the air bubbles cease to flow, top up the reservoir. Move to step 4.
4. Turn the steering hard over on opposite lock. Run the engine for several minutes. Check the returning fluid in the reservoir. When the air bubbles cease to flow, top up reservoir. Move to step 5.
5. Allow the engine to idle for 5 minutes with the road wheels in the straight ahead position.
6. Briefly turn the steering to one lock and then to the opposite lock. If no air sounds are heard, bleeding was successful.
If air noises are present, repeat the bleeding procedure.
7. Top-up the reservoir to the max. level and secure the reservoir cap.

Steering (11.00)

Steering Column (11.04)

Description

The steering column has reach and tilt functions. These let the driver manually set the position of the steering column, by using the reach / tilt lever that is on the underside of the steering column. This is independent of the ignition switch position .

The steering intermediate shaft has two parts. The lower shaft is attached to both the steering gear and the upper shaft.

The Electronic Steering Column Lock (ESCL) is attached to the upper casting of the steering column and has a locking pin. The steering column is electrically unlocked when the ignition key is installed and operated to position 2. The lock engages when the ignition switch is removed and the steering wheel is turned to the centre position.

Specifications

Torque Figures			
Description	Nm.	lb/ft	Nominal
Steering Column to cross car beam	21-27	15.5-19.9	24Nm
Upper column to I-shaft	27.3-32.7	20-24.1	30Nm
Vee-yoke to pinion extension shaft	15.5-18.5	11.4-21.2	17Nm
Power coupling to pinion	21.2-28.8	15.6-21.2	25Nm

Maintenance

Top Shroud for the Steering Column - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Top Shroud for the Steering Column - Remove and Install	11.04.AA

Remove

1. Release the steering column adjustment lever.
2. Move the steering wheel to the longest column position.
3. Push the adjustment lever back to lock the steering wheel.
4. Release the seven clips and remove the lower panel from the driver's side of the instrument panel.

For Pre-08MY vehicles:

5. Put the key in the ignition switch and turn it to position 1 to release the Electronic Steering Column Lock (ESCL).

For 08MY vehicles or newer:

6. Put the Emotion Control Unit (ECU) into the docking station at position 2 to release the ESCL.

7. Turn the steering wheel to get access to the top screw in the front face of the shroud at the left side .

Note: The top screw goes through the top shroud and a tab on the bottom shroud to attach it.

8. Remove the screw.
9. Turn the steering wheel to get access to the top screw in the front face of the shroud at the right side .

Note: The top screw goes through the top shroud and a tab on the bottom shroud to attach it.

10. Remove the screw.
11. Remove the top shroud.

Install

1. Put the top shroud in position on the steering column.

For Pre-08MY vehicles:

2. Put the key in the ignition switch and turn it to position 1 to release the Electronic Steering Column Lock (ESCL).

For 08MY vehicles or newer:

3. Put the Emotion Control Unit (ECU) into the docking station at position 2 to release the ESCL.
4. Turn the steering wheel to get access to the top screw hole in the front face of the shroud at the left side.
5. Install the screw.
6. Turn the steering wheel to get access to the top screw hole in the front face of the shroud at the right side.
7. Install the screw.

Bottom Shroud for the Steering Column - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Bottom Shroud for the Steering Column - Remove and Install	11.04.AB

Remove

1. Release the seven clips and remove the lower panel from the driver's side of the instrument panel.

For Pre-08MY vehicles:

2. Put the key in the ignition switch and turn it to position 1 to release the Electronic Steering Column Lock (ESCL).

For 08MY vehicles or newer:

3. Install the Emotion Control Unit (ECU) into the docking station at position 2 to release ESCL.

Turn the steering wheel to get access to the two screws in the front face of the shrouds at the left side (refer to Figure 1).

Note: The top screw goes through the top shroud and a tab on the bottom shroud to attach it.



Figure 1

4. Remove the two screws at the left side of the front face of the column shrouds.
5. Turn the steering wheel to get access to the two screws in the front face of the shrouds at the right side.

Note: The top screw goes through the top shroud and a tab on the bottom shroud to attach it.

6. Remove the two screws at the right side of the front face of the column shrouds.
7. Remove the three screws that attach the bottom shroud to the steering column.
8. On pre-08MY vehicles remove the ignition key from the ignition switch.
9. Remove the bottom shroud.
10. If a new shroud is to be installed on pre-08MY vehicles, remove the ignition switch grommet.

Install

1. If necessary, install the ignition switch grommet on the bottom column shroud (shroud).
2. Put the shroud in position on the steering column.
3. Install the three screws that attach the shroud to the steering column.

For Pre-08MY vehicles:

4. Put the key in the ignition switch and turn it to position 1 to release the ESCL.

For 08MY vehicles or newer:

5. Put the Emotion Control Unit (ECU) into the docking station at position 2 to release the ESCL.
6. Turn the steering wheel to get access to the two screws in the front face of the shrouds at the left side.

Note: The top screw goes through the top shroud and a tab on the bottom shroud to attach it.

7. Install the two screws at the left side of the front face of the column shrouds.
8. Turn the steering wheel to get access to the two screws in the front face of the shrouds at the right side.

Note: The top screw goes through the top shroud and a tab on the bottom shroud to attach it.

9. Install the two screws at the right side of the front face of the column shrouds.
10. Put the lower panel on the driver's side of the instrument panel and engage the seven clips.

Steering Column Gaiter - Renew

Repair Operation Time (ROT)	
Item	Code
Steering Column Gaiter-Renew	11.04.BB

Remove

1. Power driver's seat to its lowest and most rearward position.
2. Remove the top and bottom shrouds from the steering column (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-3-4).
3. Centralise the steering wheel until the steering lock engages.
4. Remove the ignition key.

WARNING

LEAVE THE VEHICLE FOR TWO MINUTES AFTER YOU DISCONNECT THE BATTERY ,BEFORE YOU DO WORK ON THE AIRBAG SYSTEM. IF YOU DO NOT, THE AIRBAG SYSTEM CAN OPERATE AND CAUSE INJURY.

5. Disconnect the vehicle battery.
6. Remove the steering wheel (see Workshop Manual procedure 11.06.AB Steering Wheel - Renew).
7. Attach the rotary coupling in position with masking tape.
8. Release the two clips that attach the column switch harness to the load-spread plate.
9. Pull back steering column bulkhead gaiter.
10. Remove and discard pinch bolt, upper column to intermediate shaft.
11. Remove the four Torx bolts that attach the upper column mounting.
12. Release upper column from intermediate shaft.
13. Support steering column assembly.
14. Remove gaiter from steering column.

Install

1. Install the gaiter on the steering column.
2. Put the upper steering column assembly in position and connect it to the intermediate shaft.
3. Position the upper column to the mounting, install and torque the four Torx bolts.
4. Install and torque the column pinch bolt.
5. Put the steering column gaiter in position.
6. Remove masking tape from the rotary coupler.
7. Install steering wheel (see Workshop Manual procedure 11.06.AB Steering Wheel - Renew).
8. Connect vehicle battery.
9. Install the steering column shrouds (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-3-4).


10. Put the driver's seat and the steering column in their initial positions.

Steering Column - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Steering Column (Upper) Renew	11.04.CB

Removal

1. Operate the driver's seat to its lowest and most rearward position.
2. Remove the top and bottom steering column shrouds (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-3-4).



Caution

Align the steering wheel and the rack to the centre position. If you do not, the rotary coupling can be damaged. Also, it can be difficult to align the steering wheel in the straight-ahead position.


3. Centre the steering and engage the steering column lock.
4. Pull back the bulkhead seal.
5. Remove the pinch bolt that attaches the upper column to the intermediate shaft.
6. Make sure that the vehicle battery is disconnected at the negative terminal.
7. On pre-08MY vehicles, remove the key from the ignition switch.

⚠ WARNING ⚠

LEAVE THE VEHICLE FOR TWO MINUTES AFTER YOU DISCONNECT THE BATTERY, BEFORE YOU DO WORK ON THE AIRBAG SYSTEM. IF YOU DO NOT, THE AIRBAG SYSTEM CAN OPERATE AND CAUSE INJURY.

8. Remove the air bag module (Refer to 'Driver Airbag', page 1-20-4).
9. Remove the steering wheel (Refer to 'Steering Wheel - Remove and Install', page 11-5-1).
10. Use masking tape to hold the rotary coupling in position.
11. On automatic vehicles only, remove the paddle shift assembly.
12. Disconnect the five electrical connectors from the column switches and the rotary coupler.


13. Remove the four M8 upper column attachment screws.




14. Remove the upper column from the intermediate shaft.

Installation

1. Do the steps that follow to install the upper column:
 - 1.1 Connect the intermediate shaft to the upper column.
 - 1.2 Put the steering column in position onto its mount.
 - 1.3 Install the four M8 attachment screws.
 - 1.4 Torque the four screws to **21 - 27 Nm**.



2. Install the M8 universal joint attachment screw.
3. Torque the screw to **20-25 Nm**.
4. Install the bulkhead seal.



5. Install the steering column switch block (Refer to 'Column Controls', page 11-4-1).
6. Connect the wiring harness plugs.
7. Remove the material applied to hold the clockspring rotor in position.
8. **Automatic Vehicles Only.**
Install the paddle shift assembly. Connect the wiring harness plug.
9. Install the steering wheel (Refer to 'Steering Wheel - Remove and Install', page 11-5-1).
10. Install the air bag module (Refer to 'Driver Airbag', page 1-20-4).
11. Install the steering column cowls.
12. Install the underscuttle.

13. Connect the vehicle battery.

Top and Bottom Shrouds for the Steering Column - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Top and Bottom Shrouds for the Steering Column - Remove and Install	11.04.DB

Remove the Bottom Shroud

1. Release the seven clips and remove the lower panel from the driver's side of the instrument panel.

For Pre-08MY vehicles:

2. Put the key in the ignition switch and turn it to position 1 to release the Electronic Steering Column Lock (ESCL).

For 08MY vehicles or newer:

3. Put the Emotion Control Unit (ECU) into the docking station at position 2 to release the ESCL.
4. Turn the steering wheel to get access to the one or two screws in the front face of the shrouds at the left side.

Note: The top screw goes through the top shroud and a tab on the bottom shroud to attach it.



Figure 1

5. Remove the one or two screws at the left side of the front face of the column shrouds.
6. Turn the steering wheel to get access to the one or two screws in the front face of the shrouds at the right side.

Note: The top screw goes through the top shroud and a tab on the bottom shroud to attach it.

7. Remove the one or two screws at the right side of the front face of the column shrouds.
8. Remove the three screws that attach the bottom shroud to the steering column.
9. On pre-08MY vehicles remove the ignition key from the ignition switch.
10. Remove the bottom shroud.
11. If a new shroud is to be installed on pre-08MY vehicles, remove the ignition switch grommet.

Remove the Top Shroud

1. Release the steering column adjustment lever.
2. Move the steering wheel to the longest column position.
3. Push the adjustment lever back to lock the steering wheel.
4. Remove the top shroud.

Install the Top Shroud

1. Put the top shroud in position on the steering column.

Install the Bottom Shroud

1. If necessary, install the ignition switch grommet on the bottom column shroud (shroud).
2. Put the shroud in position on the steering column.
3. Install the three screws that attach the shroud to the steering column.

For Pre-08MY vehicles:

4. Put the key in the ignition switch to release the ESCL.

For 08MY vehicles or newer:

5. Put the Emotion Control Unit (ECU) into the docking station at position 2 to release the ESCL.
6. Turn the steering wheel to get access to the one or two screws in the front face of the shrouds at the left side.

Note: The top screw goes through the top shroud and a tab on the bottom shroud to attach it.

7. Install the one or two screws at the left side of the front face of the column shrouds.
8. Turn the steering wheel to get access to the one or two screws in the front face of the shrouds at the right side.

Note: The top screw goes through the top shroud and a tab on the bottom shroud to attach it.

9. Install the one or two screws at the right side of the front face of the column shrouds.
10. Put the lower panel on the driver's side of the instrument panel and engage the seven clips.

Steering Column Lower Shaft Assembly-Renew

Repair Operation Time (ROT)	
Item	Code
Steering Column Lower Shaft Assembly-Renew	11.04.DD

Remove

1. Operate the driver's seat to its lowest and most rearward position.
2. Raise the vehicle and make it safe.
3. Remove the left side front wheel arch liner (see Workshop Manual procedure 01.02.FB Wheel Arch Liner - Front - LH - Renew).
4. Remove and discard the link bolt that attaches the lower steering column shaft to the coupling.
5. Release the shaft link for the lower steering column from the coupling.

6. Lower the vehicle.
7. Remove the top and bottom shrouds from the steering column (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-3-4).
8. Disconnect the vehicle battery.
9. Turn the steering to the centre position to engage the column lock and remove the ignition key.
10. Remove the steering wheel (Refer to 'Steering Wheel-Renew', page 11-5-1).
11. Use masking tape to hold the rotary coupling in position.
12. Release the two clips that attach the column switch harness to the load-spread plate.
13. Pull back the steering column bulkhead gaiter.
14. Remove and discard the pinch bolt that attaches the upper column to the intermediate shaft.
15. Remove the four Torx bolts that attach the upper column mounting.
16. Release the upper column from lower steering column shaft.
17. Use an applicable support to hold the steering column assembly.
18. Remove the lower steering column shaft.

Installation

1. Install the lower steering column shaft.
2. Raise the vehicle and make it safe.
3. Connect the lower steering shaft to the coupling.
4. Install a new bolt but do not torque at this stage.
5. Lower the vehicle.
6. Put the upper steering column assembly in position.
7. Connect it to the intermediate shaft.
8. Put the upper column in position on its mounting.
9. Install and torque the four Torx bolts.
10. Install and torque column pinch bolt.
11. Put the steering column gaiter in position.
12. Remove the masking tape from the rotary coupler.

Caution

Align the steering wheel and the rack to the centre position during assembly. If you do not, the rotary coupling can be damaged. Also, it can be difficult to align the steering wheel in the straight-ahead position.

13. Install steering wheel (Refer to 'Steering Wheel-Renew', page 11-5-1).
14. Install the steering column shrouds (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-3-4).
15. Raise the vehicle and make it safe.
16. Torque tighten lower steering column shaft link bolt.
17. Install LH front wheel arch liner (see Workshop Manual procedure 01.02.FB Wheel Arch Liner - Front - LH - Renew).
18. Lower the vehicle.
19. Connect the vehicle battery.



20. Put the driver's seat and the steering column in their initial positions.

Steering (11.00)

Steering Column Switches (11.05)

Maintenance

Ignition Switch (Pre-08 MY Only) - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Ignition Switch-Renew	11.05.AB

Remove

1. Operate the driver's seat to its lowest and most rearward position.
2. Remove the steering column shrouds (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-4-4).

WARNING
LEAVE THE VEHICLE FOR TWO MINUTES AFTER YOU DISCONNECT THE BATTERY BEFORE YOU DO WORK. IF YOU DO NOT, THE AIRBAG SYSTEM CAN OPERATE AND CAUSE INJURY

3. Disconnect the vehicle battery.
4. Turn the steering wheel to the centre position until the steering lock engages.
5. Remove the screw that attaches the load-spread plate to the column.
6. Remove the mounting bracket for the column shrouds.
7. Release the two clips that attach the column switch harness to the load-spread plate.
8. Release the steering column switch from the column (to give access).
9. Release the ignition switch from the column.
10. Disconnect the electrical connector from the ignition switch.

Install

1. Connect the electrical connector to the ignition switch.
2. Install the ignition switch onto the column.
3. Install the steering column switch.
4. Put the load-spread plate in position and attach the two harness clips.
5. Install the screw that attaches the load-spread plate.
6. Install the steering column shrouds (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-3-4).
7. Connect the vehicle battery.
8. Operate the driver's seat to its initial position.

Steering Column Stalk Assembly Switch-Renew (Pre-08 MY Only)

Repair Operation Time (ROT)	
Item	Code
Steering Column Stalk Assembly Switch-Renew	11.06.BK

Remove

1. Operate the driver's seat to its lowest and most rearward position.
2. Remove the top and bottom shrouds from the steering column (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-3-4).
3. Remove the screw that attaches the load-spread plate to the steering column and remove the load-spread plate.





Figure 1

4. Collect the mounting bracket for the column shrouds.
5. Release the two clips that attach the column switch harness to the load-spread plate.
6. Disconnect the electrical connectors from the steering column switches.
7. Release the clips and remove steering column switches from the column.

Install

1. Install the steering column switches and make sure that the clips engage.
2. Connect the electrical connectors to the column switches.
3. Put the load-spread plate in position and install the two harness clips.
4. Install the screw to attach the load-spread plate.
5. Install the top and bottom steering column shrouds (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-3-4).
6. Connect the vehicle battery.
7. Put the driver's seat and the steering column back to their initial positions.

8. Automatic transmission only.
 - 8.1 Remove the four screws and release the paddle shift assembly.
 - 8.2 Disconnect the electrical connector and remove paddle shift.
9. Disconnect the electrical connectors from the column switch.



10. Unclip the column controls from the steering column and remove.

Installation

1. Install the column controls.
 - 1.1 Clip the column controls to the steering column.
 - 1.2 Connect the wiring harness plugs.
2. On automatic transmission vehicles, connect the electrical connector and install the paddle shift.
3. Install the airbag module (Refer to 'Driver's Airbag Module - Remove and Install', page 11-5-1).
4. Install the steering column cowls (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-4-4).

⚠ **WARNING** ⚠

DO NOT INSTALL THE RESTRAINT BAG WITHOUT FIRST READING AND FULLY UNDERSTANDING THE WARNINGS RELATED TO RESTRAINT BAG REMOVAL. FOLLOW THE STEP BY STEP PROCEDURE FOR REFITTING THE RESTRAINT BAG.

5. Install the airbag (Refer to 'Driver's Airbag Module - Remove and Install', page 11-5-1).
6. Install the steering wheel (Refer to 'Steering Wheel - Remove and Install', page 11-5-1).

Cruise Control Switch - Renew

Repair Operation Time (ROT)	
Item	Code
Cruise Control Switch - Renew	11.06.BL

Remove

WARNING

LEAVE THE VEHICLE FOR TWO MINUTES AFTER YOU DISCONNECT THE BATTERY BEFORE YOU DO WORK. IF YOU DO NOT, THE AIRBAG SYSTEM CAN OPERATE AND CAUSE INJURY.

1. Remove airbag module (Refer to 'Driver's Airbag Module - Remove and Install', page 11-5-1).
2. Remove the cruise control switch.

Install

1. Install the cruise control switch.
2. Make sure that the routing of the switch harness is correct.
3. Install the airbag module (Refer to 'Driver's Airbag Module - Remove and Install', page 11-5-1).

Indicator Switch for the Steering Column - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Indicator Switch for the Steering Column - Remove and Install	11.06.CK

Remove

1. Remove the top shroud from the steering column (Refer to 'Top Shroud for the Steering Column - Remove and Install', page 11-4-1).
2. Release the clips that attach the indicator switch to its mounting.
3. Release the indicator switch from its mounting.
4. Disconnect the electrical connector for the indicator switch.
5. Remove the indicator switch.

Install

1. Connect the electrical connector to the indicator switch.
2. Install the indicator switch in the mounting.
3. Make sure that the clips that attach the switch are correctly engaged.
4. Install the top shroud to the steering column (Refer to 'Top Shroud for the Steering Column - Remove and Install', page 11-4-1).

Airbag Rotary Coupler Assembly - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Airbag Rotary Coupler Assembly - Remove and Install	11.06.CM

Remove

For Pre-08MY vehicles:

- Put the key in the ignition switch and turn it to position 1 to release the Electronic Steering Column Lock (ESCL).

For 08MY vehicles or newer:

- Put the Emotion Control Unit (ECU) into the docking station at position 2 to release the ESCL..

WARNING
LEAVE THE VEHICLE FOR TWO MINUTES AFTER YOU DISCONNECT THE BATTERY BEFORE YOU DO WORK. IF YOU DO NOT, THE AIRBAG SYSTEM CAN OPERATE AND CAUSE INJURY.

- Disconnect the vehicle battery.
- Turn the steering wheel to get access to one of the two M6 screws that attach the airbag module.



Figure 1

- Remove the M6 screw.
- Turn the steering wheel to get access to the second M6 screw that attaches the airbag module.
- Remove the second M6 screw.

- Move the airbag module to get access to the two electrical connectors.



Figure 2

- Disconnect the two electrical connector for the airbag module.
- Remove the airbag module and keep it in an approved storage area.
- Turn the steering to the centre position.
- Disconnect the electrical connector for the steering wheel harness.



Figure 3

- Remove the M10 Torx screw that attaches the steering wheel.



Figure 4

- Remove the steering wheel assembly.

15. Apply tape to hold the rotary coupler in its central position.



Figure 5

16. Remove the top and bottom steering column shrouds (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-4-4).
17. Remove the screw that attaches the load-spread plate to the steering column.




Figure 5

18. Remove the load-spread plate.
19. Release the clips that attach the column switches to the rotary coupler.
20. Remove the column switches from the rotary coupler.

21. Remove the electrical connector (1) from the rotary coupler.




Figure 6

22. Release the two clips that attach the rotary coupler to the steering column and remove the rotary coupler.

Install

1. Put tape on the rotary coupler to hold it in its central position.
2. Push the rotary coupler onto the steering column until the two clips engage.
3. Install the electrical connector (1) for the rotary coupler.
4. Install the column switches into the rotary coupler.
5. Connect the electrical connectors for the column switches.
6. Put the load-spread plate in position on the steering column.
7. Install the screw that attaches the load-spread plate.
8. If a rotary coupler is to be installed that is not new, remove the tape used to hold it in its central position.
9. For a new rotary coupler, remove the locking key.
10. Install the top and bottom steering column shrouds (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-4-4).
11. Put the electrical cables from the rotary coupler through the steering wheel.

Caution

Align the steering wheel and the rack to the centre position during assembly. If you do not, the rotary coupling can be damaged. Also, it can be difficult to align the steering wheel in the straight-ahead position.

12. Align and install the steering wheel assembly.
13. Install and torque the M10 screw that attaches the steering wheel (Refer to 'Specifications', page 11-4-1).
14. Connect the electrical connector for the steering wheel harness.
15. Connect the two electrical cables to the airbag module.
16. Put the airbag module in position.

17. Turn the steering wheel to get access to install one of the two airbag module M6 attachment screws.
18. Install the first M6 attachment screw.
19. Turn the steering wheel to get access to install the second airbag module M6 attachment screw.
20. Install the second M6 attachment screw.
21. Connect the vehicle battery.

Wiper Switch for the Steering Column - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Wiper Switch for the Steering Column - Remove and Install	11.06.EL

Remove

1. Remove the top shroud from the steering column (Refer to 'Top Shroud for the Steering Column - Remove and Install', page 11-4-1).
2. Release the clips that attach the wiper switch to its mounting.
3. Release the wiper switch from its mounting.
4. Disconnect the electrical connector for the wiper switch.
5. Remove the wiper switch.

Install

1. Connect the electrical connector to the wiper switch.
2. Install the wiper switch in the mounting.
3. Make sure that the clips that attach the switch are correctly engaged.
4. Install the top shroud to the steering column (Refer to 'Top Shroud for the Steering Column - Remove and Install', page 11-4-1).



ASTON MARTIN

Steering (11.00)

Steering Wheel (11.06)

Specifications

Torque Figures

Description	Nm.	lb / ft.
Steering Wheel	40	30
Airbag Module Attachment Screws	9	6.6

Maintenance

Steering Wheel - Remove and Install

Repair Operation Time (ROT)

Item	Code
Steering Wheel - Remove and Install	11.06.AB

Remove

1. Remove the driver's airbag module (Refer to 'Driver's Airbag Module - Remove and Install', page 11-5-1).
2. Turn the steering to the centre position.
3. Disconnect the vehicle battery.
4. Disconnect the electrical connector for the steering wheel harness..
5. Place the steering in the straight ahead position.
6. Disconnect the electrical connector for the steering wheel harness.



Figure A11-06-1096

Caution

Do not use steering lock to hold the wheel when you remove the attachment screw. The steering lock can be permanently damaged.

7. Remove the M10 steering wheel attachment screw.



Figure A11-06-1095

8. Remove the steering wheel assembly.
9. Apply tape to hold the rotary coupler in its central position.

Installation

1. Put the electrical cables from the rotary coupler through the steering wheel.

Caution

Align the steering wheel and the rack to the centre position during assembly. If you do not, the rotary coupling can be damaged. Also, it can be difficult to align the steering wheel in the straight-ahead position.

2. Align and install the steering wheel assembly.
3. Install and torque the M10 screw that attaches the steering wheel (Refer to 'Specifications', page 11-5-1).
4. Connect the electrical connector for the steering wheel harness.
5. Install the driver's airbag module (Refer to 'Driver's Airbag Module - Remove and Install', page 11-5-1).
6. Connect vehicle battery.

Driver's Airbag Module - Remove and Install

Repair Operation Time (ROT)

Item	Code
Driver's Airbag Module remove and Install	11.06.BC

Removal

For Pre-08MY vehicles:

1. Put the key in the ignition switch and turn it to position 1 to release the Electronic Steering Column Lock (ESCL).

For 08MY vehicles or newer:

- Put the Emotion Control Unit (ECU) into the docking station at position 2 to release the ESCL..

WARNING
LEAVE THE VEHICLE FOR TWO MINUTES AFTER YOU DISCONNECT THE BATTERY BEFORE YOU DO WORK. IF YOU DO NOT, THE AIRBAG SYSTEM CAN OPERATE AND CAUSE INJURY.

- Disconnect the vehicle battery.
- Turn the steering wheel to get access to one of the two M6 screws that attach the airbag module.



Figure A11-06-1093

- Remove the M6 screw.
- Turn the steering wheel to get access to the second M6 screw that attaches the airbag module.
- Remove the second M6 screw.
- Move the airbag module to get access to the two electrical connectors.



Figure A11-06-1094

- Disconnect the two electrical connector for the airbag module.
- Remove the airbag module and keep it in an approved storage area.

Install

- Connect the two electrical cables to the airbag module.
- Put the airbag module in position.
- Turn the steering wheel to get access to install one of the two airbag module M6 attachment screws.

Climate Control (12.00)

Body Ventilation (12.01)


Air Intake & Distribution System

Outside air enters the plenum via inlets at the base of the windscreen.

Fresh mode - Air is drawn in through the plenum and into the blower unit. From the blower unit air enters the A/C unit where it is cooled and dehumidified as it passes through the evaporator. It is then 'reheated' to the selected temperature as it passes through the heater matrix,.

Air flows from the cabin into the boot via air vent grilles and through apertures in the rear parcel shelf. The air is exhausted from the vehicle through extraction vent assemblies (incorporating one way flaps) in the lower part of the rear bumpers, concealed by the bumper trim.

Recirculation mode - The air in the passenger compartment is drawn into the A/C system via the recirculation air inlets on the blower unit.



Item	Description	Item	Description
1.	Air Intake	4.	Cabin Distribution Box
2.	Windscreen air outlets	5.	Cabin air vents
3.	Defrost/Demist Ducting	6.	Side window air outlets

The A/C unit is linked and sealed to the defrost / demisting and cabin air ducting assemblies. The A/C unit incorporates two actuator operated flaps which regulate airflow to the selected air flow mode and temperature blend.

The centre vent duct incorporates a baffle plate which balances the volume of airflow of the centre and end of dash vents.


Maintenance

Actuators

Repair Operation Time (ROT)	
Item	Code
Actuators Renew	TBA

The A/C and blower unit assembly uses three actuators

- Blower unit
 - 1 Air intake actuator
- A/C unit
 - 2 Air mode actuator
 - 3 Air mix actuator



The removal procedure is the same for all three actuators.

To remove the blower unit actuator remove the A/C unit from the IP (Refer to 'A/C Unit', page 12-3-11).

Removal

1. Remove the IP from the vehicle (Refer to 'Instrument Panel (IP) (01.12)', page 1-12-1).

To gain access to the Air mode and Air mix actuators remove the A/C control module (screws x3).

2. Disconnect the actuator control rod.



The lower actuator on the A/C unit requires to be firstly removed from the A/C unit.



3. Remove the wiring harness plugs and the screws (x3). Withdraw the actuator.

Install

1. Install the actuator (screws x3). Connect the wiring harness plug.
2. Connect the actuator control rod.
3. Install the A/C control module. Connect the wiring harness plug.
4. If removed, install the A/C unit to the IP (Refer to ' ', page 12-3-10).
5. Install the IP to the vehicle (Refer to 'Instrument Panel (IP) (01.12)', page 1-12-1).



Air Intake Actuator

Inspection

1. Connect the battery positive voltage to Intake Actuator terminal 1 (or 3), and ground to terminal 3 (or 1).
2. Verify that the Air Intake Actuator operates as shown.

If the operation condition is not normal, replace the Air Intake Actuator.

Terminal (C0149)		Air Intake Actuator Operation
1	3	
Ground	B+	Fresh > Recirculate
B+	Ground	Recirculate > Fresh



Air Mix Actuator

Inspection


1. Connect the battery positive voltage to Air Mix Actuator terminal 6 (or 7), and ground to terminal 7 (or 6). Verify that the Air Mix Actuator operates as shown.

If the operation condition is not normal, replace the Air Mix Actuator.


Terminal (C2130)		Air Intake Actuator Operation
1	3	
B+	Ground	Cold - Hot (LHD) Hot - Cold (RHD)
Ground	B+	Hot - Cold (LHD) Cold - Hot (RHD)

2. Check that the resistance between terminals 3 and 5, and 1 and 5 matches the Air Mix Actuator operation as shown in the graph below.


If the operation condition and resistance are not normal, replace the Air Mix Actuator.



LHD



RHD



Airflow Mode Actuator

Inspection


1. Connect the battery positive voltage to the Airflow Mode Actuator terminal 6 (or 7), and ground to terminal 7 (or 6). Verify that the Airflow Mode Actuator operates as shown.

If the operation condition is not normal, replace the Airflow Mode Actuator.

Terminal		Airflow Mode Actuator operation
6	7	
B+	Ground	Defroster - Vent
Ground	B+	Vent - Defroster

2. Verify that the resistance between terminals 1 and 5, and 3 and 5 matches the Airflow Mode Actuator operation as shown in the graph below.

If the operation condition and resistance are not normal, replace the Airflow Mode Actuator.



Climate Control (12.00)


Heater System (12.02)

Maintenance Blower Motor


Repair Operation Time (ROT)	
Item	Code
Blower Motor Renew	12.02.BB

Removal

1. Disconnect the vehicle battery.
2. Disconnect the wiring harness plug.



3. Remove screws (x3). Withdraw the blower motor.




Installation

1. Install the blower motor to the blower unit body.
2. Install bolts (x3). Connect the wiring harness plugs.

Inspection

1. Connect the battery positive voltage to blower motor terminal 1, ground to terminal 2, and then verify that the blower motor operates smoothly.




2. If the operation condition is not normal, replace the blower motor.



ASTON MARTIN

Climate Control (12.00)

Air Conditioning (A/C) System (12.03)



01-12-005

Item	Description	Item	Description
1.	Condenser	6.	Low-side charge.
2.	Trinary switch	7.	Blower Unit.
3.	Compressor assembly	8.	Switch, A/C Cut-Off.
4.	High-side charge port	9.	Expansion valve.
5.	Receiver drier.	10.	A/C Unit.

Major Components

Compressor

- Engine mounted, driven by the accessory drive belt
- Variable displacement type
- High-pressure relief valve, to avoid system over-pressure
- ECU controlled clutch energised via a relay

Receiver drier

- Vertically mounted on the right-hand side of the engine bay
- The high-side charge port is installed to the high side entry pipe to the receiver drier

Condenser



- Multi-pass fin-over-tube type, mounted in front of the engine cooling pack and directly to the radiator

Trinary switch

Located in the compressor discharge pipe



- Provides a signal, via the A/C module, to the PCM, to disengage the compressor clutch should the refrigerant pressure be less than 2 bar or greater than 30 bar
- Provides a hard-wired signal to the PCM, to switch the cooling fans to HIGH speed at 22 bar rising pressure and to LOW speed at 17,5 bar falling pressure
- Provides a hard-wired signal to the PCM, to switch the radiator cooling fans to LOW speed at 12 bar rising pressure and to switch the fans OFF at 8 bar falling pressure

Expansion Valve



The expansion valve is located on the outside of the A/C unit and comprises of a diaphragm, connected by a capillary tube to a temperature sensing bulb, which regulates the valve according to temperature variations at the evaporator outlet pipe. This component is **not** serviceable.

A/C Unit



The A/C unit houses the evaporator, heater matrix and air flow flaps.

The unit also incorporates two servo motor operated air distribution flaps.

1. Regulates airflow to the cabin vents.
 2. Regulates airflow to the defrost / demist air ducting.
- When the cabin air flap is open, air is ducted to the cabin via face and foot level air vents.

Condensate (water) which forms on the evaporator fins is drained out of the unit case through a drain hose, located at underneath / rear of the evaporator.

Refrigerant System

Handling Refrigerant

⚠ WARNING ⚠
AVOID BREATHING A/C REFRIGERANT OR LUBRICANT VAPOR. EXPOSURE MAY IRRITATE EYES, NOSE AND THROAT. ALSO, DUE TO ENVIRONMENTAL CONCERNS, ASTON MARTIN RECOMMEND THE USE OF A RECOVERY / RECYCLING / RECHARGING UNIT WHEN DRAINING R-134A FROM THE A/C SYSTEM.
If accidental A/C system discharge occurs, ventilate work area before resuming service.

⚠ WARNING ⚠
DO NOT PERFORM A PRESSURE TEST OR LEAK TEST FOR R-134A SERVICE EQUIPMENT AND OR VEHICLE A/C USING COMPRESSED AIR. SOME MIXTURES OF AIR AND R-134A HAVE BEEN SHOWN TO BE COMBUSTIBLE AT ELEVATED PRESSURES. THESE MIXTURES, IF IGNITED, MAY CAUSE INJURY OR PROPERTY DAMAGE. ADDITIONAL HEALTH AND SAFETY INFORMATION MAY BE OBTAINED FROM REFRIGERANT MANUFACTURERS.

⚠ WARNING ⚠
DO NOT ALLOW REFRIGERANT TO LEAK NEAR A FIRE OR ANY KIND OF HEAT. A POISONOUS GAS MAY BE GENERATED IF REFRIGERANT GAS CONTACTS FIRE OR HEAT SUCH AS FROM CIGARETTES AND HEATERS. WHEN CARRYING OUT ANY OPERATION THAT CAN CAUSE REFRIGERANT LEAKAGE, EXTINGUISH OR REMOVE THE ABOVE MENTIONED HEAT SOURCES AND MAINTAIN ADEQUATE VENTILATION.

⚠ WARNING ⚠
HANDLING LIQUID REFRIGERANT IS DANGEROUS. A DROP OF REFRIGERANT ON THE SKIN CAN RESULT IN LOCALIZED FROSTBITE. WHEN HANDLING REFRIGERANT, WEAR GLOVES AND SAFETY GOGGLES. IF REFRIGERANT SPLASHES INTO THE EYES, IMMEDIATELY WASH THEM WITH CLEAN WATER AND CONSULT A DOCTOR.

Storing Refrigerant

⚠ WARNING ⚠
THE REFRIGERANT CONTAINER IS HIGHLY PRESSURIZED. IF IT IS SUBJECTED TO HIGH HEAT, IT COULD EXPLODE, SCATTERING METAL FRAGMENTS AND LIQUID REFRIGERANT THAT CAN SERIOUSLY INJURE PERSONNEL. STORE REFRIGERANT AT TEMPERATURES BELOW 40 °C (104 °F).

Handling Insufficient Refrigerant Level

Caution
If an insufficient refrigerant level is detected while troubleshooting, do not charge (add) the refrigerant. Because an accurate amount of refrigerant cannot be determined from the pressure indicated on the recovery / recycling / recharging unit, never charge the refrigerant.

Caution
If there is too much or too little refrigerant from the refilling, there may be secondary problems such as damage to the refrigerant cycle parts, or a decrease of cooling performance. Therefore, if it is determined that the refrigerant level is insufficient, completely remove refrigerant from the refrigerant cycle and refill with refrigerant to the specified amount.


Handling Compressor Oil

Caution
Use only ND8 compressor oil for this vehicle. Using a PAG oil other than DENSO OIL8 compressor oil can damage the A/C compressor.

Caution
Do not spill the ND8 compressor oil on the vehicle. A drop of compressor oil on the vehicle surface can damage the paint work. If oil gets on the vehicle, wipe it off immediately.

Caution
ND8 compressor oil has a high moisture absorption efficiency. If moisture mixes with the compressor oil, the refrigerant system could be damaged. Ensure caps are installed immediately after using the compressor oil or removing refrigerant system parts to prevent moisture absorption.

Refrigeration Cycle





Operation

1. The Compressor (1) draws low pressure, low temperature, refrigerant vapour from the evaporator (5) and compresses it, raising the refrigerant pressure and temperature.
2. This high pressure, hot, refrigerant vapour enters the condenser (2), where it is cooled by the flow of ambient air and changes state into a cooler, high pressure liquid.
3. From the condenser, the liquid passes into the receiver drier (3) which has three functions:
 - Removes moisture from the refrigerant using a desiccant
 - Filters the refrigerant to remove system contaminants
 - Stores the refrigerant to cope with varying system refrigerant demands
4. The filtered liquid refrigerant, still at high pressure, then enters the expansion valve (4). Here it passes through a controlled orifice and emerges as an atomised liquid spray. This has the effect of reducing the refrigerant pressure and temperature. The cold refrigerant spray now flows into the evaporator (5).
5. As refrigerant passes through the evaporator core, it cools the incoming airflow. Heat is absorbed by the refrigerant, during this process and it once again changes state, from an atomised cool liquid into a vapour. The refrigerant vapour then returns to the compressor for the cycle to be repeated.

An automatic safety valve is incorporated in the compressor, which will open if the system pressure rises above 41 bar. The valve will reseal when the pressure drops below 27,6 bar. When the safety valve is open, the compressor will 'free wheel' and the excess pressure will be dissipated through the expansion valve. When the pressure drops below 27.6 bar, the safety valve will close again and the compressor will be operative.

The terms 'high' and 'low' pressure (or side) refer to the pressure differential between the compressor and expansion valve ports. This differential is critical to system fault diagnosis and efficiency checks.

The high side starts at the compressor and includes the trinary switch, condenser, receiver drier and expansion valve.

The low side starts at the expansion valve outlet and includes the evaporator and all connections back to the compressor.

The trinary switch (6) monitors system pressure between the compressor and condenser. If the pressure rises above 30 bar or falls below 2 bar the compressor clutch is de-energised to prevent damage to system components.

Specifications

Refrigerant and Lubricant

Refrigerant R-134a
Compressor Lubricant ND8 (DENSO)


Capacities

Refrigerant charge Weight 850g (30 oz.)
Compressor Lubricant Sealed volume (approx. quantity) 150 cc (pre-charged)


Torque Figures

Torque Figures

Description	Nm.	lb. / ft.
AC unit Mounting	20-25	15-18.5
Compressor Mounting	23-27	17-20
Trinary switch		
A/C pipes to condenser	8-10	6-7.5





01-12-111




01-12-018

Diagnostics Electrical Connectors



A/C Module (C0792)

Pin	Specification
1	V Battery (from CCM)
2	V Ignition (from comfort relay) Recirculation acuator
3	Blank
4	Air flow mode actuator (input)
5	Solar sensor (input)
6	Ambient Temperature sensor
7	Engine coolant temperature (input)
8	Ref. voltage - Solar sensor (output) Ref. voltage - Temperature actuator (output) Ref. voltage - Air flow mode actuator (output)
9	Blank
10	Blank
11	Blank
12	Temperature actuator (input)
13	Evaporation sensor (input)
14	In-vehicle temperature sensor (input)
15	Ground
16	Sensor ground (In-vehicle, Evaporator, Air flow mode actuator, Temperature mode actuator)



A/C Module (C0791)

Pin Specification

Pin	Specification
1	Air flow mode actuator (output)
2	Temperature actuator (output)
3	Blank
4	Blank
5	Blank
6	A/C On (A/C pressure sensor)
7	Blank
8	Recirculation actuator (output)
9	Blank
10	Blank
11	Temperature level (RHD)
12	Blower speed regulator (Output)
13	Air flow mode actuator (output)
14	Temperature actuator (output)
15	Blank
16	Output
17	HAVAC ECU (input)
18	Blank
19	Blower relay (engine bay fusebox)
20	Recirculation actuator (output)
21	Blank
22	blank
23	Temperature level (LHD)
24	Blower speed regulator input)

DTC Inspection

Using AMDS

1. Connect the AMDS to the **body** diagnostic socket (Refer to 'Appendix & Glossary', page 20-1-2).
2. Select 'Air-Con' from the menu.
3. Read the fault codes from the AMDS screen.

DTC Fault Codes

DTC	Fault Code Definition
10	Switchpack 1 disconnected.
20	Switchpack 2 disconnected.
30	Analogue digital converter 100us timeout.
40	Serial transmit 10ms timeout.
111	Temperature control - short circuit to ground on A.
122	Temperature control - short circuit to 5 volts on A.
133	Temperature control - short circuit to ground on B.
144	Temperature control - short circuit to 5 volts on B.
250	Temperature – bad pair.
260	Mode control - short circuit to ground.
270	Mode control - short circuit to 5 volts.
280	Fan control - short circuit to ground.
355	Fan control – short circuit to 5 volts.
366	Bad response data - temperature.
377	Bad response data - mode.

DTC	Fault Code Definition
388	Bad response data - fan speed.
412	Bad response data - recirculation.
423	Serial communications error – header.
434	Serial communications error – checksum.
445	Serial communications error – overrun.
556	Serial communications error – framing.
567	Serial communications error – parity.
578	Electrically erasable programmable read only memory - command 120ms timeout.
589	Electrically erasable programmable read only memory - access error.
613	Electrically erasable programmable read only memory - protection error.
624	Electrically erasable programmable read only memory - not blank on verification.
635	Dynamic stability control 10 second timeout.
646	Temperature forced to default.
790	Blower speed forced to default.
791	Mode forced to default.
792	Power switch output - short circuit.
793	Electrically erasable programmable read only memory - command not ready.
794	Heating ventilating air conditioning control module – in car sensor - current fault.
795	Heating ventilating air conditioning control module – in car sensor - past fault.
796	Heating ventilating air conditioning control module – external air sensor - current fault.
797	Heating ventilating air conditioning control module – external air sensor - past fault.
798	Heating ventilating air conditioning control module – post evaporator sensor - current fault.
799	Heating ventilating air conditioning control module – post evaporator sensor - past fault.
880	Heating ventilating air conditioning control module – coolant temperature sensor - current fault.
881	Heating ventilating air conditioning control module – coolant temperature sensor - past fault.
882	Heating ventilating air conditioning control module – solar radiation sensor - current fault.
883	Heating ventilating air conditioning control module – air mix actuator cool/hot - current fault.
884	Heating ventilating air conditioning control module – air mix actuator cool/hot - past fault.
885	Heating ventilating air conditioning control module – mode actuator face/defrost - current fault.
886	Heating ventilating air conditioning control module – mode actuator face/defrost - past fault.
887	Heating ventilating air conditioning control module – air mix actuator fail.
888	Heating ventilating air conditioning control module – mode actuator fail.
889	Electrically erasable programmable read only memory - data checksum error.



Maintenance

Assessment of the A/C system operating efficiency and fault classification may be achieved by using the facilities on a Recovery / Recycling / Recharging unit.

Follow the manufacturer's instructions implicitly and observe all safety considerations.

Connections

Only use hoses with connectors which are dedicated to HFC 134a charge ports.

⚠ WARNING ⚠

UNDER NO CIRCUMSTANCES SHOULD CONNECTIONS BE MADE WITH THE A/C SYSTEM IN OPERATION OR VALVES OPEN. SHOULD VALVES BE OPEN AND A VACUUM PUMP OR REFRIGERANT CONTAINER ATTACHED, AN EXPLOSION COULD OCCUR AS A RESULT OF HIGH PRESSURE REFRIGERANT BEING FORCED BACK INTO THE VACUUM PUMP OR CONTAINER.

Recovery

⚠ WARNING ⚠

HANDLING LIQUID REFRIGERANT IS DANGEROUS. A DROP OF REFRIGERANT ON THE SKIN CAN RESULT IN LOCALIZED FROSTBITE. WHEN HANDLING REFRIGERANT, WEAR GLOVES AND SAFETY GOGGLES. IF REFRIGERANT SPLASHES INTO THE EYES, IMMEDIATELY WASH THEM WITH CLEAN WATER AND CONSULT A DOCTOR.

Caution

Do not attempt to adapt this unit for R-12 as an A/C system failure will result. Recovery / Recycle / Recharging equipment has special connections to avoid cross contamination with R-12 systems.

The A/C unit's overfill limitation mechanism has been calibrated specifically for use with the 50 lb. (23 Kg) refillable refrigerant tank.

Run the A/C system for a few minutes before starting the recovery procedure as this will enable more refrigerant to be recovered. Turn the A/C system off before starting the procedure.

Ensure the A/C system has pressure in it before beginning the recovery process; if there is no system pressure there is no refrigerant to recover.

Ensure that the oil drain valve is closed.

Read manufacturer's instructions and warnings before completing any recovery / evacuating and charging operations.

Caution

The Recovery / Recycling / Recharging unit relies on a weighing mechanism to weight the quantity of oil removed. Ensure that the Recovery / Recycle / Recharging unit is not disturbed during the recovery procedure.

1. Connect an R-134a Recovery / Recycling / Recharging unit to the vehicle A/C system.
2. Follow the Recovery / Recycling / Recharging unit manufacturer's instructions to evacuate the A/C system.

Compressor oil may be drawn out during this process, take note of the quantity recovered so that it may be replaced.

Evacuation

The removal of unwanted air and moisture, is critical to the correct operation of the A/C system. Moisture in the system can be highly destructive and may cause internal blockages due to freezing; water suspended in the lubricating oil will damage the compressor. Once the A/C system has been dismantled, or the refrigerant charge recovered, all traces of moisture must be removed before charging.

It is recommended that initially only the high-side valve be opened at the start of the procedure. After a short time a small depression should be seen on the low-side, at which point the low-side valve may be opened and the evacuation process completed. If a vacuum is not registered on the low-side, it may indicate that the expansion valve is permanently closed or that the system is blocked. This simple check may save time and effort when the system is recharged.

Read manufacturer's instructions and warnings before completing any Recovery / Recycling / Recharging operation.

1. Connect an R-134a Recovery / Recycling / Recharging unit to the vehicle A/C system.
2. Follow the Recovery / Recycling / Recharging unit manufacturer's instructions to evacuate the A/C system.

Charging

Caution

Do not exceed the specification when charging the A/C system with refrigerant. Doing so will decrease the efficiency of the A/C unit or damage the refrigeration cycle parts.

Caution

Always start the charging of refrigerant from the high-pressure side. If charging starts from the low-pressure side, vanes of the A/C compressor will not be released and abnormal noise may result.

Read manufacturer's instructions and warnings before completing any Recovery / Recycling / Recharging operation.


1. Connect an R-134a Recovery / Recycling / Recharging unit to the vehicle A/C system.
2. Follow the Recovery / Recycling / Recharging unit manufacturer's instructions to charge the A/C system.

A/C System Testing

It is recommended that a free standing air mover is placed in front of the condenser / cooling system.

Pressure Check

1. Connect the Recovery / Recycling / Recharging unit.
2. Start the engine. Allow to warm up then run at a constant 1,500 rpm.
3. Set the following A/C controls:
 - Air Circulation to 'Recirculate'
 - Temperature to 'Max' Cold
 - Air Flow to 'Vent'
4. Close all the vehicle doors and windows.
5. Measure the ambient temperature and high / low pressure side reading of Recovery / Recycling / Recharging unit gauges.
6. Verify that the intersection of the pressure reading of the Recovery / Recycling / Recharging unit gauges and the ambient temperature is in the shaded zone.



If there is any fault, inspect the refrigerant system according to the troubleshooting chart.


Performance Test

1. Check the refrigerant pressure.
2. Place a dry-bulb thermometer in the driver-side center ventilator outlet.
3. Start the engine. Allow to warm up then run at a constant 1,500 rpm.
4. Set the A/C unit fan speed to 'Max Hi'.
5. Turn the A/C system on.
6. Set the following A/C controls:
 - Air Circulation to 'Recirculate'
 - Temperature to 'Max' Cold
 - Air Flow to 'Vent'

7. Close all the doors and windows.
8. Wait until the A/C output temperature stabilizes.

Stabilized condition.
The A/C compressor repeatedly turns on and off at regular intervals.

9. After the blower air is stabilized, read the dry-bulb thermometer.
10. Verify the ambient temperature.
11. Verify the temperature is in the shaded zone.



If there is any fault, inspect the refrigerant system according to the troubleshooting chart.

Vacuum Check

1. Stop the vacuum pump, note the high and low pressure side readings of the Recovery / Recycling / Recharging unit gauges and wait for 5 min.
2. Check the high and low pressure side readings of the Recovery / Recycling / Recharging unit gauges.
 1. If the readings have changed, inspect for leaks and go to Evacuation (Refer to 'Evacuation', page 12-3-8).
 2. If the readings have not changed, go to Charging (Refer to 'Charging', page 12-3-8).



Leaks

Faults associated with low refrigerant charge weight and low pressure may be caused by leakage. Leaks traced to mechanical connections may be caused by torque relaxation or joint face contamination. Evidence of oil around such areas is an indicator of leakage.

Leak Detection

Fluorescent Tracer Dye - A fluorescent tracer dye is incorporated into the refrigeration system and can be checked for non-apparent leaks by scanning with a high intensity ultraviolet lamp. The location of leaks can be pinpointed by the bright yellow glow of the tracer dye.

Caution

Observe ALL safety precautions associated with ultraviolet equipment.

Automatic Refrigerant Leak Detector - (various manufacturers) Hand-held, portable, battery operated leak detector. Place in and around A/C system to detect refrigerant leaks.

System Pressure Fault Classification

If erratic or unusual gauge movements occur, check the equipment against known Recovery / Recycling / Recharging unit gauges.

This table should be used in conjunction with the graphical representations of 'High side' pressure / ambient temperature and 'Low side' pressure / evaporator temperature.



Low side gauge reading	High side gauge reading	Fault	Cause
Normal	Normal	Discharge air initially cool then warms up	Moisture in system
Normal to low	Normal	As above	As above
Low	Low	Discharge air slightly cool	Refrigerant charge low
Low	Low	Discharge air warm	Refrigerant charge very low
Low	Low	Discharge air slightly cool or frost build up at expansion valve	Expansion valve stuck closed
Low	Low	Discharge air slightly cool, sweating or frost after point of restriction	Restriction in High side of system
High	Low	Compressor noisy	Defective compressor reed valve
High	High	Discharge air warm and high side pipes hot	Refrigerant charge high or inefficient condenser cooling due to air flow blockage or engine cooling fans not working
High	High	Discharge air warm Sweating or frost at evaporator	Expansion valve stuck open

A/C Unit


Repair Operation Time (ROT)	
Item	Code
A/C Unit Renew	12.03.EB

Removal

1. Connect the AMDS and record any logged fault codes in the A/C system.
2. Disconnect the vehicle battery.
3. Recover the refrigerant from the A/C system (Refer to 'Recovery', page 12-3-8).
4. Drain the engine coolant.
5. Remove the IP (Refer to 'Instrument Panel (IP) (01.12)', page 1-12-1).
6. Remove the blower unit.
 - 6.1 Disconnect the wiring harness plugs (x2).
 - 6.2 Remove bolts (x3). Withdraw the blower unit.





7. Disconnect the wiring harness plugs (x3).



8. Remove bolt (x1) and nuts (x2). Withdraw the A/C unit.


Image to Follow

9. Unlatch the A/C unit from the defrost air duct (Push the A/C unit up into the IP). Withdraw the A/C unit.
5. Remove the IP (Refer to 'Instrument Panel (IP) (01.12)', page 1-12-1).
6. Remove the blower unit assembly.
 - 6.1 Disconnect the wiring harness plug (x1).
 - 6.2 Remove bolts (x3). Withdraw the blower unit.



Installation

1. Install the A/C unit to the IP. Torque bolts to **5.5 Nm**.
Ensure the A/C unit interlocks with the defrost duct.
2. Install the blower unit to the IP. Torque bolts to **5.5 Nm**.
3. Connect the wiring harness plugs.
 - (x3) to the A/C unit
 - (x2) to the blower unit
4. Install the IP (Refer to 'Instrument Panel (IP) (01.12)', page 1-12-1).
5. Recharge the A/C system (Refer to 'Charging', page 12-3-8).
6. Fill the engine coolant system (Refer to 'Cooling System (03.03)', page 3-3-1).
7. Connect the vehicle battery.
8. Start the engine. Allow the cooling system to come to normal operating temperature.
9. Carry out A/C system actuator check and functional check to ensure correct operation (Refer to 'A/C System Testing', page 12-3-9).



Heater Matrix


Repair Operation Time (ROT)	
Item	Code
Heater Matrix Renew	12.02.CB

Remove


1. Connect the AMDS and record any logged fault codes in the A/C system (Refer to 'Appendix & Glossary', page 20-1-2).
2. Disconnect the vehicle battery.
3. Recover the refrigerant from the A/C system (Refer to 'Recovery', page 12-3-8).
4. Drain the engine coolant (Refer to 'Cooling System (03.03)', page 3-3-1).

7. Remove the blower unit to A/C unit adaptor and pipe locator.

7.1 Remove the foam.



7.2 Remove the pipe location plate (screws x4). Part the pipe location plate and withdraw.




Note the orientation of the two rubber grommets.




7.3 Remove the adaptor (screws x2), clip (x1) and disconnect one plastic locator.

8. Remove the pipe clips (x2) that secure the heater pipes.



9. Withdraw the heater matrix.




Installation

1. Install the heater matrix into the A/C unit. Ensure the heater matrix is pushed fully in.
2. Install the pipe clips.
3. Install the blower unit to A/C unit adaptor and pipe locator.

Ensure that the two rubber grommets are located correctly.

4. Install the foam around the pipes



5. Install the blower unit. Torque bolts to **10-13 Nm**.
 6. Install the IP (Refer to 'Instrument Panel (IP) (01.12)', page 1-12-1).
 7. Recharge the A/C system (Refer to 'Charging', page 12-3-8).
 8. Fill the engine coolant system (Refer to 'Cooling System (03.03)', page 3-3-1).
 9. Connect the vehicle battery.
 10. Start the engine. Allow the cooling system to come to normal operating temperature.
 11. Carry out A/C system actuator check and functional check to ensure correct operation (Refer to 'A/C System Testing', page 12-3-9).
5. Remove the expansion valve
 - 5.1 Remove protective material from around the expansion valve.
 - 5.2 Remove screws (x2). Remove the A/C pipes clamp.



Evaporator


Repair Operation Time (ROT)	
Item	Code
Evaporator Renew	12.03.CB

Removal

1. Remove the A/C unit (Refer to 'A/C Unit', page 12-3-11).
2. Move the in-vehicle temperature pipe to one side.
3. With a sharp knife cut the filter gauze and foam where the two halves of the A/C unit meet.



4. Remove clip (x1) and screws (x9) that secure the two halves of the A/C unit. Part the two halves of the A/C unit.




- 5.3 Withdraw the A/C pipes.



- 5.4 Withdraw the expansion valve. Discard 'O' rings.



- Remove the clips (x2) that secure the evaporator temperature sensor element to the evaporator.



- Withdraw the evaporator.



Installation

- Insert the evaporator (inlet / outlet first) into the half of the A/C unit which houses the expansion valve.
- Complete with new 'O' rings, install the expansion valve.
- Complete with new 'O' rings, install the A/C pipes clamp (screws x2).
- Install the clips (x2) that secure the evaporator temperature sensor element to the evaporator.
- Place the two halves of the A/C unit together.

Take care to correctly locate the vent flaps.


- Install clip (x1) and screws (x9) that secure the two halves of the A/C unit.
- Connect (glue) the filter gauze and foam where the two halves of the A/C unit meet.
- Install the in-vehicle temperature pipe to the A/C unit clips.
- Install the A/C unit to the IP (Refer to 'A/C Unit', page 12-3-11).
- Install the IP (Refer to 'Instrument Panel (IP) (01.12)', page 1-12-1).
- Carry out A/C system actuator check and functional check to ensure correct operation (Refer to 'A/C System Testing', page 12-3-9).

A/C Compressor


Repair Operation Time (ROT)	
Item	Code
A/C Compressor Renew	12.03.AB

Removal


- Disconnect the vehicle battery.
- Recover the refrigerant from the A/C system (Refer to 'Recovery', page 12-3-8).
- Remove the road wheel and road wheel arch liner (for access to the A/C compressor securing bolts).




- Remove the accessory drive belt (Refer to 'Accessory Drive System (03.05)', page 3-5-1).
- Disconnect the wiring harness plug.



6. Remove the A/C pipes. Discard the O-rings.
Install suitable blanking plugs.



7. Remove bolts (x3) and withdraw the A/C compressor.



8. Measure the amount of oil held in the A/C compressor.


This step is not necessary in the case of refrigerant loss.

- 8.1 Pour oil from the old A/C compressor into a suitable measuring container. Note the amount and discard oil.
- 8.2 Install blanking plugs to the old A/C compressor.
- 8.3 Note the volume of oil recovered with the refrigerant.


Installation

If replacing a faulty A/C compressor with internal mechanical damage, also replace the receiver drier which could also be contaminated with mechanical debris.

1. Fill the new A/C compressor with the correct amount of oil.
 - 1.1 Remove the blanking plugs from the A/C compressor.
 - 1.2 Fill the A/C compressor with same amount of oil that was recovered from the original A/C compressor, plus the amount recovered from the recovery equipment.
 - 1.3 Install the blanking plugs to the A/C compressor.
2. Install the A/C compressor. Torque bolts (x4) to **23-27 Nm**.





3. Install both A/C pipes. Use new O-rings. Torque bolts (x2) to **10-13 Nm**.



4. Connect the wiring harness plug.

5. Install the accessory drive belt (Refer to 'Accessory Drive System (03.05)', page 3-5-1).
6. Remove bolts (x2).




6. Connect the vehicle battery.
7. Install the road wheel arch liner and road wheel (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
8. Recharge the A/C system.
9. Start the engine. Allow the engine cooling system to rise to normal running temperature.
10. Carry out A/C system actuator check and functional check to ensure correct operation (Refer to 'A/C System Testing', page 12-3-9).

7. Withdraw the condenser upwards.

Installation

If a new condenser is to be installed ensure the correct amount of A/C system oil is added.

1. Insert the condenser, locate the bottom of the condenser into the anchor points (x2). Install bolts (x2).



Condenser

Repair Operation Time (ROT)	
Item	Code
A/C Condenser Renew	12.03.BB


Removal

1. Disconnect the vehicle battery.
2. Recover the A/C refrigerant (Refer to 'Recovery', page 12-3-8).
3. Drain the engine coolant system (Refer to 'Cooling System (03.03)', page 3-3-1).

Caution

Ensure open ends are plugged immediately after disconnecting refrigeration parts. If moist air or foreign material enters the refrigeration cycle, cooling ability will be lowered and abnormal noise or other faults may occur.

4. Remove the 'slam' panel.
5. Disconnect the A/C pipes. Discard the O-rings. Install suitable blanking plugs.



2. Install both A/C pipes. Use new O-rings. Torque bolts (x2) to **10-13 Nm**.
3. Install the 'slam' panel.
4. Fill the coolant system (Refer to 'Cooling System (03.03)', page 3-3-1) and charge the A/C system (Refer to 'Charging', page 12-3-8).

Receiver Drier Assembly


Repair Operation Time (ROT)	
Item	Code
A/C Receiver Drier Renew	12.03.DB

Removal

1. Disconnect the vehicle battery.
2. Recover the refrigerant (Refer to 'Recovery', page 12-3-8).
3. Disconnect the A/C pipes from the receiver drier assembly. Remove and discard the 'O' rings. Install suitable blanking plugs.

Caution

Ensure open ends are plugged immediately after disconnecting refrigeration parts. If moist air or foreign material enters the refrigeration cycle, cooling ability will be lowered and abnormal noise or other faults may occur.



4. Remove bolts (x2) and withdraw the receiver drier assembly.
5. Recover the spacers and ferrules for reuse.

Installation


1. Install receiver drier assembly. Torque bolts to **2-3 Nm**.
2. Connect the refrigerant lines. Torque to **2-3 Nm**.

Install new 'O' rings to the A/C system connectors.

3. Charge the A/C system (Refer to 'Charging', page 12-3-8).
4. Connect the vehicle battery. Start the engine. Allow the engine cooling system to rise to normal running temperature.

5. Carry out A/C system actuator check and functional check to ensure correct operation (Refer to 'A/C System Testing', page 12-3-9).

Power Transistor Inspection




1. Verify that the continuity between the power transistor terminals is as indicated in the table below. If there is any fault, replace the power transistor.

If the blower motor operation is not normal even though no fault can be verified, inspect the A/C module.

Tester lead		Resistance (kilo hm)
+	-	
1	3	Infinity
1	2	11.0
1	4	Infinity
3	1	Continuity detected
3	2	Continuity detected
3	4	1.5
2	1	11.0
2	3	Infinity
2	4	Infinity
4	1	Continuity detected
4	3	1.5
4	2	Continuity detected

Removal

1. Disconnect the vehicle battery.
2. Remove the glove box.
3. Disconnect the wiring harness plug.
4. Remove the power transistor.



Installation


1. Install the power transistor and connect the wiring harness plug.
2. Install the glove box.
3. Connect the vehicle battery.

Evaporator Temperature Sensor Inspection

Inspect the Evaporator Temperature Sensor when it is installed in the A/C unit.

1. Set the fan speed Max. Hi.
2. Set the temperature control to Max. Cold.
3. Set the air intake mode to Recirculate.
4. Turn the A/C switch off.
5. Close all the doors and windows. Wait for 5 minutes.
6. Disconnect the Evaporator Temperature Sensor connector.
7. Measure the temperature at the air intake.
8. Measure the resistance between the Evaporator Temperature Sensor terminals.

If the characteristics of the Evaporator Temperature Sensor are not as shown in the graph, replace the Evaporator Temperature Sensor.



Removal

1. Disconnect the vehicle battery.
2. Remove the A/C unit (Refer to 'A/C Unit', page 12-3-11).
3. Remove the evaporator (Refer to 'Evaporator', page 12-3-14).
4. Remove the wiring harness plug from the A/C unit.
5. Remove the evaporator temperature sensor.



Installation

1. Install the evaporator temperature sensor.
2. Insert the evaporator (inlet / outlet first) into the half of the A/C unit which houses the expansion valve.
3. Complete with new 'O' rings, install the expansion valve and the A/C pipes clamp (screws x2).
4. Install the clips (x2) that secure the evaporator temperature sensor element to the evaporator.
5. Secure the two halves of the A/C unit together.

Take care to correctly locate the two vent flaps.


6. Connect (glue) the filter gauze and foam where the two halves of the A/C unit meet.
7. Install the in-vehicle temperature pipe to the A/C unit clips.
8. Install the A/C unit to the IP (Refer to 'A/C Unit', page 12-3-11).
9. Install the IP (Refer to 'Instrument Panel (IP) (01.12)', page 1-12-1).
10. Carry out A/C system actuator check and functional check to ensure correct operation (Refer to 'A/C System Testing', page 12-3-9).

Trinary Switch


Repair Operation Time (ROT)	
Item	Code
A/C Trinary Switch Renew	TBA

Removal

1. Disconnect the vehicle battery.
2. Recover the refrigerant from the A/C system.
3. Remove the foam surround.



4. Disconnect the wiring harness plug.
5. Hold the piping block with pliers or a similar tool and loosen the trinary switch using a wrench. Withdraw the trinary switch.



Installation

1. Install the trinary switch. Torque to **TBA Nm**.

Apply compressor oil to the O-ring joint.

2. Connect the wiring harness plug.
3. Install the foam surround.
4. Charge the A/C system (Refer to 'Charging', page 12-3-8).
5. Connect the vehicle battery. Start the engine. Allow the engine cooling system to rise to normal running temperature.
6. Carry out A/C system actuator check and functional check to ensure correct operation (Refer to 'A/C System Testing', page 12-3-9).

Expansion Valve

Repair Operation Time (ROT)	
Item	Code
A/C Expansion Valve Renew	TBA

Removal

1. Disconnect the vehicle battery.
2. Recover the refrigerant from the A/C system.
3. Remove protective material from around the expansion valve.
4. Remove screws (x2). Remove the A/C pipes clamp.



5. Withdraw the A/C pipes. Discard 'O' rings.



6. Withdraw the expansion valve. Discard 'O' rings.



Installation

<i>Install new 'O' rings.</i>

<i>Apply compressor oil to the 'O'-ring joints.</i>

1. Install the expansion valve to the A/C unit body.
2. Install the A/C pipes to the expansion valve.
3. Install the A/C pipes clamp.
4. Install sealant around the evaporator pipes.
5. Install the in-vehicle temperature pipe to the A/C unit clips.
6. Carry out A/C system actuator check and functional check to ensure correct operation (Refer to 'A/C System Testing', page 12-3-9)
7. Connect the vehicle battery. Start the engine. Allow the engine cooling system to rise to normal running temperature.
8. Carry out A/C system actuator check and functional check to ensure correct operation (Refer to 'A/C System Testing', page 12-3-9).



Troubleshooting

The areas for inspection (steps) are given according to various circuit malfunctions. Use the following chart to verify the symptoms of the trouble in order to diagnose the appropriate area.

Symptom(1)	Description	Possible Cause
Insufficient air (or no air) blown from vents.	Problem with each vent / duct or both. Airflow mode does not change.	<ul style="list-style-type: none"> • Fault in Airflow Mode Actuator • Fault in 'Vent' mode system • Fault in 'Heat' mode system • Fault in 'Defroster' mode system
Symptom(2)	Description	Possible Cause
Amount of air blown from vents does not change.	Fault in blower system.	<ul style="list-style-type: none"> • Blower motor fault • Blower unit fault • Power transistor system fault • Climate control unit fault
<i>Shake the wiring harness and connectors while performing the inspection to discover whether poor contact points are the cause of any intermittent malfunctions. If there is a problem, check to make sure connectors, terminals and wiring harnesses are connected correctly and undamaged.</i>		
Symptom(3)	Description	Possible Cause
Air intake mode does not change.	Air intake mode does not change when switching REC FRESH mode.	<ul style="list-style-type: none"> • Air Intake Actuator fault • Air intake door fault
<i>Shake the wiring harness and connectors while performing the inspection to discover whether poor contact points are the cause of any intermittent malfunctions. If there is a problem, check to make sure connectors, terminals and wiring harnesses are connected correctly and undamaged.</i>		
Symptom(4)	Description	Possible Cause
No temperature control with A/C Module.	Temperature does not change with operating temperature control dial	<ul style="list-style-type: none"> • Air Mix Actuator (5 V signal) system fault • A/C Module (potentiometer GND signal) system fault • Air Mix Actuator (potentiometer input signal) system fault • Air Mix Actuator (potentiometer GND signal, motor drive signal) system fault • Air Mix Actuator system fault • A/C unit air mix door fault
<i>Shake the wiring harness and connectors while performing the inspection to discover whether poor contact points are the cause of any intermittent malfunctions. If there is a problem, check to make sure connectors, terminals and wiring harnesses are connected correctly and undamaged.</i>		
Symptom(5)	Description	Possible Cause
Windshield fogged.	<ul style="list-style-type: none"> • A/C compressor does not operate while airflow mode is in DEFROSTER or HEAT DEF modes • Air intake mode does not change to FRESH while airflow mode is in DEFROSTER or HEAT DEF modes 	<ul style="list-style-type: none"> • A/C Module (B+ signal) system fault • Air intake actuator fault • A/C Module (RECIRCULATE, FRESH signal) system fault • Fault in blower unit air intake doors
<i>Shake the wiring harness and connectors while performing the inspection to discover whether poor contact points are the cause of any intermittent malfunctions. If there is a problem, check to make sure connectors, terminals and wiring harnesses are connected correctly and undamaged.</i>		

Symptom(6)	Description	Possible Cause
Air from vents not cold enough.	Magnetic clutch operates but A/C system malfunctions.	<ul style="list-style-type: none"> • Drive belt fault • Fault in blower unit or condenser • Fault in Receiver / Drier or expansion valve (valve closes too much) • Fault in refrigerant lines • A/C compressor system fault, insufficient compressor oil • Over filling of compressor oil, fault in expansion valve or A/C unit air mix link system
<p><i>Shake the wiring harness and connectors while performing the inspection to discover whether poor contact points are the cause of any intermittent malfunctions. If there is a problem, check to make sure connectors, terminals and wiring harnesses are connected correctly and undamaged.</i></p>		
Symptom(7)	Description	Possible Cause
No cool air.	Magnetic clutch does not operate.	<ul style="list-style-type: none"> • Fault in PCM A/C cut control system • Fault in A/C Module • Fault in refrigerant pressure switch • Fault in PCM (A/C signal) • Fault in PCM (IG1 signal) • Fault in A/C compressor • Fault in A/C relay • Fault in Evaporator Temperature Sensor
<p><i>Shake the wiring harness and connectors while performing the inspection to discover whether poor contact points are the cause of any intermittent malfunctions. If there is a problem, check to make sure connectors, terminals and wiring harnesses are connected correctly and undamaged.</i></p>		
Symptom(8)	Description	Possible Cause
Noise while operating A/C system.	Noise from magnetic clutch, A/C compressor, hose or refrigerant line.	<ul style="list-style-type: none"> • Magnetic clutch operation noise • A/C compressor slippage noise • Hose or refrigerant line interference noise



ASTON MARTIN

Information, Gauge and Warning (13.00)

Contents

Driver Information Module (DIM) (13.01)	13-1-2
Description	1-2
Information and Warning Lamps	1-3
DIM Display layout	1-4
<i>Message Centre Left</i>	1-4
<i>Gear Position Indicator Display (GPID)</i>	1-4
<i>Message Centre Right</i>	1-4
Maintenance	1-5
Driver Information Module (DIM)	1-5
<i>Removal</i>	1-5
<i>Installation</i>	1-6

Information, Gauge and Warning (13.00)

Driver Information Module (DIM) (13.01)

Description



The Driver Information module contains the necessary electronic control units and memories to control, process and present all necessary vehicle information to the driver.

1. Information on vehicle performance is presented in visible form using the instruments and gauges. These devices present such information as Vehicle Speed, Engine Speed, Fuel Level and Coolant Temperature.
2. Information on vehicle status is presented by an array of warning lights.
 - Red - indicate immediate danger warnings
 - Amber - indicate conditions which are serious but not immediately dangerous
 - Green and Blue - indicate normal actuation of items such as turn signals or fog lamps

The message centres and the gear position indicator display (GPID) are used to present information on the distance recorders (trip meters), current gear mode and current gear engaged.

3. The right message centre is used to display any warning / information message text. These text messages may be reinforced in some cases by illumination of the appropriate warning lamps.

The following table defines all information and warning lamps and their significance:

Information and Warning Lamps

Name / Function	Description	Symbol	Input Signal	Power On Check
General Warning – Amber / Red	Controlled internally by the DIM. It is used in conjunction with several text messages to indicate information to the driver.		Internal	
SRS (Airbag)	Controlled externally by the SRS module and indicates a fault in the SRS module.		CAN	Yes (5 Seconds)
High Engine Coolant Temp	This tell tale is controlled internally by the DIM. Activated when the engine coolant temperature signal from the CAN bus reaches a pre defined value. (The actual symbol is not lit, only the red LED.)		CAN	
DSC	Controlled externally by the ABS / DSC module. Indicates when the system is in operation or when it is turned off. The tell tale is triggered by a CAN signal.		CAN	Yes (5 Seconds)
ABS	Controlled externally by the ABS / DSC module. Indicates a fault in the ABS system. The tell tale is triggered by a CAN signal.		CAN	Yes (5 Seconds)
Rear Fog Lights	Controlled externally by the SRS module. Indicates that the rear fog lights are turned on. The tell tale is triggered by a CAN signal.		CAN	Yes (5 Seconds)
Seat Belts	Controlled externally by the CEM. Indicates that the seat belts are not fastened properly. The tell tale is triggered by a CAN signal.		CAN	Yes (5 Seconds)
Brake (General)	Controlled externally by either the CEM or the ABS / DSC module. It indicates low brake fluid level, brake fault and park brake. The tell tale is triggered by two low side inputs or a CAN signal.		Low side x 2 and CAN	Yes (5 Seconds)
Side Lights	Controlled externally by the CEM. Indicates that the side lights are on.		High side	
Oil Pressure	Controlled externally by the PCM. Indicates low oil pressure. The tell tale is triggered by a CAN signal.		CAN	Yes (5 Seconds)
Battery Charge	Controlled externally by the CEM. Indicates that the alternator is no longer charging the battery properly. The tell tale is triggered by a CAN signal.		CAN	Yes (5 Seconds)
Fuel Level Low	Controlled internally by the DIM. Activated when the fuel level drops below a pre defined value. The fuel information is provided from the CAN bus. The symbol is not lit, only the amber LED.		CAN	
Turn Left / Right	Controlled externally by the CEM. The tell tale is triggered by a CAN signal.		CAN	
High Beam	Controlled externally by the CEM. Indicates that the high beam is switched on. The tell tale is triggered by a CAN signal.		CAN	
Check Engine	Controlled externally by the PCM. Indicates a fault in the engine management system. The tell tale is not connected to the microprocessor.		Low side	
Tyre Pressure	Controlled by the DIM. Indicates a low or rapid change in the tyre pressure or a tyre pressure monitoring system fault.		Low side	Yes (5 Seconds)
Not Used				
PATS	Controlled externally by the PCM. Indicates key acceptance status.		Low side	

DIM Display layout

The DIM contains two displays, which are used to inform the driver about the vehicles status.



Message Centre Left
GPID Display
Message Centre Right

Message Centre Left

The Message Centre left is used to display the odometer (A), the Cruise control status (B), the Gear range (C) and the T1 or T2 trip distance (D).



Gear Position Indicator Display (GPID)

Automatic Transmission

On an automatic transmission vehicle the GPID display contains the two gearbox mode 'tags' (Auto and Touch), and a segmented character area. This segmented display can show P, R, N, D, 1, 2, 3, 4, 5, 6 depending on the current gear engaged. The display is dual colour.




Green - normal operation

Red - defined situations.

Manual Transmission

On a manual transmission vehicle the GPID display informs the driver when the current gear has reached it's upper rev. limit the GPID will indicate revs increasing. The optimum time to shift gear is when the GPID shows three bars and is red at the top and bottom.



For the first 2000 km (1243 mile) and when ever the engine temperature is below 40°C (104°F) the shift control will indicate early shift changes to protect the engine.

A red 'R' will show when the transmission is in reverse.

Message Centre Right

The Message Centre Right is used to display the trip function information and warning / information messages.



Maintenance Driver Information Module (DIM)

Repair Operation Time (ROT)	
Item	Code
Driver Information Module (DIM) Renew	TBA

Removal


1. Disconnect the vehicle battery.
2. Remove the following items of trim.
 - 2.1 Remove panel (pull off).
 - 2.2 Remove panel (pull off).
 - 2.3 Remove panel (pull off).

Remove Panels x3




3. Remove the screws that secure the DIM bezel (x5). Withdraw the bezel and lay it on the steering column.

The DIM bezel is attached to the leather trim.



4. Remove the screws (x4) that secure the DIM. Withdraw the DIM to the extent of the wiring harness.

Ensure the spacers are retained.





5. Disconnect the wiring harness plug. Withdraw the DIM.

Installation

1. Place the DIM to its mounting point. Connect the wiring harness plug.
2. Install the DIM (screws x4).
3. Install the DIM bezel (screws x5).

Ensure that the DIM finishers install on the inside of the cluster bezel.



4. Install the trim panels.
5. Connect the vehicle battery.

Power Supply (14.00)

Contents


Battery System (14.01)	14-1-2
Description	1-2
Battery Connect Switch	1-2
Battery Disconnection and Alarm Activation.....	1-2
Charging Circuit	1-3
+12 Volt Distribution	1-3
Specifications	1-5
Maintenance	1-5
Battery	1-5
<i>Removal</i>	1-5
<i>Installation</i>	1-5
Alternator and Regulator System (14.02)	14-2-1
Description	2-1
Specifications	2-1
Maintenance	2-1
Alternator	2-1
<i>Removal</i>	2-1
<i>Installation</i>	2-2

Power Supply (14.00)

Battery System (14.01)

Description

The 12 volt negative earth ('-' ve) battery is located under the drivers side rear seat and is grounded to the vehicle body. The battery positive ('+' ve) terminal is connected to a battery connect switch. The connect switch may be accessed by raising the rear seat cushion.



Battery Connect Switch

When the battery connect switch is in an 'open' state it isolates electrical power from all systems except the 'keep alive memory' functions in the PCMs, TCU, radio, navigation system and door modules.

This function isolates electrical power from vehicle circuits under all normal service conditions with the following exceptions:

- Before any welding or other work which may induce high voltages into the electronic control modules
- Before disconnecting any of the control modules with 'keep alive memory'
- Before any major service task (e.g. engine removal)
- Before installing any accessory which involves modification of vehicle wiring

In the above four exceptions the battery earth ('-' ve) lead should be disconnected.

When the battery earth ('-' ve) terminal is disconnected, data held in keep alive memories will be lost.

After connecting the battery, the radio preset stations and the door window controllers will require to be reset (Adaptive learning data in the PCMs and TCU (Auto transmission) modules will require to be re-learned by driving the vehicle for some miles in a range of driving conditions), **driveability may be slightly compromised until the vehicle systems have completed their adaptive learning routines again.**


Battery Disconnection and Alarm Activation

The vehicle is installed with an alarm which will be activated if the battery is disconnected. This alarm is driven by a back up battery within the alarm sounder unit.

To prevent the alarm from sounding when the battery is disconnected (for workshop procedures), disconnect the battery within 10 seconds of switching off the ignition. Always carry out the following procedures upon connection of the battery.

- Reset the clock
- Reset the radio preset programmes.
- Reset the window maximum up and maximum down settings.

Charging Circuit



Electrical power generated at the alternator flows via two 'T Piece' connectors to the engine bay 'Dirty Feed' stud. It then flows via the Battery Disconnect Switch (BDS) to the battery positive terminal. Both the alternator and the battery are earthed via the vehicle body to complete the charging circuit.

The starter motor and the 'jump start terminal' are also fed directly from the charging circuit.


+12 Volt Distribution

The +12 volt supply comes from the battery to the battery disconnect switch (BDS). Assuming that this switch is not activated, 12 volt power is then available from C0046-8 on the BDS to all of the clean feed battery studs.

The following clean feeds are then live:

- Boot fuse box clean feed
- Under bonnet fuse box clean feed
- CEM busbars 1, 2, 3, 4 and 5 clean feeds

12V power to all systems and components is then controlled by the CEM and the under bonnet / boot fuse boxes.



CIRCUIT SHEET	57
APPLICABILITY	From Chassis 00001
MODEL	DB9
CIRCUIT TITLE	Power Distribution Clean Feeds
DB 9	57

Specifications

Torque Figures

Description	Nm.	lb. / ft.
Battery Compartment Cover	9	7
Battery clamp	9	7
Battery Terminals	9	7

Maintenance Battery


Repair Operation Time (ROT)	
Item	Code
Battery Renew	14.01.AB

Removal

1. Power the drivers seat forward.
2. Remove the RH rear seat to reveal the battery compartment.


The rear trim 1/4 panel may need to be removed to gain access to the battery compartment lid bolts.

3. Remove bolts (x10). Remove the battery compartment cover.




4. Disconnect the battery terminals.

Warning
Always disconnect the earth (- ve) terminal first.



5. Remove the battery clamp. Disconnect battery vent tube and pull the battery from the compartment.

Warning
The vehicle battery is heavy and access to the battery is restricted. Take care when lifting the vehicle battery.



Installation

Warning
The vehicle battery is heavy and access to the battery is restricted. Take care when lifting the vehicle battery.

1. Lower the battery into it's compartment.

Ensure that the battery vent tube is attached to the battery and that it located into the opening provided in the body.

2. Clamp the battery. Torque bolts to **9 Nm**.

Ensure that the battery vent tube is not distorted by the battery.

Warning
Always connect the earth (- ve) terminal last.

3. Install the battery terminals. Torque to **9 Nm**.
4. Install the battery compartment cover. Torque bolts to **9 Nm**.
5. Install the rear seat base.
6. Reposition the drivers seat.




ASTON MARTIN

Power Supply (14.00)

Alternator and Regulator System (14.02)

Description

The alternator installed to this vehicle is a Denso, SC2, 150 amp rating, with a 14.4 volt regulator.



The Alternator has an 'Altmon' signal that goes to and from the secondary PCM via a wire in the 3 way connector.

The 'Altmon' signal is monitored by the secondary PCM which adjusts ignition timing and fuelling if necessary to maintain idle speed when the alternator is charging.

The alternator pulley has an in-built mechanical clutch which will slip if there is a rapid change in drive belt speed. This reduces the 'snatch' in the auxiliary drive system during gear changes.

Specifications

Torque Figures		
Description	Nm.	lb. / ft.
Alternator mounts	43-52	32-38.5


Maintenance

Alternator


Repair Operation Time (ROT)	
Item	Code
Alternator Renew	14.02.AB

Removal


1. Disconnect the vehicle battery.
2. Disconnect the wiring harness plug on rear of alternator.




3. Raise the vehicle and make safe. Remove the road wheel and road wheel arch liner.
4. Remove the undertray.
5. Release the polyvee drive belt (Refer to 'Accessory Drive System (03.05)', page 3-5-1).
6. Unclip the wiring harness from the cooling cover.



7. Remove bolts / washers (x3). Withdraw the alternator complete with the cooling shield.



For easier access to bolt, remove air ducting from underside of cooling shield.




Installation

1. Place the alternator complete with the cooling shield to mountings.

Insert bolt (1) as cooling shield is placed to alternator.

2. Secure the alternator and cooling shield assembly to engine block. Tighten bolts (x3) to **43-52 Nm**.



3. Install the air ducting to the cooling shield, if removed.
4. Clip the wiring harness to the cooling shield.
5. Connect the wiring harness plug to the alternator.
6. Install the drive belt (Refer to 'Accessory Drive System (03.05)', page 3-5-1).
7. Install the road wheel arch liners.
8. Install the road wheels (Two stages (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7)).

Vehicle Entertainment (15.00)

Contents

Audio System (15.01).....15-1-2



Vehicle Entertainment (15.00)

Audio System (15.01)

Refer to manufactures literature

Vacuum System (16.00)


Contents

Vacuum Distribution (16.01)	16-1-2
Description	1-2

Vacuum System (16.00)

Vacuum Distribution (16.01)

Description



Lighting (17.00)

Contents

Front Lights (17.01)	17-1-2
Specifications	1-2
Maintenance	1-2
Headlamp Unit.....	1-2
Headlight Alignment	1-3
Continental Conversion.....	1-3
Bulb Renewal	1-4
Side Repeater Lamp Unit - Remove and Install and Replace Bulb	1-6
Side Marker Unit Bulb	1-6
Side Marker Unit	1-6
Interior Lighting (17.02)	17-2-1
Specifications	2-1
Maintenance	2-1
Interior Light Bulb	2-1
Rear Lights (17.03)	17-3-1
Specifications	3-1
Maintenance	3-1
Light Cluster.....	3-1
Side Marker Units	3-1
Lighting Mechanisms (17.04)	17-4-1
Headlamp Levelling	4-1
Maintenance	4-1
Front Level Sensor	4-1
Rear Level Sensor.....	4-2

Lighting (17.00)

Front Lights (17.01)

Specifications

Bulbs

	Rating	Type (European)	Type (Federal)
Headlight dipped beam	35W	D1S	D1S
Headlight main beam	65W	H9	H9
Front Indicators	27W / 29W	PY27W	3457 AK
Front Position Lamp	5W	W5W (Blue)	W5W (Blue)
Side Repeater	5W	WY5W	WY5W
Side marker (front and rear)	5W	N/A	W5W

Headlamp Alignment	European	Federal
Main Beam Alignment	1.5% Down	0.7% Down Vol.
Dipped Beam Alignment	1.5% Down	0.7% Down Vol.

Main beam is fixed to the Dipped beam.


Maintenance Headlamp Unit

Repair Operation Time (ROT)		
Item	Code	
Headlamp Unit Renew	LH	17.01.AB
	RH	17.01.BB

(Including side light and indicator)

Removal

1. Raise the vehicle and make safe.
2. Remove the road wheel and road wheel arch liner.
3. Remove the air box (Refer to 'Air Charging (03.12)', page 3-12-1).
4. Remove bolts (x3) securing the headlamp unit bracket.



5. Disconnect the headlamp unit wiring harness plugs (x3)



6. Withdraw the headlamp unit.

Installation

7. Install the headlamp unit.
8. Install the air box (Refer to 'Air Charging (03.12)', page 3-12-1).
9. Install the road wheel arch liner.
10. Install the road wheel (Refer to 'Torque Tightening of Road Wheel Nuts', page 4-4-7).
11. Carry out headlamp unit alignment procedure.


Headlight Alignment

Headlight alignment should be carried out with vehicle at design weight, i.e.,

- Vehicle at kerb weight, plus
- All fluids at normal full level, plus
- A 75 kg weight in each front seat

1. Remove the access panel from the road wheel arch liner.
2. Switch the ignition to position 'II' then back to position '0'.


This will motor the headlight units to their 'set' position.




3. ROW Only.

Align the headlamps so that the cut off of the dipped beam is 1.5% below the horizontal.

LHD Headlamps




RHD Headlamps



4. Federal Only.

Align the headlamps so that the LH cut off of the dipped beam is 0.7% below the horizontal.

Federal Headlamps



5. Switch the ignition to position 'II' then back to position '0' to ensure that the headlight units are at their set position.
6. Check the headlight unit alignment again to confirm correct alignment.

Continental Conversion

(UK Specification only)

1. Disconnect the vehicle battery.
2. Gain access to the headlight unit by removing the access panel in the road wheel arch liner.
3. Remove both rubber covers.


⚠ **WARNING** ⚠

HID BULBS START-UP VOLTAGE CAN BE 1000V. MAKE SURE THAT THE POWER TO HID BULBS HAS BEEN DISCONNECTED BEFORE YOU DO MAINTENANCE TO THEM. IF YOU DO NOT DO THIS PERSONAL INJURY OR DEATH CAN OCCUR.

⚠ **WARNING** ⚠

HID BULBS GET HOT DURING OPERATION. LET THE HEADLAMP ASSEMBLIES COOL FOR AT LEAST 15 MINUTES BEFORE YOU DO MAINTENANCE TO THEM. IF YOU DO NOT DO THIS BURNS TO SKIN OR CLOTHING CAN OCCUR.


4. Disconnect the dipped beam bulb unit wiring harness plug. Remove the spring clip and withdraw the bulb unit.




5. Locate the conversion switch and move up / down until a positive 'click' is heard.

Bulb Renewal


LH Headlamp Unit



RH Headlamp Unit




Light Adjustment Switch, UK Spec



6. Install the dipped beam bulb unit. Connect wiring harness plug.
7. Install both rubber covers.
8. Install the access panel in the road wheel arch liner.
9. Connect the vehicle battery.

Main Beam Dipped Beam



Gain access to the headlight unit by first removing the access panel in the road wheel arch liner.

Dipped Beam

Repair Operation Time (ROT)		
Item	Code	
Dipped Beam Renew	LH	17.01.CB
	RH	17.01.DB

HID Bulb Disposal

Always dispose of HID bulbs in a responsible manner. Follow your local authorised standards for disposal.

The following precautions must be observed when handling HID bulbs. Failure to comply may result in exposure to ultra violet rays, severe electric shock, burns or risk of explosion.

⚠ WARNING ⚠

HID BULBS START-UP VOLTAGE CAN BE 1000V. MAKE SURE THAT THE POWER TO HID BULBS HAS BEEN DISCONNECTED BEFORE YOU DO MAINTENANCE TO THEM. IF YOU DO NOT DO THIS PERSONAL INJURY OR DEATH CAN OCCUR.

⚠ WARNING ⚠

HID BULBS GET HOT DURING OPERATION. LET THE HEADLAMP ASSEMBLIES COOL FOR AT LEAST 15 MINUTES BEFORE YOU DO MAINTENANCE TO THEM. IF YOU DO NOT DO THIS BURNS TO SKIN OR CLOTHING CAN OCCUR.

⚠ WARNING ⚠


NEVER SWITCH ON LAMPS OR TEST BULBS WITH THE LAMP HOLDER DETACHED FROM HEADLAMP.

⚠ WARNING ⚠

EYE AND HAND PROTECTION MUST BE WORN.

1. Disconnect the vehicle battery.
2. Remove the rubber cover.

3. Disconnect wiring harness plug. Remove the spring clip and withdraw the bulb unit.



4. Insert a new bulb unit. Secure with the spring clip and connect the wiring harness plug.
5. Connect the vehicle battery.


Main Beam

Repair Operation Time (ROT)	
Item	Code
Main Beam Renew	LH 17.01.GB
	RH 17.01.HB

⚠ WARNING ⚠
HID BULBS START-UP VOLTAGE CAN BE 1000V. MAKE SURE THAT THE POWER TO HID BULBS HAS BEEN DISCONNECTED BEFORE YOU DO MAINTENANCE TO THEM. IF YOU DO NOT DO THIS PERSONAL INJURY OR DEATH CAN OCCUR.

⚠ WARNING ⚠
HID BULBS GET HOT DURING OPERATION. LET THE HEADLAMP ASSEMBLIES COOL FOR AT LEAST 15 MINUTES BEFORE YOU DO MAINTENANCE TO THEM. IF YOU DO NOT DO THIS BURNS TO SKIN OR CLOTHING CAN OCCUR.

1. Disconnect the vehicle battery.
2. Twist the bulb holder anti-clockwise and pull out from it's retainer. Disconnect the wiring harness plug.
3. Connect the wiring harness plug to the new the bulb and insert the bulb unit into it's retainer. Twist clockwise to secure.




4. Connect the vehicle battery.

Indicator and Side Light

Repair Operation Time (ROT)	
Item	Code
Indicator Bulb Renew	LHF 17.01.EB
	RHF 17.01.FB
Side Bulb Renew	LHF 17.01.JB
	RHF 17.01.KB

1. Rotate the bulb holder a quarter turn anti-clockwise and withdraw.



2. Pull the bulb from it's holder and withdraw the bulb.
3. Install a new bulb and turn push to lock.
4. Install the bulb holder to the headlamp light cluster and install the rear lamp access panel.

Side Repeater Lamp Unit - Remove and Install and Replace Bulb


Repair Operation Time (ROT)	
Item	Code
Side Repeater Lamp Unit - Remove and Install	17.01.KC
Side Repeater Lamp Unit - Replace Bulb	17.01.KD

Remove

1. Raise the vehicle and make it safe.
2. Remove the two M6 Torx head screws that attach the wheelarch liner at the middle of the wheelarch.
3. Move the wheelarch liner to get access to the repeater lamp assembly.
4. Protect the adjacent paint work.
5. Hold the side repeater body and turn the bulb holder assembly counterclockwise and pull it out of the body.

WARNING
BE CAREFUL WHEN YOU INSTALL AND REMOVE THE BULB. THE GLASS OF THE BULB CAN BREAK AND CAUSE INJURY.

6. Pull the bulb to release it from the bulb holder.



Install

WARNING
BE CAREFUL WHEN YOU INSTALL AND REMOVE THE BULB. THE GLASS OF THE BULB CAN BREAK AND CAUSE INJURY.

1. Push the bulb into the bulb holder.
2. Align the bulb holder assembly with the side repeater body.
3. Push the bulb holder assembly into the side repeater body and turn it clockwise to lock it.
4. Put the wheelarch liner back into position.

5. Install the two M6 Torx head screws that attach the wheelarch liner.
6. Lower the vehicle.

Side Marker Unit Bulb

Repair Operation Time (ROT)	
Item	Code
Side Marker Unit Bulb Renew	TBA

Federal Markets Only

Renewal (Front and Rear)

1. **Front Side Marker Unit Only.**
Remove the front part of the road wheel arch liner to gain access to the bulb holder.
2. **Rear Side Marker Unit Only.**
Remove the rear light cluster to gain access to the bulb holder (Refer to 'Light Cluster', page 17-3-1).
3. Twist the bulb holder for the side marker unit 90° counterclockwise and pull it out of the side marker unit.
4. Install a new bulb into the bulb holder.
5. Put the bulb holder into the side marker unit.
6. Turn it 90° clockwise to it lock in place.
7. **Front Side Marker Unit Only.**
Install the road wheel arch liner.
8. **Rear Side Marker Unit Only.**
Install the rear light cluster (Refer to 'Light Cluster', page 17-3-1).

Side Marker Unit

Repair Operation Time (ROT)	
Item	Code
Side Marker Unit Renew	17.01.LA

Federal Markets Only

Renewal (Front and Rear)

1. **Front Side Marker Unit Only.**
Remove part of the road wheel arch liner to gain access to the rear of the side marker unit.
2. **Rear Side Marker Unit Only.**
Remove the rear bumper to gain access to the rear of the side marker unit (Refer to 'Rear Bumper', page 1-19-3).
3. Remove the two speed nuts that attach the side marker unit to the bumper.
4. Remove the side marker unit.



5. Disconnect the electrical connector at the rear of the side marker unit and remove the assembly.
6. Connect the electrical connector to a new side marker unit and install.
7. **Front Side Marker Unit Only.**
Install the road wheel arch liner.
8. **Rear Side Marker Unit Only.**
Install the rear bumper (Refer to 'Rear Bumper', page 1-19-3).



ASTON MARTIN

Lighting (17.00)

Interior Lighting (17.02)

Specifications

Bulbs

	Rating	Type
Reading lamp	3W	W3W
Rear occupant lamp	3W	W3W
Boot lamp	3W	W3W

Maintenance

Interior Light Bulb


Renew

Repair Operation Time (ROT)	
Item	Code
Interior Bulb Renew	17.02.AB

1. Taking care to protect the trim panel, lever the lamp unit from the trim panel.

Lever the lamp unit from the trim panels inline with the locating clips.


Reading Lamp



Rear Quarter Lamp



Boot Lamp



2. Twist the bulb holder approx. 20° anti-clockwise and withdraw the bulb holder. Pull the from the bulb holder and install a new bulb.
3. Push the lamp unit back into the recess in the trim panel.




ASTON MARTIN

Lighting (17.00)

Rear Lights (17.03)

The rear light cluster is a sealed unit. If any light which fails to illuminate is traced back to the rear light cluster, replace the whole unit.



Specifications

Bulbs

	Rating	Type
Rear light cluster		LED
Rear side marker	3W	W3W
Number plate	5W	C5W
High Mounted Stop Lamp		LED

Maintenance

Light Cluster

Repair Operation Time (ROT)	
Item	Code
Rear Light Cluster Renew	LH 17.03.AB
	RH 17.03.BB

Remove

1. Open the boot and remove the trim from around the light cluster mounts.
2. Release and remove nuts (x3).
3. Withdraw the rear light cluster unit.
4. Disconnect the wiring harness plug.

Installation

1. Place the rear light cluster unit to vehicle and connect the wiring harness plug.
2. Insert the rear light cluster unit into position.
Ensure the rubber seal is in position. Tighten nuts (x3).

Ensure that the light cluster profile matches the surrounding panels.

Side Marker Units

Refer to 'Front Lights (17.01)' for all information on the rear side marker lights.




ASTON MARTIN

Lighting (17.00)

Lighting Mechanisms (17.04)

Headlamp Levelling



The 'Automatic Dynamic Headlamp Levelling System' consists of:

- An Automatic Dynamic Headlamp Levelling System ECU
- A level sensor for the front suspension
- A level sensor for the rear suspension
- A bi-polar stepper motor mounted in the housing of each headlamp

The Automatic Dynamic Headlamp Levelling System prevents the dipped beam dazzling oncoming road traffic by varying the angular position of the dipped (and main beam) headlamp units relative to the position of the vehicles suspension.

Static condition - Compensates for boot or occupant load condition.

Dynamic condition - Compensates for suspension movements due to acceleration and deceleration. The sensitivity of the system is dependent on vehicle speed and the rate of change of the vehicle speed.

High amplitude low frequency inputs such as those caused by potholes are filtered out to desensitise the system in constant speed situations.


Maintenance

Front Level Sensor

Repair Operation Time (ROT)	
Item	Code
Front Level Sensor Renew	17.04.BB

Removal

1. Disconnect the vehicle ride height sensor from the lower suspension arm.
2. Remove the ride height sensor from the subframe.




Installation

1. Install the vehicle ride height sensor (LH side).

Torque to:

- (M8 (subframe)) **22.5 Nm.**
- (M8 (lower arm)) **22.5 Nm.**




Rear Level Sensor

Repair Operation Time (ROT)	
Item	Code
Rear Level Sensor Renew	17.04.CB

Removal

1. Disconnect the vehicle ride height sensor from the upper suspension arm.
2. Remove the ride height sensor from the subframe.




Installation

1. Install the vehicle ride height sensor (LH side).

Torque to:

- (M5 (subframe)) **5-6 Nm**.
- (M8 (upper arm)) **22.5 Nm**.



Electric Distribution/Electronic Control (18.00)

Contents

Wiring and Circuit Protection (18.01)	18-1-2
Fuse Boxes	1-2
Fuse Listings.....	1-2
Engine Bay Fuse / Relay Box.....	1-2
Central Electronics Module Fusebox.....	1-3
.....	1-4
Stand Alone Fuses.....	1-4
Boot Fusebox.....	1-4
How to Read the Circuits	1-4
Wires.....	1-4
Twisted Wires.....	1-5
Controller Area Network (CAN).....	1-5
High Speed CAN wire.....	1-5
Low Speed CAN wire	1-5
Media Oriented System Transport (MOST).....	1-6
Connectors	1-6
Splices	1-7
Tracing Spliced Wires	1-7
Splice Origin Page	1-7
Relays	1-8
Busbars.....	1-8
Fuses	1-8
Resistors.....	1-9
Variable Resistors	1-9
Lamps.....	1-9
Switches	1-9
Normally Open Switch	1-9
2 Position Switch	1-9
3 Position Switch	1-9
Motors and Pumps.....	1-9
Pump	1-9
Motor	1-10
Diodes.....	1-10
Light Emitting Diode (LED)	1-10
Transistor	1-10
Field Effect Transistor (FET)	1-10
Earth / Ground.....	1-10
Component Identification	1-11
Maintenance	1-17
Fuel Tank Harness - Remove and Install	1-17
Install.....	1-17
Circuit Diagrams	1-18
PCMs.....	1-107
Vehicle Control System (18.08)	18-2-1
Module Configuration	2-1
Principles of Operation	2-1
Market Configuration	2-1
Configuration.....	2-1
Customer Configuration	2-1
Data Buses	2-1
Network Bus	2-1
MOST.....	2-1
Module Locations (RHD)	2-2
Module Locations (LHD)	2-4

Electric Distribution/Electronic Control (18.00)

Wiring and Circuit Protection (18.01)


Fuse Boxes

From the clean 12V output terminal of the battery disconnect switch, electrical power is distributed to three fuse boxes:


RH drive shown. On LH drive vehicles the engine bay fuse box is located on the RH side.

The central electronic module (CEM) fuse box is always located on the passenger side.


Engine Bay Fusebox



Cabin Fusebox



Boot Fusebox




Always ensure that the fusebox covers are located correctly to prevent ingress of water / foreign materials

The fuse boxes also contain the switching relays.

Fuse Listings

Engine Bay Fuse / Relay Box




Fuse	Rating	Function
F1	10A	Keep alive power PCM (Bank B)
F2	10A	Tracker (option) / Clock
F3	10A	Cooling fan module
F4	20A	Engine management (Bank A) / Module - ABS, Key Reader and Steering angle sensors
F5	20A	Engine management (Bank B)
F6	15A	Exhaust Gas Oxygen (HEGO) sensors / Catalyst monitor sensor (CMS) (Bank B)
F7	15A	Coils 7-12 / Suppressor solenoid (Bank B)
F8	10A	Engine coolant level sensor (Bank B)
F9	20A	Injectors 7-12 / Mass air flow sensor (MAF) (Bank B)
F10	10A	A/C clutch
F11	15A	Horn
F12	10A	Keep alive power PCM (Bank A)
F13	20A	Injectors 1-6 / Mass air flow sensor (MAF) (Bank A)
F14	10A	Vapour Management valve (VMV) (Bank A)
F15	25A	Starter motor
F16	15A	Coils 1-6 / Suppressor solenoids (Bank A)
F17	5A	Glove box release solenoid
F18	15A	Exhaust Gas Oxygen (HEGO) sensors / Catalyst monitor sensor (CMS) (Bank A)
F19	30A	ABS module / Battery feed
F20	30A	ABS module / Battery feed
F21	30A	Heated front screen
F22	5A	Spare
F23		Blank
F24	5A	Alternator warning lamp
F25	5A	Spare
F26	20A	Headlamp wash pump
F27	25A	Spare

Fuse	Rating	Function
F28	10A	Module - ABS, Key Reader and Steering angle sensors
F29	25A	Spare
F30	5A	Alternator battery sensing
F31	30A	Heated front screen
F32	30A	Wiper (slow)
F33	30A	Wiper (fast)
F34	20A	Heater Blower motor
F35	60A	Cooling fan module

Relay	Rating	Function
R1	PCM A	
	Coolant fan pack	
R2	PCM B	
R3	Injectors (1-6 (Bank A))	
	MAF Sensor (1-6 (Bank A))	
	Ignition coils (1-6 (Bank A))	
	Front and rear HEGOs and CMS (1-6 (Bank A))	
	VMV	
R4	Wiper motor	
R5	Injectors (7-12 (Bank B))	
	Ignition coils (7-12 (Bank B))	
	MAF Sensor (7-12 (Bank B))	
	Engine coolant level and VMV	
R6	Heater blower moter	
R7	Glovebox	
R8	Wiper motor	

Central Electronics Module Fusebox



Fuse	Rating	Function
F43	10A	Multi media module display / Phone (option) / GPS tuner (option (not Middle East)) / Media player
F44	10A	Airbag module
F45	15A	Accessory socket and illumination
F46	5A	ROPS / Convertible roof switch / Driver Information / Master light switch / Glove box relay / Master lock switch / Battery Off switch
F47	5A	Interior lamps (front / footwell / rear) / Boot lamps relay

Fuse	Rating	Function
F48	15A	Front windscreen relay and wash pump
F49	10A	Airbag module
F50	5A	Spare
F51	10A	Diagnostic connectors / Centre stack switches
F52	5A	Start button
F53	10A	Headlamp levelling module / Power steering module
F54	10A	Engine fuse box, Boot fuse box
F55	20A	Spare
F56	10A	Centre console module / Sounder module / Hazard switch
F57	15A	Diagnostic connectors / Brake pedal switch
F58	10A	High beam (RH)
F59	10A	High beam (LH)
F60	15A	Drivers seat heating
F61	15A	Passenger seat heating
F62	20A	A/C module
F63	20A	Spare
F64	5A	AM / FM receiver module / Traffic Monitoring Control module (TMC)
F65	5A	Media player / Multi media module and display / Antenna amplifiers / Audio amplifier
F66	10A	Centre console module / Infotainment control module
F67	15A	Spare
F68	5A	Spare
F69	5A	Convertible roof module (Volante)
F70	15a	Spare
F71		Spare
F72		Spare
F73	5A	Spare
F74	15A	Fuel pump
F75		Spare
F76		Spare
F77	15A	Boot power socket
F78		Blank
F79	5A	Reversing lamps / Module - Parking aid (option)
F80	5A	Battery 'Off' switch
F81	20A	Ignition switch
F82	25A	Passenger door module
F83	25A	Driver door module
F84	25A	Passenger seat power and switch pack
F85	30A	Driver seat power and switch pack
F86	5A	Start button, Driver and passenger seats

Stand Alone Fuses		
Fuse	Rating	Function
F1	40A	Cabin Fuse box supply
F2	30A	Cabin Fuse box supply
F3		Blank
F4	40A	Cabin Fuse box supply
F5	20A	Cabin Fuse box supply

Boot Fusebox



Fuse	Rating	Function
F1	5A	Convertible deck lid lock motors
F2	20A	Spare
F3	30A	Heated rear window
F4	20A	Rear quarter glass motor (LH) (Volante) Spare (Coupe)
F5	30A	Spare
F6	20A	Rear quarter glass motor (RH) (Volante) Spare (Coupe)
F7	5A	Battery disconnect switch (BDS) power
F8	30A	Fuel pump module (Bank B) / Tracker
F9	20A	Fuel pump module (Bank A)
F10	30A	Convertible roof module
F11	20A	Spare
F12	20A	Transmission control module (Automatic)
F13	10A	Tyre pressure monitoring
F14	5A	Rear parking assistance module (optional)
F15	5A	Transmission control module (Automatic)
F16	30A	Convertible roof hydraulic pump
F17	5A	Boot lamps / Rear power socket illumination
F18	30A	Audio amplifier
F19	5A	Spare
F20	10A	Canister vent
F21	30A	Convertible roof lid lock motors relay
F22	20A	Exhaust by-pass and vacuum pump

Relay	Rating	Function
R1		Fuel pump driver module (7-12 (Bank B)) Tracker (If installed)
R2		Fuel pump driver module (1-6 (Bank A))
R3		Canister vent valve Exhaust bypass valve and vacuum pump
R4		TCM (auto only) Spare Tyre pressure monitor Parking aid (if installed)
R5		Rear quarter glass motor (Volante) Spare (Coupe) BDS Rear quarter glass motor (Volante) Spare (Coupe)
R6		Boot lamps
R7		Heated rear window



How to Read the Circuits

Below is a simple guide to what symbols mean on the circuit diagrams. For some of the symbols there are descriptions as to how they function.

Wires



Wire numbers have been deleted from the original engineering circuits. This allows the type size to be increased for improved legibility of the service circuits.

Wires vary in size to allow different current to be carried. For example a wire with a diameter of 0.50mm (This is the diameter of all the internal copper strands together) will carry 11A (dependant on ambient temperature) whilst a wire with a diameter of 2.00mm will carry 25A.



Twisted Wires



The 'figure of 8' shown on circuits as below denotes a twisted wire and shows the wires that are twisted together. A wire generates a certain amount of 'electrical noise' when a current is passed through it. By twisting the 2 wires together the 'electrical noise' is cancelled out on each wire by the opposing wire. This is used more on sensors and audio speakers.



Screened and Twisted Screen Wires

The signals through a wire can be affected by externally generated electrical noise. To reduce the external interference the wires are placed inside a conductive sleeve. One end of the conductive sleeve is always open whilst the other end can be terminated to a ground, to a component, or left open.

The symbol for the screen is an oval with the wires that are to be screened inside it. The letters 'SCR' define the screen.



Controller Area Network (CAN)

Controller Area Network (CAN) is the wiring between intelligent modules of the vehicle. This wiring carries the electronic data around the vehicle allowing the various modules and components to interrogate the network and read their specific data signals.


There are 2 different speeds of network.

Low speed - Transmits at 125,000 bits per second. Mainly for body controller systems such as seats and doors

High speed - Transmits at 500,000 bits per second. Mainly for engine management and powertrain associated systems such as ABS.

All wiring in the CAN is twisted. The twisted wires always consist of one wire with a black trace in it for the negative side and one with a brown trace in it for the positive.


High Speed CAN wire



Low Speed CAN wire



The symbol below shows a module or a component connector with the pin numbers that have CAN wires coming from them.



'CAN LS+' - Low speed CAN positive side

'CAN LS-' - Low speed CAN Negative Side

This naming convention also applies to the High Speed CAN network.

To aid identification of the different speed CAN's in the vehicle different colours of wire have been used, e.g. the Low Speed Volcano is GB twisted with GN, the High Speed Volcano is RB twisted with RN.



There is attached on a separate page a list for wire colour abbreviations and what colour they refer to.

Media Oriented System Transport (MOST)

A fibre optic carries out a similar function to that of a wire in that it transmits data signals. The differences being that where a wire is made up of copper strands in an insulated sleeve a fibre optic is a plastic tube with a highly polished reflective inside surface.

The fibre optic carries the data in the form of a pulse of light, which is sent via an infrared transmitter and picked up at the next component in the loop via an infrared receiver. The light pulse is then converted to an electrical signal that is used by that module or component.




The CAN sends signals around the vehicle where the modules or components remove their specific signals. The fibre optic is in a loop with the module components in that loop, one fibre goes in and one fibre goes out. This is shown below.





Connectors

There are 2 types of interconnect shown on the circuits. Each connector is given a dedicated 'C' number. The number after the dash is the pin number, also known as the cavity number. The example below is C0582 that when checked on the attached list refers to the CEM Connector Cockpit 2 (C3).

The 1st type is shown for a **connector** that is on a module or component with a mating harness connector attached to it.



The 2nd type is shown for a connector on a harness with the mating connector on another harness. This is known as an **Inline**. Again the above naming convention applies.





The terminals in a connector housing can have a special coating on them. This coating if required is selected using the following criteria.

- A specific coating requested by component / system owner.

Or

- The current passing through the terminal.
- The environment the connector is to be situated with respect to temperature.
- The open circuit voltage passing through the terminal at a given.


Depending on the above criteria the coating, if required, can either be gold, silver, phosphor bronze. Generally tin is the common plating on the terminals but there are some that are gold. These are identified in the circuits with the letter 'G' which stands for gold after the connector number. An example of this is shown below.



Splices

A splice is used where more than 2 wires that have the same requirement i.e. they need the same signal and meet in the same harness. In the example below the Front Position Lamp-LH and Front Side marker-LH require the same output signal from the CEM. Therefore the 2 wires for the lamps are spliced into the output wire from the CEM on the Forward Harness.

Splice No.	SPL1	FLL	FOR
Associated name			
Harness that the splice is on			



Tracing Spliced Wires


Some splices appear on pages as a wire that goes to one spot and seems to terminate in space. An example of this is shown below.

Splice Origin Page

(e.g.P9)




Other Page(s) on which the splice occurs.




A separate page is attached containing a list of splice abbreviations and the harness to which they refer.

Relays


Another significant component in the circuits is a relay, this is in simple terms a switch that operates on the principal of electromagnetism. Below is the circuit symbol for a typical relay. The relay shown below is a normally open relay in its inoperative state i.e The arm is in the open position.



Relays can have either 4 or 5 terminals on the base. The circuit of the relay is shown on the base or the side of the housing. There are 2 types of numbering convention for the relay terminals, both of which are shown below.



Below is a circuit diagram to show the function and operation of a relay in a simple circuit.




The current from a battery for example flows through the wires to the high power normally open switch (The arm between pins 30 & 87A) and the low power coil (The box between pins 85 & 86). As you can see in the example above the lamp is in not illuminated, because the switch is open.

For the relay to operate there needs to be current flow through the low power coil i.e Current in to the coil then through to an earth. The current passes through the relay coil and creates a magnetic field, this magnetic field is strong enough to 'grab' the high power normally open switch.


The magnetic field pulls the switch from it's normally open contact to a normally closed contact. The normally closed contact has a path to an earth, in this case it goes through a lamp.

The high power current then flows through the high power normally open switch through the lamp and then to an earth. This can be seen more clearly in the diagram below. Lamp Illuminates




Busbars

A busbar is where a electrical supply is fed into a conductive bar, wire or pcb track and various modules or components 'tap' into this busbar to draw their required power. The Central Electronic Module has 4 of these busbars internally, each of which is supplied from an external power supply, that supply can be a battery feed, ignition feed or a switched supply.



The symbol shown below is the symbol used on the circuits for a busbar, the number inside the box refers to the busbar number in the Central Electronic Module.




Fuses


A fuse is a device used to protect a module or component from excessive electrical current which can cause damage or destroy that module or component. In practice the fuse is placed in between the power source and the module or component that is being protected.

The size or 'Rating' of the fuse in amps is calculated according to the power requirements of the module or component it is protecting with other factors being taken into consideration. If the rating has been calculated correctly then the fuse will 'blow' when excessive current passes through it before any harm or permanent damage occurs to the module or component it is protecting.

In a correctly protected circuit, the fuse is placed 'Inline' between the power source in this case the battery and the lamp. If the lamp goes 'short circuit', a massive current will begin to flow and the fuse will fail causing an open circuit. The battery and wiring are protected from over current damage.



Below is the fuse symbol as shown on the circuit diagrams. The number above the fuse symbol is the fuse number; allocated to this fuse. The number below the fuse symbol is the rating.



Resistors

A resistor is an electronic component that by way of its construction reduces the current flowing through it. A resistors unit of measure is the Ohm.


The diagrams below show a resistor and a variable resistor.



Variable Resistors


A variable resistor works in the same manner as a normal resistor but the resistance values can fluctuate. The construction of a variable resistor depends upon its use and environment.

One example is for the fuel tank level sensor. The tank full level is 10 ohms and the tank empty level is 204 ohms, the resistance will vary between 10 and 204 ohms depending on how much fuel is in the tank.



Lamps


Below is the symbol for a light bulb, shown below the symbol is the power of the bulb in watts.



Switches

There are numerous of types of switch, several of examples are shown below.


Normally Open Switch



2 Position Switch



3 Position Switch




Motors and Pumps

The same symbol is used for a pump or a motor, the description differentiates between them.

Pump




Motor



Field Effect Transistor (FET)

A field effect transistor (FET) is, in simplistic terms, a switch with no moving parts. The 'switching' is controlled by electronics and currents etc. rather than a physical switch being operated. The main difference between this and the type of transistor shown above is this one operates using a magnetic field.





Earth / Ground

For an electrical current to 'flow' around a circuit it has to start from a power source and go to an earth / ground. If there are any breaks in this circuit then current will not flow, this is called an 'Open circuit'

Diodes

The simplest way of describing a diode is 'a non return valve'. The current will flow through the diode from the anode to the cathode, due to the construction of it though current cannot come back. Diodes are used to reduce the possibilities of 'back feed'. This is where current comes through the circuit the wrong way for one reason or another. Below is the circuit symbol for a diode.




There are 2 types of earth, Signal Earth and Chassis Earth, these are referred to sometimes as a Quiet Earth and Noisy Earth respectively.

Light Emitting Diode (LED)

The light emitting diode (LED) works on the same principal as the diode. The main difference is that in the manufacturing process one of the materials is replaced by another. This replacement material has certain properties that when a certain voltage passes through it glows.

Some sensors for example specify a Signal / Quiet Earth. While components such as pumps and motors can have a Chassis / Noisy Earth. The reason behind this is that pumps, motors and the like can generate 'electrical noise' by the way of their operation. Some of this 'electrical noise' can be transferred through wires, it is this 'electrical noise' that can have an adverse effect on sensor signals and affect the control readings.

Arrow Symbol indicating light emission



Anode

LED Colour

Keeping Signal / Quiet and Chassis / Noisy earths separate reduces the effect of 'electrical noise' being transferred from component to component.




This symbol is a standard symbol for earths.

Transistor

A transistor in simplistic terms is a switch with no moving parts. The 'switching' is controlled by electronics and currents etc. rather than a physical switch being operated. Below is the circuit symbol for it. The example shown below is one of the most common basic type used called a 'Bipolar'.

On the circuit diagrams some earths are shown as eyelets with the description of Earth-**** next to it, the earths also comply with the 4 digit C number. An example of this is shown below.



Component Identification

Component	Connector	Circuit Page	Component	Connector	Circuit Page
Airbag-Driver	C0257	3	Cabin-Boot Inline 4	C0109	
Airbag-Passenger1	C0251	3	Cabin-Boot Inline 7	C0607	
Airbag-Passenger2	C0261	3	Cabin-Boot Inline 8	C0608	
Airbag-Side-Left	C0948	3	Cabin-Boot MOST Connector	C0420	
Airbag-Side-Right	C0949	3	Cabin-Centre Stack Inline 1	C0083	
Alternator/Generator	C0226	60, 69	Cabin-Centre Stack Inline 2	C1165	
Alternator/Generator Battery Terminal	C1893	58	Cabin-Centre Stack Inline 3	C1185	
AM/FM Receiver Module	C2538	7	Cabin-Centre Stack Inline 4	C1322	
AM/FM Receiver Module	C2219	7	Cabin-Centre Stack MOST Connection	C1898	
AM/FM Receiver Module (MOST)	C0102	74, 75	Cabin-Driver Airbag Inline	C0273	
Amplifier-(Aud Power)	C2588	46	Cabin-Engine Inline 1	C2242	
Antenna Amplifer1	C2510	7	Cabin-Engine Inline 2	C2243	
Antenna Amplifer1	C0491	7	Cabin-Engine Inline 3	C2244	
Antenna Amplifer2	C2511	7	Cabin-Engine Inline 4	C2245	
Antenna Amplifer2	C0492	7	Cabin-Fuel Tank Inline 1	C1187	
Antenna-GPS	C1598	17	Cabin-Fuel Tank Inline 2	C0113	
Antenna-Phone	C2233	17	Cabin-Passenger Airbag Inline	C0305	
Bar-ROPS-LH	C2672	60	Capacitor	C1323	9
Bar-ROPS-RH	C2673	60	CEM Busbar 3 Feed	C2509	57
Battery Fusebox	C0632	57	CEM Busbar 4 Feed	C2841	57
Battery Negative Terminal	C0045	57, 58	CEM Busbar 5 Feed	C2842	
Battery Positive Terminal	C0192	57, 58	CEM Connector Cockpit 1 (C1)	C0580	
Battery-Backup-Tracker	C0800	64	CEM Connector Cockpit 2 (C3)	C0582	
Boot Fusebox - Conn A	C2010		CEM Connector Floor 1 (C5)	C0584	
Boot Fusebox - Conn B	C2011		CEM Connector Floor 2 (C8)	C0587	
Boot Fusebox - Conn C	C2012		CEM Connector Front End 1 (C7)	C0586	
Boot Fusebox - Conn D	C2013		CEM Connector Front End 2 (C9)	C0588	
Boot Lamp1	C0119	36	CEM Connector Roof 1 (C6)	C0585	
Boot Lamp2	C0120	36	CEM Connector Roof 2 (C10)	C0589	
Boot-Boot Lid Harness	C0384		Clock-Analogue	C0232	31
Boot-Convertible Roof Inline 1	C0349		Clutch-Compressor-Air Conditioning (A/C)	C0127	6
Boot-Convertible Roof Inline 2	C0084		Coil Suppressor-Bank A	C0997	47
Boot-Transmission Inline 1	C0746		Coil Suppressor-Bank B	C2455	47
Boot-Transmission Inline 2	C0747		Connector-Fuel Tank	C0114	41
C1 Engine Bay Fusebox	C0570		Convertible Roof Conn4 (HRW)	C2808	42
C10 Engine Bay Fusebox	C0579		Convertible Roof1	C2805	19
C2 Engine Bay Fusebox	C0571		Convertible Roof2	C2806	19
C3 Engine Bay Fusebox	C0572		Convertible Roof3	C2807	19
C4 Engine Bay Fusebox	C0573		Convertible Roof5	C2809	20
C5 Engine Bay Fusebox	C0574		Convertible Roof6 (Hydraulic Pump)	C2810	18
C6 Engine Bay Fusebox	C0575		Diagnostic Connector A - Powertrain	C0549	16, 54
C7 Engine Bay Fusebox	C0576		Diagnostic Connector B - Body	C0877	14, 53
C8 Engine Bay Fusebox	C0577		Direction Mode Actuator	C0413	5, 6
C9 Engine Bay Fusebox	C0578		Door Lock-Drivers Door	C1449	22
Cabin-Boot Inline 2	C0144		Door Lock-Passenger Door	C1451	22
Cabin-Boot Inline 3	C0117		Driver Seat-Conn1	C2378	61, 61A



Component	Connector	Circuit Page	Component	Connector	Circuit Page
Driver Seat-Conn3	C0751	2, 61A	Earth Eyelet-ECU B Caseground	C2650	56
Driver Seat-Conn4	C0255	15, 61	Earth Eyelet-ECU B Powerground	C0558	56
Drivers Door Module Conn 1	C0336	22, 23, 26, 28, 35, 49	Earth Eyelet-ECU B Powerground	C0559	56
Drivers Door Module Conn 2	C0337	15, 23, 25, 26, 28	Earth Eyelet-FPDMs	C2727	41
Drivers Door Module Conn 3	C0338	23	Earth Eyelet-Front Brake Pad Wear Sensors	C2564	30
Drivers Door-Cabin Inline	C0744	49	Earth Eyelet-Fuel Flap Release Switch	C2920	32
Drivers Door-Puddle Lamp	C0978	18	Earth Eyelet-Fuel Flap Release Switch	C2921	32
Dual Relay Base-Tonneau Lid Lock	C0063	6	Earth Eyelet-Fuel Flap Sol, Bt Lmps, Mtr-Boot	C2692	1, 32, 36
Earth Eyelet-Aircon Clutch	C0560	46	Earth Eyelet-Fuel Tank	C2899	41
Earth Eyelet-Amplifier	C0808	22, 23, 26, 28, 35, 49	Earth Eyelet-Glovebox Release Motor	C2929	32
Earth Eyelet-Antenna Amplifiers	C2713A/B	7	Earth Eyelet-Headlamp Wash Pump	C2603	73
Earth Eyelet-Auto Int, Start, Glove Rel, Red Grd	C2716	32, 63	Earth Eyelet-Heated Rear Window (Con)	C2693	42
Earth Eyelet-Bank A Cam/Crank Screen	C0563	65	Earth Eyelet-Heated Rear Window (Coupe)	C1679	42
Earth Eyelet-Bank B Cam/Crank Screen	C0561	66	Earth Eyelet-HFS LH	C2597	42
Earth Eyelet-Blower Motor	C0564	5	Earth Eyelet-HFS RH	C2598	42
Earth Eyelet-Body	C2934	41	Earth Eyelet-HID Module & DIM	C0709	31, 34
Earth Eyelet-Body to Battery Negative	C1661	57, 58	Earth Eyelet-Horn	C0018	71
Earth Eyelet-Bonnet Switch	C1972	63	Earth Eyelet-Hydraulic Roof Pump	C2710	18
Earth Eyelet-Boot Fusebox	C2697	57	"Earth Eyelet-ICM,MP & Switches"	C0555	10, 11, 12, 17, 31
Earth Eyelet-Boot Release Sw, Batt Condition	C2694	36, 69	Earth Eyelet-Key Read & Ind Switch	C0706	33, 35, 63
Earth Eyelet-Brake Fluid Level Switch	C2562	50	Earth Eyelet-LH Front Lights	C1626	33
Earth Eyelet-CCM (Noisy)	C1169	17	Earth Eyelet-LH Headlamp DI	C1964	35
Earth Eyelet-CCM (Quiet)	C1170	17	Earth Eyelet-LH Rear Lamp	C2605	35, 37, 38, 39, 40
Earth Eyelet-CCMTrip Switches	C1355	30	Earth Eyelet-LH Side Repeater	C1968	35
Earth Eyelet-CEM (Quiet)	C2648	56	Earth Eyelet-Mass Air Flow Sensor A	C0551	67
Earth Eyelet-CEM Chassis	C2570	56	Earth Eyelet-Mass Air Flow Sensor B	C0552	67
Earth Eyelet-CHMSL	C2626	39	Earth Eyelet-Master Lock & Int Boot Rel Sw	C2646	25
Earth Eyelet-Convert Roof Sw	C2566	18	Earth Eyelet-MMM,GPS,Tyre Press	C2634	17, 31, 52
Earth Eyelet-Convertible Roof Module	C0810	18	Earth Eyelet-Module ABS	C0434	51
Earth Eyelet-Convertible Roof Module	C2635	18	Earth Eyelet-Module ABS	C0362	51
Earth Eyelet-Cooling Fan Module	C0562	21	Earth Eyelet-Module-Auto Transmission	C2696	6
Earth Eyelet-Drivers Door	C2600	22, 23, 26, 28	Earth Eyelet-OBDD Chassis Gnd	C2629	53, 54
Earth Eyelet-Drivers Seat	C2567	61	Earth Eyelet-OBDD Signal Gnd	C2628	53, 54
Earth Eyelet-Drivers Seat	C2568	61			
Earth Eyelet-ECU A Caseground	C2651	56			
Earth Eyelet-ECU A Powerground	C0556	56			
Earth Eyelet-ECU A Powerground	C0557	56			

Component	Connector	Circuit Page	Component	Connector	Circuit Page
Earth Eyelet-Passenger Door	C2601	22, 24, 27, 29	ECU B (T-Trans)	C0637	
Earth Eyelet-Passenger Seat	C0811	62	Eyelet-Battery Feed to Battery Conditioner	C2175	69
Earth Eyelet-Passenger Seat	C2569	62	Eyelet-Boot Fusebox Battery Feed	C2609	57
Earth Eyelet-PDC Module	C2630	55	Eyelet-Boot Fusebox Clean Feed	C1890	57
Earth Eyelet-Phone, MMD, Aircon	C1398	5, 17, 52	Eyelet-Cabin Side BDS Feed	C1891	57
Earth Eyelet-Power Socket/Cigar Lighter	C2599	1	Eyelet-Cabin Side Clean Feed	C2704	57
Earth Eyelet-Power Steering Solenoid	C2565	59	Eyelet-Cabin Side Clean Feed Stud	C1627	57
Earth Eyelet-Rear Doors Ajar	C2712	22	Eyelet-Engine Dirty Feed Supply	C2607	58
Earth Eyelet-Rear Quarter light Motor-LH	C2644	20	Eyelet-Underbonnet Fusebox Battery Feed	C2608	57
Earth Eyelet-Rear Quarter light Motor-RH	C2645	20	Eyelet-Underbonnet Fusebox Clean Feed	C2705	57
Earth Eyelet-Remote Receiver	C0707	63	Facia-Cabin Inline 1	C0047	
Earth Eyelet-RH Front Lights	C1947	33	Facia-Cabin Inline 12	C1167	
Earth Eyelet-RH Headlamp DI	C1967	35	Facia-Cabin Inline 13	C1168	
Earth Eyelet-RH Rear Lamp & Side markers	C2604	35, 37, 38, 39, 40	Facia-Cabin Inline 2	C1363	
Earth Eyelet-RH Side Repeater	C1969	35	Facia-Cabin Inline 3	C1184	
Earth Eyelet-ROPS Module	C2563	60	Facia-Cabin Inline 4	C0223	
Earth Eyelet-Rotary Coupler	C0017	71	Facia-Cabin Inline 5	C0229	
Earth Eyelet-Rr Brake Pad Wear Sensors & Mod-Aut	C2695	9, 30, 38	Facia-Cabin Inline 6	C0231	
Earth Eyelet-Screen Wash Level Sensor	C1971	73	Facia-Cabin Inline 7	C0467	
Earth Eyelet-Screen Wash Pump	C2652	50	Facia-Cabin Inline 8	C0469	
Earth Eyelet-Sounder, Vac Pump, Rear Power	C2602	1, 63, 68	Facia-Cabin Inline 9	C0765	
Earth Eyelet-Stalk Trip Sw	C0821	30	Facia-Cabin Inline MMM	C2246	
Earth Eyelet-Steering Angle Sensor	C2561	50	Forward-Cabin Inline 1	C2410	
Earth Eyelet-Switch-Battery Disconnect	C2647	57	Forward-Cabin Inline 2	C2411	
Earth Eyelet-Tonneau Lid Motor Relays	C2711	18	Forward-Cabin Inline 3	C2409	
Earth Eyelet-Tonneau Lid Switches	C2643	20	Forward-Cabin Inline 4	C2412	
Earth Eyelet-Tracker	C0553	64	Forward-Engine Inline 1	C2275	
Earth Eyelet-UBFB Relay 11 Coil	C3002	70	Forward-Engine Inline 2	C2276	
Earth Eyelet-Under Bonnet Fusebox	C1210	57	FPDM A (1-6)	C2203	41
Earth Eyelet-Wash Wipe Switch	C0554	73	FPDM B (7-12)	C2369	41, 64
Earth Eyelet-Windscreen Wiper Motor	C0809	73	Fresh/Recirc Actuator	C0419	5
ECU A (C-Cowl)	C0635		Front Position Lamp-LH	C0538	33
ECU A (E-Engine)	C0636		Front Position Lamp-RH	C0537	33
ECU A (T-Trans)	C0634		Front Side marker-LH	C0917	33
ECU B (C-Cowl)	C0638		Front Side marker-RH	C0916	33
ECU B (E-Engine)	C2464		Fuel Pump-A (LH)	C0204	41
			Fuel Pump-B (RH)	C0205	41
			Fuel Tank Connector	C0115	41
			Fuse-Stand Alone-Battery Conditioner	C0601	69
			Headlamp-HID Auto Level-LH	C0013	35
			Headlamp-HID Auto Level-LH	C0009	33
			Headlamp-HID Auto Level-RH	C0012	35
			Headlamp-HID Auto Level-RH	C0011	33
			Heated Front Screen-LH	C0247	42



Component	Connector	Circuit Page	Component	Connector	Circuit Page
Heated Front Screen-RH	C0246	42	Module-Aircon-Conn A	C0791	5
Heated Rear Window (Feed)	C0381	42	Module-Aircon-Conn B	C0792	6
Heated Rear Window (Gnd)	C0382	42	Module-Amplifier (AUD2)	C2589	45, 46
Horn	C0003	71	Module-Amplifier (AUD3)	C2796	45, 46
Ignition Coil 1	C0156	47	Module-Amplifier (MOST)	C2102	74, 75
Ignition Coil 10	C2461	47	Module-Automatic Transmission	C0932	9
Ignition Coil 11	C2462	47	Module-Centre Console (Sim)	C0947	17
Ignition Coil 12	C2463	47	Module-Centre Console (Trip Switches)	C2522	30
Ignition Coil 2	C0052	47	Module-Centre Console-Conn1 (Key A)	C0428	
Ignition Coil 3	C0276	47	Module-Centre Console-Conn2 (Midd)	C0429	
Ignition Coil 4	C1770	47	Module-Centre Console-Conn3 (Key B)	C0430	
Ignition Coil 5	C1771	47	Module-Convertible Roof1	C2802	15, 18, 19, 20, 36
Ignition Coil 6	C1772	47	Module-Convertible Roof2	C2803	18, 19, 20
Ignition Coil 7	C2087	47	Module-Cooling Fan Pack	C2471	21
Ignition Coil 8	C2088	47	Module-Cooling Fan Pack	C2470	21
Ignition Coil 9	C2460	47	Module-Driver Information	C0230	13, 14, 30, 31, 34, 55, 59, 60
Illumination-Accessory / Cigar Lighter	C0074	1	Module-HID Lighting	C1543	34
Illumination-Rear Power Outlet	C0351	1	Module-Infotainment Control	C2115	14, 17
Injector 1	C0522	48	Module-Infotainment Control (MOST)	C2105	74, 75
Injector 10	C2457	48	Module-Parking Aid 1	C0957	30, 53, 55
Injector 11	C2458	48	Module-Parking Aid 3	C1457	55
Injector 12	C2459	48	Module-Phone (Antenna)	C2537	17
Injector 2	C0523	48	Module-Phone (Main)	C2118	14, 17
Injector 3	C0524	48	Module-Phone (SIM)	C1644	17
Injector 4	C0525	48	Module-Power Steering	C0316	30, 59
Injector 5	C0526	48	Module-Remote Receiver	C0674	63
Injector 6	C0527	48	Module-ROPS	C2792	60
Injector 7	C0528	48	Module-Sounder	C0520	63
Injector 8	C0529	48	Module-Tracker	C2838	64
Injector 9	C2456	48	Module-Tyre Pressure Monitor	C1537	31
Interface-Auto Switches	C2737	8,9	MOST Phone Link	C1023	74, 75
'Keep Alive' Fuse	C1875	57	Motor-Boot Latch	C2052	1, 36
Lamp-CHMSL	C0613	39	Motor-Electronic Throttle A	C2465	72
Lamp-Convertible CHMSL	C2623	39	Motor-Electronic Throttle B	C2466	72
Lamp-Footwell-LH	C0077	49	Motor-Heater Blower	C0056	5
Lamp-Footwell-RH	C0076	49	Motor-Rear Quarter light-LH	C2592	20
M6 Cooling Fan Feed Stud	C1641	21	Motor-Rear Quarter light-RH	C2593	20
Map Lamp-LH	C0355	49	Motor-Tonneau Lid Lock-LH	C2594	18
Map Lamp-RH	C0356	49	Motor-Tonneau Lid Lock-RH	C2874	18
Media Player	C2111	17	Motor-Windscreen Wipers	C0030	73
Media Player (MOST)	C2107	74, 75	Multi Media Module (MOST)	C2104	74, 75
Microphone	C1303	46	Multi Media Module (Power)	C2113	52
Mirror-Door-Driver side	C0352	26, 28	Multi Media Module (Screen)	C2114	52
Mirror-Door-Passenger side	C0353	27, 29			
Module-ABS	C0501	13, 51, 53, 56			
Module-Airbag 1	C0256	2, 3, 15			
Module-Airbag 2	C1649	2, 3, 15, 53			

Component	Connector	Circuit Page	Component	Connector	Circuit Page
Multi Media Module Display (Power)	C2516	52	Sensor-Catalyst Monitor-Rear	C0644	43
Multi Media Module Display (Screen)	C2515	52	Sensor-Crank Position A	C0168	65
Passenger Door Module Conn 1	C0322	22, 24, 27, 29, 35, 49	Sensor-Crank Position B	C0170	66
Passenger Door Module Conn 2	C0323	15, 24, 25	Sensor-Engine Coolant Level	C0147	66
Passenger Door Module Conn 3	C0324	24	Sensor-Engine Coolant Temp	C0169	65
Passenger Door-Cabin Inline	C0733		Sensor-Evap	C0417	6
Passenger Door-Puddle Lamp	C0979	49	Sensor-F/L/ABS	C0516	51
Passenger Seat-Conn1	C2379	62	Sensor-F/R/ABS	C0517	51
Passenger Seat-Conn3	C0752	2	Sensor-Front Impact-Left	C1652	3
Passenger Seat-Conn4	C0253	2, 62, 15	Sensor-Front Impact-Right	C1653	3
Phone Link-Centre Stack	C1645		Sensor-Fuel Level	C2303	41
Phone Module (MOST)	C2103	74, 75	Sensor-Fuel Rail Temp	C2251	65
Pretensioner-Driver	C1497	2	Sensor-Fuel Tank Pressure	C0132	68
Pretensioner-Passenger	C0252	2	Sensor-Hall-Front Header Closed	C0497	
Pump-Headlamp Wash	C1342	73	Sensor-Heated Oxygen-Front	C0164	44
Pump-Screen Washer Fluid	C0828	73	Sensor-Heated Oxygen-Rear	C0908	44
Pump-Vacuum	C1977	68	Sensor-Heated Oxygen-Rear	C0642	43
REAR BUMPER-BOOT INLINE1	C1914		Sensor-Hlamp Level-FR	C1574	34
REAR BUMPER-BOOT INLINE2	C1915		Sensor-Hlamp Level-RR	C1575	34
Rear Interior Map Lamp-LH	C1111	49	Sensor-In Car Temp	C0412	6
Rear Interior Map Lamp-RH	C1112	49	Sensor-Key Reader	C0672	56, 63
Rear Lamp-LH	C0121	35, 37, 38, 39, 40	Sensor-Mass Air Flow (1-6)	C0149	67
Rear Lamp-RH	C0125	35, 37, 38, 39, 40	Sensor-Mass Air Flow (7-12)	C2370	67
Rear Side marker-LH	C0919	40	Sensor-Mass Movement	C0359	63
Rear Side marker-RH	C0918	40	Sensor-PDC-RIL	C0964	55
Regulator-Blower Speed	C0068	5	Sensor-PDC-RIR	C0965	55
Seat-Left	C2363	3	Sensor-PDC-ROL	C0963	55
Seat-Right	C2368	3	Sensor-PDC-ROR	C0966	55
Sensor Heated-Oxygen-Front	C0370		Sensor-Pedal Position A (Primary)	C1589	72
Sensor-Aircon Pressure (MID)	C1465	6	Sensor-Pedal Position B (Secondary)	C0787	72
Sensor-Aircon Pressure (HI & LO)	C1257	6	Sensor-R/L/ABS	C0502	51
Sensor-Ambient Temp	C0884	6	Sensor-R/R/ABS	C0503	51
Sensor-Barometric Pressure	C0188	68	Sensor-Screen Wash Fluid Level	C0620	73
Sensor-Brake Pad Wear (F/L)	C0050	50	Sensor-Side Impact-Left	C2345	3
Sensor-Brake Pad Wear (F/R)	C0968	50	Sensor-Side Impact-Right	C2346	3
Sensor-Brake Pad Wear (R/L)	C2578	50	Sensor-Steering Angle	C1672	13, 50, 56
Sensor-Brake Pad Wear (R/R)	C2579	50	Sensor-Sun	C0881	6
Sensor-Brake Pedal Travel	C2446	51	Sensor-Switch Buckle-Driver	C2405	2
Sensor-Brake Pressure	C2444	51	Sensor-Vehicle Speed (Automatic)	C0195	68
Sensor-Cam Position (VRS) A	C0176		Sensor-Vehicle Speed (Manual)	C1561	68
Sensor-Cam Position (VRS) B	C1463	66	Sensor-Yaw rate Acceleration	C1656	51
Sensor-Catalyst Monitor-Front	C0103	44	Side Repeater-LH	C1930	35
Sensor-Catalyst Monitor-Front	C0643	43	Side Repeater-RH	C1931	35
Sensor-Catalyst Monitor-Rear	C0676	44	Socket-Accessory/Cigar Lighter	C0089	1
			Socket-Rear Power Outlet	C1632	1
			Solenoid-Fuel Flap Release	C0690	32
			Solenoid-Glovebox Release	C2833	32
			Solenoid-Power Assisted Steering	C2571	59



Component	Connector	Circuit Page	Component	Connector	Circuit Page
Sounder-PDC Rear	C0405	55	Switchpack-Seat-Manual 3	C2801	62
Speaker-Dual-Front Centre	C0369	45	Switch-Park	C2736	8
Speaker-Dual-Front Left	C0340	45	Switch-PDC Disable	C1541	55
Speaker-Dual-Front Right	C0339	45	Switch-Rear Fog Lamps	C0064	10, 37
Speaker-Rear Left	C0310	46	Switch-Recirc	C0750	4, 11
Speaker-Rear Right	C0308	46	Switch-Reduced Guard	C2787	63
Starter Motor Terminal	C0178	58	Switch-Reverse	C0166	8
Starter-Motor	C0179	70	Switch-Reverse (Inline)	C0163	38
Stator-Steering Wheel	C0082	3	Switch-Sport	C0985	8, 12
Subwoofer-Active	C0656	46	Switch-Start Button	C2453	70
Switch Pack-Drivers Door	C0054	26, 28	Switch-Steering Column-Wiper	C0278	73
Switch -Window-Passenger Door	C0087	24	Switch-Tonneau Lid Closed1	C2573	20
Switch-Aircon Request	C1494	4, 11	Switch-Tonneau Lid Closed2	C2962	
Switch-Battery Disconnect	C1271	57, 58	Switch-Touchtronic (Paddles)	C0410	9
Switch-Battery Disconnect Terminal	C0046	57, 58	Temp Actuator	C2130	5, 6
Switch-Battery Off	C1822	57	Terminal-Jump Start	C2307	58
Switch-Bonnet	C0007	63	TMC Module	C0897	7
Switch-Boot Release	C0221	36	TMC Module	C2220	7
Switch-Boot Release (Interior)	C1681	36	TMC Module (MOST)	C0899	74, 75
Switch-Brake Boost	C2448	51	Transducer-Fuel Rail Pressure	C2467	65
Switch-Brake Fluid Level	C0026	50	Transducer-Fuel Rail Pressure	C2468	66
Switch-Brake Pedal	C0075	39	Transducer-Power Steering Pressure	C2469	65
Switch-Buckle-Passenger	C0262	2	Tuner-GPS	C1608	17
Switch-Clutch Bottom Of Travel	C0667	70	Tuner-GPS	C1609	17
Switch-Clutch Top of Travel	C1491	70	Tuner-GPS (MOST)	C2517	74, 75
Switch-Convertible Roof	C2591	18	Unit-Battery Conditioner	C2797	69
Switch-Cruise Control	C0749	71	Valve-Canister Vent	C2371	68
Switch-Direction Indicator	C0036	30, 33, 35	Valve-Electric Vapour Management	C2472	65
Switch-Drive	C2735	9	Valve-Electric Vapour Management	C2473	66
Switch-Fuel Flap Release	C0748	32	Valve-Exhaust Bypass	C1685	68
Switch-Glovebox Release	C0238	32	Window Motor-Drivers Door	C0740	23
Switch-Hazard	C0096	11, 35	Window Motor-Passenger Door	C0741	24
Switch-Heated Front Screen	C0131	10, 42			
Switch-Heated Rear Window	C0072	10, 42			
Switch-Horn (Steering Wheel)	C1908	71			
Switch-Ignition	C0028	70			
Switch-IVD	C0984	12, 50			
Switch-Manual Handbrake	C0648	39			
Switch-Master Light	C1082	10			
Switch-Master Light	C0041	10, 33			
Switch-Master Locking	C0328	25			
Switch-Neutral	C2359	9			
Switch-Oil Pressure	C0187	65			
Switchpack-Seat-Manual 1	C0773	61			
Switchpack-Seat-Manual 1	C0776	62			
Switchpack-Seat-Manual 2	C0774	61			
Switchpack-Seat-Manual 2	C2800	62			
Switchpack-Seat-Manual 3	C0775	61			

Maintenance

Fuel Tank Harness - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Fuel Tank Harness - Remove and Install	18.01.HC

Remove

1. Remove the fuel tank and cannister assembly (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).
2. Remove the nut (2) that attaches the earth connection for the harness to the fuel tank and release earth connection from the stud (Refer to Figure 1).




Figure 1

3. Disconnect the electrical connector (3) for the harness.
4. Release the two clips that attach harness to the cannister bracket (Refer to Figure 2).



Figure 2

5. Release the three "fir-tree" cable ties that attach the harness to the fuel tank and the fuel tank heatshield.
6. Remove the harness.

Install

1. Install the "fir-tree" cable ties that attaches the harness to the fuel tank and the fuel tank heatshield.
2. Attach the harness to the fuel tank with the cable ties.
3. Install the clips that attach the harness to the cannister bracket.
4. Connect the electrical connector (3) for the harness.

5. Install earth connection onto the fuel tank stud.
6. Install and tighten attachment nut for the earth connection.
7. Install the fuel tank and cannister assembly (Refer to 'Fuel Tank - Remove and Install', page 10-1-11).



Circuit Diagrams

Sheet No.	Title	Sheet No.	Title	Wire Colours
Fusebox Diagrams				
UB 1 - 3	Underbonnet Fusebox	Sheet 34	Exterior Lighting (HID Headlamp Auto Levelling)	B Black
CEM 1 - 7	Central Electronic Module	Sheet 35	Exterior Lighting (Direction Indicators and Side Repeaters)	G Green
B 1 - 2	Boot Fusebox	Sheet 36	Exterior Lighting (License Plate Lamps and Boot Release)	K Pink
Circuit Diagrams				
Sheet 1	Accessory Socket, Cigar Lighter and Boot Latch	Sheet 37	Exterior Lighting (Rear Fog Lamps)	N Brown
Sheet 2	Active Restraint System	Sheet 38	Exterior Lighting (Reverse Lamps - Manual Transmission)	O Orange
Sheet 3	Active Restraint System	Sheet 39	Exterior Lighting (Stop Lamps and High Mounted Stop Lamp)	P Purple
Sheet 4	Air Conditioning	Sheet 40	Exterior Lighting (Tail Lamps and Side Markers)	R Red
Sheet 5	Air Conditioning	Sheet 41	Fuel System	S Slate (Grey)
Sheet 6	Air Conditioning	Sheet 42	Heated Screens (Heated Window and Rear Window)	U Blue
Sheet 7	AM_FM Receiver Modul and Antenna Amplifier	Sheet 43	Oxygen Sensors and Catalyst Monitor Sensors Bank A	W White
Sheet 8	Automatic transmission	Sheet 44	Oxygen Sensors and Catalyst Monitor Sensors Bank B	Y Yellow
Sheet 9	Automatic Transmission	Sheet 45	In-Car Entertainment	SCR Screen
Sheet 10	Background Illumination	Sheet 46	In-Car Entertainment	FO Fibre Optic
Sheet 11	Background Illumination	Sheet 47	Ignition Coils	MAP Twisted Wire
Sheet 12	Background Illumination	Sheet 48	Fuel Injectors	MAB Screened Wire
Sheet 13	CAN Bus 2 (High Speed Volcano)	Sheet 49	Interior Illumination (plus Door Puddle Lamps)	
Sheet 14	CAN Bus (Low Speed Volcano)	Sheet 50	Interactive Vehicle Dynamics	
Sheet 15	CAN Bus 1 (Powertrain)	Sheet 51	Interactive Vehicle Dynamics	
Sheet 16	CCM, ICM, MP, GPS, Phone	Sheet 52	Multi-Media Module and Display	
Sheet 17	Convertible Roof	Sheet 53	OBD II Connectors (Body B)	
Sheet 18	Convertible Roof	Sheet 54	OBD II Connectors (Powertrain A)	
Sheet 19	Convertible Roof	Sheet 55	Parking Distance Aid	
Sheet 20	Cooling Fans	Sheet 56	Power and Grounds-EEC (Wake-Up and Grounds - CEM)	AU Auto Transmission
Sheet 21	Doors (Driver and Passenger Door Locks)	Sheet 57	Power Distribution (Clean Feeds)	BT Boot
Sheet 22	Doors (Electric Window - Drivers Door)	Sheet 58	Power Distribution (Dirty Feeds)	BTLLD Boot Lid
Sheet 23	Doors (Electric Window - Passengers Door)	Sheet 59	Power Steering	BUMP Bumper
Sheet 24	Doors (Master Locking Switch)	Sheet 60	Roll-Over Protection (Convertible Only)	CA Cabin
Sheet 25	Doors (Power Mirror - Drivers Door)	Sheet 61	Seat (Driver - Manual)	CENST Centre Stack
Sheet 26	Doors (Power Mirror - Passengers Door)	Sheet 62	Seat (Passenger - Manual)	CON Convertible Roof
Sheet 27	Doors (Power Fold Mirror - Passengers Door)	Sheet 63	Security System	DRDR Drivers Door
Sheet 28	Doors (Power Fold Mirror - Drivers Door)	Sheet 64	Security System	EN Engine
Sheet 29	Driver Information Module	Sheet 65	Sensors (Engine Bay)	FA Facia
Sheet 30	Driver Information Module	Sheet 66	Sensors (Engine Bay)	FOR Forward
Sheet 31	Electric Glovebox (& Fuel Flap Release)	Sheet 67	Sensors Rearward	PADR Passenger Door
Sheet 32	Exterior Lighting (Headlamps and Front Side Markers)	Sheet 68	Starting and Charging (Charge and Battery Monitor)	
Sheet 33		Sheet 69	Starting and Charging (Starting)	
		Sheet 70	Steering Wheel Switches (Horns and Cruise Control)	
		Sheet 71	Throttles and Throttle Pedal	
		Sheet 72	Wash/Wipe System	
		Sheet 73	MOST Network	
		Sheet 74	MOST Network	
		Sheet 75	MOST Network	





CIRCUIT TITLE
Circuit Index

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
00



Refer To Vehicle Circuit Diagrams C2608-1

FUSEBOX CONNECTOR	CIRCUIT C NUMBER	HARNESS
1	C0570	Forward
2	C0571	Forward
3	C0572	Forward
4	C0573	Forward
5	C0574	Forward
6	C0575	Forward
7	C0576	Engine
8	C0577	Engine
9	C0578	Engine
10	C0579	Forward

UNUSED FUSES

FUSE No.	RATING (A)	SUPPLY
22	5	IGNITION
25	5	IGNITION
27	25	PERM. BATTERY
29	25	PERM. BATTERY




CIRCUIT TITLE
Underbonnet Fusebox
1 of 3

MODEL
Coupe

APPLICABILITY
From Chassis 00001

FUSEBOX SHEET
UB 1




VIEW THROUGH LID

FUSEBOX CONNECTOR	CIRCUIT C NUMBER	HARNESS
1	C0570	Forward
2	C0571	Forward
3	C0572	Forward
4	C0573	Forward
5	C0574	Forward
6	C0575	Forward
7	C0576	Engine
8	C0577	Engine
9	C0578	Engine
10	C0579	Forward

FUSE No.	RATING (A)	SUPPLY
22	5	IGNITION
25	5	IGNITION
27	25	PERM. BATTERY
29	25	PERM. BATTERY

UNUSED FUSES




CIRCUIT TITLE
Underbonnet Fusebox
2 of 3

MODEL
Coupe

APPLICABILITY
From Chassis 00001


FUSEBOX SHEET
UB 2



VIEW THROUGH LID

UNUSED FUSES

FUSE No.	RATING (A)	SUPPLY
22	5	IGNITION
25	5	IGNITION
27	25	PERM. BATTERY
29	25	PERM. BATTERY



FUSEBOX CONNECTOR	CIRCUIT C. NUMBER	HARNESS
1	C0570	Forward
2	C0571	Forward
3	C0572	Forward
4	C0573	Forward
5	C0574	Forward
6	C0575	Forward
7	C0576	Engine
8	C0577	Engine
9	C0578	Engine
10	C0579	Forward




CIRCUIT TITLE
Underbonnet Fusebox
3 of 3

MODEL
Coupe


APPLICABILITY
From Chassis 00001

FUSEBOX SHEET
UB 3

Central Electronic Module



CIRCUIT TITLE	MODEL	APPLICABILITY	FUSEBOX SHEET
 Central Electronic Module 1 of 7	Coupe	From Chassis 00001	CEM 1



CIRCUIT TITLE
Central Electronic Module
2 of 7

MODEL
Coupe

APPLICABILITY
From Chassis 00001

FUSEBOX SHEET
CEM 2

A	<p>Central Electronic Module</p>								
B									
C									
D									
E									
F									




CIRCUIT TITLE
Central Electronic Module
3 of 7

MODEL
Coupe

APPLICABILITY
From Chassis 00001

FUSEBOX SHEET
CEM 3




DB9


CIRCUIT TITLE
Central Electronic Module
4 of 7

MODEL
Coupe

APPLICABILITY
From Chassis 00001


FUSEBOX SHEET
CEM 4





SOURCE No. 1 2 3 4 5 6 7 8

FUSEBOX SHEET	APPLICABILITY	MODEL	CIRCUIT TITLE	CEM 6
	From Chassis 00001	Coupe	Central Electronic Module 6 of 7	




CIRCUIT TITLE
Central Electronic Module
7 of 7

MODEL
Coupe

APPLICABILITY
From Chassis 00001

FUSEBOX SHEET
CEM 7



UNUSED FUSES

FUSE No.	RATING (A)	SUPPLY
19	5	IGNITION
6	20	IGNITION
4	30	IGNITION
5	30	BATTERY

FUSEBOX CONNECTOR	CONNECTOR COLOUR	CIRCUIT C NUMBER
A	WHITE	C2010
B	BLACK	C2011
C	GREEN	C2012
D	BLUE	C2013




CIRCUIT TITLE
Boot Fusebox
1 of 2

MODEL
Coupe

APPLICABILITY
From Chassis 00001

FUSEBOX SHEET
Boot 1



FUSE No.	RATING (A)	SUPPLY
19	5	IGNITION
6	20	IGNITION
4	30	IGNITION
5	30	BATTERY

FUSEBOX CONNECTOR	CONNECTOR COLOUR	CIRCUIT C NUMBER
A	WHITE	C2010
B	BLACK	C2011
C	GREEN	C2012
D	BLUE	C2013




CIRCUIT TITLE
Boot Fusebox
2 of 2

MODEL
Coupe

APPLICABILITY
From Chassis 00001

FUSEBOX SHEET
Boot 2



Symbols	
	Bus
	Bar
	FET
	CAN
	Train




CIRCUIT TITLE
Accessory Sockets,
Cigar Lighter, Boot Latch

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
01




CIRCUIT TITLE
Active Restraint System

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
02




CIRCUIT TITLE
Active Restraint System

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
03



Symbols

- Bus
- Bar
- FET
- CAN
- Tran


CIRCUIT SHEET
04

APPLICABILITY
From Chassis 00001

MODEL
Coupe

CIRCUIT TITLE
Air Conditioning





Symbols

	Bus
	Bar
	FET
	CAN
	Tran




CIRCUIT TITLE
Air Conditioning

MODEL
Coupe

APPLICABILITY
From Chassis 00001


CIRCUIT SHEET
05



Symbols	
	Bus
	Bar
	FET
	CAN
	Tran




View of Bootlid Antenna




AM/FM1

FM2 with optional TMC

Central Electronic Module



Antenna Amplifier 2 (AM/FM2 & TMC)



Antenna Wire

Antenna Wire

Antenna Wire

Antenna Wire

Antenna Wire

Antenna Wire

Antenna Wire

Antenna Wire

Antenna Wire

Antenna Wire

Antenna Wire

Antenna Wire

Symbols
Bus
Bar
FET
CAN
Tran

DB9

CIRCUIT TITLE
AM_FM Receiver Module
and Antenna Amplifier

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
07

Interface-Auto Switches

- REV SIG RTN B,0.5
- REV SW2 (I) C2737-6 OW,0.5
- REV SW1 (I) C2737-5 OB,0.5
- REV TTX (O) C2737-7 WP,0.5


Primary PCM

- REV TT (O) C0634-28G OY,0.5 C2244-21 OY,0.5 C0467-21 OY,0.5
- SPL1-DIMOUT/CA P8,10,71 ORIGIN P10
- SPORT SW (I) C0634-33G G,0.5 C2243-1 G,0.5 C1322-20 G,0.5
- SPORT TT (O) C0634-18G UG,0.5 C2243-2 UG,0.5 C1322-21 UG,0.5
- PARK TT (O) C0634-45G UG,0.5 C2244-22 UG,0.5 C0467-22 UG,0.5
- PRND1 (I) C0634-4G UR,0.5 C2244-15 UR,0.5
- PRND2 (I) C0634-29G CB,0.5 C2245-17 UG,0.5


Interface-Auto Switches

- PRND2 (O) C2737-22 UG,0.5 C1184-19 UG,0.5
- PRND1 (O) C2737-21 UR,0.5 C0223-12 UR,0.5
- VIGN. (I) C2737-17 WP,0.5
- 2 STAGE ILL. (I) C2737-18 Y,0.5
- BVREF (I) C2737-19 YR,0.75
- SIGRTN (I) C2737-20 BP,0.5 C0231-13 BP,0.5
- PARK TTX (O) C2737-11 WP,0.5
- PARK SW2 (I) C2737-10 RW,0.5
- PARK SW1 (I) C2737-9 RB,0.5
- PARK SIG RTN (I) C2737-12 B,0.5


Switch-Reverse



Switch-Sport




Switch-Park



Symbols

- Bus
- Bar
- FET
- CAN
- Tran






Symbols

- Bus Bar
- FET
- CAN
- Tran

DB 9	CIRCUIT TITLE Automatic Transmission	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 09
-------------	--	-----------------------	--	-----------------------------------




CIRCUIT TITLE
Background Illumination

MODEL
Coupe


APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
10



Symbol	Bus	Bar	FET	CAN	Tran

DB9	CIRCUIT TITLE Background Illumination	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 11
------------	---	-----------------------	--	-----------------------------------



DB9



CIRCUIT TITLE
Background Illumination

MODEL
Coupe



APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
12

CAN Link - Manual Transmission




Module-Driver Instrument




CAN Link - Automatic Transmission


Module-Automatic Transmission




Central Electronic Module



Body Diagnostics(B)



See P53 for OBDII - Body Connector



CIRCUIT TITLE
CAN Bus 2
(High Speed Volcano)


MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
13


Central Electronic Module

OBD2 - Body (B)




See Sheet 53 for details of the OBD2 - Body Connector


Centre Console Module





Module-Infotainment Control



Module-Phone



Module-Driver Instrument




CIRCUIT TITLE
CAN Bus
(Low Speed Volcano 1)

MODEL
Coupe


APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
14



DRIVERS DOOR




Module-Airbag




Seat-Drivers





Module-Convertible Roof 1



Seat-Passenger



PASSENGER DOOR




CIRCUIT TITLE
CAN Bus
(Low Speed Volcano)

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
15


Note:
 CAN Bus 1 is used exclusively for diagnostics.
 CAN Bus 3 is used for inter-module communications.



Symbols

- Bus
- Bar
- FET
- CAN
- Tran


DB9	CIRCUIT TITLE CAN Bus 1 & 3 (Powertrain)	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 16
------------	---	-----------------------	--	-----------------------------------



Symbols

- Bus Bar
- FET
- CAN
- Tran

DB9	CIRCUIT TITLE CCM, ICM, MP, GPS and PHONE	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 17
------------	--	-----------------------	--	-----------------------------------




CIRCUIT TITLE
Convertible Roof


MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
19



DB9	CIRCUIT TITLE Convertible Roof	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 20
------------	-----------------------------------	----------------	-------------------------------------	----------------------------



Symbols	
	Bus Bar
	FET
	CAN
	Tran


CIRCUIT SHEET
21

APPLICABILITY
From Chassis 00001


MODEL
Coupe

CIRCUIT TITLE
Convertible Roof





DB9	CIRCUIT TITLE Door Driver and Passenger Locks	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 22
------------	--	-----------------------	--	-----------------------------------



Symbols	
	Bus Bar
	FET
	CAN
	Tran


CIRCUIT SHEET
23

APPLICABILITY
From Chassis 00001

MODEL
Coupe

CIRCUIT TITLE
Door
Electric Window - Drivers





Symbols	
	Bus
	Bar
	FET
	CAN
	Tran


CIRCUIT SHEET
24

APPLICABILITY
From Chassis 00001

MODEL
Coupe

CIRCUIT TITLE
Doors
Electric Window
- Passengers






DB9

CIRCUIT TITLE
 Doors
 Master Locking

MODEL
 Coupe

APPLICABILITY
 From Chassis 00001

CIRCUIT SHEET
25




DB9

CIRCUIT TITLE
 Drivers Door
 Power Mirror

MODEL
 Coupe

APPLICABILITY
 From Chassis 00001

CIRCUIT SHEET
26



Symbols

- Bus
- Bar
- FET
- CAN
- Tran


CIRCUIT SHEET
27

APPLICABILITY
From Chassis 00001


MODEL
Coupe

CIRCUIT TITLE
Passenger Door
Electric Mirror





DB9	CIRCUIT TITLE Drivers Door Power Fold Mirror	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 28
------------	---	-----------------------	--	-----------------------------------



Symbols

- Bus
- Bar
- FET
- CAN
- Tran


CIRCUIT SHEET
29

APPLICABILITY
From Chassis 00001

MODEL
Coupe

CIRCUIT TITLE
Passenger Door
Power Fold Mirror





Symbols

- Bus Bar
- FET
- CAN
- Tran

Module-Driver Information

FRONT BRAKE PADS
 REAR BRAKE PADS
 VRS OUT-Km/h
 VRS OUT-km
 TRIP ADJ SW
 READ MESSAGE SW
 TRIP FUNCTION SW
 MIL (EEC)
 ALARM LED


CIRCUIT SHEET
30

APPLICABILITY
 From Chassis 00001

MODEL
 Coupe

CIRCUIT TITLE
 Driver Information Module






Symbols

- Bus Bar
- FET
- CAN
- Tran

CIRCUIT SHEET 31	APPLICABILITY From Chassis 00001	MODEL Coupe	CIRCUIT TITLE Driver Information Module	DB9
-----------------------------------	--	-----------------------	---	------------




CIRCUIT SHEET
32

APPLICABILITY
From Chassis 00001

MODEL
Coupe

CIRCUIT TITLE
Glovebox and Fuel Flap Release

DB9



1 2 3 4 5 6 7 8

A B C D E F




CIRCUIT TITLE
Exterior Lighting - Front Headlamps and Markers

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
33




CIRCUIT TITLE
Exterior Lighting - Front Headlamp Levelling

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
34




CIRCUIT TITLE
Exterior Lighting
Direction Indicators

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
35



DB9

CIRCUIT TITLE
Exterior Lighting
Rear Fog Lights

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
37

A


B

C

D

E


F





Rear Lamp-RH



Rear Lamp-LH



Switch-Reverse




DB9

CIRCUIT TITLE
Exterior Lighting
Reversing Lamps


MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
38



DB9	CIRCUIT TITLE Exterior Lighting Brake Lights	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 39
------------	---	-----------------------	--	-----------------------------------



SOURCE No.

1 2 3 4 5 6 7 8

A B C D E F




CIRCUIT TITLE
Exterior Lighting
Tail Lamps


MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
40




DB9	CIRCUIT TITLE Fuel System	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 41
------------	-------------------------------------	-----------------------	--	-----------------------------------



Symbols	
	Bus Bar
	FET
	CAN
	Tran

CIRCUIT SHEET	APPLICABILITY	MODEL	CIRCUIT TITLE
42	From Chassis 00001	Coupe	Heated Screens






DB9

CIRCUIT TITLE
 Primary PCM
 Heated Oxygen Sensors,
 Catalyst Monitor Sensors

MODEL
 Coupe

APPLICABILITY
 From Chassis 00001

CIRCUIT SHEET
43



SOURCE No.

8

7

6

5

4

3

2

1

A

B


C

D


E

F

Secondary PCM



Secondary PCM



Symbols

- Bus Bar
- FET
- CAN
- Tran




CIRCUIT TITLE
 Secondary PCM
 Heated Oxygen Sensors,
 Catalyst Monitor Sensors

MODEL
 Coupe

APPLICABILITY
 From Chassis 00001

CIRCUIT SHEET
44



SOURCE No. 1 2 3 4 5 6 7 8




CIRCUIT TITLE
In-Car Entertainment
Linn Amplifier

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
45



Symbols	
	Bus
	Bar
	FET
	CAN
	Tran




CIRCUIT TITLE
In-Car Entertainment

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
46




CIRCUIT TITLE
Ignition Coils

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
47




CIRCUIT TITLE
Fuel Injectors

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
48




CIRCUIT TITLE
Interior Illumination

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
49



Symbols	
	Bus Bar
	FET
	CAN
	Tran




CIRCUIT TITLE
Interactive
Vehicle Dynamics

MODEL
Coupe

APPLICABILITY
From Chassis 00001


CIRCUIT SHEET
50




Symbols

- Bus Bar
- FET
- CAN
- Tran

DB9	CIRCUIT TITLE Interactive Vehicle Dynamics	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 51



CIRCUIT SHEET 52	APPLICABILITY From Chassis 00001	MODEL Coupe	CIRCUIT TITLE Multi-Media Module	DB9
-----------------------------------	--	-----------------------	--	------------



DB9

CIRCUIT TITLE
OBD II Body Connector

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
53

A

B


C

D


E

F

Central Electronic Module



OBD2-Powertrain (A)



See P16 for CAN bus detail

Symbols

- Bus
- Bar
- FET
- CAN
- Tran




CIRCUIT TITLE
OBD II Powertrain Connector

MODEL
Coupe

APPLICABILITY
From Chassis 00001


CIRCUIT SHEET
54



Symbols

- Bus
- Bar
- FET
- CAN
- Tran

DB9	CIRCUIT TITLE Parking Distance Aid	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 55
------------	--	-----------------------	--	-----------------------------------



SOURCE No. 1 2 3 4 5 6 7 8




CIRCUIT TITLE
Power & Grounds CEM

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
56




CIRCUIT TITLE
Power Distribution
Clean Feeds

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
57



1

2

3

4

5

6

7

8

A

B

C

D

E

F


DB9


CIRCUIT TITLE
Power Distribution
(Dirty Feeds)

MODEL
Coupe

APPLICABILITY
From Chassis 00001


CIRCUIT SHEET
58





Symbols	
	Bus
	Bar
	FET
	CAN
	Tran

DB9	CIRCUIT TITLE Roll Over Protection	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 60
------------	--	-----------------------	--	-----------------------------------




CIRCUIT TITLE
 Seat
 (Driver's Manual)

MODEL
 Coupe

APPLICABILITY
 From Chassis 00001

CIRCUIT SHEET
61




CIRCUIT TITLE
Seat
(Passenger's Manual)

MODEL
Coupé


APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
62



Symbols	
	Bus Bar
	FET
	CAN
	Tran

DB9	CIRCUIT TITLE Security System	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 63
------------	---	-----------------------	--	-----------------------------------



Symbols	
	Bus
	Bar
	FET
	CAN
	Tran

CIRCUIT SHEET
64


APPLICABILITY
 From Chassis 00001

MODEL
 Coupe


CIRCUIT TITLE
 Security System




Sensor-Crank Position



Sensor-Cam Position (VRS)




Sensor-Engine Coolant Temp




Sensor-Fuel Rail Temp




Transducer-Fuel Rail Pressure




Underbonnet Fusebox



Central Electronic Module



Transducer-Power Steering Pressure



Valve-Electric Vapour Management



Switch-Oil Pressure



Symbols

- Bus Bar
- FET
- CAN
- Tran




CIRCUIT TITLE
Sensors
(Engine Bay)

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
65




DB9

CIRCUIT TITLE
Sensors
(Engine Bay)

MODEL
Coupe

APPLICABILITY
From Chassis 00001




CIRCUIT SHEET
66



Symbols

- Bus Bar
- FET
- CAN
- Tran

DB9	CIRCUIT TITLE Sensors (Engine Bay)	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 67
------------	---	-----------------------	--	-----------------------------------




CIRCUIT TITLE
Sensors (Rear)

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
68





CIRCUIT TITLE
Starting and Charging


MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
70




Underbonnet Fusebox



See Power Distribution

Central Electronic Module



YB,1.0 C0003-1
 B,1.0 C0003-2

Earth-Horn

C0018-1

C0017-1

C0082-3

C0082-4

C0210-1


C0210-2

C0210-3

C0210-6

C0210-4


Primary PCM




Rotary Coupler (Steering Wheel)



Switch-Horn (Steer Wheel)



Switch-Cruise Control (Steer Column)




CIRCUIT TITLE
Steering Wheel Switches

MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
71

SOURCE No.	1	2	3	4	5	6	7	8																																																																																																																																																												
A	<p style="text-align: center;">Sensor-Pedal Position A (Primary)</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">APP2 RTN</td> <td style="width: 15%;">C1589-3</td> <td style="width: 15%;">BG,0.5</td> <td style="width: 15%;">C2243-9</td> <td style="width: 15%;">BG,0.5</td> <td style="width: 15%;">C0635-18G</td> <td style="width: 15%;">APP2 RTN</td> </tr> <tr> <td>APP2 BVREF</td> <td>C1589-7</td> <td>UW,0.5</td> <td>C2243-10</td> <td>UW,0.5</td> <td>C0635-16G</td> <td>APP2 BVREF</td> </tr> <tr> <td>APP2</td> <td>C1589-6</td> <td>SW,0.5</td> <td>C2243-11</td> <td>SW,0.5</td> <td>C0635-17G</td> <td>APP2 (I)</td> </tr> <tr> <td>APP1 RTN</td> <td>C1589-5</td> <td>B,0.5</td> <td>C2243-12</td> <td>B,0.5</td> <td>C0635-6G</td> <td>APP1 RTN</td> </tr> <tr> <td>APP1 BVREF</td> <td>C1589-1</td> <td>OS,0.5</td> <td>C2243-13</td> <td>OS,0.5</td> <td>C0635-4G</td> <td>APP1 BVREF</td> </tr> <tr> <td>APP1</td> <td>C1589-2</td> <td>SB,0.5</td> <td>C2243-14</td> <td>SB,0.5</td> <td>C0635-5G</td> <td>APP1 (I)</td> </tr> </table> <p style="text-align: center;">Sensor-Pedal Position B (Secondary)</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">APP2 RTN</td> <td style="width: 15%;">C0787-3</td> <td style="width: 15%;">BG,0.5</td> <td style="width: 15%;">C2243-3</td> <td style="width: 15%;">BG,0.5</td> <td style="width: 15%;">C0638-18G</td> <td style="width: 15%;">APP2 RTN</td> </tr> <tr> <td>APP2 BVREF</td> <td>C0787-7</td> <td>UW,0.5</td> <td>C2243-4</td> <td>UW,0.5</td> <td>C0638-16G</td> <td>APP2 BVREF</td> </tr> <tr> <td>APP2</td> <td>C0787-6</td> <td>SW,0.5</td> <td>C2243-5</td> <td>SW,0.5</td> <td>C0638-17G</td> <td>APP2 (I)</td> </tr> <tr> <td>APP1 RTN</td> <td>C0787-5</td> <td>B,0.5</td> <td>C2243-6</td> <td>B,0.5</td> <td>C0638-6G</td> <td>APP1 RTN</td> </tr> <tr> <td>APP1 BVREF</td> <td>C0787-1</td> <td>OS,0.5</td> <td>C2243-7</td> <td>OS,0.5</td> <td>C0638-4G</td> <td>APP1 BVREF</td> </tr> <tr> <td>APP1</td> <td>C0787-2</td> <td>SB,0.5</td> <td>C2243-8</td> <td>SB,0.5</td> <td>C0638-5G</td> <td>APP1 (I)</td> </tr> </table> <p style="text-align: center;">Motor-Electronic Throttle B</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">TPRTN</td> <td style="width: 15%;">C2466-2</td> <td style="width: 15%;">G</td> <td style="width: 15%;">OR,0.5</td> <td style="width: 15%;">C2464-7G</td> <td style="width: 15%;">TPRTN</td> </tr> <tr> <td>TPBVREF</td> <td>C2466-3</td> <td>G</td> <td>OW,0.5</td> <td>C2464-18G</td> <td>TPBVREF</td> </tr> <tr> <td>TP1-NS</td> <td>C2466-5</td> <td>G</td> <td>OU,0.5</td> <td>C2464-19G</td> <td>TP1-NS (I)</td> </tr> <tr> <td>TP2-PS</td> <td>C2466-6</td> <td>G</td> <td>OG,0.5</td> <td>C2464-29G</td> <td>TP2-PS (I)</td> </tr> <tr> <td>TACM-</td> <td>C2466-1</td> <td>G</td> <td>OY,05</td> <td>C2464-48</td> <td>TACM- (O)</td> </tr> <tr> <td>TACM+</td> <td>C2466-4</td> <td>G</td> <td>OS,05</td> <td>C2464-47</td> <td>TACM+ (O)</td> </tr> </table> <p style="text-align: center;">Motor-Electronic Throttle A</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%;">TPRTN</td> <td style="width: 15%;">C2465-2</td> <td style="width: 15%;">G</td> <td style="width: 15%;">OR,0.5</td> <td style="width: 15%;">C0636-7G</td> <td style="width: 15%;">TPRTN</td> </tr> <tr> <td>TPBVREF</td> <td>C2465-3</td> <td>G</td> <td>OW,0.5</td> <td>C0636-18G</td> <td>TPBVREF</td> </tr> <tr> <td>TP1-NS</td> <td>C2465-5</td> <td>G</td> <td>OU,0.5</td> <td>C0636-19G</td> <td>TP1-NS (I)</td> </tr> <tr> <td>TP2-PS</td> <td>C2465-6</td> <td>G</td> <td>OG,0.5</td> <td>C0636-29G</td> <td>TP2-PS (I)</td> </tr> <tr> <td>TACM-</td> <td>C2465-1</td> <td>G</td> <td>OY,05</td> <td>C0636-48</td> <td>TACM- (O)</td> </tr> <tr> <td>TACM+</td> <td>C2465-4</td> <td>G</td> <td>OS,05</td> <td>C0636-47</td> <td>TACM+ (O)</td> </tr> </table>								APP2 RTN	C1589-3	BG,0.5	C2243-9	BG,0.5	C0635-18G	APP2 RTN	APP2 BVREF	C1589-7	UW,0.5	C2243-10	UW,0.5	C0635-16G	APP2 BVREF	APP2	C1589-6	SW,0.5	C2243-11	SW,0.5	C0635-17G	APP2 (I)	APP1 RTN	C1589-5	B,0.5	C2243-12	B,0.5	C0635-6G	APP1 RTN	APP1 BVREF	C1589-1	OS,0.5	C2243-13	OS,0.5	C0635-4G	APP1 BVREF	APP1	C1589-2	SB,0.5	C2243-14	SB,0.5	C0635-5G	APP1 (I)	APP2 RTN	C0787-3	BG,0.5	C2243-3	BG,0.5	C0638-18G	APP2 RTN	APP2 BVREF	C0787-7	UW,0.5	C2243-4	UW,0.5	C0638-16G	APP2 BVREF	APP2	C0787-6	SW,0.5	C2243-5	SW,0.5	C0638-17G	APP2 (I)	APP1 RTN	C0787-5	B,0.5	C2243-6	B,0.5	C0638-6G	APP1 RTN	APP1 BVREF	C0787-1	OS,0.5	C2243-7	OS,0.5	C0638-4G	APP1 BVREF	APP1	C0787-2	SB,0.5	C2243-8	SB,0.5	C0638-5G	APP1 (I)	TPRTN	C2466-2	G	OR,0.5	C2464-7G	TPRTN	TPBVREF	C2466-3	G	OW,0.5	C2464-18G	TPBVREF	TP1-NS	C2466-5	G	OU,0.5	C2464-19G	TP1-NS (I)	TP2-PS	C2466-6	G	OG,0.5	C2464-29G	TP2-PS (I)	TACM-	C2466-1	G	OY,05	C2464-48	TACM- (O)	TACM+	C2466-4	G	OS,05	C2464-47	TACM+ (O)	TPRTN	C2465-2	G	OR,0.5	C0636-7G	TPRTN	TPBVREF	C2465-3	G	OW,0.5	C0636-18G	TPBVREF	TP1-NS	C2465-5	G	OU,0.5	C0636-19G	TP1-NS (I)	TP2-PS	C2465-6	G	OG,0.5	C0636-29G	TP2-PS (I)	TACM-	C2465-1	G	OY,05	C0636-48	TACM- (O)	TACM+	C2465-4	G	OS,05	C0636-47	TACM+ (O)
APP2 RTN	C1589-3	BG,0.5	C2243-9	BG,0.5	C0635-18G	APP2 RTN																																																																																																																																																														
APP2 BVREF	C1589-7	UW,0.5	C2243-10	UW,0.5	C0635-16G	APP2 BVREF																																																																																																																																																														
APP2	C1589-6	SW,0.5	C2243-11	SW,0.5	C0635-17G	APP2 (I)																																																																																																																																																														
APP1 RTN	C1589-5	B,0.5	C2243-12	B,0.5	C0635-6G	APP1 RTN																																																																																																																																																														
APP1 BVREF	C1589-1	OS,0.5	C2243-13	OS,0.5	C0635-4G	APP1 BVREF																																																																																																																																																														
APP1	C1589-2	SB,0.5	C2243-14	SB,0.5	C0635-5G	APP1 (I)																																																																																																																																																														
APP2 RTN	C0787-3	BG,0.5	C2243-3	BG,0.5	C0638-18G	APP2 RTN																																																																																																																																																														
APP2 BVREF	C0787-7	UW,0.5	C2243-4	UW,0.5	C0638-16G	APP2 BVREF																																																																																																																																																														
APP2	C0787-6	SW,0.5	C2243-5	SW,0.5	C0638-17G	APP2 (I)																																																																																																																																																														
APP1 RTN	C0787-5	B,0.5	C2243-6	B,0.5	C0638-6G	APP1 RTN																																																																																																																																																														
APP1 BVREF	C0787-1	OS,0.5	C2243-7	OS,0.5	C0638-4G	APP1 BVREF																																																																																																																																																														
APP1	C0787-2	SB,0.5	C2243-8	SB,0.5	C0638-5G	APP1 (I)																																																																																																																																																														
TPRTN	C2466-2	G	OR,0.5	C2464-7G	TPRTN																																																																																																																																																															
TPBVREF	C2466-3	G	OW,0.5	C2464-18G	TPBVREF																																																																																																																																																															
TP1-NS	C2466-5	G	OU,0.5	C2464-19G	TP1-NS (I)																																																																																																																																																															
TP2-PS	C2466-6	G	OG,0.5	C2464-29G	TP2-PS (I)																																																																																																																																																															
TACM-	C2466-1	G	OY,05	C2464-48	TACM- (O)																																																																																																																																																															
TACM+	C2466-4	G	OS,05	C2464-47	TACM+ (O)																																																																																																																																																															
TPRTN	C2465-2	G	OR,0.5	C0636-7G	TPRTN																																																																																																																																																															
TPBVREF	C2465-3	G	OW,0.5	C0636-18G	TPBVREF																																																																																																																																																															
TP1-NS	C2465-5	G	OU,0.5	C0636-19G	TP1-NS (I)																																																																																																																																																															
TP2-PS	C2465-6	G	OG,0.5	C0636-29G	TP2-PS (I)																																																																																																																																																															
TACM-	C2465-1	G	OY,05	C0636-48	TACM- (O)																																																																																																																																																															
TACM+	C2465-4	G	OS,05	C0636-47	TACM+ (O)																																																																																																																																																															
B	<div style="text-align: right; margin-bottom: 10px;">  </div>																																																																																																																																																																			
C																																																																																																																																																																				
D																																																																																																																																																																				
E																																																																																																																																																																				
F																																																																																																																																																																				

DB9


CIRCUIT TITLE
Throttles and
Throttle Pedals

MODEL
Coupe


APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
72


Underbonnet Fusebox




Centre Console Module




Switch-Steering Column-Wiper




Central Electronic Module



Motor-Windscreen Wipers



Pump-Headlamp Wash



Pump Washer Fluid



Sensor Screen Wash Fluid Level



Symbols

- Bus Bar
- FET
- CAN
- Tran




CIRCUIT TITLE
Wash Wipe System

MODEL
Coupe

APPLICABILITY
From Chassis 00001


CIRCUIT SHEET
73



Symbols

- Bus
- Bar
- FET
- CAN
- Tran

DB9	CIRCUIT TITLE MOST Network (Coupe)	MODEL Coupe	APPLICABILITY From Chassis 00001	CIRCUIT SHEET 74
------------	---	-----------------------	--	-----------------------------------



CIRCUIT TITLE
MOST Network
(Convertible)


MODEL
Coupe

APPLICABILITY
From Chassis 00001

CIRCUIT SHEET
75

ASTON MARTIN CIRCUIT DIAGRAM

CONFIDENTIAL



DRAWN BY	A.PEARSON	SIGNATURE	A.PEARSON	DATE	29-03-04	SYSTEM	SPANISH OAK PRIMARY	PROJECT	AM803	BUILD	JOB1	CSPC CODE	XX.XX.XX
CHECKED BY		SIGNATURE		DATE		SUB SYSTEM	ECU A	DRAWING No	V1.05	No OF SHEETS	2	ISSUE LEVEL	A
APPROVED BY		SIGNATURE		DATE		VARIANT	RHD/LHD	SYSTEM OWNER	STEVE ARMITSTEAD	SHEET No	2	DATE	04-Feb-04

ASTON MARTIN CIRCUIT DIAGRAM

C ECU_B (E--Engine)

- (C07) CYLINDER(0) C2464-1 PAGE 47
- INJECTOR(1)(0) C2464-2 PAGE 48
- INJECTOR(6)(0) C2464-3 PAGE 48
- INJECTOR(4)(0) C2464-4 PAGE 48
- INJECTOR(3)(0) C2464-5 PAGE 48
- THROTTLE POT RIN C2464-7 PAGE 72
- INJECTOR(5)(0) C2464-8 PAGE 48
- INJECTOR(2)(0) C2464-9 PAGE 48
- INJECTOR(7)(0) C2464-10 PAGE 48
- INJECTOR(8)(0) C2464-11 PAGE 48
- (C011) CYLINDER(0) C2464-12 PAGE 47
- INLET AIR TEMP(0) C2464-13 PAGE 67
- CAM/CRANK RIN C2464-15 PAGE 66
- THROTTLE POT REF VOL C2464-18 PAGE 72
- TP1-NS(1) C2464-19 PAGE 72
- (C09) CYLINDER(0) C2464-24 PAGE 47
- CID(1)(0) C2464-25 PAGE 66
- TP2-PS(1) C2464-29 PAGE 72
- HECO1(1)(0) C2464-30 PAGE 44
- HECO2(1)(0) C2464-31 PAGE 44
- CRANK POS(1)(0) C2464-34 PAGE 66
- (C012) CYLINDER(0) C2464-35 PAGE 47
- FUEL TANK PRESS TRAN C2464-37 PAGE 66
- (C08) CYLINDER(0) C2464-38 PAGE 47
- (C010) CYLINDER(0) C2464-39 PAGE 47
- REF VOLT A C2464-40 PAGE 66
- SIGNAL RIN A C2464-41 PAGE 44,66,67
- CRANK POS(1) C2464-45 PAGE 72
- THROTTLE MTR-(0) C2464-47 PAGE 72
- THROTTLE MTR-(0) C2464-48 PAGE 72
- HRI1(1)(0) C2464-49 PAGE 44
- HRI2(1)(0) C2464-50 PAGE 44


VIEW LOOKING INTO MODULE CONNECTORS



IMPORTANT--CHECK KEYWAY BELOW TO ENSURE CORRECT CONNECTOR

B




- ECU_B (C--Cowl)
- APP1 REF VOLT C0638-4 PAGE 72
- APP1(1) C0638-5 PAGE 72
- APP1 RIN C0638-6 PAGE 72
- BRAKE PEDAL SWITCH(0) C0638-7 PAGE 39
- BRAKE ON/OFF SWITCH(0) C0638-8 PAGE 39
- CASE GROUND C0638-10 PAGE 56
- CE1+ C0638-11 PAGE 16
- MOTOR FUEL PUMP(0) C0638-12 PAGE 41
- APP2 REF VOLT C0638-16 PAGE 72
- APP2(1) C0638-17 PAGE 72
- APP2 RIN C0638-18 PAGE 72
- RESTRAINT DEPLOY IN(0) C0638-20 PAGE 2
- FUEL PUMP MONITOR(0) C0638-21 PAGE 41
- CE1- C0638-23 PAGE 16
- POWERHOLD(0) C0638-24 PAGE 56
- VEHICLE SPEED SENSOR-(1) C0638-32 PAGE 68
- VEHICLE SPEED SENSOR-(1) C0638-33 PAGE 68
- EMV(0) C0638-34 PAGE 66
- POWER C0638-35 PAGE 56
- POWER C0638-36 PAGE 56
- FEFS C0638-44 PAGE 16
- KEEP ALIVE POWER C0638-45 PAGE 56
- POWER GROUND C0638-47 PAGE 56
- POWER GROUND C0638-48 PAGE 56
- POWER GROUND C0638-49 PAGE 56
- IGNSNS(1) C0638-50 PAGE 56



SP, OAK 'A' IS ALWAYS LEFT
SP, OAK 'B' IS ALWAYS RIGHT

A ECU_B (I--Trans)

- ENG COOL LEVEL(0) C0637-4 PAGE 66
- PR/SEC SWITCH(0) C0637-6 PAGE 44
- MF-(1) C0637-9 PAGE 67
- MF-(1) C0637-10 PAGE 67
- CEB+ C0637-14 PAGE 13
- HECO1(1) C0637-24 PAGE 44
- HECO2(1) C0637-25 PAGE 44
- CE2- C0637-26 PAGE 13
- CEB+ C0637-30 PAGE 16
- CEB- C0637-31 PAGE 16
- AUTOM(1) C0637-38 PAGE 69
- SIGNAL RIN C C0637-41 PAGE 44
- HRI1(1) C0637-47 PAGE 44
- HRI2(1) C0637-48 PAGE 44



- HS CAN
- LS CAN
- BUSBAR
- FET
- CAN
- TRAN

VIEWED THROUGH WIRE INSERTION SIDE OF CONNECTORS

DRAWN BY	A. PEARSON	SIGNATURE	A. PEARSON	DATE	29-03-04	SYSTEM	SPANISH OAK SECONDARY	PROJECT	AM803	BUILD	JOB1	CPC CODE	XX.XX.XX	PAGE
CHECKED BY		SIGNATURE		DATE		SUB SYSTEM	ECU B	DRAWING No.	V1.05	ISSUE LEVEL	A	ISSUE LEVEL	A	
APPROVED BY		SIGNATURE		DATE		VARIANT	RHD/LHD	SHEET No.	1	No OF SHEETS	2	DATE	04-Feb-04	

Electric Distribution/Electronic Control (18.00)

Vehicle Control System (18.08)

Module Configuration

Principles of Operation

All configurable modules are packaged in a kit which contains a warning label and a multi-language sheet re-emphasizing the requirements to configure replacement modules.

Replacement configurable modules must be configured using AMDS.

Market Configuration

This data is required so that modules can interact with the vehicle correctly. By using AMDS this data will be retrieved in the following ways:

- Indirectly from a mirrored image of the old modules data stored in an 'As is' database on DCS
- Indirectly from information stored in AMDS

Configuration

The complexity of the electronics involved with module configuration and the multiplex communication network which they are connected to preclude the use of general workshop electrical test equipment.

AMDS contains detailed instructions on module configuration.

Install the new module(s) and download the 'As is' data using the vehicle configuration software on AMDS.

AMDS will permanently retain the configuration information

Customer Configuration

There are certain modules / functions that the customer may or may not want reconfigured or enabled. Some of these preferences are accessed through the 'in-car' menus, available on the infotainment centre. Others are set in the vehicle configuration or specific software files, these items can be toggled or configured by AMDS.

The 'As is' database (AML) holds customer original preferences. When a new module is installed to a previously upgraded or reconfigured vehicle these preferences can be retrieved and re-applied as required through AMDS

Data Buses

The primary data required for control and operation is carried on CAN data buses.

Two Can buses are used:

- High Speed CAN bus operates at 500 k bits / sec and is primarily used to transmit powertrain data
- The Powertrain (high speed) CAN bus operates at 500 k bits / sec and is only used to link the two PCMs
- Low Speed CAN bus operates at 125 k bits / sec and is used to transmit data relevant to the body system.

For data bus circuits - (Refer to 'Circuit Diagrams', page 18-1-18).

Network Bus


MOST


The MOST network bus is a fibre optical network used only for the Infotainment System

For the MOST network circuits - (Refer to 'Circuit Diagrams', page 18-1-18).





Module Locations (RHD)





Module Locations (LHD)







ASTON MARTIN

Electronic Features (19.00)


Contents

Active Anti-Theft System (19.01)	19-1-2
Alarm System Overview	1-2
Component Descriptions	1-2
Functional Description	1-3
Overview – Alarm	1-3
General setting.....	1-3
Door open.....	1-3
Disable the Alarm	1-3
Reduced guard mode	1-3
Alarm Cycle	1-3
Panic Alarm	1-3
Remote Transmitter	1-4
Key Learning Operations.....	1-4
Integrated Passive Anti-Theft System (IPATS)	1-4
Description	1-4
Disarming IPATS	1-4
Arming IPATS.....	1-4
IPATS LED	1-4
Key Programming.....	1-5
Maintenance	1-5
Pats Tranceiver ECU (Pre-08 MY Only) - Remove and Install	1-5
Alarm Siren Assembly - Remove and Install	1-5
Navigation (19.07)	19-7-1
Maintenance	7-1
Mechanism for the Navigation Display Screen - Remove and Install (12MY onward)	7-1
Navigation Display Screen - Remove and Install (12MY onward).....	7-6

Electronic Features (19.00)

Active Anti-Theft System (19.01)

Alarm System Overview



All alarm and central locking operations are controlled from within the Central Electronic Module (CEM).

Communications with the Mass Movement Sensor, the Instrument Module, the Remote Key Less Entry Function and the Battery Backed Sounder are via data buses.

Component Descriptions

Battery Backed Sounder

This device produces the audible out-put from the alarm system. The sounder can also house a tilt sensor to detect unauthorised vehicle movement.

Guard Reduction Switch

Used to disable the mass movement sensor, double locking and tilt sensor, so that people or animals can be left in the vehicle.

Mass Movement Sensor (optional)

Detects movement within the cabin of the car using microwaves. It is specifically designed to protect the ignition barrel and lock.

Central Electronics Module (CEM)

This module controls the vehicle alarm system. The CEM controls all alarm system inputs and outputs.

Driver Information Module (DIM)

Instrument Cluster

The message centre right provides text messages displaying alarm information to the user.

Ajar switches (perimeter sensors)

The car is equipped with ajar switches to sense unauthorised access to the following areas:

- Doors (Cabin area)
- Boot (Luggage compartment)
- Bonnet (Engine bay)

Remote Transmitter

Remote Key less Entry (RKE)

Controls the vehicle locking functionality (Refer to the vehicles Owner's Guide for operation).



Functional Description

Overview – Alarm

The Vehicle Alarm System (VAS) will generate an audible and visual warning if the vehicle doors, bonnet or boot are opened without first disarming the system using an authorised remote transmitter key.

There are two types of alarm system:

- Standard
- High Specification (optional). Includes an interior movement sensor and tilt sensor

The interior movement sensor offers further protection of the ignition barrel and steering wheel lock, the tilt sensor will detect unauthorised angular movement of the vehicle.

A Battery Backup sounder (BBS) is used to protect the sounder from disconnection. The BBS will sound if any attempt is made to disconnect it from the rest of the alarm system when the vehicle is armed.

General setting

The system will be armed on the first press of the remote transmitter 'Lock' button. The alarm system will arm and deadlock 25 seconds after receiving the arm request.

Door open

If the alarm system is set when any door, bonnet or boot are left open, then the alarm will be armed on all closed doors only, 25 seconds after the alarm set command has been requested. The open door, bonnet or boot will not be armed. 5 seconds after the open door, bonnet or boot have been closed, the alarm will Arm on that door, bonnet or boot.

Disable the Alarm

The alarm will be disabled following the unlock or boot open commands from the remote transmitter key or by turning the ignition key in the ignition barrel.

Reduced guard mode

When the vehicle is in reduced guard mode the mass movement and tilt sensors are disabled. This allows people or animals to be left in the vehicle.

With doors, boot and bonnet closed, ignition key in position '0' or 'I' or within 60 sec after removing the keys the reduced guard button can be activated.

The ignition key must have been in position 'II' first.

When the alarm is set, the vehicle will enter reduced guard mode. To deactivate reduced guard mode simply insert and turn the ignition key to position 'II'.

If the alarm is deactivated and then activated without turning the ignition key to position 'II' first, then the reduced guard mode will remain active.

Alarm Cycle

When the alarm has been activated there will be two outputs, these are listed below:

Audible output device (Siren)

The audible alarm signal is generated by the battery backed sounder. Duration of one alarm cycle is 25 seconds. The maximum number of cycles is ten.

Visible output device DI's

The turn indicators are activated during and alarm cycle. The alarm signal is given by flashing all direction indicators for 5 minutes. Following an alarm cycle the vehicle alarm will remain set.

Panic Alarm

The Panic Alarm is to be used in emergency situations for attracting attention while in or outside the vehicle.

Activate Panic Alarm

The Panic Alarm can be activated using the Panic Alarm button on the remote transmitter, there are two ways to initiate the feature:

- Press the Panic Alarm button for a minimum time of 3 seconds.
- Press the Panic Alarm button twice, the second press must be made within 3 seconds from the first press.

Deactivate Panic Alarm

The panic alarm cannot be deactivated for the first 5 seconds of operation following its activation. Following the first 5 seconds of the panic alarm cycle, it can then be deactivated in following ways:

- Pressing the panic button on the remote transmitter.
- The activation time has exceeded (25 seconds).

Panic alarm cycle

When active, the DI's will flash and the vehicle horn will sound for 25 seconds.


Remote Transmitter

The security system allows up to eight remote transmitters to be used for controlling the system functions.

The remote transmitter come in packs of two. Each transmitter is associated with a series of numbers, which are shown on a label located on the transmitter packaging. These numbers are required to program the transmitter to a vehicle.

CAUTION

DO NOT LOSE THE TRANSMITTER PACKAGING, WITH THE NUMBER LABEL ATTACHED, BEFORE PROGRAMMING TO THE VEHICLE. THE REMOTE TRANSMITTERS CAN NOT BE PROGRAMMED WITHOUT THE SEED AND KEY ID NUMBERS.



Key Learning Operations

Using AMDS.

1. Select 'Set up and Configuration'.
2. Select either:
 - Transmitter add
 - Transmitter Delete
3. Follow the on screen instructions. Type in the Key ID and the Seed numbers when prompted.
4. If adding a transmitter.

After programming, point a transmitter at the vehicle and attempt to lock / unlock the vehicle. If the vehicle does not lock / unlock, attempt to lock / unlock using the second transmitter from the pack.

After a successful 'Transmitter add' operation delete the Key ID and Seed numbers taken from the packaging label.

The remaining Key ID and Seed numbers are for the remaining remote transmitter. **Ensure that they remain together.**

If the CEM is required to be renewed then all remote transmitter must be renewed as well.

Integrated Passive Anti-Theft System (IPATS)

Description

IPATS (immobilisation system) is responsible for enabling / disabling engine functionality. The system is totally passive and requires no extra intervention from the user.

To prevent the engine from starting the IPATS disables the fuel pumps, injectors, and the crank circuit.

Disarming IPATS


When the ignition key is located in the ignition barrel and turned to position 'II', the key is validated. If successful, subsequent requests for crank and engine start will be allowed. If the key validation fails, then engine starting will be prevented.

Arming IPATS

To arm the system the user simply removes the ignition key.

IPATS LED

An IPATS LED is located in the DIM to display the immobilisation status and DTC's using flash codes.



Normal behaviour following a successful key read is for the LED to illuminate for three seconds and then to extinguish.

If the self-test detects any problem with IPATS when the ignition is turned on, the IPATS LED will flash at 4Hz for 1 minute. The IPATS LED will then flash one of the following codes:

DTC	Flash Code	Description
B1681	11	Transceiver not connected
B2103	12	Transceiver antenna coil malfunction
B1600	13	No key-code from the key
B1602	14	Invalid/Partial key code from transceiver
B1601	15	Keycode not recognised (but correct format)
B1213	21	Less than two keys stored
B1342		EEPROM fault (failed store operation)
B2431		Key would not store, (key fault)

Key Programming

Internet access required

All vehicle keys are required to perform key programming.

Using AMDS.

1. Insert the first key to the ignition.
2. Select 'Set up and Configuration' on AMDS.
3. Select either:
 - Key Learn
 - Key Delete
4. Follow the on screen instructions. You will be prompted to program successive keys as required.

Count Keys

Using AMDS.

Select Count keys to check how many keys are programmed into the vehicle security.

Maintenance

Pats Tranceiver ECU (Pre-08 MY Only) - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Pats Tranceiver ECU (Pre-08 MY Only) - Remove and Install	19.01.BB

Remove

1. Remove the top and bottom steering column shrouds (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-4-4).
2. Release the clips that attach the wiper switch to its mounting.
3. Release the wiper switch from its mounting.
4. Move the wiper switch away to give access.
5. Remove the self-tapping screw that attaches the PATS tranceiver ECU (ECU) to the steering column.
6. Disconnect the electrical connector for the ECU.
7. Remove the ECU.

Install

1. Put the ECU in position on the steering column.
2. Install the self-tapping screw to attach the ECU.
3. Connect the electrical connector for the ECU.
4. Install the wiper switch in the mounting.
5. Make sure that the clips that attach the switch are correctly engaged.
6. Install the top and bottom steering column shrouds (Refer to 'Top and Bottom Shrouds for the Steering Column - Remove and Install', page 11-4-4).

Alarm Siren Assembly - Remove and Install

Repair Operation Time (ROT)	
Item	Code
Alarm Siren Assembly - Remove and Install	19.01.CA

Remove

1. Remove the left rear wheel (refer to Workshop Manual procedure 04.04.EC).
2. Remove the M6 Torx screws that attach the rear of the left, rear wheelarch liner.
3. Move the wheelarch liner away to get access to the alarm siren assembly (siren).
4. Remove the the drain hose for the fuel filler from the clips.
5. Move the drain hose for the fuel filler away.
6. Remove the two M6 nuts that attach the siren to the mounting bracket.
7. Disconnect the electrical connector from the siren.
8. Remove the siren.

Install

1. Connect the electrical connector to the siren.
2. Put the siren in position into the mounting bracket.
3. Install the two M6 nuts to attach the siren to the mounitng bracket.
4. Install the drain hose for the fuel filler into the attachment clips,
5. Put the wheelarch liner into the fully installed position.
6. Install the M6 Torx screws that attach the wheelarch liner.
7. Install the left rear wheel (refer to Workshop Manual procedure 04.04.EC).



ASTON MARTIN

Electronic Features (19.00)

Navigation (19.07)


Maintenance

Mechanism for the Navigation Display Screen - Remove and Install (12MY onward)


Repair Operation Time (ROT)	
Item	Code
Mechanism for the Navigation Display Screen - Remove and Install (12MY onward)	19.07.CA

Remove

- Remove the veneer bezel for the Instrument Panel (IP) (Refer to Workshop Manual Procedure 01.12.AV - Veneer Bezel for the Instrument Panel (IP)).
- Release the electrical connector from the clip that attaches it to the mechanism for the navigation display screen.




- Release the wiring harness for the navigation display screen from the clip that attaches it to the mechanism for the navigation display screen.




- Manually move the navigation display screen into the open position.




- Cut the cable tie that attaches the wiring harness to the navigation display screen.




- Disconnect the electrical connector from the navigation display screen.




14. Remove the two screws that attach the holder for the navigation display screen to the mechanism for the navigation display screen.




17. Remove the holder for the navigation display screen.




15. Release the holder for the navigation display screen from the mechanism for the navigation display screen.




18. Remove the navigation display screen.




16. Release the holder for the navigation display screen from the two clips that attach it to the mechanism for the navigation display screen.




19. Remove the four screws that attach the veneer bezel door for the navigation display screen to the mechanism for the navigation display screen.




20. Remove the veneer bezel door.



21. Remove the four screws that attach the mechanism for the navigation display screen to the veneer bezel.




22. Remove the mechanism for the navigation display screen.




Install


1. Install the mechanism for the navigation display screen.





2. Install, but do not fully tighten, the four screws that attach the mechanism for the navigation display screen to the veneer bezel.




3. Install the veneer bezel door.




4. Install and tighten the four screws that attach the veneer bezel door for the navigation display screen to the mechanism for the navigation display screen.
7. Install the holder for the navigation display screen to the two clips that attach it to the mechanism for the navigation display screen.




5. Install the navigation display screen.




8. Install the holder for the navigation display screen to the mechanism for the navigation display screen.




6. Put the holder for the navigation display screen into position.



9. Install and tighten the two screws that attach the holder for the navigation display screen to the mechanism for the navigation display screen.



10. Connect the electrical connector to the navigation display screen.




11. Install a new cable tie that attaches the wiring harness to the navigation display screen.




12. Manually move the navigation display screen into the closed position.




13. Install the wiring harness for the navigation display screen to the clip that attaches it to the mechanism for the navigation display screen.




14. Install the electrical connector to the clip that attaches it to the mechanism for the navigation display screen.




15. Use the adjusters to make sure that the veneer bezel door is correctly aligned with the veneer bezel.



16. Tighten the four screws that attach the mechanism for the navigation display screen to the veneer bezel.



3. Release the wiring harness for the navigation display screen from the clip that attaches it to the mechanism for the navigation display screen.



17. Install the veneer bezel for the IP (Refer to Workshop Manual procedure 01.12.AV - Veneer Bezel for the Instrument Panel (IP)).


4. Manually move the navigation display screen into the open position.

Navigation Display Screen - Remove and Install (12MY onward)

Repair Operation Time (ROT)	
Item	Code
Navigation Display Screen - Remove and Install (12MY onward)	19.07.CB

Remove


1. Remove the veneer bezel for the Instrument Panel (IP) (Refer to Workshop Manual Procedure 01.12.AV - Veneer Bezel for the Instrument Panel (IP)).
2. Release the electrical connector from the clip that attaches it to the mechanism for the navigation display screen.




5. Cut the cable tie that attaches the wiring harness to the navigation display screen.




6. Disconnect the electrical connector from the navigation display screen.




9. Release the holder for the navigation display screen from the two clips that attach it to the mechanism for the navigation display screen.




7. Remove the two screws that attach the holder for the navigation display screen to the mechanism for the navigation display screen.




10. Remove the holder for the navigation display screen.



8. Release the holder for the navigation display screen from the mechanism for the navigation display screen.




11. Remove the navigation display screen.




Install


1. Install the navigation display screen.




2. Put the holder for the navigation display screen into position.




3. Install the holder for the navigation display screen to the two clips that attach it to the mechanism for the navigation display screen.




4. Install the holder for the navigation display screen to the mechanism for the navigation display screen.





5. Install and tighten the two screws that attach the holder for the navigation display screen to the mechanism for the navigation display screen.




6. Connect the electrical connector to the navigation display screen.





7. Install a new cable tie that attaches the wiring harness to the navigation display screen.
10. Install the electrical connector to the clip that attaches it to the mechanism for the navigation display screen.



8. Manually move the navigation display screen into the closed position.
11. Use the adjusters to make sure that the veneer bezel door is correctly aligned with the veneer bezel.



9. Install the wiring harness for the navigation display screen to the clip that attaches it to the mechanism for the navigation display screen.
12. Tighten the four screws that attach the mechanism for the navigation display screen to the veneer bezel.



13. Install the veneer bezel for the IP (Refer to Workshop Manual procedure 01.12.AV - Veneer Bezel for the Instrument Panel (IP)).



ASTON MARTIN

Appendix & Glossary

Contents


Diagnostic Ports	20-1-2
Fluids / Capacities	20-1-2
Terms	20-1-3
Special Tools - Pictorial Index	20-1-3
Specialist Tool Operation	20-1-8
Engine Support Brackets (43-27940)	20-1-8
PowerTrain Trolleys (43-27981)	20-1-8
Front Mounts	20-1-8
Rear Mounts	20-1-9
PowerTrain Trolleys Brace Bars	
(43-28161)	20-1-9
Ball Joint Splitter (43-26738)	20-1-10
Track Rod Ends	20-1-10
Vertical Link.....	20-1-10
Brake Hose Check (43-27822)	20-1-10
Front Brake Caliper	20-1-10
Crankshaft Rear Oil Seal Remove (43-27831) .	20-1-11
Crankshaft Rear Oil Seal Installer (43-27411)	20-1-12
Torque Figures	20-1-14
General Torque Figures	20-1-14
Torque Conversion Tables	20-1-15

Appendix & Glossary

Diagnostic Ports

Diagnostic ports are provided for:

- OBD II
- Body - including



Fluids / Capacities

Capacities

	Europe	USA
Engine sump (incl. filter)	10.4 ltr	11.0 qts
Engine sump (excl. filter)	9.5 ltr	10.0 qts
Engine cooling system	15 ltr	15.5 qts
Screen washer reservoir	6.9 ltr	7.3 qts
Gearbox		
Manual (including final drive and cooler)	4 ltr	4.2 qts
Automatic (including cooler)	9.7 ltr	10.2 qts
Final drive (Automatic) including cooler	1.6 ltr	1.7 qts
Transmission Cooler		
Manual Gearbox	TBA	TBA
Automatic Gearbox	1.6 ltr	1.7 qts
Automatic Final Drive	0.7	0.7
Fuel tank	80 ltr	21.0 galls

Approx. 78 litres (17.2 UK Gallons) usable.

Recommended Fluids

Engine oil Mobil 1 New Life 0W-40 or Or: Fully Synthetic
0W-30 API: SL/SJ/EC/CF, ACEA: A1/A5/B1/B5, ILSAC: GF3
0W-40 API: SL/SJ/EC/EF, ACEA: A3/B3/B4, ILSAC: GF3

Do not mix Mobil 1 oil with any mineral oils.

Engine coolant Havoline OAT
(50/50 solution with water)

Do not mix OAT coolant with any glycol based anti-freeze.

Automatic transmission fluid Shell ATF M 1375-4

Automatic transmission final drive oil Shell Spirax ASX 75W-90
Or: (DO NOT MIX WITH SHELL SPIRAX ASX)
Shell SAE 75W-90 plus Kendall additive

Manual gearbox oil / Final drive Castrol BOT270A

Brake / Clutch fluid Castrol React Performance DOT4

Power steering fluid Pentosin CHF 11S (Current production)
Texaco Cold Climate (DB9 up to A12418 - EXAMINE THE LABEL ON THE PAS RESERVOIR)

A/C refrigerant HFC134A.

Fuel 95 RON Unleaded (Min.) or 98 RON Super Unleaded (recommended). E10 Fuel compatible.

Terms


Frequently used alternative names or spellings for vehicle components mentioned in this Workshop Manual.

UK English	US English
Bonnet	Hood
Boot	Trunk
Brake Disc	Rotor
Handbrake	Parking Brake
Petrol	Gasoline
Tyre	Tire
Wing	Fender
Windscreen	Windshield
Sill	Rocker Panel


Special Tools - Pictorial Index

Part No. / Description


43-10047 (Wiring Harness Repair Kit)



4G43-43-10048 (PCM II Test Lead)




43-27750 (MOST Tester)




Part No. / Description


43-26738 (Ball Joint Splitter)



204-524 (Front Suspension Support)




43-27928 (Rear Subframe Bush Removal)




36-10-013

Supplied with above



43-27929 (Rear Subframe Receiver Cup)




Part No. / Description


43-27930 (Rear Subframe Bush Installer)




43-27822 (Brake Hose Install)



43-27933 (Handbrake Cable Removal)



43-27399 (Cylinder Bore Protectors)



43-27827 (Crankshaft Rear Oil Seal and Slinger Removal)


Image to Follow

Part No. / Description


43-27831 (Crankshaft Rear Oil Seal Slinger Install)

Image to Follow


43-27411 (Crankshaft Rear Oil Seal Install)




43-27412 (Crankshaft Front Oil Seal Install)



43-27413 (Cylinder Block Spreader)




43-27414 (Clutch Alignment)




Part No. / Description


43-27974(Camshaft Set)




43-27981 (Multi-purpose Trolley) x2



43-27985 (Rear Subframe Trolley Adaptors)




43-27986 (Engine/Subframe Trolley Adaptors)




Part No. / Description


43-27987 (Trolley Brace Bars)




43-27873 (Crankshaft Holding)



43-27944 (Timing Chain Tensioner Pins)




43-27945 (Engine Support Adaptor)




Part No. / Description


43-27946 (Engine Lifting Brackets)




43-27947 (Engine Mount Top Nut Adaptor)



43-27996 (Transaxle Seal Instal)




43-28002 (Fuel Pipe Disconnect Tool)




Part No. / Description


43-28005 (Filler Neck Disconnect Tool)



43-28006 (Fuel Tank Drainage Adaptor)




310-140 (Fuel Pump Install / Remove)



43-28009 (Quick Disconnect Tool)


43-28010 (Quick Disconnect Tool)

43-28011 (Quick Disconnect Tool)




Part No. / Description


43-28015 (Quick Disconnect Tool)




43-28052 (Oxygen Sensor Diagnostic Lead)



501-073A (Airbag Simulators)




43-28079 (Side Airbag and Pretensioner simulators)




Part No. / Description


43-28089 (Trim Removal)




43-28090 (IP Alignment Pins)



43-28095 (Door Service Trolley)




43-28092 (Front Veneer Removal)




Part No. / Description


43-28096 (IP Removal)



43-28091 (Wiper Linkage to Wiper Motor)



43-27999 (Gear Selector Cable Remove)



Specialist Tool Operation

To assist the technician in the operation of some of the specialist tools available for this vehicle, listed here are specialist tool operating procedures.

Engine Support Brackets (43-27940)

PowerTrain Trolleys (43-27981)

Images of where to locate the powertrain trolleys to the rear and front subframes to come

When removing the powertrain in total use both powertrain trolleys joined together using service tool (Refer to '43-28161 (Trolley Brace Bars)', page 20-1-5).

The link bars install as shown. They are not handed.

Front Mounts





Rear Mounts



**PowerTrain Trolleys Brace Bars
(43-27987)**



Ball Joint Splitter (43-26738)

Track Rod Ends

To get access to the vertical link lower ball joint.

1. For each affected wheel station, loosen the road wheel nuts $\frac{1}{4}$ turn each.
2. Raise vehicle and make it safe.
3. Remove the road wheel(s).
4. Install service tool No. 204-524 to the front hub.
Place a support under service tool No. 204-524. Lower vehicle enough to raise the suspension to ride height.

Image to follow

5. Insert service tool No. 204-523.

Image to follow

Vertical Link

To access upper and lower ball joints on the vertical link:

Note steering geometry settings before removing upper control arm.

1. Remove upper control arm from body. Allow the vertical link and lower arm to fall forward.
2. Top and bottom ball joints can then be accessed.

Brake Hose Check (43-27822)

Front Brake Caliper

CAUTION

MAKE SURE THAT THE ALIGNMENT LINE ON THE FLEXIBLE BRAKE PIPE REMAINS IN A STRAIGHT LINE.

CAUTION

ON LH AND RH CALIPERS THE BRAKE PIPE MUST ROUTE TOWARDS THE FRONT OF THE CAR.

1. Insert the brake pipe union to the caliper.
 - Ensure that the flex hose alignment line is straight
 - Ensure that the brake pipe elbow faces forward.Torque to **22 Nm**.
2. Install the brake pipe alignment tool. Check that the brake pipe orientation is correct:
 - The flex hose alignment line is straight
 - The brake pipe faces forward and locates correctly in the alignment tool



3. If the alignment is **not** correct, carefully back off the pipe union at the brake calliper until the pipe can be rotated backwards to allow forward movement when being re-torqued. Re torque the brake pipe union to **22 Nm** then re check alignment as detailed above.

Crankshaft Rear Oil Seal Remove (43-27831)


CAUTION
THROUGHOUT THIS PROCEDURE IT IS ESSENTIAL
THAT ALL PARTS REMAIN CLEAN, FREE OF DIRT,
GREASE AND DEBRIS.

- Using the sleeved punch (supplied with the new oil seal kit), pierce three equally spaced holes in the oil seal slinger.

There are three weak areas on the slinger, indicated in the image below.




Pierce holes in areas provided



- Place the oil seal removal tool into position.



- Line up the three holes in the oil seal removal tool with the three pierced holes in the oil seal slinger.
- Insert three screws (supplied with the new oil seal kit) into the three holes provided in the oil seal removal tool.



Screw the three screws in enough to attach to the oil seal slinger. Insert the oil seal removal tool bolt.

- Turn the bolt of the oil seal removal tool clockwise to withdraw the oil seal slinger.
- Remove the oil seal slinger, the three screws and the bolt from the oil seal removal tool.

CAUTION
ENSURE THAT THE OIL SEAL REMOVAL TOOL IS
CLEAN, FREE OF DIRT, GREASE AND DEBRIS.

- Using the oil seal removal tool, carefully knock the crankshaft oil seal through the oil seal housing.


The oil seal will stop against the crankshaft / engine block web.



- Using the sleeved punch (supplied with the new oil seal kit), pierce a hole in the crankshaft oil seal at the top (12 o'clock) only.



9. Screw the sleeved screw (supplied with the new oil seal kit) into the pierced hole enough to attach to the crankshaft oil seal.
10. Pull the crankshaft oil seal from the seal housing and the crankshaft.
3. Wipe the lip of the new oil seal with clean engine oil.
4. Place the seal install tool, complete with the new oil seal, into position and install the nut and bearing assembly.



Crankshaft Rear Oil Seal Installer (43-27411)

CAUTION

THROUGHOUT THIS PROCEDURE IT IS ESSENTIAL THAT ALL PARTS REMAIN CLEAN, FREE OF DIRT, GREASE AND DEBRIS.

1. Install the bolt assembly of the oil seal install tool.




2. Place the oil seal to the oil seal installation tool.

The holes on the oil seal facing outward (away from the engine block).



5. Wind the nut and bearing assembly in until the oil seal install tool bottoms out on the oil seal housing.

When the oil seal install tool has bottomed out on the oil seal housing the new oil seal has been installed to the correct depth.



6. Remove the oil seal install tool. Do not remove the bolt assembly.

7. Using the oil seal slinger install tool repeat from step two to install the oil seal slinger.

The oil seal slinger installs one way only on the oil seal slinger install tool.



Torque Figures

General Torque Figures

Nom. Dia.	Applied Torque (Nm)										
	4.6 & 4.82		8.8 / 8		9.8 / 9		10.9 & 10.9 / 10		12.9 / 12		
	Mean	+/-	Mean	+/-	Mean	+/-	Mean	+/-	Mean	+/-	
M3	0.5	0.1	1.4	0.2	-	-	1.9	0.4	2.3	0.5	
M4	1.2	0.2	3.1	0.6	-	-	4.5	0.8	5.2	1	
M5	2.4	0.5	6.2	1.2	6.9	1.3	8.9	1.7	10.4	2	
M6	4.1	0.8	10.4	2	11.8	2.3	15.2	2.7	17.5	3.3	
M8	9.9	2	25	5	28	5.5	36	7	42	8	
M10	19.5	3.9	50.5	9.5	56	10	72	13	84	16	
M12	34.2	6.8	88	17	99	19	126	24	147	28	
M14	54.4	10.9	140	28	157	30	200	40	235.5	46.5	
M16	85	17.2	217.5	42.5	245	47	310	61	363.5	70.5	
M18	116.7	23.4	313.5	58.5	-	-	433	80	509	94	
M20	165	33	437.5	82.5	-	-	605	114	707	133	
M22	225	45	602.5	102.5	-	-	832	157	974	187	
M24	286	57	774	154	-	-	1070	213	1244	247	
M27	417	83	1115	215	-	-	1547	298	1810	350	
M30	567	113	1520	290	-	-	2102	402	2450	470	
M33	722	154	2062	400	-	-	2856	551	3335	645	
M36	994	199	2650	510	-	-	3664	703	4275	825	
M39	1285	255	3435	660	-	-	4746	910	5545	1065	

Torque Conversion Tables

Newton Metres to Pounds Feet											
	Pounds Feet										
	0	1	2	3	4	5	6	7	8	9	
Newton Metres	0	-	0.74	1.47	2.21	2.95	3.69	4.42	5.16	5.90	6.64
	10	7.38	8.11	8.85	9.59	10.33	11.06	11.80	12.54	13.28	14.01
	20	14.75	15.49	16.23	16.96	17.71	18.44	19.18	19.91	20.65	21.39
	30	22.13	22.86	23.60	24.34	25.08	25.81	26.55	27.29	28.03	28.76
	40	29.50	30.24	30.98	31.71	32.45	33.19	33.93	34.68	35.40	36.14
	50	36.88	37.62	38.35	39.09	39.83	40.57	41.30	42.04	42.78	43.52
	60	44.25	44.99	45.73	46.47	47.20	47.94	48.68	49.42	50.15	50.89
	70	51.63	52.37	53.10	53.84	54.58	55.32	56.06	56.79	57.53	58.27
	80	59.00	59.74	60.48	61.22	61.95	62.69	63.43	64.17	64.91	65.64
	90	66.38	67.12	67.86	68.59	68.33	70.07	70.81	71.54	72.28	73.02
	100	73.76	74.49	75.23	75.97	76.71	77.44	78.18	78.92	79.66	80.39
	110	81.13	81.87	82.61	83.34	84.08	84.82	85.56	86.29	87.03	87.77
	120	88.51	89.24	89.98	90.72	91.46	92.19	92.93	93.67	94.41	95.15
	130	95.88	96.62	97.36	98.09	98.83	98.58	100.3	101.00	101.78	102.52
	140	103.26	104.00	104.73	105.47	108.21	106.95	107.68	108.42	109.16	109.90
	150	110.63	111.37	112.11	112.85	113.59	114.33	115.06	115.80	116.54	117.27
	160	118.01	118.75	119.49	120.22	120.98	121.70	122.44	123.17	123.91	124.65
	170	125.39	126.12	126.86	127.60	128.34	129.07	129.81	130.55	131.29	132.02
	180	132.76	133.50	134.24	134.87	135.71	136.45	137.19	137.92	138.68	139.40
	190	140.14	140.87	141.61	142.35	143.09	143.83	144.56	145.30	146.04	146.78
	200	147.51	148.25	148.99	149.73	150.46	151.20	151.94	152.68	153.41	154.15
	210	154.89	155.63	156.36	157.10	157.83	158.58	159.31	160.05	160.79	161.53
	220	162.26	163.00	163.74	164.48	165.21	165.95	166.69	167.43	168.16	168.90
	230	169.64	170.38	171.11	171.85	172.59	173.33	174.07	174.80	175.54	176.28
	240	177.02	177.75	178.49	179.23	179.97	180.70	181.44	182.18	182.92	183.65
	250	184.39	185.13	185.87	186.60	187.34	158.08	188.82	189.55	190.29	191.03
	260	191.77	192.50	193.24	193.98	194.72	195.45	196.19	198.93	197.67	198.40
	270	198.14	198.58	200.62	201.35	202.09	202.83	203.57	204.31	205.10	205.78
	280	206.52	207.26	207.99	208.73	209.47	210.21	210.94	211.68	212.42	213.16
	290	213.89	214.63	215.37	216.11	216.84	217.58	218.32	219.06	219.79	220.53
	300	221.27	222.01	222.74	223.48	224.22	224.98	225.68	226.43	227.17	227.91
	310	228.64	229.38	230.12	230.86	231.68	232.33	233.07	233.81	234.55	235.28
	320	236.02	238.76	237.50	238.23	238.97	239.71	240.45	241.18	241.92	242.68
	330	243.40	244.13	244.87	245.61	246.35	247.08	247.82	248.56	249.20	250.03
	340	250.77	251.51	252.25	252.98	253.72	254.46	255.20	255.93	256.67	257.41
	350	258.15	258.68	259.62	260.36	261.10	261.84	262.57	263.31	264.05	264.79
	360	265.52	268.26	267.00	267.74	268.47	267.21	269.95	270.68	271.42	272.16
	370	272.90	273.64	274.37	275.11	275.85	276.59	277.32	278.06	278.80	279.54
	380	280.27	281.01	281.75	282.49	283.22	283.98	284.70	285.44	286.17	286.91
390	287.65	298.38	289.12	289.86	298.68	291.34	292.08	292.81	293.55	294.29	



Newton Metres to Pounds Feet (Continued)											
		Pounds Feet									
		0	1	2	3	4	5	6	7	8	9
Newton Metres	400	295.03	295.76	298.50	297.24	297.98	298.71	299.45	300.19	300.93	301.68
	410	302.40	303.14	303.88	304.61	305.35	306.09	306.83	307.56	308.30	309.04
	420	309.78	310.51	311.25	311.99	312.73	313.46	314.20	314.94	315.68	316.41
	430	317.15	317.89	318.63	319.36	320.10	320.84	321.58	322.32	323.05	323.79
	440	324.53	325.27	326.00	326.74	327.48	328.22	328.95	329.68	330.43	331.17
	450	331.90	332.64	333.38	334.12	334.85	335.59	336.33	337.07	337.80	338.54
	460	339.28	340.02	340.75	341.49	342.23	342.97	343.70	344.44	345.18	345.92
	470	346.65	347.39	348.13	348.87	349.60	350.34	351.08	351.82	352.56	353.29
	480	354.03	354.77	355.51	356.24	356.98	357.72	358.46	359.19	359.93	350.67
	490	361.41	362.14	362.88	363.62	364.36	365.08	365.83	366.57	367.31	368.04
	500	368.78	369.52	370.26	370.99	371.73	372.47	373.21	373.94	374.68	375.42
	510	376.16	376.89	377.63	378.37	379.11	379.85	380.58	381.32	382.06	382.80
	520	383.53	384.27	385.01	385.75	386.48	387.22	387.96	388.70	389.43	390.17
	530	390.91	391.65	392.38	393.12	393.86	394.60	395.33	396.07	396.81	397.55
	540	398.28	399.02	399.76	400.50	401.23	401.97	402.71	403.45	404.18	404.92
	550	405.68	406.40	407.13	407.87	408.61	409.35	410.09	410.82	411.56	412.30
	560	413.04	413.77	414.51	415.25	415.99	416.72	417.46	418.20	418.94	419.67
	570	420.41	421.15	421.87	422.62	423.36	424.10	424.84	425.57	426.31	427.05
	580	427.79	428.52	429.26	430.00	430.74	431.47	432.21	432.95	433.68	434.42
	590	435.16	435.90	436.64	437.37	438.11	438.85	439.59	440.33	441.06	441.80
600	442.54	443.28	444.01	444.75	445.49	448.23	446.96	447.70	448.44	449.18	
610	449.91	456.65	451.39	452.13	452.86	453.60	454.34	455.08	455.81	456.55	
620	457.29	456.03	458.76	459.50	460.24	460.98	401.71	462.45	463.19	463.93	
630	464.66	465.40	468.14	466.88	467.61	468.35	469.09	468.83	470.57	471.30	
640	472.04	472.78	473.52	474.25	474.99	475.73	476.47	477.20	477.94	478.68	
650	479.42	480.15	480.89	481.63	482.37	483.10	483.84	484.58	485.32	486.05	
660	486.79	487.53	488.27	489.00	489.74	490.48	491.22	491.95	492.68	493.43	
670	494.17	484.90	489.64	496.38	497.12	497.85	498.59	499.33	500.07	500.81	
680	501.54	502.28	503.02	503.76	504.49	505.23	505.97	506.71	507.44	508.18	
690	508.92	509.68	510.39	511.13	511.87	512.61	513.34	514.08	514.82	515.56	
700	516.29	517.03	517.77	518.51	519.25	519.98	520.72	521.46	522.19	522.93	
710	523.67	524.41	525.14	525.88	526.62	527.36	528.10	528.83	529.57	530.31	
720	531.05	531.78	532.52	533.26	534.00	534.73	535.47	536.21	536.95	537.68	
730	538.42	539.16	539.90	540.63	541.37	542.11	542.85	543.56	544.32	545.06	
740	545.80	546.53	547.27	548.01	548.75	549.48	550.22	550.96	551.70	552.43	
750	553.17	553.91	554.65	555.38	556.12	556.86	557.60	558.34	559.07	559.80	
760	560.55	561.29	562.02	562.76	568.50	564.24	564.97	565.71	568.45	567.19	
770	567.92	568.68	569.40	570.14	570.87	571.61	572.35	573.09	573.82	574.56	
780	575.30	576.04	576.77	577.51	578.25	578.99	579.72	580.40	581.20	581.94	
790	582.67	583.41	584.15	584.89	585.62	586.36	587.10	587.84	588.58	589.31	

Newton Metres to Pounds Feet (Continued)											
		Pounds Feet									
		0	1	2	3	4	5	6	7	8	9
Newton Metres	800	590.79	591.53	592.26	593.00	593.74	594.48	595.21	595.95	596.58	596.68
	810	597.43	598.16	598.90	599.64	600.38	601.11	601.85	602.59	603.33	604.06
	820	604.80	605.54	606.28	607.01	607.75	608.49	609.23	609.96	610.70	611.44
	830	612.18	612.91	613.65	614.39	615.13	615.86	616.60	617.34	618.08	618.81
	840	619.55	620.29	621.03	621.77	622.50	623.24	623.98	624.72	625.45	626.19
	850	626.93	627.67	628.40	629.14	629.68	630.62	631.35	632.09	632.83	633.57
	860	634.30	635.04	635.78	636.52	637.25	637.99	638.73	639.47	640.20	640.94
	870	641.68	642.42	643.15	643.89	644.63	645.37	646.10	646.84	647.58	648.32
	880	649.06	649.79	650.53	651.27	652.01	652.74	653.48	654.22	654.96	655.69
	890	656.43	657.17	657.91	658.64	659.38	660.12	660.86	661.59	662.33	663.07
	900	663.81	664.54	665.28	666.02	666.76	667.49	668.23	668.97	669.71	670.44
	910	671.18	671.92	672.66	673.39	674.13	674.87	675.61	676.35	677.08	677.82
	920	678.56	679.30	680.03	680.77	681.51	682.25	682.98	683.72	683.46	685.20
	930	685.93	686.67	687.41	688.15	688.88	689.62	690.36	691.10	691.83	692.57
	940	693.31	694.05	684.78	695.52	696.26	697.00	697.73	698.47	699.21	699.95
	950	700.68	701.42	702.16	702.90	703.63	704.37	705.11	705.85	706.59	707.32
	960	708.06	708.80	708.54	710.27	711.01	711.75	712.49	713.22	713.96	714.70
	970	715.44	716.17	716.91	717.65	718.39	719.12	719.86	720.60	721.34	722.07
	980	722.81	723.55	724.29	725.02	725.76	726.50	727.24	727.97	728.71	729.45
	990	730.19	730.92	731.66	732.40	733.14	733.87	734.61	735.35	736.09	736.83

Pounds Feet to Newton Metres											
		Newton Metres									
		0	1	2	3	4	5	6	7	8	9
Pounds Feet	0	-	1.36	2.71	4.07	5.42	6.78	8.13	9.49	10.85	12.20
	10	13.56	14.91	16.27	17.63	18.98	20.34	21.69	23.05	24.40	25.76
	20	27.12	28.47	29.83	31.18	32.54	33.89	35.25	36.61	37.96	39.32
	30	40.67	42.03	43.39	44.74	46.10	47.45	48.81	50.16	51.52	52.88
	40	54.23	55.59	56.94	58.30	59.66	61.01	62.37	63.72	65.08	66.43
	50	67.79	69.15	70.50	71.86	73.21	74.57	75.93	77.28	78.64	79.99
	60	81.35	82.70	84.06	85.42	86.77	88.13	89.49	90.84	92.20	93.55
	70	94.91	96.26	97.62	98.97	100.33	101.68	103.04	104.40	105.75	107.11
	80	108.47	109.82	111.12	112.53	113.89	115.25	116.60	117.96	119.31	120.67
	90	122.02	123.38	124.74	126.09	127.45	128.80	130.16	131.51	132.87	134.23
	100	135.58	136.94	138.29	139.65	141.01	142.36	143.72	145.07	146.43	147.78
	110	149.14	150.50	151.85	153.21	154.56	155.92	157.28	158.63	159.99	161.34
	120	164.05	165.41	162.70	166.77	163.12	169.48	170.83	172.19	173.55	174.90
	130	176.26	177.61	178.97	180.32	181.68	183.04	184.39	185.75	187.10	188.46
	140	189.82	191.17	192.53	193.88	195.24	196.59	197.95	199.31	200.66	202.02
	150	203.37	204.73	206.08	207.44	208.80	210.15	211.51	212.86	214.22	215.58
	160	216.93	218.29	219.64	221.00	222.35	223.71	225.07	226.42	227.78	229.13
	170	230.49	231.85	233.20	234.56	235.91	237.27	238.64	239.98	241.34	242.69
	180	244.05	245.40	246.76	248.12	249.47	250.83	252.18	253.54	254.89	250.25
	190	257.61	258.96	260.32	261.67	263.03	264.38	265.74	267.10	263.45	269.81



Pounds Feet to Newton Metres (Continued)											
	Newton Metres										
	0	1	2	3	4	5	6	7	8	9	
Pounds Feet	200	271.16	272.52	273.88	275.23	276.59	277.94	279.30	280.65	282.01	283.37
	210	284.72	286.08	287.43	288.79	290.15	291.50	292.86	294.21	295.57	296.92
	220	298.28	299.64	300.99	302.35	303.70	305.06	306.42	307.77	309.13	310.48
	230	311.84	313.19	314.55	315.91	317.26	318.62	319.97	321.33	322.68	324.04
	240	325.40	326.75	328.11	329.46	330.82	332.18	333.53	334.89	336.24	337.60
	250	338.95	340.31	341.67	343.02	344.38	345.73	347.09	348.45	349.80	351.16
	260	352.51	353.87	355.22	356.58	357.94	359.29	360.65	362.00	363.36	364.72
	270	366.07	367.43	368.78	370.14	371.49	372.85	374.21	375.56	376.92	378.27
	280	379.63	380.98	382.34	363.70	385.05	386.41	387.76	389.12	390.48	391.63
	290	393.19	394.54	395.90	397.26	398.61	398.97	401.32	402.63	464.03	405.39
	300	406.75	408.10	409.46	410.81	412.17	413.52	414.98	416.24	417.59	418.95
	310	420.30	421.68	423.02	424.37	425.73	427.08	428.44	429.79	431.15	492.51
	320	433.86	435.22	436.57	437.93	439.29	440.64	442.00	443.35	444.71	448.06
	330	447.42	448.78	450.13	451.49	452.84	454.20	455.56	456.91	458.27	459.62
	340	460.98	462.33	463.69	465.05	466.40	467.76	489.11	470.47	471.63	473.18
	350	474.54	475.89	477.25	478.60	479.98	481.32	482.67	464.03	485.38	486.74
	360	488.09	489.45	498.81	492.16	493.52	494.87	496.23	497.59	498.94	500.30
	370	501.65	503.01	504.36	505.72	507.08	598.43	509.79	511.14	512.50	513.86
	380	515.21	516.57	517.92	519.28	520.63	521.98	523.34	524.70	526.06	527.41
	390	528.77	530.13	531.48	532.84	534.19	535.55	536.90	538.26	539.62	540.97
400	542.33	543.68	545.04	546.40	547.75	549.11	550.46	551.82	553.17	554.53	
410	555.89	557.24	558.60	559.95	561.31	562.66	564.02	565.38	566.73	568.09	
420	569.45	570.80	572.16	573.51	574.87	576.22	577.59	578.93	580.29	581.65	
430	583.00	584.38	585.71	587.07	598.41	589.78	591.14	592.49	593.85	595.20	
440	596.56	597.92	599.27	600.63	601.98	603.34	604.70	606.05	607.41	608.76	
450	610.12	611.47	612.83	614.19	615.54	616.90	618.25	619.61	620.97	622.32	
460	623.68	625.03	626.39	627.74	629.10	630.46	631.81	633.17	634.52	635.98	
470	637.23	638.59	639.95	641.30	642.68	644.01	645.37	640.73	648.08	649.44	
480	650.79	652.15	653.50	654.86	656.22	657.57	658.93	660.28	661.64	663.00	
490	664.35	665.71	667.06	668.42	669.77	671.13	672.49	673.84	675.20	676.55	
500	677.91	679.27	680.62	680.98	683.33	684.69	686.04	687.04	688.76	690.11	
510	691.47	692.82	694.18	697.54	696.89	698.25	699.60	700.96	702.31	703.67	
520	705.03	706.38	707.74	709.09	710.45	711.80	713.16	714.52	715.87	717.23	
530	718.58	719.94	721.30	722.65	724.01	725.36	726.72	728.07	729.43	730.79	
540	732.14	733.50	734.85	736.21	737.57	738.92	740.28	741.63	742.99	744.35	
550	745.70	747.06	748.41	749.77	751.12	752.48	753.84	755.19	756.55	757.90	
560	759.26	760.61	761.97	763.33	764.68	766.04	767.39	768.75	770.11	771.48	
570	772.82	774.17	775.53	776.88	778.24	779.69	780.95	782.31	783.66	785.02	
580	786.37	787.73	789.09	790.44	791.80	793.15	794.51	795.87	797.22	798.58	
590	799.93	801.28	802.64	804.00	805.36	806.71	808.07	809.42	810.78	812.14	

Pounds Feet to Newton Metres (Continued)											
	Newton Metres										
	0	1	2	3	4	5	6	7	8	9	
Pounds Feet	600	813.49	814.85	816.20	817.56	818.91	820.27	821.63	822.98	824.34	825.69
	610	827.05	828.41	829.76	831.12	832.47	833.83	835.18	836.54	837.90	839.25
	620	840.61	841.96	844.32	844.68	848.03	847.39	848.74	850.10	851.45	852.81
	630	854.17	855.52	856.88	858.23	859.59	860.94	862.30	863.68	865.01	868.37
	640	867.72	868.08	870.44	871.79	873.15	874.50	875.86	877.21	878.57	879.93
	650	881.28	882.64	883.99	885.35	886.71	888.06	889.42	890.77	892.13	893.48
	660	894.84	896.20	897.55	898.91	900.26	901.62	902.98	904.33	905.68	907.04
	670	908.40	909.75	911.11	912.47	913.82	915.17	916.55	917.89	919.25	920.60
	680	921.96	923.31	924.67	926.02	927.38	928.74	930.09	931.45	932.80	934.16
	690	935.51	936.87	938.23	939.58	940.94	942.29	943.65	945.01	946.36	947.72
	700	949.07	956.43	951.78	953.14	954.50	955.85	957.21	958.56	959.92	961.28
	710	962.63	963.99	965.34	966.70	968.05	969.41	970.77	972.12	973.47	974.83
	720	976.19	977.55	978.90	980.26	981.61	982.97	984.32	985.68	987.04	988.39
	730	989.75	991.10	992.46	993.82	995.17	996.53	997.68	999.24	1000.6	1002.0
	740	1003.3	1004.7	1006.0	1007.4	1008.7	1010.1	1011.4	1012.8	1014.2	1015.5
	750	1016.9	1018.2	1019.6	1020.9	1022.3	1023.6	1025.0	1026.4	1027.7	1029.1
	760	1030.4	1031.8	1033.1	1034.5	1035.8	1037.2	1038.6	1039.9	1041.3	1042.6
	770	1044.0	1045.3	1048.7	1048.1	1049.4	1050.8	1052.1	1053.5	1054.8	1056.2
	780	1057.5	1058.9	1060.3	1061.6	1063.0	1064.3	1065.7	1067.0	1068.4	1069.7
	790	1071.1	1072.5	1073.8	1075.2	1076.5	1077.9	1079.2	1080.6	1081.9	1083.3
800	1084.7	1086.0	1087.4	1088.7	1090.1	1091.4	1092.8	1094.2	1095.5	1096.9	
810	1098.2	1099.6	1100.9	1102.3	1103.6	1105.0	1106.4	1107.8	1109.1	1110.4	
820	1111.8	1113.1	1114.5	1115.8	1117.2	1118.6	1119.9	1121.3	1122.6	1124.0	
830	1125.3	1126.7	1128.0	1129.4	1130.8	1132.1	1133.5	1134.8	1136.2	1137.5	
840	1138.9	1140.2	1141.6	1143.0	1144.3	1145.7	1147.0	1148.4	1149.7	1151.1	
850	1152.5	1153.8	1155.2	1156.5	1157.9	1159.2	1160.6	1161.9	1163.3	1164.7	
860	1168.0	1167.4	1168.7	1170.1	1171.4	1172.8	1174.1	1175.5	1176.9	1178.2	
870	1179.6	1180.9	1182.3	1183.6	1185.0	1186.3	1187.7	1189.1	1190.4	1191.8	
880	1193.1	1194.5	1195.8	1197.2	1198.5	1199.9	1201.3	1202.6	1204.0	1205.3	
890	1206.7	1208.0	1209.4	1210.8	1212.1	1213.5	1214.8	1216.2	1217.5	1218.9	
900	1220.2	1221.6	1223.0	1224.3	1225.7	1227.0	1228.4	1229.7	1231.1	1232.4	
910	1233.8	1235.2	1236.5	1237.9	1239.2	1240.6	1241.9	1243.3	1244.6	1246.0	
920	1247.4	1248.7	1250.1	1251.4	1252.8	1254.1	1255.5	1256.8	1258.2	1259.6	
930	1260.9	1262.3	1263.6	1265.0	1266.3	1267.7	1269.1	1270.4	1271.8	1273.1	
940	1274.5	1275.8	1277.2	1278.5	1279.9	1281.3	1282.6	1284.0	1285.3	1286.7	
950	1288.0	1289.4	1290.7	1292.1	1293.5	1294.8	1296.2	1297.5	1298.9	1300.2	
960	1301.6	1302.9	1304.3	1305.7	1307.0	1308.4	1309.7	1311.1	1312.4	1313.8	
970	1315.1	1316.5	1317.9	1319.2	1320.6	1321.9	1323.3	1324.6	1326.0	1327.4	
980	1328.7	1330.1	1331.4	1332.8	1334.1	1335.5	1336.8	1338.2	1339.6	1340.9	
990	1342.3	1343.6	1345.0	1346.3	1347.7	1349.0	1350.4	1351.8	1353.1	1354.5	



ASTON MARTIN